

# LISTA DE APLICACIONES - BUYERS GUIDE



## 141524-066



Qty: 944

Weight: 1.349

O.E.M.	MAKE
16 114 577 80	FIAT
16 172 817 80	PEUGEOT
4252.46	PEUGEOT
4252.47	CITROËN
4254.43	CITROËN
4254.68	CITROËN
7 175 298 5	FIAT
7 175 985	FIAT
7 177 007 2	FIAT
7 177 252 7	FIAT
7 217 598 5	FIAT
7 736 227 4	FIAT
7 736 486 0	FIAT
86 60 004 475	RENAULT
86 71 016 689	RENAULT
9 949 407	FIAT
9 949 408	FIAT
E172357	CITROËN



1 - 690142 E

## 141524-066

E1 90R-01100/343



Brembo

109.6x49.9x20

WVA	FMSI
23860	D1582-9247
23921	
MAKE	
CITROËN	
FIAT	
PEUGEOT	



Trac.	CC	Kw	CV	
				Front / Rear

### CITROËN

#### JUMPER II / RELAY (230P) 02.94-04.02

					Bus (Minibus-M2-Segment)			
2.0 (RFW (XU10J2U))		Gasolina	FWD	1998	80	109	02.94-04.02	■
2.0 (XU10J2)		Gasolina	FWD	1998	81	110	04.02-06.06	■
2.0 bivalent (XU10J2)		Gasol./Gas (CNG)	FWD	1998	81	110	02.03-06.06	■
1.9 D (D9B (XUD9A/U))		Diesel	FWD	1905	51	69	01.99-04.02	■
1.9 TD (D8C (XUD9UTF))		Diesel	FWD	1905	66	90	08.94-04.02	■
2.0 HDi (RHV (DW10UTD))		Diesel	FWD	1997	62	84	04.02-06.06	■
2.2 HDi (4HY (DW12UTED))		Diesel	FWD	2179	74	101	04.02-06.06	■
2.5 D (T9A (DJ5))		Diesel	FWD	2446	63	86	08.94-04.02	■
2.5 D 4x4 (T9A (DJ5))		Diesel	4WD	2446	63	86	08.96-04.02	■
2.5 TD (T8A (DJ5T))		Diesel	FWD	2446	76	103	08.94-04.02	■
2.5 TDI (THX (DJ5TED))		Diesel	FWD	2446	79	107	12.96-11.00	■
2.5 TDI 4x4 (THX (DJ5TED))		Diesel	4WD	2446	79	107	12.96-11.00	■
2.8 HDi (8140.43S)		Diesel	FWD	2798	94	128	09.00-04.02	■
2.8 HDi (8140.43S)		Diesel	FWD	2798	94	128	04.02-06.06	■
2.8 HDi 4x4 (8140.43S)		Diesel	4WD	2798	94	128	09.00-04.02	■
2.8 HDi A las 4 ruedas (8140.43S)	Eq.V_ Brasil	Diesel	4WD	2798	94	128	04.02-06.06	■

#### JUMPER II / RELAY (230) 03.94-04.02

					Platform/Chassis (LCVs-N1 Segment)			
2.0 (RFW (XU10J2U))		Gasolina	FWD	1998	80	109	03.94-04.02	■
2.0 HDi (RHV (DW10UTD))		Diesel	FWD	1997	62	84	04.02-06.06	■
2.2 HDi (4HY (DW12UTED))		Diesel	FWD	2179	74	101	04.02-06.06	■
2.2 HDi (4HY (DW12UTED))		Diesel	FWD	2179	74	101	02.02-06.06	■

# LISTA DE APLICACIONES - BUYERS GUIDE

2.5 D (T9A (DJ5))		Diesel	FWD	2446	63	86	03.94-04.02	■
2.5 D 4x4 (T9A (DJ5))		Diesel	4WD	2446	63	86	03.00-04.02	■
2.5 TDI (THX (DJ5TED))		Diesel	FWD	2446	79	107	12.96-04.02	■
2.5 TDI 4x4 (THX (DJ5TED))		Diesel	4WD	2446	79	107	03.00-04.02	■
2.8 D (8140.63 (F28D))		Diesel	FWD	2798	64	87	01.99-02.02	■
2.8 HDI (8140.43S)		Diesel	FWD	2798	94	128	09.00-04.02	■
2.8 HDI (8140.43S)		Diesel	FWD	2798	94	128	04.02-06.06	■
2.8 HDi 4x4 (F28TDCR)		Diesel	4WD	2798	94	128	02.02-06.06	■
2.8 HDI (8140.43N)		Diesel	FWD	2798	107	146	05.04-06.06	■
<b>JUMPER II / RELAY (230L) 02.94-08.02</b>					<b>Van (LCVs-N1 Segment)</b>			
2.0 (RFL)		Gasolina	FWD	1998	80	109	03.94-04.02	■
2.0 (XU10J2)		Gasolina	FWD	1998	81	110	04.02-06.06	■
2.0 bivalent (XU10J2)		Gasol./Gas (CNG)	FWD	1998	81	110	02.03-06.06	■
1.9 D (DJY (XUD9A))		Diesel	FWD	1905	50	68	07.99-04.02	■
1.9 D (D9B (XUD9A/U))		Diesel	FWD	1905	51	69	02.94-04.02	■
1.9 TD (DHX (XUD9TF/BTF))		Diesel	FWD	1905	66	90	03.94-04.02	■
1.9 TD (D8C (XUD9UTF))		Diesel	FWD	1905	68	92	03.94-04.02	■
2.0 HDi (RHV (DW10UTD))		Diesel	FWD	1997	62	84	04.02-06.06	■
2.2 HDi (4HY (DW12UTD))		Diesel	FWD	2179	74	101	04.02-06.06	■
2.5 D (T9A (DJ5))		Diesel	FWD	2446	63	86	03.94-04.02	■
2.5 D 4x4 (T9A (DJ5))		Diesel	4WD	2446	63	86	03.00-04.02	■
2.5 TD (T8A (DJ5T))		Diesel	FWD	2446	76	103	03.94-04.02	■
2.5 TDI (THX (DJ5TED))		Diesel	FWD	2446	79	107	12.96-11.00	■
2.5 TDI 4x4 (THX (DJ5TED))		Diesel	4WD	2446	79	107	03.00-11.00	■
2.8 D (8140.63 (F28D))		Diesel	FWD	2798	64	87	01.99-02.02	■
2.8 HDI (8140.43S)		Diesel	FWD	2798	94	128	09.00-04.02	■
2.8 HDI (8140.43S)		Diesel	FWD	2798	94	128	04.02-06.06	■
2.8 HDi 4x4 (8140.43S)		Diesel	4WD	2798	94	128	09.00-04.02	■
2.8 HDi 4x4 (8140.43S)		Diesel	4WD	2798	94	128	04.02-06.06	■
2.8 HDI (8140.43N)		Diesel	FWD	2798	107	146	04.04-06.06	■
<b>FIAT</b>								
<b>DUCATO II (230_) 03.94-05.05</b>					<b>Bus (Minibus-M2-Segment)</b>			
2.0 (RFL)		Gasolina	FWD	1998	81	110	12.01-07.06	■
2.0 4x4 (RFL)		Gasolina	4WD	1998	81	110	05.02-07.06	■
2.0 JTD (RHV)		Diesel	FWD	1997	62	84	12.01-07.06	■
2.3 JTD (F1AE0481C)		Diesel	FWD	2286	81	110	12.01-07.06	■
2.8 JTD (8140.43S)		Diesel	FWD	2798	94	128	11.00-04.02	■
2.8 JTD (8140.43S)	-12/07	Diesel	FWD	2798	94	128	12.01-	■
2.8 JTD 4x4 (8140.43S)		Diesel	4WD	2798	94	128	11.00-04.02	■
2.8 JTD 4x4 (8140.43S)		Diesel	4WD	2798	94	128	12.01-07.06	■
2.8 TD (8140.43)		Diesel	FWD	2799	90	122	11.03-07.06	■
2.8 TD 4x4 (8140.43)		Diesel	4WD	2799	90	122	11.03-07.06	■
2.8 D (8140.63)		Diesel	FWD	2800	64	87	02.98-04.02	■
2.8 TDI (8140.43)		Diesel	FWD	2800	90	122	10.97-04.02	■
2.8 JTD (8140.43N)		Diesel	FWD	2800	107	145	04.04-07.06	■
<b>DUCATO II (230_) 03.94-04.02</b>					<b>Platform/Chassis (LCVs-N1 Segment)</b>			
2.0 (RFL)		Gasolina	FWD	1998	81	110	04.02-07.06	■
2.0 JTD (RHV)		Diesel	FWD	1997	62	84	12.01-07.06	■
2.3 JTD (F1AE0481C)		Diesel	FWD	2286	81	110	12.01-07.06	■

# LISTA DE APLICACIONES - BUYERS GUIDE

2.8 JTD (8140.43S)		Diesel	FWD	2798	94	128	12.01-07.06	■
2.8 JTD 4x4 (8140.43S)		Diesel	4WD	2798	94	128	12.01-07.06	■
2.8 JTD (8140.43)		Diesel	FWD	2799	90	122	11.03-07.06	■
2.8 JTD 4x4		Diesel	4WD	2799	90	122	11.03-07.06	■
2.8 TDI (8140.43)		Diesel	FWD	2800	90	122	12.98-04.02	■
2.8 JTD Power (8140.43N)		Diesel	FWD	2800	107	146	04.04-07.06	■
<b>DUCATO II (230_) 03.94-05.05</b>					<b>Van (LCVs-N1 Segment)</b>			
2.0 (RFL)		Gasolina	FWD	1998	81	110	12.01-07.06	■
2.0 4x4 (RFL)		Gasolina	4WD	1998	81	110	05.02-07.06	■
2.0 JTD (RHV)		Diesel	FWD	1997	62	84	12.01-07.06	■
2.3 JTD (F1AE0481C)		Diesel	FWD	2286	81	110	12.01-07.06	■
2.5 TD (8140.47)		Diesel	FWD	2499	80	109	06.94-08.98	■
2.5 TD 4x4 (8140.47)		Diesel	4WD	2499	80	109	11.94-04.98	■
2.5 TDI (8140.47R)		Diesel	FWD	2500	80	109	03.94-04.02	■
2.8 JTD (8140.43S)		Diesel	FWD	2798	94	128	11.00-04.02	■
2.8 JTD (8140.43S)	-12/07	Diesel	FWD	2798	94	128	12.01-12.11	■
2.8 JTD 4x4 (8140.43S)		Diesel	4WD	2798	94	128	11.00-04.02	■
2.8 JTD 4x4 (8140.43S)		Diesel	4WD	2798	94	128	12.01-07.06	■
2.8 TD (8140.43)		Diesel	FWD	2799	90	122	12.01-07.06	■
2.8 TD		Diesel	RWD	2799	90	122	11.03-07.06	■
2.8 D (8140.63)		Diesel	FWD	2800	64	87	05.98-04.02	■
2.8 JTD Power (8140.43N)		Diesel	FWD	2800	107	146	04.04-07.06	■
<b>DUCATO III (250_) 07.06-</b>					<b>Bus (Minibus-M2-Segment)</b>			
120 Multijet 2,3 D (F1AE0481D)		Diesel	FWD	2287	88	120	07.06-	■
130 Multijet 2,3 D (F1AE0481N)		Diesel	FWD	2287	96	131	01.07-	■
130 Multijet 2,3 D (F1AE3481D)		Diesel	FWD	2287	96	131	01.07-	■
130 Multijet 2,3 D (F1AGL411D)		Diesel	FWD	2287	96	131	01.07-	■
<b>DUCATO III (250_) 07.06-</b>					<b>Platform/Chassis (LCVs-N1 Segment)</b>			
120 Multijet 2,3 D (F1AE0481D)		Diesel	FWD	2287	88	120	07.06-	■
120 Multijet 2,3 D (F1AGL4114)		Diesel	FWD	2287	88	120	07.06-	■
<b>DUCATO III (250_) 07.06-</b>					<b>Van (LCVs-N1 Segment)</b>			
120 Multijet 2,3 D (F1AE0481D)		Diesel	FWD	2287	88	120	07.06-	■
120 Multijet 2,3 D (F1AGL4114)		Diesel	FWD	2287	88	120	07.06-	■
<b>PEUGEOT</b>								
<b>BOXER II (230P) 03.94-12.09</b>					<b>Bus (Minibus-M2-Segment)</b>			
2.0 (RFL (XU10J2U))	01/04-	Gasolina	FWD	1998	81	110	12.01-06.06	■
2.0 BiFuel		Gasol./Gas (LPG)	FWD	1998	81	110	12.01-06.06	■
2.0 HDi (RHV (DW10TD))	01/04-	Diesel	FWD	1997	62	84	12.01-06.06	■
2.0 HDi (RHV (DW10UTD))	01/04-	Diesel	FWD	1997	62	84	12.01-06.06	■
2.2 HDi (4HY (DW12UTD))	01/04-	Diesel	FWD	2179	74	101	12.01-06.06	■
2.8 D (8140.63 (F28D))	ch- 16194400	Diesel	FWD	2798	64	87	01.99-02.02	■
2.8 HDi (8140.43S (F28DTCR))	ch- 16194400, Eq.V_ 1000-1400 kg.	Diesel	FWD	2798	93	126	10.00-11.01	■
2.8 HDi (8140.43S (F28DTCR))	01/04-	Diesel	FWD	2798	94	128	12.01-06.06	■
2.8 HDi 4x4 (8140.43S (F28DTCR))	ch- 16194400, Eq.V_ 1000-1400 kg.	Diesel	4WD	2798	94	128	10.00-04.02	■
2.8 HDi 4x4 (8140.43S (F28DTCR))	01/04-	Diesel	4WD	2798	94	128	12.01-06.06	■
2.8 HDi (8140.43N)		Diesel	FWD	2798	107	145	04.04-06.06	■

# LISTA DE APLICACIONES - BUYERS GUIDE

BOXER II (ZCT_) 03.94-04.02					Platform/Chassis (LCVs-N1 Segment)			
2.0 (RFL (XU10J2U))		Gasolina	FWD	1998	81	110	12.01-04.02	■
2.0 BiFuel		Gasol./Gas (LPG)	FWD	1998	81	110	12.01-06.06	■
2.0 HDi (RHV (DW10TD))		Diesel	FWD	1997	62	84	12.01-06.06	■
2.0 HDi (RHV (DW10UTD))		Diesel	FWD	1997	62	84	12.01-06.06	■
2.2 HDi (4HY (DW12UTED))		Diesel	FWD	2179	74	101	12.01-06.06	■
2.5 TDI (THX (DJ5TED))		Diesel	FWD	2446	79	107	01.97-04.02	■
2.8 D (8140.63 (F28D))	ch- 16194400	Diesel	FWD	2798	64	87	01.99-02.02	■
2.8 HDi (8140.43S (F28DTCR))	ch- 16194400, Eq.V_ 1000-1400 kg.	Diesel	FWD	2798	93	126	10.00-11.01	■
2.8 HDi (8140.43S (F28DTCR))		Diesel	FWD	2798	94	128	12.01-06.06	■
2.8 HDi 4x4 (8140.43S (F28DTCR))		Diesel	4WD	2798	94	128	12.01-06.06	■
2.8 HDi (8140.43N)		Diesel	FWD	2798	107	146	04.04-06.06	■
BOXER II (230L) 03.94-08.06					Van (LCVs-N1 Segment)			
2.0 (RFL (XU10J2U))	01/04-	Gasolina	FWD	1998	81	110	12.01-06.06	■
2.0 BiFuel		Gasol./Gas (LPG)	FWD	1998	81	110	12.01-06.06	■
2.0 HDi (RHV (DW10UTD))		Diesel	FWD	1997	62	84	08.01-04.02	■
2.0 HDi (RHV (DW10TD))	01/04-	Diesel	FWD	1997	62	84	04.02-06.06	■
2.0 HDi (RHV (DW10UTD))	01/04-	Diesel	FWD	1997	62	84	04.02-06.06	■
2.2 HDi (4HY (DW12UTED))	01/04-	Diesel	FWD	2179	74	101	12.01-06.06	■
2.8 D (8140.63 (F28D))	ch- 16194400	Diesel	FWD	2798	64	87	01.99-02.02	■
2.8 HDi (8140.43S (F28DTCR))	ch- 16194400, Eq.V_ 1000-1400 kg.	Diesel	FWD	2798	93	126	10.00-11.01	■
2.8 HDi (8140.43S (F28DTCR))		Diesel	FWD	2798	93	126	09.05-09.09	■
2.8 HDi (8140.43S (F28DTCR))	01/04-	Diesel	FWD	2798	94	128	12.01-06.06	■
2.8 HDi 4x4 (8140.43S (F28DTCR))	ch- 16194400, Eq.V_ 1000-1400 kg.	Diesel	4WD	2798	94	128	10.00-04.02	■
2.8 HDi 4x4 (8140.43S (F28DTCR))	01/04-	Diesel	4WD	2798	94	128	12.01-06.06	■
2.8 HDi (8140.43N)		Diesel	FWD	2798	107	146	04.04-06.06	■
BOXER III / MANAGER 04.06-					Van (LCVs-N1 Segment)			
2.8 HDi		Diesel	RWD	2798	93	127	04.06-09.09	■