

LISTA DE APLICACIONES - BUYERS GUIDE

151040




8 424073 016867

Qty: 660

Weight: 10.780

O.E.M.	MAKE
8 285 388 435	SETRA
8 285 388 436	SETRA
8 285 388 533	SETRA
8 285 388 535	SETRA
8 285 408 463	SETRA
8 285 525 000	SETRA
8 285 526 000	SETRA
81 50820 5006	MAN
81 50820 5020	MAN
81 50820 5021	MAN
81 50820 5040	MAN
81 50820 5041	MAN
81 50820 5047	MAN
81 50820 5048	MAN
81 50820 6000	MAN
81 50820 6001	MAN
81 50820 6002	MAN
81 50820 6003	MAN
81 50820 6004	MAN
81 50820 6005	MAN
81 50820 6014	MAN
81 50820 6015	MAN
81 50820 6016	MAN
81 50820 6025	MAN
81 50820 6036	MAN



151040

E 9 90R-01178/660



Lucas-Meritor D3 -D Elsa

249.6x118.2x28

WVA

29030

29083

29113

MAKE

DAF

ERF

IVECO

MAN

MERCEDES-BENZ

RENAULT TRUCKS

SETRA

TEMSA

VAN HOOL



Trac.	CC	Kw	CV
-------	----	----	----



Front / Rear

DAF							
							Bus
DEN OUDSTEN 01.91-							
All models		Diesel				01.91-	■
ERF							
							Platform/Chassis
ECS 01.00-							
All models		Diesel				01.00-	■ ■
							Platform/Chassis
ECX 01.01-							
-		Diesel				01.01-	■ ■
IVECO							
							Dumper 01.91-
Dumper 01.91-							
-		Diesel				01.91-	■ ■
MAN							
							Dump Truck
E2000 08.97-							
24.273		Diesel		9973	198	269 06.95-02.00	■
24.273		Diesel		9973	198	269 06.95-02.00	■
24.273		Diesel		9973	198	269 06.95-02.00	■
26.273		Diesel		9973	198	269 06.95-02.00	■
26.273		Diesel		9973	198	269 06.95-02.00	■
26.273		Diesel		9973	198	269 05.96-02.00	■
26.273		Diesel		9973	198	269 06.95-02.00	■
27.273		Diesel		9973	198	269 06.95-02.00	■
27.273		Diesel		9973	198	269 06.95-02.00	■
27.273		Diesel		9973	198	269 05.96-02.00	■

LISTA DE APLICACIONES - BUYERS GUIDE

27.273		Diesel		9973	198	269	06.95-02.00	■
28.273		Diesel		9973	198	269	08.95-02.00	■
28.273		Diesel		9973	198	269	05.96-02.00	■
33.273		Diesel		9973	198	269	05.96-02.00	■
33.273		Diesel		9973	198	269	08.95-02.00	■
24.293		Diesel		9973	213	290	06.95-02.00	■
24.293		Diesel		9973	213	290	06.95-02.00	■
24.293		Diesel		9973	213	290	06.95-02.00	■
26.293		Diesel		9973	213	290	05.96-02.00	■
26.293		Diesel		9973	213	290	06.95-02.00	■
26.293		Diesel		9973	213	290	06.95-02.00	■
26.293		Diesel		9973	213	290	06.95-02.00	■
27.293		Diesel		9973	213	290	06.95-02.00	■
27.293		Diesel		9973	213	290	06.95-02.00	■
27.293		Diesel		9973	213	290	05.96-02.00	■
27.293		Diesel		9973	213	290	06.95-02.00	■
28.293		Diesel		9973	213	290	05.96-02.00	■
28.293		Diesel		9973	213	290	08.95-02.00	■
33.293		Diesel		9973	213	290	08.95-02.00	■
33.293		Diesel		9973	213	290	05.96-02.00	■
24.323		Diesel		9973	235	320	06.95-02.00	■
24.323		Diesel		9973	235	320	06.95-02.00	■
24.323		Diesel		9973	235	320	06.95-02.00	■
26.323		Diesel		9973	235	320	06.95-02.00	■
26.323		Diesel		9973	235	320	06.95-02.00	■
26.323		Diesel		9973	235	320	06.95-02.00	■
26.323		Diesel		9973	235	320	05.96-02.00	■
27.323		Diesel		9973	235	320	05.96-02.00	■
27.323		Diesel		9973	235	320	06.95-02.00	■
27.323		Diesel		9973	235	320	06.95-02.00	■
27.323		Diesel		9973	235	320	06.95-02.00	■
28.323		Diesel		9973	235	320	08.95-02.00	■
28.323		Diesel		9973	235	320	05.96-02.00	■
33.323		Diesel		9973	235	320	05.96-02.00	■
33.323		Diesel		9973	235	320	08.95-02.00	■
24.343		Diesel		9973	250	340	06.95-02.00	■
24.343		Diesel		9973	250	340	06.95-02.00	■
24.343		Diesel		9973	250	340	06.95-02.00	■
26.343		Diesel		9973	250	340	05.96-02.00	■
26.343		Diesel		9973	250	340	06.95-02.00	■
26.343		Diesel		9973	250	340	06.95-02.00	■
26.343		Diesel		9973	250	340	06.95-02.00	■
27.343		Diesel		9973	250	340	06.95-02.00	■
27.343		Diesel		9973	250	340	06.95-02.00	■
27.343		Diesel		9973	250	340	05.96-02.00	■
27.343		Diesel		9973	250	340	06.95-02.00	■
28.343		Diesel		9973	250	340	06.95-02.00	■
28.343		Diesel		9973	250	340	05.96-02.00	■
28.343		Diesel		9973	250	340	06.95-02.00	■
28.343		Diesel		9973	250	340	06.95-02.00	■
33.343		Diesel		9973	250	340	08.95-02.00	■

LISTA DE APLICACIONES - BUYERS GUIDE

33.343		Diesel		9973	250	340	05.96-02.00	■	
26.293		Diesel		11967	213	290	05.96-02.00	■	
26.293		Diesel		11967	213	290	05.96-02.00	■	
27.293		Diesel		11967	213	290	05.96-02.00	■	
27.293		Diesel		11967	213	290	05.96-02.00	■	
28.293		Diesel		11967	213	290	05.96-02.00	■	
28.293		Diesel		11967	213	290	05.96-02.00	■	
33.293		Diesel		11967	213	290	05.96-02.00	■	
33.293		Diesel		11967	213	290	05.96-02.00	■	
19.310 FLK (D 2866 LF23)		Diesel		11967	228	310	05.00-	■	■
26.310 FAVLK (D 2866 LF23)		Diesel		11967	228	310	05.00-	■	■
30.314		Diesel		11967	228	310	08.97-03.05	■	
26.343		Diesel		11967	250	340	05.96-02.00	■	
26.343		Diesel		11967	250	340	05.96-02.00	■	
27.343		Diesel		11967	250	340	05.96-02.00	■	
27.343		Diesel		11967	250	340	05.96-02.00	■	
28.343		Diesel		11967	250	340	05.96-02.00	■	
28.343		Diesel		11967	250	340	05.96-02.00	■	
33.343		Diesel		11967	250	340	05.96-02.00	■	
33.343		Diesel		11967	250	340	05.96-02.00	■	
19.360 FLK (D 2866 LF24)		Diesel		11967	265	360	05.00-	■	■
26.360 FAVLK (D 2866 LF24)		Diesel		11967	265	360	05.00-	■	■
28.360 FANLK (D 2866 LF24)		Diesel		11967	265	360	05.00-	■	■
30.364		Diesel		11967	265	360	07.97-03.05	■	
33.360 DFAK, DFALK (D 2866 LF24)		Diesel		11967	265	360	05.00-	■	■
33.360 DFLK (D 2866 LF24)		Diesel		11967	265	360	05.00-	■	
19.410 FLK (D 2866 LF25)		Diesel		11967	301	410	05.00-	■	■
26.410 FAVLK (D 2866 LF25)		Diesel		11967	301	410	05.00-	■	■
28.410 FANLK (D 2866 LF25)		Diesel		11967	301	410	05.00-	■	■
30.410 FANLK (D 2866 LF25)		Diesel		11967	301	410	05.00-	■	■
30.414		Diesel		11967	301	409	07.97-03.05	■	
32.410 VFARK (D 2866 LF25)		Diesel		11967	301	410	05.00-	■	■
32.414		Diesel		11967	301	409	07.97-03.05	■	
33.410 DFAK, DFALK (D 2866 LF25)		Diesel		11967	301	410	05.00-	■	■
33.410 DFLK (D 2866 LF25)		Diesel		11967	301	410	05.00-	■	
50.410 VFAVK, VFAVK-HK, VFAV-G (D 2866 LF25)		Diesel		11967	301	410	03.01-	■	■
50.414		Diesel		11967	301	409	03.96-03.04	■	
19.460 FLK (D 2876 LF 03)		Diesel		12816	338	460	05.00-	■	■
26.460 FAVLK (D 2876 LF 03)		Diesel		12816	338	460	05.00-	■	■
28.460 FANLK (D 2876 LF 03)		Diesel		12816	338	460	05.00-	■	■
30.460 FANLK (D 2876 LF 03)		Diesel		12816	338	460	05.00-	■	■
30.464		Diesel		12816	338	460	07.97-03.05	■	
32.464		Diesel		12816	338	460	07.97-03.05	■	
32.464		Diesel		12816	338	460	07.97-03.05	■	
33.460 DFAK, DFALK (D 2876 LF 03)		Diesel		12816	338	460	05.00-	■	■
33.460 DFLK (D 2876 LF 03)		Diesel		12816	338	460	05.00-	■	
50.460 VFAVK, VFAV-G, VFAVK-HK (D 2876 LF 03)		Diesel		12816	338	460	03.01-	■	■
E2000 08.97-									Platform/Chassis
24.273		Diesel		9973	198	269	06.95-02.00	■	
24.273		Diesel		9973	198	269	06.95-02.00	■	

LISTA DE APLICACIONES - BUYERS GUIDE

24.273		Diesel		9973	198	269	06.95-02.00	■
26.273		Diesel		9973	198	269	06.95-02.00	■
26.273		Diesel		9973	198	269	06.95-02.00	■
26.273		Diesel		9973	198	269	06.95-02.00	■
26.273		Diesel		9973	198	269	05.96-02.00	■
27.273		Diesel		9973	198	269	05.96-02.00	■
27.273		Diesel		9973	198	269	06.95-02.00	■
27.273		Diesel		9973	198	269	06.95-02.00	■
27.273		Diesel		9973	198	269	06.95-02.00	■
28.273		Diesel		9973	198	269	08.95-02.00	■
28.273		Diesel		9973	198	269	05.96-02.00	■
33.273		Diesel		9973	198	269	05.96-02.00	■
33.273		Diesel		9973	198	269	08.95-02.00	■
24.293		Diesel		9973	213	290	06.95-02.00	■
24.293		Diesel		9973	213	290	06.95-02.00	■
24.293		Diesel		9973	213	290	06.95-02.00	■
26.293		Diesel		9973	213	290	05.96-02.00	■
26.293		Diesel		9973	213	290	06.95-02.00	■
26.293		Diesel		9973	213	290	06.95-02.00	■
26.293		Diesel		9973	213	290	06.95-02.00	■
27.293		Diesel		9973	213	290	06.95-02.00	■
27.293		Diesel		9973	213	290	06.95-02.00	■
27.293		Diesel		9973	213	290	05.96-02.00	■
27.293		Diesel		9973	213	290	06.95-02.00	■
28.293		Diesel		9973	213	290	08.95-02.00	■
28.293		Diesel		9973	213	290	05.96-02.00	■
33.293		Diesel		9973	213	290	08.95-02.00	■
33.293		Diesel		9973	213	290	05.96-02.00	■
24.323		Diesel		9973	235	320	06.95-02.00	■
24.323		Diesel		9973	235	320	06.95-02.00	■
24.323		Diesel		9973	235	320	06.95-02.00	■
26.323		Diesel		9973	235	320	06.95-02.00	■
26.323		Diesel		9973	235	320	05.96-02.00	■
26.323		Diesel		9973	235	320	06.95-02.00	■
26.323		Diesel		9973	235	320	06.95-02.00	■
27.323		Diesel		9973	235	320	06.95-02.00	■
27.323		Diesel		9973	235	320	05.96-02.00	■
27.323		Diesel		9973	235	320	06.95-02.00	■
27.323		Diesel		9973	235	320	06.95-02.00	■
28.323		Diesel		9973	235	320	08.95-02.00	■
28.323		Diesel		9973	235	320	05.96-02.00	■
33.323		Diesel		9973	235	320	08.95-02.00	■
33.323		Diesel		9973	235	320	05.96-02.00	■
24.343		Diesel		9973	250	340	06.95-02.00	■
24.343		Diesel		9973	250	340	06.95-02.00	■
24.343		Diesel		9973	250	340	06.95-02.00	■
26.343		Diesel		9973	250	340	06.95-02.00	■
26.343		Diesel		9973	250	340	06.95-02.00	■
26.343		Diesel		9973	250	340	05.96-02.00	■
26.343		Diesel		9973	250	340	06.95-02.00	■
27.343		Diesel		9973	250	340	06.95-02.00	■

LISTA DE APLICACIONES - BUYERS GUIDE

27.343		Diesel		9973	250	340	06.95-02.00	■	
27.343		Diesel		9973	250	340	06.95-02.00	■	
27.343		Diesel		9973	250	340	05.96-02.00	■	
28.343		Diesel		9973	250	340	06.95-02.00	■	
28.343		Diesel		9973	250	340	05.96-02.00	■	
28.343		Diesel		9973	250	340	06.95-02.00	■	
28.343		Diesel		9973	250	340	06.95-02.00	■	
33.343		Diesel		9973	250	340	08.95-02.00	■	
33.343		Diesel		9973	250	340	05.96-02.00	■	
26.293		Diesel		11967	213	290	05.96-02.00	■	
26.293		Diesel		11967	213	290	05.96-02.00	■	
27.293		Diesel		11967	213	290	05.96-02.00	■	
27.293		Diesel		11967	213	290	05.96-02.00	■	
28.293		Diesel		11967	213	290	05.96-02.00	■	
28.293		Diesel		11967	213	290	05.96-02.00	■	
33.293		Diesel		11967	213	290	05.96-02.00	■	
33.293		Diesel		11967	213	290	05.96-02.00	■	
26.310 FAVLC (D 2866 LF23)		Diesel		11967	228	310	05.00-	■	
28.310 FNLC (D 2866 LF23)		Diesel		11967	228	310	05.00-	■	■
28.310 FNLC		Diesel		11967	228	310	05.00-	■	■
28.310 FNLC		Diesel		11967	228	310	05.00-	■	■
30.310 FNLC (D 2866 LF23)		Diesel		11967	228	310	05.00-	■	■
32.310 VFLC (D 2866 LF23)		Diesel		11967	228	310	05.00-	■	■
32.310 VFNLC (D 2866 LF23)		Diesel		11967	228	310	05.00-	■	■
32.310 VFNLC (D 2866 LF23)		Diesel		11967	228	310	05.00-	■	■
26.343		Diesel		11967	250	340	05.96-02.00	■	
26.343		Diesel		11967	250	340	05.96-02.00	■	
27.343		Diesel		11967	250	340	05.96-02.00	■	
27.343		Diesel		11967	250	340	05.96-02.00	■	
28.343		Diesel		11967	250	340	05.96-02.00	■	
28.343		Diesel		11967	250	340	05.96-02.00	■	
33.343		Diesel		11967	250	340	05.96-02.00	■	
33.343		Diesel		11967	250	340	05.96-02.00	■	
26.360 FAVLC (D 2866 LF24)		Diesel		11967	265	360	05.00-	■	
28.360 FANLC (D 2866 LF24)		Diesel		11967	265	360	05.00-	■	■
28.360 FNALC (D 2866 LF24)		Diesel		11967	265	360	05.00-	■	■
28.360 FNLC (D 2866 LF24)		Diesel		11967	265	360	05.00-	■	■
28.360 FNLC		Diesel		11967	265	360	05.00-	■	■
28.360 FNLC		Diesel		11967	265	360	05.00-	■	■
30.360 FNLC (D 2866 LF24)		Diesel		11967	265	360	05.00-	■	■
30.364		Diesel		11967	265	360	07.97-03.05	■	
32.360 VFLC (D 2866 LF24)		Diesel		11967	265	360	05.00-	■	■
32.360 VFNLC (D 2866 LF24)		Diesel		11967	265	360	05.00-	■	■
32.360 VFNLC (D 2866 LF24)		Diesel		11967	265	360	05.00-	■	■
33.360 DFALC (D 2866 LF24)		Diesel		11967	265	360	05.00-	■	■
33.360 DFLC (D 2866 LF24)		Diesel		11967	265	360	05.00-	■	
26.410 DFARC (D 2866 LF25)		Diesel		11967	301	410	05.00-	■	
26.410 DFRC (D 2866 LF25)		Diesel		11967	301	410	05.00-	■	
26.410 FAVLC		Diesel		11967	301	410	05.00-	■	
28.410 FANLC (D 2866 LF25)		Diesel		11967	301	410	05.00-	■	■
28.410 FNLC (D 2866 LF25)		Diesel		11967	301	410	05.00-	■	■

LISTA DE APLICACIONES - BUYERS GUIDE

28.410 FNLC		Diesel		11967	301	410	05.00-	■	■
28.410 FNLC		Diesel		11967	301	410	05.00-	■	■
30.410 FANLC (D 2866 LF25)		Diesel		11967	301	410	05.00-	■	■
30.410 FNLC (D 2866 LF25)		Diesel		11967	301	410	05.00-	■	■
30.414		Diesel		11967	301	409	07.97-03.05	■	
32.410 VFCL,VFRC, VFLRC (D 2866 LF25)		Diesel		11967	301	410	05.00-	■	■
32.410 VFNLC (D 2866 LF25)		Diesel		11967	301	410	05.00-	■	■
32.410 VFNLC (D 2866 LF25)		Diesel		11967	301	410	05.00-	■	■
32.414		Diesel		11967	301	409	07.97-03.05	■	
33.410 DFALC (D 2866 LF25)		Diesel		11967	301	410	05.00-	■	■
33.410 DFCL (D 2866 LF25)		Diesel		11967	301	410	05.00-	■	
35.410 FVNLC (D 2866 LF25)		Diesel		11967	301	410	05.00-	■	■
35.410 FVNLC (D 2866 LF25)		Diesel		11967	301	410	05.00-	■	■
26.460 DFARC (D 2876 LF 03)		Diesel		12816	338	460	05.00-	■	
26.460 FAVLC (D 2876 LF 03)		Diesel		12816	338	460	05.00-	■	
26.464		Diesel		12816	338	460	01.97-03.04	■	
28.460 FANLC (D 2876 LF 03)		Diesel		12816	338	460	05.00-	■	■
28.460 FNLC (D 2876 LF 03)		Diesel		12816	338	460	05.00-	■	■
28.460 FNLC		Diesel		12816	338	460	05.00-	■	■
28.460 FNLC		Diesel		12816	338	460	05.00-	■	■
30.460 FANLC (D 2876 LF 03)		Diesel		12816	338	460	05.00-	■	■
30.460 FNLC (D 2876 LF 03)		Diesel		12816	338	460	05.00-	■	■
30.464		Diesel		12816	338	460	07.97-03.05	■	
32.460 VFARK		Diesel		12816	338	460	05.00-	■	■
32.460 VFCL, VFLRC (D 2876 LF 03)		Diesel		12816	338	460	05.00-	■	■
32.460 VFNLC (D 2876 LF 03)		Diesel		12816	338	460	05.00-	■	■
32.460 VFNLC (D 2876 LF 03)		Diesel		12816	338	460	05.00-	■	■
33.460 DFALC (D 2876 LF 03)		Diesel		12816	338	460	05.00-	■	■
33.460 DFCL (D 2876 LF 03)		Diesel		12816	338	460	05.00-	■	
35.460 FVNLC (D 2876 LF 03)		Diesel		12816	338	460	05.00-	■	■
35.460 FVNLC (D 2876 LF 03)		Diesel		12816	338	460	05.00-	■	■
50.464		Diesel		12816	338	460	03.96-03.04	■	
E2000 08.97-				Platform/Chassis					
28.230 FNLC (E 2866 DF 01)		Gasolina		11967	170	231	05.00-	■	■
28.230 FNLC		Gasolina		11967	170	231	05.00-	■	■
E2000 08.97-				Truck Tractor					
19.310 FLS (D 2866 LF23)		Diesel		11967	228	310	05.00-	■	■
30.314		Diesel		11967	228	310	08.97-03.05	■	
19.360 FLS (D 2866 LF24)		Diesel		11967	265	360	05.00-	■	■
30.364		Diesel		11967	265	360	07.97-03.05	■	
30.364		Diesel		11967	265	360	07.97-03.05	■	
33.360 DFALS (D 2866 LF24)		Diesel		11967	265	360	04.01-	■	■
33.360 DFLS (D 2866 LF24)		Diesel		11967	265	360	05.00-	■	
19.410 FLS (D 2866 LF25)		Diesel		11967	301	410	05.00-	■	■
26.414		Diesel		11967	301	409	01.97-03.04	■	
26.414		Diesel		11967	301	409	01.97-03.04	■	
30.414		Diesel		11967	301	409	07.97-03.05	■	
30.414		Diesel		11967	301	409	07.97-03.05	■	
33.410 DFALS (D 2866 LF25)		Diesel		11967	301	410	04.01-	■	■
33.410 DFLS (D 2866 LF25)		Diesel		11967	301	410	05.00-	■	
19.460 FLS (D 2876 LF 03)		Diesel		12816	338	460	05.00-	■	■

LISTA DE APLICACIONES - BUYERS GUIDE

26.460 DFLS, DFLRS (D 2876 LF 03)	Diesel		12816	338	460	05.00-	■		
26.464	Diesel		12816	338	460	01.97-03.04	■		
29.460 FVAS (D 2876 LF 03)	Diesel		12816	338	460	05.00-	■	■	
30.464	Diesel		12816	338	460	07.97-03.05	■		
30.464	Diesel		12816	338	460	07.97-03.05	■		
33.460 DFALS (D 2876 LF 03)	Diesel		12816	338	460	04.01-	■	■	
33.460 DFLS (D 2876 LF 03)	Diesel		12816	338	460	05.00-	■		
41.460 DFVS, DFVLS (D 2876 LF 03)	Diesel		12816	338	460	06.00-	■	■	
33.600 DFLS (D 2840 LF21)	Diesel		18273	441	600	06.00-	■		
41.600 DFVS, DFVLS (D 2840 LF21)	Diesel		18273	441	600	06.00-	■	■	
EL 01.93-02.01							Bus		
EL 202,EL 222 (D 0826 LUH 03)	Diesel		6871	157	214	01.93-06.97	■		
EL 202,EL 222 (D 0826 LUH 05)	Diesel		6871	157	214	01.93-06.97	■		
EL 202,EL 222 (D 0826 LUH 12)	Diesel		6871	157	214	01.93-06.97	■		
EL 202,EL 262 (D 0826 LUH)	Diesel		6871	184	250	04.94-06.97	■		
EL 262 (D 2866 LUH 22)	Diesel		11967	191	260	07.98-02.01	■		
EM 08.87-							Bus		
EM 192 (D 0826 LOH 06)	Diesel		6871	140	190	10.93-06.97	■		
EM 222,EM 223 (D 0826 LOH 15)	Diesel		6871	162	220	02.96-	■		
EM 222,EM 223 (D 0826 LUH 12)	Diesel		6871	162	220	02.96-	■		
EM 223 (D 0826 LOH 15)	Diesel		6871	162	220	08.87-	■		
F2000 01.94-							Concrete Mixer		
26.314 DF-TM (D 2866 LF23)	Diesel		11967	228	310	05.01-	■	■	
27.314 DF-TM	Diesel		11967	228	310	05.01-	■	■	
32.314 VF-TM (D 2866 LF23)	Diesel		11967	228	310	05.01-	■	■	
35.314 VF-TM	Diesel		11967	228	310	03.02-	■	■	
26.364 DF-TM (D 2866 LF24)	Diesel		11967	265	360	05.01-	■	■	
27.364 DF-TM	Diesel		11967	265	360	05.01-	■	■	
32.364 VF-TM (D 2866 LF24)	Diesel		11967	265	360	05.01-	■	■	
35.364 VF-TM (D 2866 LF24)	Diesel		11967	265	360	03.02-	■	■	
27.373 DF-TM	Diesel		11967	272	370	07.00-	■	■	
27.403 DF-TM	Diesel		11967	294	400	07.00-	■	■	
26.414 DF-TM (D 2866 LF25)	Diesel		11967	301	409	05.01-	■	■	
27.414 DF-TM	Diesel		11967	301	409	05.01-	■	■	
32.414 VF-TM (D 2866 LF25)	Diesel		11967	301	409	05.01-	■	■	
35.414 VF-TM (D 2866 LF25)	Diesel		11967	301	409	03.02-	■	■	
27.423 DF-TM	Diesel		11967	309	420	07.00-	■	■	
26.414	Diesel		12816	301	409	07.94-03.01	■		
27.414	Diesel		12816	301	409	08.94-02.05	■		
27.414	Diesel		12816	301	409	07.94-03.01	■		
32.414	Diesel		12816	301	409	04.95-03.03	■		
35.414	Diesel		12816	301	409	04.95-02.05	■		
26.464 DF-TM (D 2876 LF 03)	Diesel		12816	338	460	05.01-	■	■	
27.463 DF-TM	Diesel		12816	338	460	07.00-	■	■	
27.464 DF-TM	Diesel		12816	338	460	05.01-	■	■	
32.464 VF-TM (D 2876 LF 03)	Diesel		12816	338	460	05.01-	■	■	
35.464 VF-TM (D 2876 LF 03)	Diesel		12816	338	460	03.02-	■	■	
F2000 01.94-									
40.403 DFS	Diesel			294	400	01.94-	■		
40.463 DFS	Diesel			338	460	01.94-	■		

LISTA DE APLICACIONES - BUYERS GUIDE

F2000 01.94-					Dump Truck			
18.273		Diesel		9973	198	269	06.94-01.00	■
19.273FAK (D 2865 LF22)		Diesel		9973	198	269	01.94-	■
19.273FK (D 2865 LF22)		Diesel		9973	198	269	01.94-	■
26.273 DFK,26.273 DFLK (D 2865 LF22)		Diesel		9973	198	269	01.94-12.95	■
27.273DFAK (D 2865 LF22)		Diesel		9973	198	269	01.94-12.95	■
27.273DFK (D 2865 LF22)		Diesel		9973	198	269	01.94-12.95	■
33.273		Diesel		9973	198	269	08.94-01.00	■
18.293		Diesel		9973	213	290	06.94-01.00	■
19.293 FAK (D 2865 LF20)		Diesel		9973	213	290	01.94-	■
19.293 FAK (D 2865 LF24)		Diesel		9973	213	290	01.94-	■
19.293 FK,19.293 FLK (D 2865 LF20)		Diesel		9973	213	290	01.94-	■
19.293 FK,19.293 FLK (D 2865 LF24)		Diesel		9973	213	290	01.94-	■
26.293 DFK,26.293 DFLK (D 2865 LF20)		Diesel		9973	213	290	01.94-	■
26.293 DFK,26.293 DFLK (D 2865 LF24)		Diesel		9973	213	290	01.94-	■
27.293DFAK (D 2865 LF20)		Diesel		9973	213	290	01.94-	■
27.293DFAK (D 2865 LF24)		Diesel		9973	213	290	01.94-	■
27.293 DFK (D 2865 LF20)		Diesel		9973	213	290	01.94-	■
27.293 DFK (D 2865 LF24)		Diesel		9973	213	290	01.94-	■
32.293		Diesel		9973	213	290	04.95-01.00	■
33.293		Diesel		9973	213	290	08.94-01.00	■
35.293		Diesel		9973	213	290	04.95-01.00	■
18.323		Diesel		9973	235	320	06.94-01.00	■
19.323FAK (D 2865 LF23)		Diesel		9973	235	320	01.94-12.95	■
19.323 FK,19.323 FLK (D 2865 LF23)		Diesel		9973	235	320	01.94-12.95	■
26.323 DFK,26.323 DFLK (D 2865 LF23)		Diesel		9973	235	320	01.94-12.95	■
27.323 DFAK, DFA-KI (D 2865 LF23)		Diesel		9973	235	320	01.94-	■
27.323 DFK, DF-KI (D 2865 LF23)		Diesel		9973	235	320	01.94-	■
32.323		Diesel		9973	235	320	04.95-01.00	■
33.323 DFAK (D 2865 LF23)		Diesel		9973	235	320	01.94-12.95	■
33.323 DFK (D 2865 LF23)		Diesel		9973	235	320	01.94-12.95	■
35.323		Diesel		9973	235	320	04.95-01.00	■
37.323		Diesel		9973	235	320	05.95-01.00	■
41.323		Diesel		9973	235	320	05.95-01.00	■
18.343		Diesel		9973	250	340	06.94-01.00	■
19.343FAK (D 2865 LF21)		Diesel		9973	250	340	01.94-	■
19.343 FK,19.343 FLK (D 2865 LF21)		Diesel		9973	250	340	01.94-	■
19.344		Diesel		9973	250	340	06.94-01.00	■
26.343 DFK,26.343 DFLK (D 2865 LF21)		Diesel		9973	250	340	01.94-	■
27.343DFAK (D 2865 LF21)		Diesel		9973	250	340	01.94-	■
27.343DFK (D 2865 LF21)		Diesel		9973	250	340	01.94-	■
32.343VFK (D 2865 LF21)		Diesel		9973	250	340	08.95-	■
33.343 DFAK (D 2865 LF21)		Diesel		9973	250	340	01.94-	■
33.343 DFK (D 2865 LF21)		Diesel		9973	250	340	01.94-	■
35.343VFK (D 2865 LF21)		Diesel		9973	250	340	08.95-	■
37.343		Diesel		9973	250	340	05.95-01.00	■
41.343VFK (D 2865 LF21)		Diesel		9973	250	340	08.95-	■
18.314		Diesel		11967	228	310	06.94-08.99	■
19.314 FAK, FA-KI, FAK-L		Diesel		11967	228	310	05.01-	■ ■
19.314 FK, FK-L, F-KI, FL-KI, F-NL, FLK (D 2866 LF34)		Diesel		11967	228	310	06.94-02.05	■ ■
26.314 DFK, DFLK, DFLK-L (D 2866 LF23)		Diesel		11967	228	310	05.01-	■ ■

LISTA DE APLICACIONES - BUYERS GUIDE

27.314 DFAK, DFA-KI, DFAK-L	Diesel	11967	228	310	05.01-	■	■
27.314 DFK, DFLK, DFLK-L, DF-KI	Diesel	11967	228	310	05.01-	■	■
28.314	Diesel	11967	228	310	07.94-03.01	■	
32.314 VFK, VF-HK (D 2866 LF23)	Diesel	11967	228	310	05.01-	■	■
35.314	Diesel	11967	228	310	04.95-02.05	■	
37.314	Diesel	11967	228	310	04.95-03.03	■	
18.364	Diesel	11967	265	360	06.94-08.99	■	
19.364 FAK, FA-KI, FAK-L (D 2866 LF35)	Diesel	11967	265	360	06.98-	■	■
19.364 FK, FK-L, F-KI, FL-KI, F-NL, FLK (D 2866 LF35)	Diesel	11967	265	360	06.98-	■	■
26.364 DFK, DFLK, DFLK-L (D 2866 LF24)	Diesel	11967	265	360	05.01-	■	■
27.364 DFAK, DFA-KI, DFAK-L	Diesel	11967	265	360	05.01-	■	■
27.364 DFK, DFK-KI, DFK-L, DF-KI	Diesel	11967	265	360	05.01-	■	■
28.364	Diesel	11967	265	360	07.94-03.01	■	
32.364 VFK, VF-HK (D 2866 LF24)	Diesel	11967	265	360	05.01-	■	■
33.364 DFAK, DFAK-HK, DFA-KI	Diesel	11967	265	360	05.01-	■	■
33.364 DFK, DF-KI	Diesel	11967	265	360	05.01-	■	
35.364 VFK, VF-HK, VF-KI (D 2866 LF24)	Diesel	11967	265	360	03.02-	■	■
37.364	Diesel	11967	265	360	04.95-03.03	■	
38.364	Diesel	11967	265	360	08.94-02.05	■	
41.364 VFK, VF-HK, VF-KI	Diesel	11967	265	360	03.02-	■	■
18.373	Diesel	11967	272	370	06.94-08.99	■	
19.373 FAK, FA-KI, FAK-L (D 2866 LF21)	Diesel	11967	272	370	01.94-	■	
19.373 FK, FK-L, F-KI, FL-KI, F-NL, FLK (D 2866 LF21)	Diesel	11967	272	370	01.94-	■	
26.373 DFK,26.373 DFLK (D 2866 LF21)	Diesel	11967	272	370	01.94-12.95	■	
27.373 DFAK, DFA-KI, DFAK-L (D 2866 LF21)	Diesel	11967	272	370	01.94-	■	
27.373 DFK, DFK-KI, DFK-L, DF-KI (D 2866 LF21)	Diesel	11967	272	370	01.94-	■	
33.373 DFAK, DFAK-HK, DFA-KI (D 2866 LF21)	Diesel	11967	272	370	01.94-	■	
33.373 DFK, DF-KI (D 2866 LF21)	Diesel	11967	272	370	01.94-	■	
35.373 VFK, VF-HK, VF-KI	Diesel	11967	272	370	03.02-	■	■
40.373 DFAK	Diesel	11967	272	370	05.01-	■	■
40.373 DFK	Diesel	11967	272	370	05.01-	■	■
41.373 VFK, VF-HK, VF-KI	Diesel	11967	272	370	03.02-	■	■
18.403	Diesel	11967	294	400	06.94-08.99	■	
19.403 FAK, FA-KI (D 2866 LF20)	Diesel	11967	294	400	01.94-	■	
19.403 FK, F-KI, FK-L,FLK, FL-KI, F-NL (D 2866 LF20)	Diesel	11967	294	400	01.94-	■	
26.403 DFK,26.403 DFLK (D 2866 LF20)	Diesel	11967	294	400	01.94-	■	
27.403 DFAK, DFA-KI, DFAK-L (D 2866 LF20)	Diesel	11967	294	400	01.94-	■	
27.403 DFK, DFK-KI, DFK-L, DF-KI (D 2866 LF20)	Diesel	11967	294	400	01.94-	■	
33.403 DFAK, DFAK-HK, DFA-KI (D 2866 LF20)	Diesel	11967	294	400	01.94-	■	
33.403 DFK, DF-KI (D 2866 LF20)	Diesel	11967	294	400	01.94-	■	
35.403 VFK, VF-HK, VF-KI (D 2866 LF20)	Diesel	11967	294	400	03.02-	■	
40.403 DFAK (D 2866 LF20)	Diesel	11967	294	400	01.94-	■	■
40.403 DFK (D 2866 LF20)	Diesel	11967	294	400	01.94-	■	■
41.403 VFK, VF-HK, VF-KI (D 2866 LF20)	Diesel	11967	294	400	08.95-	■	
18.414	Diesel	11967	301	409	06.94-08.99	■	
19.414 FAK, FA-KI, FAK-L (D 2866 LF31)	Diesel	11967	301	409	06.98-	■	■
19.414 FK, F-KI, FK-L,FLK, FL-KI, F-NL (D 2866 LF31)	Diesel	11967	301	409	06.98-	■	■
26.414 DFK, DFLK, DFLK-L (D 2866 LF25)	Diesel	11967	301	409	05.01-	■	■

LISTA DE APLICACIONES - BUYERS GUIDE

27.414 DFAK, DFA-KI, DFAK-L	Diesel	11967	301	409	05.01-	■	■
27.414 DFK, DFK-KI, DFK-L, DF-KI	Diesel	11967	301	409	05.01-	■	■
28.414	Diesel	11967	301	409	07.94-03.01	■	
32.414 VFK, VF-HK (D 2866 LF25)	Diesel	11967	301	409	05.01-	■	■
33.414 DFAK, DFAK-HK, DFA-KI	Diesel	11967	301	409	05.01-	■	■
33.414 DFK, DF-KI	Diesel	11967	301	409	05.01-	■	
35.414 VFK, VF-HK, VF-KI (D 2866 LF25)	Diesel	11967	301	409	03.02-	■	■
37.414	Diesel	11967	301	409	04.95-03.03	■	
38.414	Diesel	11967	301	409	08.94-02.05	■	
40.414 DFAK	Diesel	11967	301	409	05.01-	■	■
40.414 DFK	Diesel	11967	301	409	05.01-	■	■
41.414 VFK, VF-HK, VF-KI	Diesel	11967	301	409	03.02-	■	■
18.423	Diesel	11967	309	420	06.94-08.99	■	
19.423 FAK, FA-KI (D 2866 LF22)	Diesel	11967	309	420	01.94-	■	
19.423 FK, F-KI, FK-L, FLK, FL-KI, F-NL (D 2866 LF22)	Diesel	11967	309	420	01.94-	■	
26.423 DFK, 26.423 DFLK (D 2866 LF22)	Diesel	11967	309	420	01.94-12.95	■	
27.423 DFAK, DFA-KI, DFAK-L (D 2866 LF22)	Diesel	11967	309	420	01.94-	■	
27.423 DFK, DFK-KI, DFK-L, DF-KI (D 2866 LF22)	Diesel	11967	309	420	01.94-	■	
33.423 DFAK, DFAK-HK, DFA-KI (D 2866 LF22)	Diesel	11967	309	420	01.94-	■	
33.423 DFK, DF-KI (D 2866 LF22)	Diesel	11967	309	420	01.94-	■	
35.423 VFK, VF-HK, VF-KI	Diesel	11967	309	420	03.02-	■	■
38.423	Diesel	11967	309	420	08.94-02.05	■	
40.423 DFAK	Diesel	11967	309	420	05.01-	■	■
40.423 DFK	Diesel	11967	309	420	05.01-	■	■
41.423 VFK, VF-HK, VF-KI	Diesel	11967	309	420	03.02-	■	■
18.414	Diesel	12816	301	409	06.94-08.99	■	
19.414	Diesel	12816	301	409	06.94-08.99	■	
26.414	Diesel	12816	301	409	07.94-02.04	■	
27.414	Diesel	12816	301	409	08.94-02.05	■	
27.414	Diesel	12816	301	409	07.94-03.01	■	
28.414	Diesel	12816	301	409	07.94-03.01	■	
32.414	Diesel	12816	301	409	04.95-03.03	■	
33.414	Diesel	12816	301	409	08.94-02.05	■	
35.414	Diesel	12816	301	409	04.95-02.05	■	
37.414	Diesel	12816	301	409	04.95-03.03	■	
38.414	Diesel	12816	301	409	08.94-02.05	■	
41.414	Diesel	12816	301	409	05.95-02.05	■	
18.463	Diesel	12816	338	460	06.94-08.99	■	
18.464	Diesel	12816	338	460	06.94-08.99	■	
19.463 FAK, FA-KI, FAK-L (D 2876 LF 02)	Diesel	12816	338	460	01.94-	■	
19.463 FK, F-KI, FK-L, FLK, FL-KI, F-NL (D 2876 LF 02)	Diesel	12816	338	460	01.94-	■	
19.464 FAK, FA-KI, FAK-L (D 2876 LF 06)	Diesel	12816	338	460	06.98-	■	■
19.464 FK, F-KI, FK-L, FLK, FL-KI, F-NL (D 2876 LF 06)	Diesel	12816	338	460	06.98-	■	■
26.463 DFK, DFLK, DFLK-L (D 2876 LF 02)	Diesel	12816	338	460	01.94-	■	
26.464 DFK, DFLK, DFLK-L (D 2876 LF 03)	Diesel	12816	338	460	05.01-	■	■
27.463 DFAK, DFA-KI, DFAK-L (D 2876 LF 02)	Diesel	12816	338	460	01.94-	■	
27.463 DFK, DFK-KI, DFK-L, DF-KI (D 2876 LF 02)	Diesel	12816	338	460	01.94-	■	
27.464 DFAK, DFA-KI, DFAK-L	Diesel	12816	338	460	05.01-	■	■
27.464 DFK, DFK-KI, DFK-L, DF-KI	Diesel	12816	338	460	05.01-	■	■

LISTA DE APLICACIONES - BUYERS GUIDE

28.464		Diesel		12816	338	460	07.94-03.01	■		
32.463VFK (D 2876 LF 02)		Diesel		12816	338	460	08.95-	■		
32.464 VFK, VF-HK (D 2876 LF 03)		Diesel		12816	338	460	05.01-	■	■	
33.463 DFAK, DFAK-HK, DFA-KI (D 2876 LF 02)		Diesel		12816	338	460	01.94-	■		
33.463 DFK, DF-KI (D 2876 LF 02)		Diesel		12816	338	460	01.94-	■		
33.464 DFAK, DFAK-HK, DFA-KI		Diesel		12816	338	460	05.01-	■	■	
33.464 DFK, DF-KI		Diesel		12816	338	460	05.01-	■		
35.463 VFK, VF-HK, VF-KI (D 2876 LF 02)		Diesel		12816	338	460	08.95-	■		
35.464 VFK, VF-HK, VF-KI (D 2876 LF 03)		Diesel		12816	338	460	03.02-	■	■	
37.464		Diesel		12816	338	460	04.95-03.03	■		
38.463		Diesel		12816	338	460	08.94-02.05	■		
38.464		Diesel		12816	338	460	08.94-02.05	■		
40.463 DFAK (D 2876 LF 02)		Diesel		12816	338	460	01.94-	■	■	
40.463 DFK (D 2876 LF 02)		Diesel		12816	338	460	01.94-	■	■	
41.463 VFK, VF-HK, VF-KI (D 2876 LF 02)		Diesel		12816	338	460	08.95-	■		
41.464 VFK, VF-HK, VF-KI		Diesel		12816	338	460	03.02-	■	■	
F2000 01.94-							Dump Truck			
19.233 FK, FK-L, CNG (E 2866 DF 01)		Gasolina		11967	170	231	03.00-	■	■	
F2000 01.94-							Municipal Vehicle			
26.314 FVL-KO (D 2866 LF23)		Diesel		11967	228	310	05.01-	■		
26.364 FVL-KO (D 2866 LF24)		Diesel		11967	265	360	05.01-	■		
26.414 FVL-KO (D 2866 LF25)		Diesel		11967	301	409	05.01-	■		
26.414		Diesel		12816	301	409	07.94-02.05	■		
26.464 FVL-KO (D 2876 LF 03)		Diesel		12816	338	460	05.01-	■		
F2000 01.94-							Municipal Vehicle			
26.233 FVL-KO		Gasolina		11967	170	231	03.00-	■		
F2000 01.94-							Platform/Chassis			
18.273 F, FL, FLL (D 2865 LF22)		Diesel		9973	198	269	06.94-	■		
19.273 F, FL, FLL (D 2865 LF22)		Diesel		9973	198	269	01.94-	■		
19.273FA (D 2865 LF22)		Diesel		9973	198	269	01.94-	■		
22.273		Diesel		9973	198	269	07.94-01.00	■		
23.273		Diesel		9973	198	269	06.94-01.00	■		
24.273 FNLLC (D 2865 LF22)		Diesel		9973	198	269	01.94-12.95	■		
26.273 DFC,26.273 DFCL (D 2865 LF22)		Diesel		9973	198	269	01.94-12.95	■		
26.273 FNLC,26.273 FNLLC,26.273 FVLC (D 2865 LF22)		Diesel		9973	198	269	01.94-12.95	■		
26.273 FNLC,26.273 FNLLC,26.273 FVLC		Diesel		9973	198	269	01.94-12.95	■	■	
27.273		Diesel		9973	198	269	06.94-01.00	■		
27.273		Diesel		9973	198	269	07.94-01.00	■		
27.273DFAC (D 2865 LF22)		Diesel		9973	198	269	01.94-12.95	■		
27.273 DFC (D 2865 LF22)		Diesel		9973	198	269	01.94-12.95	■		
28.273		Diesel		9973	198	269	07.94-01.00	■		
33.273		Diesel		9973	198	269	08.94-01.00	■		
18.293		Diesel		9973	213	290	06.94-01.00	■		
19.293FAC (D 2865 LF20)		Diesel		9973	213	290	01.94-	■		
19.293FAC (D 2865 LF24)		Diesel		9973	213	290	01.94-	■		
19.293 FC,19.293 FLC,19.293 FLLC (D 2865 LF20)		Diesel		9973	213	290	01.94-	■		
19.293 FC,19.293 FLC,19.293 FLLC (D 2865 LF24)		Diesel		9973	213	290	01.94-	■		
22.293		Diesel		9973	213	290	07.94-01.00	■		

LISTA DE APLICACIONES - BUYERS GUIDE

23.293 FNLLC (D 2865 LF20)	Diesel	9973	213	290	01.94-	■
23.293 FNLLC (D 2865 LF24)	Diesel	9973	213	290	01.94-	■
24.293 FNLLC (D 2865 LF24)	Diesel	9973	213	290	01.94-	■
26.293 DFC,26.293 DFCL (D 2865 LF20)	Diesel	9973	213	290	01.94-	■
26.293 DFC,26.293 DFCL (D 2865 LF24)	Diesel	9973	213	290	01.94-	■
26.293 FNLC,26.293 FNLLC,26.293 FVLC (D 2865 LF20)	Diesel	9973	213	290	01.94-	■
26.293 FNLC,26.293 FNLLC,26.293 FVLC (D 2865 LF24)	Diesel	9973	213	290	01.94-	■
26.293 FNLC,26.293 FNLLC,26.293 FVLC	Diesel	9973	213	290	01.94-	■ ■
27.293	Diesel	9973	213	290	06.94-01.00	■
27.293	Diesel	9973	213	290	07.94-01.00	■
27.293DFAC (D 2865 LF20)	Diesel	9973	213	290	01.94-	■
27.293DFAC (D 2865 LF24)	Diesel	9973	213	290	01.94-	■
27.293 DFC (D 2865 LF20)	Diesel	9973	213	290	01.94-	■
27.293 DFC (D 2865 LF24)	Diesel	9973	213	290	01.94-	■
28.293	Diesel	9973	213	290	07.94-01.00	■
32.293VFC (D 2865 LF24)	Diesel	9973	213	290	08.95-	■
33.293	Diesel	9973	213	290	08.94-01.00	■
35.293	Diesel	9973	213	290	04.95-01.00	■
18.323	Diesel	9973	235	320	06.94-01.00	■
19.323FAC (D 2865 LF23)	Diesel	9973	235	320	01.94-12.95	■
19.323 FC,19.323 FLC,19.323 FLLC (D 2865 LF23)	Diesel	9973	235	320	01.94-12.95	■
22.323	Diesel	9973	235	320	07.94-01.00	■
23.323	Diesel	9973	235	320	06.94-01.00	■
24.323 FNLLC (D 2865 LF23)	Diesel	9973	235	320	01.94-12.95	■
26.323 DFC,26.323 DFCL (D 2865 LF23)	Diesel	9973	235	320	01.94-12.95	■
26.323 FNLC,26.323 FNLLC,26.323 FVLC (D 2865 LF23)	Diesel	9973	235	320	01.94-12.95	■
26.323 FNLC,26.323 FNLLC,26.323 FVLC	Diesel	9973	235	320	01.94-12.95	■ ■
27.323	Diesel	9973	235	320	06.94-01.00	■
27.323	Diesel	9973	235	320	07.94-01.00	■
27.323DFAC (D 2865 LF23)	Diesel	9973	235	320	01.94-12.95	■
27.323 DFC (D 2865 LF23)	Diesel	9973	235	320	01.94-12.95	■
28.323	Diesel	9973	235	320	07.94-01.00	■
32.323	Diesel	9973	235	320	04.95-08.01	■
33.323 DFAC (D 2865 LF23)	Diesel	9973	235	320	01.94-12.95	■
33.323 DFC (D 2865 LF23)	Diesel	9973	235	320	01.94-12.95	■
35.323	Diesel	9973	235	320	04.95-01.00	■
37.323	Diesel	9973	235	320	05.95-01.00	■
41.323	Diesel	9973	235	320	05.95-01.00	■
18.343	Diesel	9973	250	340	06.94-01.00	■
19.343FAC (D 2865 LF21)	Diesel	9973	250	340	01.94-	■
19.343 FC,19.343 FLC,19.343 FLLC (D 2865 LF21)	Diesel	9973	250	340	01.94-	■
19.344	Diesel	9973	250	340	06.94-01.00	■
22.343	Diesel	9973	250	340	07.94-01.00	■
23.343 FNLLC (D 2865 LF21)	Diesel	9973	250	340	01.94-	■
23.344	Diesel	9973	250	340	06.94-01.00	■
24.343 FNLLC (D 2865 LF21)	Diesel	9973	250	340	01.94-	■
26.343 DFC,26.343 DFCL (D 2865 LF21)	Diesel	9973	250	340	01.94-	■
26.343 FNLC,26.343 FNLLC,26.343 FVLC (D 2865 LF21)	Diesel	9973	250	340	01.94-	■
26.343 FNLC,26.343 FNLLC,26.343 FVLC	Diesel	9973	250	340	01.94-	■ ■

LISTA DE APLICACIONES - BUYERS GUIDE

27.343		Diesel		9973	250	340	06.94-01.00	■
27.343		Diesel		9973	250	340	07.94-01.00	■
27.343DFAC (D 2865 LF21)		Diesel		9973	250	340	01.94-	■
27.343 DFC (D 2865 LF21)		Diesel		9973	250	340	01.94-	■
28.343		Diesel		9973	250	340	07.94-01.00	■
32.343VFC (D 2865 LF21)		Diesel		9973	250	340	08.95-	■
33.343 DFAC (D 2865 LF21)		Diesel		9973	250	340	01.94-	■
33.343 DFC (D 2865 LF21)		Diesel		9973	250	340	01.94-	■
35.343VFC (D 2865 LF21)		Diesel		9973	250	340	08.95-	■ ■
37.343		Diesel		9973	250	340	05.95-01.00	■
41.343VFC (D 2865 LF21)		Diesel		9973	250	340	08.95-	■ ■
18.314		Diesel		11967	228	310	06.94-05.02	■
19.314 FAC		Diesel		11967	228	310	05.01-	■ ■
19.314 FC, FLC, FLLC, FLLW, FRC, FLRC, FLLRC, FLL, FLLR, F-N (D 2866 LF34)		Diesel		11967	228	310	06.98-	■
22.314		Diesel		11967	228	310	07.94-02.05	■
23.314 FNLLC		Diesel		11967	228	310	05.01-	■
23.314 FNLLC		Diesel		11967	228	310	05.01-	■
24.314		Diesel		11967	228	310	06.94-02.05	■
24.314 FNLLRC		Diesel		11967	228	310	05.01-	■ ■
26.314 DFC, DFLC		Diesel		11967	228	310	05.01-	■
26.314 FNLC, FNLLC, FNLLRC, FNLLW, FNLRC, FNLLRC, FVLC (D 2866 LF23)		Diesel		11967	228	310	05.01-	■
26.314 FNLC, FNLLC, FNLLRC, FNLLW, FNLRC, FNLLRC, FVLC		Diesel		11967	228	310	05.01-	■ ■
27.314 DFAC (D 2866 LF23)		Diesel		11967	228	310	05.01-	■ ■
27.314 DFC		Diesel		11967	228	310	05.01-	■
27.314 FVL (D 2866 LF23)		Diesel		11967	228	310	06.98-	■
28.314		Diesel		11967	228	310	07.94-03.01	■
32.314 VF, VFC (D 2866 LF23)		Diesel		11967	228	310	05.01-	■ ■
35.314		Diesel		11967	228	310	04.95-02.05	■
37.314		Diesel		11967	228	310	04.95-03.03	■
18.364		Diesel		11967	265	360	06.94-05.02	■
19.364FAC (D 2866 LF35)		Diesel		11967	265	360	06.98-	■
19.364 FC, FLC, FLLC, FLLW, FRC, FLRC, FLLRC, FLL, FLLR, F-N (D 2866 LF35)		Diesel		11967	265	360	06.98-	■
22.364		Diesel		11967	265	360	07.94-02.05	■
23.364 FNLLC		Diesel		11967	265	360	05.01-	■
23.364 FNLLC		Diesel		11967	265	360	05.01-	■
24.364		Diesel		11967	265	360	06.94-02.05	■
24.364 FNLLRC		Diesel		11967	265	360	05.01-	■ ■
26.364 DFC, DFLC (D 2866 LF24)		Diesel		11967	265	360	05.01-	■
26.364 FNLC, FNLLC, FNLLRC, FNLLW, FNLRC, FNLLRC, FVLC (D 2866 LF24)		Diesel		11967	265	360	05.01-	■
26.364 FNLC, FNLLC, FNLLRC, FNLLW, FNLRC, FNLLRC, FVLC		Diesel		11967	265	360	05.01-	■ ■
27.364 DFAC (D 2866 LF24)		Diesel		11967	265	360	05.01-	■ ■
27.364 DFC		Diesel		11967	265	360	05.01-	■
27.364 FVL (D 2866 LF24)		Diesel		11967	265	360	06.98-	■
28.364		Diesel		11967	265	360	07.94-03.01	■
32.364 VF, VFC (D 2866 LF24)		Diesel		11967	265	360	05.01-	■ ■
33.364 DFAC		Diesel		11967	265	360	05.01-	■ ■
33.364 DFC		Diesel		11967	265	360	05.01-	■
35.364 VF, VFC, VFRC (D 2866 LF24)		Diesel		11967	265	360	05.01-	■ ■
37.364		Diesel		11967	265	360	04.95-03.03	■

LISTA DE APLICACIONES - BUYERS GUIDE

38.364		Diesel		11967	265	360	08.94-02.05	■	
41.364 VF, VFC, VFRC		Diesel		11967	265	360	05.01-	■	■
18.373		Diesel		11967	272	370	06.94-08.99	■	
19.373FAC (D 2866 LF21)		Diesel		11967	272	370	01.94-	■	
19.373 FC, FLC, FLLC, FRC, FLRC, F-NL (D 2866 LF21)		Diesel		11967	272	370	01.94-	■	
22.373		Diesel		11967	272	370	07.94-02.05	■	
24.373		Diesel		11967	272	370	06.94-02.05	■	
24.373 FNLLC (D 2866 LF21)		Diesel		11967	272	370	01.94-12.95	■	
26.373 DFC,26.373 DFLLC (D 2866 LF21)		Diesel		11967	272	370	01.94-12.95	■	
26.373 FNLC,26.373 FNLLC,26.373 FVLC (D 2866 LF21)		Diesel		11967	272	370	01.94-12.95	■	
26.373 FNLC,26.373 FNLLC,26.373 FVLC		Diesel		11967	272	370	01.94-12.95	■	■
27.373DFAC (D 2866 LF21)		Diesel		11967	272	370	01.94-	■	
27.373 DFC (D 2866 LF21)		Diesel		11967	272	370	01.94-	■	
32.373		Diesel		11967	272	370	03.97-08.01	■	
33.373 DFAC (D 2866 LF21)		Diesel		11967	272	370	01.94-	■	
33.373 DFC (D 2866 LF21)		Diesel		11967	272	370	01.94-	■	
35.373 VF, VFC, VFRC		Diesel		11967	272	370	05.01-	■	■
41.373 VF, VFC, VFRC		Diesel		11967	272	370	05.01-	■	■
18.403		Diesel		11967	294	400	06.94-08.99	■	
19.403FAC (D 2866 LF20)		Diesel		11967	294	400	01.94-	■	
19.403 FC, FLC, FLLC, FRC, FLRC, F-NL (D 2866 LF20)		Diesel		11967	294	400	01.94-	■	
22.403		Diesel		11967	294	400	07.94-02.05	■	
23.403		Diesel		11967	294	400	06.94-02.04	■	
23.403 FNLLC (D 2866 LF20)		Diesel		11967	294	400	01.94-	■	
24.403 FNLLC (D 2866 LF20)		Diesel		11967	294	400	06.94-02.05	■	
24.403 FNLLC		Diesel		11967	294	400	06.94-02.05	■	
26.403 DFC,26.403 DFLLC (D 2866 LF20)		Diesel		11967	294	400	01.94-	■	
26.403 FNLC,26.403 FNLLC,26.403 FVLC (D 2866 LF20)		Diesel		11967	294	400	01.94-	■	
26.403 FNLC,26.403 FNLLC,26.403 FVLC		Diesel		11967	294	400	01.94-	■	■
27.403DFAC (D 2866 LF20)		Diesel		11967	294	400	01.94-	■	
27.403 DFC (D 2866 LF20)		Diesel		11967	294	400	01.94-	■	
32.403VFC (D 2866 LF20)		Diesel		11967	294	400	08.95-	■	
33.403 DFAC (D 2866 LF20)		Diesel		11967	294	400	01.94-	■	
33.403 DFC (D 2866 LF20)		Diesel		11967	294	400	01.94-	■	
35.403 VF, VFC, VFRC (D 2866 LF20)		Diesel		11967	294	400	08.95-	■	
41.403 VF, VFC, VFRC (D 2866 LF20)		Diesel		11967	294	400	08.95-	■	
18.414		Diesel		11967	301	409	06.94-05.02	■	
19.414FAC (D 2866 LF31)		Diesel		11967	301	409	06.98-	■	
19.414 FC, FLC, FLLC, FRC, FLRC, FLLRC, FLL, FLLR, F-NL (D 2866 LF31)		Diesel		11967	301	409	06.98-	■	
22.414		Diesel		11967	301	409	07.94-02.05	■	
23.414 FNLLC		Diesel		11967	301	409	05.01-	■	
23.414 FNLLC		Diesel		11967	301	409	05.01-	■	
24.414		Diesel		11967	301	409	06.94-02.05	■	
24.414 FNLLRC		Diesel		11967	301	409	05.01-	■	■
26.414 DFC, DFLLC (D 2866 LF25)		Diesel		11967	301	409	05.01-	■	
26.414 FNLC, FNLLC, FNLLRC, FNLLW, FNLR, FNLLRC, FVLC (D 2866 LF25)		Diesel		11967	301	409	05.01-	■	
26.414 FNLC, FNLLC, FNLLRC, FNLLW, FNLR, FNLLRC, FVLC		Diesel		11967	301	409	05.01-	■	■
27.414 DFAC (D 2866 LF25)		Diesel		11967	301	409	05.01-	■	■

LISTA DE APLICACIONES - BUYERS GUIDE

27.414 DFC		Diesel		11967	301	409	05.01-	■	
27.414 FVL (D 2866 LF25)		Diesel		11967	301	409	06.98-	■	
28.414		Diesel		11967	301	409	07.94-03.01	■	
32.414 VF, VFC (D 2866 LF25)		Diesel		11967	301	409	05.01-	■	■
33.414 DFAC		Diesel		11967	301	409	05.01-	■	■
33.414 DFC		Diesel		11967	301	409	05.01-	■	
35.414 VF, VFC, VFRC (D 2866 LF25)		Diesel		11967	301	409	05.01-	■	■
37.414		Diesel		11967	301	409	04.95-03.03	■	
38.414		Diesel		11967	301	409	08.94-02.05	■	
41.414 VF, VFC, VFRC		Diesel		11967	301	409	05.01-	■	■
18.423		Diesel		11967	309	420	06.94-08.99	■	
19.423FAC (D 2866 LF22)		Diesel		11967	309	420	01.94-12.95	■	
19.423 FC, FLC, FLLC, F-NL (D 2866 LF22)		Diesel		11967	309	420	01.94-	■	
22.423		Diesel		11967	309	420	07.94-02.05	■	
24.423		Diesel		11967	309	420	06.94-02.05	■	
24.423		Diesel		11967	309	420	06.94-02.05	■	
24.423 FNLLC (D 2866 LF22)		Diesel		11967	309	420	01.94-12.95	■	
26.423 DFC,26.423 DFLC (D 2866 LF22)		Diesel		11967	309	420	01.94-12.95	■	
26.423 FNLC,26.423 FNLLC,26.423 FVLC (D 2866 LF22)		Diesel		11967	309	420	01.94-12.95	■	
26.423 FNLC,26.423 FNLLC,26.423 FVLC		Diesel		11967	309	420	01.94-12.95	■	■
27.423DFAC (D 2866 LF22)		Diesel		11967	309	420	01.94-	■	
27.423 DFC (D 2866 LF22)		Diesel		11967	309	420	01.94-	■	
32.423		Diesel		11967	309	420	03.97-08.01	■	
33.423 DFAC (D 2866 LF22)		Diesel		11967	309	420	01.94-	■	
33.423 DFC (D 2866 LF22)		Diesel		11967	309	420	01.94-	■	
35.423 VF, VFC, VFRC		Diesel		11967	309	420	05.01-	■	■
38.423		Diesel		11967	309	420	08.94-02.05	■	
41.423 VF, VFC, VFRC		Diesel		11967	309	420	05.01-	■	■
18.414		Diesel		12816	301	409	06.94-05.02	■	
19.414		Diesel		12816	301	409	06.94-01.03	■	
22.414		Diesel		12816	301	409	07.94-02.05	■	
23.414		Diesel		12816	301	409	06.94-02.04	■	
23.414		Diesel		12816	301	409	06.94-02.04	■	
24.414		Diesel		12816	301	409	06.94-02.05	■	
24.414		Diesel		12816	301	409	06.94-02.05	■	
26.414		Diesel		12816	301	409	06.94-02.05	■	
26.414		Diesel		12816	301	409	06.94-02.05	■	
26.414		Diesel		12816	301	409	07.94-02.04	■	
27.414		Diesel		12816	301	409	08.94-02.05	■	
27.414		Diesel		12816	301	409	07.94-03.01	■	
28.414		Diesel		12816	301	409	07.94-03.01	■	
32.414		Diesel		12816	301	409	04.95-03.03	■	
33.414		Diesel		12816	301	409	08.94-02.05	■	
35.414		Diesel		12816	301	409	04.95-02.05	■	
37.414		Diesel		12816	301	409	04.95-03.03	■	
38.414		Diesel		12816	301	409	08.94-02.05	■	
41.414		Diesel		12816	301	409	05.95-02.05	■	
18.463		Diesel		12816	338	460	06.94-08.99	■	
18.464		Diesel		12816	338	460	06.94-05.02	■	
19.463FAC (D 2876 LF 02)		Diesel		12816	338	460	01.94-	■	
19.463 FC, FLC, FLLC, FRC, FLRC, F-NL (D 2876 LF 02)		Diesel		12816	338	460	01.94-	■	

LISTA DE APLICACIONES - BUYERS GUIDE

19.464 FAC (D 2876 LF 06)		Diesel		12816	338	460	06.98-	■	■
19.464 FC, FLC, FLLC, FLL, FRC, FLLR, FLLRC, FLLW, F-NL (D 2876 LF 06)		Diesel		12816	338	460	06.98-	■	
22.463		Diesel		12816	338	460	07.94-02.05	■	
22.464		Diesel		12816	338	460	07.94-02.05	■	
23.463		Diesel		12816	338	460	06.94-02.04	■	
23.463 FNLLC (D 2876 LF 02)		Diesel		12816	338	460	01.94-	■	
23.464 FNLLC		Diesel		12816	338	460	05.01-	■	
23.464 FNLLC		Diesel		12816	338	460	05.01-	■	
24.463 FNLLC (D 2876 LF 02)		Diesel		12816	338	460	01.94-	■	
24.463 FNLLC		Diesel		12816	338	460	06.94-02.05	■	
24.464		Diesel		12816	338	460	06.94-02.05	■	
24.464 FNLLRC		Diesel		12816	338	460	05.01-	■	■
26.463 DFC, DFCL (D 2876 LF 02)		Diesel		12816	338	460	01.94-	■	
26.463 FNLC, FNLLC, FNLLRC, FNLLW, FNLRC, FNLLRC, FVLC (D 2876 LF 02)		Diesel		12816	338	460	01.94-	■	
26.463 FNLC, FNLLC, FNLLRC, FNLLW, FNLRC, FNLLRC, FVLC		Diesel		12816	338	460	01.94-	■	■
26.464 DFC, DFCL (D 2876 LF 03)		Diesel		12816	338	460	05.01-	■	
26.464 FNLC, FNLLC, FNLLRC, FNLLW, FNLRC, FNLLRC, FVLC (D 2876 LF 03)		Diesel		12816	338	460	05.01-	■	
26.464 FNLC, FNLLC, FNLLRC, FNLLW, FNLRC, FNLLRC, FVLC		Diesel		12816	338	460	05.01-	■	■
27.463DFAC (D 2876 LF 02)		Diesel		12816	338	460	01.94-	■	
27.463 DFC (D 2876 LF 02)		Diesel		12816	338	460	01.94-	■	
27.464 DFAC (D 2876 LF 03)		Diesel		12816	338	460	05.01-	■	■
27.464 DFC (D 2876 LF 06)		Diesel		12816	338	460	01.94-	■	
27.464 FVL (D 2876 LF 03)		Diesel		12816	338	460	06.98-	■	
28.464		Diesel		12816	338	460	07.94-03.01	■	
32.463VFC (D 2876 LF 02)		Diesel		12816	338	460	08.95-	■	
32.464 VF, VFC (D 2876 LF 03)		Diesel		12816	338	460	05.01-	■	■
33.463 DFAC (D 2876 LF 02)		Diesel		12816	338	460	01.94-	■	
33.463 DFC (D 2876 LF 02)		Diesel		12816	338	460	01.94-	■	
33.464 DFAC		Diesel		12816	338	460	05.01-	■	■
33.464 DFC		Diesel		12816	338	460	05.01-	■	
35.463 VF, VFC, VFRC (D 2876 LF 02)		Diesel		12816	338	460	08.95-	■	
35.464 VF, VFC, VFRC (D 2876 LF 03)		Diesel		12816	338	460	05.01-	■	■
37.464		Diesel		12816	338	460	04.95-03.03	■	
38.463		Diesel		12816	338	460	08.94-02.05	■	
38.464		Diesel		12816	338	460	08.94-02.05	■	
41.463 VF, VFC, VFRC (D 2876 LF 02)		Diesel		12816	338	460	08.95-	■	
41.464 VF, VFC, VFRC (D 2876 LF 06)		Diesel		12816	338	460	06.98-	■	■
26.603 DFC, DFCL (D 2840 LF20)		Diesel		18273	441	600	06.96-	■	
33.603 DFC (D 2840 LF20)		Diesel		18273	441	600	06.96-	■	
F2000 01.94-								Platform/Chassis	
19.233 FC CNG (E 2866 DF 01)		Gasolina		11967	170	231	03.00-	■	
26.233 FVLC CNG (E 2866 DF 01)		Gasolina		11967	170	231	09.96-	■	
F2000 01.94-								Truck Tractor	
18.273		Diesel		9973	198	269	06.94-01.00	■	
19.273 FS,19.273 FLS (D 2865 LF22)		Diesel		9973	198	269	01.94-12.95	■	
22.273		Diesel		9973	198	269	07.94-01.00	■	
26.273 DFS,26.273 DFSL (D 2865 LF22)		Diesel		9973	198	269	01.94-12.95	■	
26.273 FNLS,26.273 FVLS (D 2865 LF22)		Diesel		9973	198	269	01.94-12.95	■	

LISTA DE APLICACIONES - BUYERS GUIDE

26.273 FNLS,26.273 FVLS	Diesel	9973	198	269	01.94-12.95	■	■
27.273	Diesel	9973	198	269	07.94-01.00	■	
27.273DFAS (D 2865 LF22)	Diesel	9973	198	269	01.94-12.95	■	
27.273 DFS (D 2865 LF22)	Diesel	9973	198	269	01.94-12.95	■	
28.273	Diesel	9973	198	269	07.94-01.00	■	
33.273	Diesel	9973	198	269	08.94-01.00	■	
18.293	Diesel	9973	213	290	06.94-01.00	■	
19.293FAS (D 2865 LF20)	Diesel	9973	213	290	01.94-	■	
19.293FAS (D 2865 LF24)	Diesel	9973	213	290	01.94-	■	
19.293 FS,19.293 FLS,19.293 FLLS (D 2865 LF20)	Diesel	9973	213	290	01.94-	■	
19.293 FS,19.293 FLS,19.293 FLLS (D 2865 LF24)	Diesel	9973	213	290	01.94-	■	
22.293	Diesel	9973	213	290	07.94-01.00	■	
26.293 DFS,26.293 DFLS (D 2865 LF20)	Diesel	9973	213	290	01.94-	■	
26.293 DFS,26.293 DFLS (D 2865 LF24)	Diesel	9973	213	290	01.94-	■	
26.293 FNLS,26.293 FVLS (D 2865 LF20)	Diesel	9973	213	290	01.94-	■	
26.293 FNLS,26.293 FVLS (D 2865 LF24)	Diesel	9973	213	290	01.94-	■	
26.293 FNLS,26.293 FVLS	Diesel	9973	213	290	01.94-	■	■
27.293	Diesel	9973	213	290	07.94-01.00	■	
27.293DFAS (D 2865 LF20)	Diesel	9973	213	290	01.94-	■	
27.293DFAS (D 2865 LF24)	Diesel	9973	213	290	01.94-	■	
27.293 DFS (D 2865 LF20)	Diesel	9973	213	290	01.94-	■	
27.293 DFS (D 2865 LF24)	Diesel	9973	213	290	01.94-	■	
28.293	Diesel	9973	213	290	07.94-01.00	■	
33.293	Diesel	9973	213	290	08.94-01.00	■	
18.323	Diesel	9973	235	320	06.94-01.00	■	
19.323FAS (D 2865 LF23)	Diesel	9973	235	320	01.94-12.95	■	
19.323 FS,19.323 FLS,19.323 FLLS (D 2865 LF23)	Diesel	9973	235	320	01.94-12.95	■	
22.323	Diesel	9973	235	320	07.94-01.00	■	
26.323 DFS,26.323 DFLS (D 2865 LF23)	Diesel	9973	235	320	01.94-12.95	■	
26.323 FNLS,26.323 FVLS (D 2865 LF23)	Diesel	9973	235	320	01.94-12.95	■	
26.323 FNLS,26.323 FVLS	Diesel	9973	235	320	01.94-12.95	■	■
27.323	Diesel	9973	235	320	07.94-01.00	■	
27.323DFAS (D 2865 LF23)	Diesel	9973	235	320	01.94-12.95	■	
27.323 DFS (D 2865 LF23)	Diesel	9973	235	320	01.94-12.95	■	
28.323	Diesel	9973	235	320	07.94-01.00	■	
33.323 DFAS (D 2865 LF23)	Diesel	9973	235	320	01.94-12.95	■	
33.323 DFS (D 2865 LF23)	Diesel	9973	235	320	01.94-12.95	■	
18.343	Diesel	9973	250	340	06.94-01.00	■	
19.343FAS (D 2865 LF21)	Diesel	9973	250	340	01.94-	■	
19.343 FS,19.343 FLS,19.343 FLLS (D 2865 LF21)	Diesel	9973	250	340	01.94-	■	
19.344	Diesel	9973	250	340	06.94-01.00	■	
22.343	Diesel	9973	250	340	07.94-01.00	■	
26.343 DFS,26.343 DFLS (D 2865 LF21)	Diesel	9973	250	340	01.94-	■	
26.343 FNLS,26.343 FVLS (D 2865 LF21)	Diesel	9973	250	340	01.94-	■	
26.343 FNLS,26.343 FVLS	Diesel	9973	250	340	01.94-	■	■
27.343	Diesel	9973	250	340	07.94-01.00	■	
27.343DFAS (D 2865 LF21)	Diesel	9973	250	340	01.94-	■	
27.343 DFS (D 2865 LF21)	Diesel	9973	250	340	01.94-	■	
28.343	Diesel	9973	250	340	07.94-01.00	■	
33.343 DFAS (D 2865 LF21)	Diesel	9973	250	340	01.94-	■	

LISTA DE APLICACIONES - BUYERS GUIDE

33.343 DFS (D 2865 LF21)	Diesel	9973	250	340	01.94-	■
18.314	Diesel	11967	228	310	06.94-05.02	■
19.314FAS (D 2866 LF34)	Diesel	11967	228	310	06.98-	■
19.314 FS, FLS, FLLS, FRS, FLRS, FLLRS (D 2866 LF34)	Diesel	11967	228	310	06.98-	■
22.314	Diesel	11967	228	310	07.94-02.05	■
24.314	Diesel	11967	228	310	06.94-02.05	■
24.314	Diesel	11967	228	310	06.94-02.05	■
26.314 DFS, DFLS (D 2866 LF23)	Diesel	11967	228	310	05.01-	■
26.314 FNLS (D 2866 LF23)	Diesel	11967	228	310	05.01-	■
26.314 FVLS, FVLRS (D 2866 LF23)	Diesel	11967	228	310	05.01-	■
27.314 DFAS	Diesel	11967	228	310	05.01-	■ ■
27.314 DFS	Diesel	11967	228	310	05.01-	■
28.314	Diesel	11967	228	310	07.94-03.01	■
18.364	Diesel	11967	265	360	06.94-05.02	■
19.364FAS (D 2866 LF35)	Diesel	11967	265	360	06.98-	■
19.364 FS, FLS, FLLS, FRS, FLRS, FLLRS (D 2866 LF35)	Diesel	11967	265	360	06.98-	■
22.364	Diesel	11967	265	360	07.94-02.05	■
24.364	Diesel	11967	265	360	06.94-02.05	■
24.364	Diesel	11967	265	360	06.94-02.05	■
26.364 DFS, DFLS (D 2866 LF24)	Diesel	11967	265	360	05.01-	■
26.364 FNLS (D 2866 LF24)	Diesel	11967	265	360	05.01-	■
26.364 FVLS, FVLRS (D 2866 LF24)	Diesel	11967	265	360	05.01-	■
27.364 DFAS	Diesel	11967	265	360	05.01-	■ ■
27.364 DFS	Diesel	11967	265	360	05.01-	■
28.364	Diesel	11967	265	360	07.94-03.01	■
33.364 DFAS	Diesel	11967	265	360	05.01-	■ ■
33.364 DFS, DFRS	Diesel	11967	265	360	05.01-	■
38.364	Diesel	11967	265	360	08.94-02.05	■
18.373	Diesel	11967	272	370	06.94-08.99	■
19.373FAS (D 2866 LF21)	Diesel	11967	272	370	01.94-	■
19.373 FS, FLS, FLLS, FRS, FLRS, FLLRS (D 2866 LF21)	Diesel	11967	272	370	01.94-	■
22.373	Diesel	11967	272	370	07.94-02.05	■
24.373	Diesel	11967	272	370	06.94-02.05	■
24.373	Diesel	11967	272	370	06.94-02.05	■
26.373 DFS,26.373 DFLS (D 2866 LF21)	Diesel	11967	272	370	01.94-12.95	■
26.373 FNLS,26.373 FVLS (D 2866 LF21)	Diesel	11967	272	370	01.94-12.95	■
26.373 FNLS,26.373 FVLS	Diesel	11967	272	370	01.94-12.95	■ ■
27.373DFAS (D 2866 LF21)	Diesel	11967	272	370	01.94-	■
27.373 DFS (D 2866 LF21)	Diesel	11967	272	370	01.94-	■
33.373 DFAS (D 2866 LF21)	Diesel	11967	272	370	01.94-	■
33.373 DFS, DFRS (D 2866 LF21)	Diesel	11967	272	370	01.94-	■
18.403	Diesel	11967	294	400	06.94-08.99	■
19.403FAS (D 2866 LF20)	Diesel	11967	294	400	01.94-	■
19.403 FS, FLS, FLLS, FRS, FLRS, FLLRS (D 2866 LF20)	Diesel	11967	294	400	01.94-	■
22.403	Diesel	11967	294	400	07.94-02.05	■
24.403 FNLLS	Diesel	11967	294	400	06.94-02.05	■
24.403 FNLLS	Diesel	11967	294	400	06.94-02.05	■
26.403 DFS,26.403 DFLS (D 2866 LF20)	Diesel	11967	294	400	01.94-	■
26.403 FNLS,26.403 FVLS (D 2866 LF20)	Diesel	11967	294	400	01.94-	■
26.403 FNLS,26.403 FVLS	Diesel	11967	294	400	01.94-	■ ■

LISTA DE APLICACIONES - BUYERS GUIDE

27.403DFAS (D 2866 LF20)	Diesel	11967	294	400	01.94-	■
27.403 DFS (D 2866 LF20)	Diesel	11967	294	400	01.94-	■
33.403 DFAS (D 2866 LF20)	Diesel	11967	294	400	01.94-	■
33.403 DFS, DFRS (D 2866 LF20)	Diesel	11967	294	400	01.94-	■
40.403 DFAS (D 2866 LF20)	Diesel	11967	294	400	01.94-	■
40.403 DFS (D 2866 LF20)	Diesel	11967	294	400	01.94-	■
18.414	Diesel	11967	301	409	06.94-05.02	■
19.414FAS (D 2866 LF31)	Diesel	11967	301	409	06.98-	■
19.414 FS, FLS, FLLS, FRS, FLRS, FLLRS (D 2866 LF31)	Diesel	11967	301	409	06.98-	■
22.414	Diesel	11967	301	409	07.94-02.05	■
24.414	Diesel	11967	301	409	06.94-02.05	■
24.414	Diesel	11967	301	409	06.94-02.05	■
26.414 DFS, DFLS (D 2866 LF25)	Diesel	11967	301	409	05.01-	■
26.414 FNLS (D 2866 LF25)	Diesel	11967	301	409	05.01-	■
26.414 FVLS, FVLRS (D 2866 LF25)	Diesel	11967	301	409	05.01-	■
27.414 DFAS	Diesel	11967	301	409	05.01-	■ ■
27.414 DFS	Diesel	11967	301	409	05.01-	■
28.414	Diesel	11967	301	409	07.94-03.01	■
33.414 DFAS	Diesel	11967	301	409	05.01-	■ ■
33.414 DFS, DFRS	Diesel	11967	301	409	05.01-	■
38.414	Diesel	11967	301	409	08.94-02.05	■
18.423	Diesel	11967	309	420	06.94-08.99	■
19.423FAS (D 2866 LF22)	Diesel	11967	309	420	01.94-12.95	■
19.423 FS, FLS, FLLS (D 2866 LF22)	Diesel	11967	309	420	01.94-	■
22.423	Diesel	11967	309	420	07.94-02.05	■
24.423	Diesel	11967	309	420	06.94-02.05	■
24.423	Diesel	11967	309	420	06.94-02.05	■
26.423 DFS,26.423 DFLS (D 2866 LF22)	Diesel	11967	309	420	01.94-12.95	■
26.423 FNLS,26.423 FVLS (D 2866 LF22)	Diesel	11967	309	420	01.94-12.95	■
26.423 FNLS,26.423 FVLS	Diesel	11967	309	420	01.94-12.95	■ ■
27.423DFAS (D 2866 LF22)	Diesel	11967	309	420	01.94-12.95	■
27.423 DFS (D 2866 LF22)	Diesel	11967	309	420	01.94-	■
33.423 DFAS (D 2866 LF22)	Diesel	11967	309	420	01.94-	■
33.423 DFS, DFRS (D 2866 LF22)	Diesel	11967	309	420	01.94-	■
38.423	Diesel	11967	309	420	08.94-02.05	■
18.414	Diesel	12816	301	409	06.94-05.02	■
19.414	Diesel	12816	301	409	06.94-08.05	■
22.414	Diesel	12816	301	409	07.94-02.05	■
24.414	Diesel	12816	301	409	06.94-02.05	■
24.414	Diesel	12816	301	409	06.94-02.05	■
26.414	Diesel	12816	301	409	06.94-02.05	■
26.414	Diesel	12816	301	409	06.94-02.05	■
26.414	Diesel	12816	301	409	07.94-02.04	■
27.414	Diesel	12816	301	409	08.94-02.05	■
27.414	Diesel	12816	301	409	07.94-03.01	■
28.414	Diesel	12816	301	409	07.94-03.01	■
33.414	Diesel	12816	301	409	08.94-02.05	■
38.414	Diesel	12816	301	409	08.94-02.05	■
18.463	Diesel	12816	338	460	06.94-08.99	■
18.464	Diesel	12816	338	460	06.94-05.02	■
19.463FAS (D 2876 LF 02)	Diesel	12816	338	460	01.94-	■

LISTA DE APLICACIONES - BUYERS GUIDE

19.463 FS, FLS, FLLS, FRS, FLRS, FLLRS (D 2876 LF 02)	Diesel		12816	338	460	01.94-	■
19.464FAS (D 2876 LF 06)	Diesel		12816	338	460	06.98-	■
19.464 FS, FLS, FLLS, FRS, FLRS, FLLRS (D 2876 LF 06)	Diesel		12816	338	460	06.98-	■
22.463	Diesel		12816	338	460	07.94-02.05	■
22.464	Diesel		12816	338	460	07.94-02.05	■
24.463 FNLLS	Diesel		12816	338	460	06.94-02.05	■
24.463 FNLLS	Diesel		12816	338	460	06.94-02.05	■
24.464	Diesel		12816	338	460	06.94-02.05	■
24.464	Diesel		12816	338	460	06.94-02.05	■
26.463 DFS, DFLS (D 2876 LF 02)	Diesel		12816	338	460	01.94-	■
26.463 FNLS, FVLS, FVLRS (D 2876 LF 02)	Diesel		12816	338	460	01.94-	■
26.463 FNLS, FVLS, FVLRS	Diesel		12816	338	460	01.94-	■ ■
26.464 DFS, DFLS (D 2876 LF 03)	Diesel		12816	338	460	05.01-	■ ■
26.464 FNLS (D 2876 LF 03)	Diesel		12816	338	460	05.01-	■
26.464 FVLS, FVLRS (D 2876 LF 03)	Diesel		12816	338	460	05.01-	■
27.463DFAS (D 2876 LF 02)	Diesel		12816	338	460	01.94-	■
27.463 DFS (D 2876 LF 02)	Diesel		12816	338	460	01.94-	■
27.464 DFAS	Diesel		12816	338	460	05.01-	■ ■
27.464 DFS (D 2876 LF 06)	Diesel		12816	338	460	01.94-	■
28.464	Diesel		12816	338	460	07.94-03.01	■
33.463 DFAS (D 2876 LF 02)	Diesel		12816	338	460	01.94-	■
33.463 DFS, DFRS (D 2876 LF 02)	Diesel		12816	338	460	01.94-	■
33.464 DFAS	Diesel		12816	338	460	05.01-	■ ■
33.464 DFS, DFRS	Diesel		12816	338	460	05.01-	■
38.463	Diesel		12816	338	460	08.94-02.05	■
38.464	Diesel		12816	338	460	08.94-02.05	■
40.463 DFAS (D 2876 LF 02)	Diesel		12816	338	460	01.94-	■ ■
40.463 DFS (D 2876 LF 02)	Diesel		12816	338	460	01.94-	■
19.603 FLS, 19604 FLS (D 2840 LF20)	Diesel		18273	441	600	04.96-	■
26.603 DFS, DFLS (D 2840 LF20)	Diesel		18273	441	600	06.96-	■
26.604 DFLS	Diesel		18273	441	600	04.00-	■
27.603 DFAS (D 2840 LF20)	Diesel		18273	441	600	01.96-	■
27.603 DFS (D 2840 LF20)	Diesel		18273	441	600	01.96-	■
27.604 DFS	Diesel		18273	441	600	04.00-	■
28.603	Diesel		18273	441	600	03.96-08.01	■
33.603 DFAS (D 2840 LF20)	Diesel		18273	441	600	06.96-	■
33.603 DFS, DFRS (D 2840 LF20)	Diesel		18273	441	600	06.96-	■
33.604 DFAS	Diesel		18273	441	600	04.00-	■ ■
33.604 DFS	Diesel		18273	441	600	04.00-	■
F2000 01.94-							Truck Tractor
19.233 CNG	Gasolina		11967	170	231	06.94-02.05	■
26.233 CNG	Gasolina		11967	170	231	07.94-02.05	■
F90 06.86-12.97							Concrete Mixer
32.262VFTM (D 2865 LF/260)	Diesel		9973	191	260	02.89-02.90	■
F90 06.86-12.97							
27.502 DF/DFS	Diesel		18195	368	500	06.86-	■
27.502 DF/DFS	Diesel		18195	368	500	06.86-	■
48.502VF	Diesel		18195	368	500	06.86-	■
48.502VF	Diesel		18195	368	500	06.86-	■

LISTA DE APLICACIONES - BUYERS GUIDE

F90 06.86-12.97					Dump Truck			
19.262FAK (D 2865 LF/260)	Diesel		9973	191	260	02.89-02.90	■	
19.262FK (D 2865 LF/260)	Diesel		9973	191	260	01.88-02.90	■	
24.262DFK (D 2865 LF/260)	Diesel		9973	191	260	01.88-02.90	■	
26.262DFAK (D 2865 LF/260)	Diesel		9973	191	260	02.89-02.90	■	
26.262DFK (D 2865 LF/260)	Diesel		9973	191	260	01.88-02.90	■	
32.262VFK (D 2865 LF/260)	Diesel		9973	191	260	02.89-02.90	■	
33.262DFAK (D 2865 LF/260)	Diesel		9973	191	260	07.89-02.90	■	
33.262DFK (D 2865 LF/260)	Diesel		9973	191	260	08.88-02.90	■	
35.262VFK (D 2865 LF/260)	Diesel		9973	191	260	02.89-02.90	■	
41.262VFK (D 2865 LF/260)	Diesel		9973	191	260	07.89-02.90	■	
19.272FAK (D 2865 LF02)	Diesel		9973	198	269	02.90-05.95	■	
19.272FAK (D 2865 LF05)	Diesel		9973	198	269	02.90-05.95	■	
19.272FK (D 2865 LF02)	Diesel		9973	198	269	02.90-05.95	■	
19.272FK (D 2865 LF05)	Diesel		9973	198	269	02.90-05.95	■	
24.272DFK (D 2865 LF02)	Diesel		9973	198	269	02.90-12.90	■	
25.272DFK (D 2865 LF02)	Diesel		9973	198	269	09.90-12.92	■	
25.272DFK (D 2865 LF05)	Diesel		9973	198	269	09.90-12.92	■	
26.272DFAK (D 2865 LF02)	Diesel		9973	198	269	02.90-12.92	■	
26.272DFAK (D 2865 LF05)	Diesel		9973	198	269	02.90-12.92	■	
26.272DFK (D 2865 LF02)	Diesel		9973	198	269	02.90-06.96	■	
26.272DFK (D 2865 LF05)	Diesel		9973	198	269	02.90-06.96	■	
32.272VFK (D 2865 LF02)	Diesel		9973	198	269	02.90-04.95	■	
32.272VFK (D 2865 LF05)	Diesel		9973	198	269	02.90-04.95	■	
35.272VFK (D 2865 LF02)	Diesel		9973	198	269	02.90-12.92	■	
19.322FAK (D 2865 LF03)	Diesel		9973	235	320	02.90-06.96	■	
19.322FAK (D 2865 LF06)	Diesel		9973	235	320	02.90-06.96	■	
19.322FK (D 2865 LF03)	Diesel		9973	235	320	02.90-05.95	■	
19.322FK (D 2865 LF06)	Diesel		9973	235	320	02.90-05.95	■	
24.322DFK (D 2865 LF03)	Diesel		9973	235	320	02.90-12.90	■	
25.322DFK (D 2865 LF03)	Diesel		9973	235	320	09.90-12.92	■	
25.322DFK (D 2865 LF06)	Diesel		9973	235	320	09.90-12.92	■	
26.322 DFAK (D 2865 LF03)	Diesel		9973	235	320	02.90-12.92	■	
26.322 DFAK (D 2865 LF06)	Diesel		9973	235	320	02.90-12.92	■	
26.322DFK (D 2865 LF03)	Diesel		9973	235	320	02.92-06.96	■	
26.322DFK (D 2865 LF06)	Diesel		9973	235	320	02.92-06.96	■	
32.322VFK (D 2865 LF03)	Diesel		9973	235	320	02.90-06.96	■	
32.322VFK (D 2865 LF06)	Diesel		9973	235	320	02.90-06.96	■	
35.322VFAK (D 2865 LF03)	Diesel		9973	235	320	02.90-06.96	■	
35.322VFAK (D 2865 LF06)	Diesel		9973	235	320	02.90-06.96	■	
35.322VFK (D 2865 LF03)	Diesel		9973	235	320	02.90-06.96	■	
35.322VFK (D 2865 LF06)	Diesel		9973	235	320	02.90-06.96	■	
35.322VFK (D 2865 LF03)	Diesel		9973	235	320	02.90-06.96	■	
35.322VFK (D 2865 LF06)	Diesel		9973	235	320	02.90-06.96	■	
19.342FAK (D 2865 LF09)	Diesel		9973	250	340	05.94-06.96	■	
19.342FK (D 2865 LF09)	Diesel		9973	250	340	05.94-05.95	■	
26.342 DFK,26.342 DFLK (D 2865 LF09)	Diesel		9973	250	340	05.94-06.96	■	
32.342VFK (D 2865 LF09)	Diesel		9973	250	340	05.94-06.96	■	
35.342VFK (D 2865 LF09)	Diesel		9973	250	340	05.94-06.96	■	
19.242FK (D 2866 F/240)	Diesel		11967	177	241	01.88-02.89	■	
24.242DFK (D 2866 F/240)	Diesel		11967	177	241	01.88-07.89	■	

LISTA DE APLICACIONES - BUYERS GUIDE

26.242DFAK (D 2866 F/240)		Diesel		11967	177	241	01.90-01.90	■
26.242DFK (D 2866 F/240)		Diesel		11967	177	241	02.90-06.97	■
33.242DFAK (D 2866 F/240)		Diesel		11967	177	241	01.88-08.88	■
33.242DFK (D 2866 F/240)		Diesel		11967	177	241	01.88-08.88	■
19.292FAK (D 2866 LF/290)		Diesel		11967	213	290	05.88-02.90	■
19.292FK (D 2866 LF/290)		Diesel		11967	213	290	07.86-02.90	■
24.292DFK (D 2866 LF/290)		Diesel		11967	213	290	04.87-02.90	■
26.292DFAK (D 2866 LF/290)		Diesel		11967	213	290	05.88-02.90	■
26.292DFK (D 2866 LF/290)		Diesel		11967	213	290	09.87-02.90	■
32.292VFK (D 2866 LF/290)		Diesel		11967	213	290	03.88-02.90	■
33.292DFAK (D 2866 LF/290)		Diesel		11967	213	290	05.88-02.90	■
33.292DFK (D 2866 LF/290)		Diesel		11967	213	290	09.87-02.90	■
35.292VFK (D 2866 LFZ/290)		Diesel		11967	213	290	10.88-04.95	■
41.292VFK (D 2866 LF/290)		Diesel		11967	213	290	10.88-02.90	■
24.302DFK (D 2866 LF04)		Diesel		11967	221	299	05.90-12.90	■
25.302DFK (D 2866 LF04)		Diesel		11967	221	299	09.90-12.91	■
26.302DFAK (D 2866 LF04)		Diesel		11967	221	299	05.90-12.91	■
26.302DFK (D 2866 LF04)		Diesel		11967	221	299	05.90-12.91	■
32.302VFK (D 2866 LF04)		Diesel		11967	221	299	05.90-09.91	■
35.302VFK (D 2866 LF04)		Diesel		11967	221	299	05.90-09.91	■
19.332FAK (D 2866 LF/330)		Diesel		11967	243	330	05.88-02.90	■
19.332FK (D 2866 LF/330)		Diesel		11967	243	330	07.86-02.90	■
24.332DFK (D 2866 LF/330)		Diesel		11967	243	330	04.87-02.90	■
26.332DFAK (D 2866 LF/330)		Diesel		11967	243	330	05.88-02.90	■
26.332 DFK (D 2866 LF/330)		Diesel		11967	243	330	09.87-02.90	■
32.332VFK (D 2866 LF/330)		Diesel		11967	243	330	03.88-02.90	■
33.332DFAK (D 2866 LF/330)		Diesel		11967	243	330	05.88-02.90	■
33.332DFK (D 2866 LF/330)		Diesel		11967	243	330	09.87-02.90	■
35.332VFK (D 2866 LFZ/330)		Diesel		11967	243	330	10.88-04.95	■
41.332VFK (D 2866 LF/330)		Diesel		11967	243	330	10.88-02.90	■
19.372FK (D 2866 LXF)		Diesel		11967	249	339	05.90-04.95	■
24.372DFK (D 2866 LXF)		Diesel		11967	249	339	05.90-12.90	■
25.372DFK (D 2866 LXF)		Diesel		11967	249	339	09.90-12.92	■
32.372VFK (D 2866 LXF)		Diesel		11967	249	339	05.90-04.95	■
35.372VFK (D 2866 LXF)		Diesel		11967	249	339	02.90-04.95	■
19.362FAK (D 2866 LXF)		Diesel		11967	265	360	05.88-02.90	■
19.362FK (D 2866 KF)		Diesel		11967	265	360	07.86-02.90	■
19.362FK (D 2866 LXF)		Diesel		11967	265	360	07.86-02.90	■
24.362DFK (D 2866 KF)		Diesel		11967	265	360	04.87-02.90	■
24.362DFK (D 2866 LXF)		Diesel		11967	265	360	04.87-02.90	■
26.362DFAK (D 2866 LXF)		Diesel		11967	265	360	05.88-02.90	■
26.362DFK (D 2866 KF)		Diesel		11967	265	360	09.87-02.90	■
26.362DFK (D 2866 LXF)		Diesel		11967	265	360	09.87-02.90	■
32.362VFK (D 2866 LXF)		Diesel		11967	265	360	03.88-02.90	■
33.362DFAK (D 2866 LXF)		Diesel		11967	265	360	05.88-02.90	■
33.362DFK (D 2866 KF)		Diesel		11967	265	360	09.87-02.90	■
33.362DFK (D 2866 LXF)		Diesel		11967	265	360	09.87-02.90	■
35.362VFK (D 2866 LXF)		Diesel		11967	265	360	10.88-02.90	■
41.362VFK (D 2866 LXF)		Diesel		11967	265	360	10.88-02.90	■
48.362VFAK (D 2866 LXF)		Diesel		11967	265	360	07.89-02.90	■
19.372FAK (D 2866 LF03)		Diesel		11967	272	370	02.90-06.96	■

LISTA DE APLICACIONES - BUYERS GUIDE

19.372FAK (D 2866 LF05)		Diesel		11967	272	370	02.90-06.96	■
19.372FAK (D 2866 LF15)		Diesel		11967	272	370	02.90-06.96	■
19.372FK (D 2866 LF03)		Diesel		11967	272	370	02.90-05.95	■
19.372FK (D 2866 LF05)		Diesel		11967	272	370	02.90-05.95	■
19.372FK (D 2866 LF15)		Diesel		11967	272	370	02.90-05.95	■
24.372DFK (D 2866 LF03)		Diesel		11967	272	370	02.90-12.90	■
24.372 DFS, 24.372 DFLS (D 2866 LF03)		Diesel		11967	272	370	02.90-04.95	■
25.372DFK (D 2866 LF03)		Diesel		11967	272	370	09.90-12.92	■
25.372DFK (D 2866 LF05)		Diesel		11967	272	370	09.90-12.92	■
26.372DFAK (D 2866 LF03)		Diesel		11967	272	370	01.92-06.96	■
26.372DFAK (D 2866 LF05)		Diesel		11967	272	370	01.92-06.96	■
26.372DFK (D 2866 LF03)		Diesel		11967	272	370	01.92-06.96	■
26.372DFK (D 2866 LF05)		Diesel		11967	272	370	01.92-06.96	■
26.372DFK (D 2866 LF15)		Diesel		11967	272	370	01.92-06.96	■
32.372VFK (D 2866 LF03)		Diesel		11967	272	370	02.90-06.96	■
32.372VFK (D 2866 LF05)		Diesel		11967	272	370	02.90-06.96	■
32.372VFK (D 2866 LF15)		Diesel		11967	272	370	02.90-06.96	■
33.372DFAK (D 2866 LF03)		Diesel		11967	272	370	01.91-06.96	■
33.372DFAK (D 2866 LF05)		Diesel		11967	272	370	01.91-06.96	■
33.372DFAK (D 2866 LF15)		Diesel		11967	272	370	01.91-06.96	■
33.372DFK (D 2866 LF03)		Diesel		11967	272	370	01.91-06.96	■
33.372DFK (D 2866 LF05)		Diesel		11967	272	370	01.91-06.96	■
33.372DFK (D 2866 LF15)		Diesel		11967	272	370	01.91-06.96	■
35.372VFK (D 2866 LF03)		Diesel		11967	272	370	02.90-06.96	■
35.372VFK (D 2866 LF05)		Diesel		11967	272	370	02.90-06.96	■
35.372VFK (D 2866 LF15)		Diesel		11967	272	370	02.90-06.96	■
35.372VFK (D 2866 LF03)		Diesel		11967	272	370	02.90-12.97	■
35.372VFK (D 2866 LF05)		Diesel		11967	272	370	02.90-12.97	■
35.372VFK (D 2866 LF15)		Diesel		11967	272	370	02.90-12.97	■
19.402FAK (D 2866 LF16)		Diesel		11967	294	400	05.94-06.96	■
19.402FK (D 2866 LF16)		Diesel		11967	294	400	05.94-05.95	■
26.402 DFK,26.402 DFLK (D 2866 LF16)		Diesel		11967	294	400	05.94-06.96	■
32.402VFK (D 2866 LF16)		Diesel		11967	294	400	05.94-06.96	■
33.402DFAK (D 2866 LF16)		Diesel		11967	294	400	05.94-06.96	■
33.402DFK (D 2866 LF16)		Diesel		11967	294	400	05.94-06.96	■
35.402VFK (D 2866 LF16)		Diesel		11967	294	400	05.94-06.96	■
35.402VFK (D 2866 LF16)		Diesel		11967	294	400	05.94-12.97	■
19.422FAK (D 2866 LF06)		Diesel		11967	309	420	02.90-06.96	■
19.422FAK (D 2866 LF09)		Diesel		11967	309	420	02.90-06.96	■
19.422FK (D 2866 LF06)		Diesel		11967	309	420	02.90-05.95	■
19.422FK (D 2866 LF09)		Diesel		11967	309	420	02.90-05.95	■
24.422DFK (D 2866 LF06)		Diesel		11967	309	420	02.90-12.90	■
25.422DFK (D 2866 LF06)		Diesel		11967	309	420	09.90-12.92	■
25.422DFK (D 2866 LF09)		Diesel		11967	309	420	09.90-12.92	■
26.422DFAK (D 2866 LF06)		Diesel		11967	309	420	02.90-12.92	■
26.422DFAK (D 2866 LF09)		Diesel		11967	309	420	02.90-12.92	■
26.422DFK (D 2866 LF06)		Diesel		11967	309	420	02.90-12.95	■
26.422DFK (D 2866 LF09)		Diesel		11967	309	420	02.90-12.95	■
32.422VFK		Diesel		11967	309	420	02.90-06.96	■
33.422DFAK (D 2866 LF06)		Diesel		11967	309	420	01.94-06.96	■
33.422DFAK (D 2866 LF09)		Diesel		11967	309	420	01.94-06.96	■

LISTA DE APLICACIONES - BUYERS GUIDE

33.422DFK (D 2866 LF06)		Diesel		11967	309	420	01.94-06.96	■	
33.422DFK (D 2866 LF09)		Diesel		11967	309	420	01.94-06.96	■	
35.422VFK (D 2866 LF06)		Diesel		11967	309	420	02.90-06.96	■	
35.422VFK (D 2866 LF09)		Diesel		11967	309	420	02.90-06.96	■	
35.422VFK (D 2866 LF06)		Diesel		11967	309	420	02.90-12.97	■	
35.422VFK (D 2866 LF09)		Diesel		11967	309	420	02.90-12.97	■	
19.462FK (D 2840 LF 460)		Diesel		18273	338	460	05.87-02.90	■	
24.502 DFK (D 2840 LF01)		Diesel		18273	368	500	02.90-12.90	■	
F90 06.86-12.97								Platform/Chassis	
15.192 FL (D 2146 HM 1 U)		Diesel		9660	141	192	01.89-12.97	■	■
19.262 F,19.262 FL,19.262 FLL (D 2865 LF/260)		Diesel		9973	191	260	01.88-02.90	■	
19.262FA (D 2865 LF/260)		Diesel		9973	191	260	02.89-02.90	■	
24.262DF (D 2865 LF/260)		Diesel		9973	191	260	01.88-02.90	■	
24.262 FNL,24.262 FNLL,24.262 FVL (D 2865 LF/260)		Diesel		9973	191	260	01.88-02.90	■	
26.262DF (D 2865 LF/260)		Diesel		9973	191	260	01.88-02.90	■	
26.262DFA (D 2865 LF/260)		Diesel		9973	191	260	02.89-02.90	■	
32.262VF (D 2865 LF/260)		Diesel		9973	191	260	02.89-02.90	■	
33.262 DF (D 2865 LF/260)		Diesel		9973	191	260	08.88-02.90	■	
33.262 DFA (D 2865 LF/260)		Diesel		9973	191	260	07.89-02.90	■	
35.262VF (D 2865 LF/260)		Diesel		9973	191	260	02.89-02.90	■	
35.262VFA (D 2865 LF/260)		Diesel		9973	191	260	07.89-02.90	■	
41.262VF (D 2865 LF/260)		Diesel		9973	191	260	07.89-02.90	■	
19.272 F,19.272 FL,19.272 FLL (D 2865 LF02)		Diesel		9973	198	269	02.90-05.95	■	
19.272 F,19.272 FL,19.272 FLL (D 2865 LF05)		Diesel		9973	198	269	02.90-05.95	■	
19.272FA (D 2865 LF02)		Diesel		9973	198	269	02.90-05.95	■	
19.272FA (D 2865 LF05)		Diesel		9973	198	269	02.90-05.95	■	
24.272DF (D 2865 LF02)		Diesel		9973	198	269	02.90-12.90	■	
24.272 FNL,24.272 FNLL,24.272 FVL (D 2865 LF02)		Diesel		9973	198	269	02.90-05.95	■	
24.272 FNL,24.272 FNLL,24.272 FVL (D 2865 LF05)		Diesel		9973	198	269	02.90-05.95	■	
24.272 FNL,24.272 FNLL,24.272 FVL		Diesel		9973	198	269	02.90-05.95	■	■
25.272DF (D 2865 LF02)		Diesel		9973	198	269	09.90-12.92	■	
25.272DF (D 2865 LF05)		Diesel		9973	198	269	09.90-12.92	■	
25.272 FNL,25.272 FNLL,25.272 FVL (D 2865 LF02)		Diesel		9973	198	269	09.90-10.93	■	
25.272 FNL,25.272 FNLL,25.272 FVL (D 2865 LF05)		Diesel		9973	198	269	09.90-10.93	■	
25.272 FNL,25.272 FNLL,25.272 FVL		Diesel		9973	198	269	09.90-10.93	■	■
26.272DF (D 2865 LF02)		Diesel		9973	198	269	02.90-06.96	■	
26.272DF (D 2865 LF05)		Diesel		9973	198	269	02.90-06.96	■	
26.272DFA (D 2865 LF02)		Diesel		9973	198	269	02.90-12.92	■	
26.272DFA (D 2865 LF05)		Diesel		9973	198	269	02.90-12.92	■	
26.272 FNL,26.272 FNLL (D 2865 LF05)		Diesel		9973	198	269	03.91-05.95	■	
32.272VF (D 2865 LF02)		Diesel		9973	198	269	02.90-04.95	■	
32.272VF (D 2865 LF05)		Diesel		9973	198	269	02.90-04.95	■	
33.272 DF (D 2865 LF05)		Diesel		9973	198	269	10.92-04.95	■	
33.272DFA (D 2865 LF05)		Diesel		9973	198	269	10.92-04.95	■	
35.272VF (D 2865 LF02)		Diesel		9973	198	269	02.90-12.91	■	
41.272VF (D 2865 LF02)		Diesel		9973	198	269	02.90-12.91	■	
19.322 F,19.322 FL,19.322 FLL (D 2865 LF03)		Diesel		9973	235	320	02.90-05.95	■	
19.322 F,19.322 FL,19.322 FLL (D 2865 LF06)		Diesel		9973	235	320	02.90-05.95	■	

LISTA DE APLICACIONES - BUYERS GUIDE

19.322FA (D 2865 LF03)	Diesel	9973	235	320	02.90-06.96	■
19.322FA (D 2865 LF06)	Diesel	9973	235	320	02.90-06.96	■
24.322DF (D 2865 LF03)	Diesel	9973	235	320	02.90-12.90	■
24.322 FNL,24.322 FNLL,24.322 FVL (D 2865 LF03)	Diesel	9973	235	320	02.90-05.95	■
24.322 FNL,24.322 FNLL,24.322 FVL (D 2865 LF06)	Diesel	9973	235	320	02.90-05.95	■
24.322 FNL,24.322 FNLL,24.322 FVL	Diesel	9973	235	320	02.90-05.95	■ ■
25.322 DF, 25.322 DFL (D 2865 LF03)	Diesel	9973	235	320	09.90-12.92	■
25.322 DF, 25.322 DFL (D 2865 LF06)	Diesel	9973	235	320	09.90-12.92	■
25.322 FNL, 25.322 FNLL, 25.322 FVL (D 2865 LF03)	Diesel	9973	235	320	09.90-12.92	■
25.322 FNL, 25.322 FNLL, 25.322 FVL (D 2865 LF06)	Diesel	9973	235	320	09.90-12.92	■
26.322DF (D 2865 LF03)	Diesel	9973	235	320	02.90-06.96	■
26.322DF (D 2865 LF06)	Diesel	9973	235	320	02.90-06.96	■
26.322DFA (D 2865 LF03)	Diesel	9973	235	320	02.90-12.92	■
26.322DFA (D 2865 LF06)	Diesel	9973	235	320	02.90-12.92	■
26.322 FNL,26.322 FNLL (D 2865 LF03)	Diesel	9973	235	320	03.91-05.95	■
26.322 FNL,26.322 FNLL (D 2865 LF06)	Diesel	9973	235	320	03.91-05.95	■
32.322VF (D 2865 LF03)	Diesel	9973	235	320	02.90-06.96	■
32.322VF (D 2865 LF06)	Diesel	9973	235	320	02.90-06.96	■
33.322 DF (D 2865 LF03)	Diesel	9973	235	320	09.91-06.96	■
33.322 DF (D 2865 LF06)	Diesel	9973	235	320	09.91-06.96	■
33.322DFA (D 2865 LF03)	Diesel	9973	235	320	09.91-06.96	■
33.322DFA (D 2865 LF06)	Diesel	9973	235	320	09.91-06.96	■
35.322 VK (D 2865 LF03)	Diesel	9973	235	320	02.90-06.96	■
35.322 VK (D 2865 LF06)	Diesel	9973	235	320	02.90-06.96	■
41.322VF (D 2865 LF03)	Diesel	9973	235	320	02.90-06.96	■
41.322VF (D 2865 LF06)	Diesel	9973	235	320	02.90-06.96	■
19.342 F,19.342 FL,19.342 FLL (D 2865 LF09)	Diesel	9973	250	340	05.94-05.95	■
19.342FA (D 2865 LF09)	Diesel	9973	250	340	05.94-06.96	■
24.342 FNL,24.342 FNLL (D 2865 LF09)	Diesel	9973	250	340	05.94-05.95	■
26.342 DF,26.342 DFL (D 2865 LF09)	Diesel	9973	250	340	05.94-06.96	■
33.342 DF (D 2865 LF09)	Diesel	9973	250	340	05.94-06.96	■
33.342DFA (D 2865 LF09)	Diesel	9973	250	340	05.94-06.96	■
35.342VF (D 2865 LF09)	Diesel	9973	250	340	05.94-06.96	■
41.342VF (D 2865 LF09)	Diesel	9973	250	340	05.94-06.96	■
19.242 F,19.242 FL,19.242 FLL (D 2866 F/240)	Diesel	11967	177	241	01.88-01.89	■
24.242DF (D 2866 F/240)	Diesel	11967	177	241	01.88-07.89	■
24.242 FNL,24.242 FNLL,24.242 FVL (D 2866 F/240)	Diesel	11967	177	241	01.88-02.90	■
26.242DF (D 2866 F/240)	Diesel	11967	177	241	02.90-06.97	■
19.292 F,19.292 FL,19.292 FLL (D 2866 LF/290)	Diesel	11967	213	290	07.86-02.90	■
19.292FA (D 2866 LF/290)	Diesel	11967	213	290	05.88-02.90	■
24.292DF (D 2866 LF/290)	Diesel	11967	213	290	04.87-02.90	■
24.292 FNL,24.292 FNLL,24.292 FVL (D 2866 LF/290)	Diesel	11967	213	290	10.86-02.90	■
26.292 DF, 26.292 DFL (D 2866 LF/290)	Diesel	11967	213	290	09.87-02.90	■
26.292DFA (D 2866 LF/290)	Diesel	11967	213	290	05.88-02.90	■
32.292VF (D 2866 LF/290)	Diesel	11967	213	290	03.88-02.90	■
33.292 DF (D 2866 LF/290)	Diesel	11967	213	290	09.87-02.90	■
33.292DFA (D 2866 LF/290)	Diesel	11967	213	290	05.88-02.90	■
35.292VF (D 2866 LFZ/290)	Diesel	11967	213	290	10.88-04.95	■

LISTA DE APLICACIONES - BUYERS GUIDE

41.292VF (D 2866 LF/290)	Diesel	11967	213	290	10.88-02.90	■
24.302DF (D 2866 LF04)	Diesel	11967	221	299	05.90-12.90	■
24.302 FNL,24.302 FNLL,24.302 FVL (D 2866 LF04)	Diesel	11967	221	299	05.90-10.90	■
24.302 FNL,24.302 FNLL,24.302 FVL	Diesel	11967	221	299	05.90-10.90	■ ■
25.302DF (D 2866 LF04)	Diesel	11967	221	299	09.90-12.91	■
25.302 FNL, 25.302 FNLL, 25.302 FVL (D 2866 LF04)	Diesel	11967	221	299	09.90-12.91	■
26.302DF (D 2866 LF04)	Diesel	11967	221	299	05.90-12.91	■
26.302DFA (D 2866 LF04)	Diesel	11967	221	299	05.90-12.91	■
26.302 FNL, 26.302 FNLL, 26.302 FVL (D 2866 LF04)	Diesel	11967	221	299	03.91-12.91	■
32.302VF (D 2866 LF04)	Diesel	11967	221	299	05.90-09.91	■
35.302VF (D 2866 LF04)	Diesel	11967	221	299	05.90-09.91	■
19.332 F,19.332 FL,19.332 FLL (D 2866 LF/330)	Diesel	11967	243	330	07.86-02.90	■
19.332FA (D 2866 LF/330)	Diesel	11967	243	330	05.88-02.90	■
24.332DF (D 2866 LF/330)	Diesel	11967	243	330	04.87-02.90	■
24.332 FNL,24.332 FNLL,24.332 FVL (D 2866 LF/330)	Diesel	11967	243	330	10.86-02.90	■
26.332 DF, 26.332 DFL (D 2866 LF/330)	Diesel	11967	243	330	09.87-02.90	■
26.332DFA (D 2866 LF/330)	Diesel	11967	243	330	05.88-02.90	■
32.332VF (D 2866 LF/330)	Diesel	11967	243	330	03.88-02.90	■
33.332DFA (D 2866 LF/330)	Diesel	11967	243	330	05.88-02.90	■
35.332VF (D 2866 LFZ/330)	Diesel	11967	243	330	10.88-04.95	■
41.332VF (D 2866 LF/330)	Diesel	11967	243	330	10.88-02.90	■
19.372 F,19.372 FL,19.372 FLL (D 2866 LXF)	Diesel	11967	249	339	05.90-04.95	■
24.372DF (D 2866 LXF)	Diesel	11967	249	339	05.90-12.90	■
24.372FVL (D 2866 LXF)	Diesel	11967	249	339	05.90-12.90	■
25.372DF (D 2866 LXF)	Diesel	11967	249	339	09.90-12.92	■
32.372VF (D 2866 LXF)	Diesel	11967	249	339	02.90-06.96	■
35.372VF (D 2866 LXF)	Diesel	11967	249	339	02.90-04.95	■
19.362 F,19.362 FL,19.362 FLL (D 2866 KF)	Diesel	11967	265	360	07.86-02.90	■
19.362 F,19.362 FL,19.362 FLL (D 2866 LXF)	Diesel	11967	265	360	07.86-02.90	■
19.362FA (D 2866 LXF)	Diesel	11967	265	360	05.88-02.90	■
24.362DF (D 2866 KF)	Diesel	11967	265	360	04.87-02.90	■
24.362DF (D 2866 LXF)	Diesel	11967	265	360	04.87-02.90	■
24.362 FNL,24.362 FNLL,24.362 FVL (D 2866 KF)	Diesel	11967	265	360	10.86-02.90	■
24.362 FNL,24.362 FNLL,24.362 FVL (D 2866 LXF)	Diesel	11967	265	360	10.86-02.90	■
26.362 DF, 26.362 DFL (D 2866 KF)	Diesel	11967	265	360	09.87-02.90	■
26.362 DF, 26.362 DFL (D 2866 LXF)	Diesel	11967	265	360	09.87-02.90	■
26.362DFA (D 2866 LXF)	Diesel	11967	265	360	05.88-02.90	■
32.362VF (D 2866 LXF)	Diesel	11967	265	360	03.88-02.90	■
33.362 DF (D 2866 KF)	Diesel	11967	265	360	09.87-02.90	■
33.362 DF (D 2866 LXF)	Diesel	11967	265	360	09.87-02.90	■
33.362DFA (D 2866 LXF)	Diesel	11967	265	360	05.88-02.90	■
35.362VF (D 2866 LXF)	Diesel	11967	265	360	10.88-02.90	■
41.362VF (D 2866 LXF)	Diesel	11967	265	360	10.88-02.90	■
48.362VF (D 2866 LXF)	Diesel	11967	265	360	07.89-02.90	■
48.362VFA (D 2866 LXF)	Diesel	11967	265	360	07.89-02.90	■
19.372 F,19.372 FL,19.372 FLL (D 2866 LF03)	Diesel	11967	272	370	02.90-05.95	■
19.372 F,19.372 FL,19.372 FLL (D 2866 LF05)	Diesel	11967	272	370	02.90-05.95	■
19.372 F,19.372 FL,19.372 FLL (D 2866 LF15)	Diesel	11967	272	370	02.90-05.95	■

LISTA DE APLICACIONES - BUYERS GUIDE

19.372FA (D 2866 LF03)		Diesel		11967	272	370	02.90-06.96	■
19.372FA (D 2866 LF05)		Diesel		11967	272	370	02.90-06.96	■
19.372FA (D 2866 LF15)		Diesel		11967	272	370	02.90-06.96	■
19.372FAS (D 2866 LF03)		Diesel		11967	272	370	02.90-06.96	■
19.372FAS (D 2866 LF05)		Diesel		11967	272	370	02.90-06.96	■
19.372FAS (D 2866 LF15)		Diesel		11967	272	370	02.90-06.96	■
24.372DF (D 2866 LF03)		Diesel		11967	272	370	02.90-12.90	■
24.372 FNL,24.372 FNLL,24.372 FVL (D 2866 LF03)		Diesel		11967	272	370	02.90-05.95	■
24.372 FNL,24.372 FNLL,24.372 FVL (D 2866 LF15)		Diesel		11967	272	370	02.90-05.95	■
24.372 FNL,24.372 FNLL,24.372 FVL		Diesel		11967	272	370	02.90-05.95	■ ■
25.372DF (D 2866 LF03)		Diesel		11967	272	370	09.90-12.92	■
25.372DF (D 2866 LF05)		Diesel		11967	272	370	09.90-12.92	■
25.372 FNL, 25.372 FNLL, 25.372 FVL (D 2866 LF03)		Diesel		11967	272	370	09.90-12.92	■
25.372 FNL, 25.372 FNLL, 25.372 FVL (D 2866 LF05)		Diesel		11967	272	370	09.90-12.92	■
26.372 DF,26.372 DFL (D 2866 LF03)		Diesel		11967	272	370	02.90-06.96	■
26.372 DF,26.372 DFL (D 2866 LF05)		Diesel		11967	272	370	02.90-06.96	■
26.372 DF,26.372 DFL (D 2866 LF15)		Diesel		11967	272	370	02.90-06.96	■
26.372DFA (D 2866 LF03)		Diesel		11967	272	370	02.90-12.92	■
26.372DFA (D 2866 LF05)		Diesel		11967	272	370	02.90-12.92	■
26.372 FNL,26.372 FNLL,26.372 FVL (D 2866 LF03)		Diesel		11967	272	370	09.90-12.95	■
26.372 FNL,26.372 FNLL,26.372 FVL (D 2866 LF05)		Diesel		11967	272	370	09.90-12.95	■
26.372 FNL,26.372 FNLL,26.372 FVL (D 2866 LF15)		Diesel		11967	272	370	09.90-12.95	■
26.372 FNL,26.372 FNLL,26.372 FVL		Diesel		11967	272	370	09.90-12.95	■ ■
32.372VF (D 2866 LF03)		Diesel		11967	272	370	02.90-06.96	■
32.372VF (D 2866 LF05)		Diesel		11967	272	370	02.90-06.96	■
32.372VF (D 2866 LF15)		Diesel		11967	272	370	02.90-06.96	■
33.372 DF (D 2866 LF03)		Diesel		11967	272	370	09.91-06.96	■
33.372 DF (D 2866 LF05)		Diesel		11967	272	370	09.91-06.96	■
33.372 DF (D 2866 LF15)		Diesel		11967	272	370	09.91-06.96	■
33.372DFA (D 2866 LF03)		Diesel		11967	272	370	09.91-06.96	■
33.372DFA (D 2866 LF05)		Diesel		11967	272	370	09.91-06.96	■
33.372DFA (D 2866 LF15)		Diesel		11967	272	370	09.91-06.96	■
35.372VF (D 2866 LF03)		Diesel		11967	272	370	02.90-06.96	■
35.372VF (D 2866 LF05)		Diesel		11967	272	370	02.90-06.96	■
35.372VF (D 2866 LF15)		Diesel		11967	272	370	02.90-06.96	■
35.372VF (D 2866 LF03)		Diesel		11967	272	370	02.90-12.97	■
35.372VF (D 2866 LF05)		Diesel		11967	272	370	02.90-12.97	■
35.372VF (D 2866 LF15)		Diesel		11967	272	370	02.90-12.97	■
40.372DF (D 2866 LF03)		Diesel		11967	272	370	12.91-06.96	■
40.372DF (D 2866 LF05)		Diesel		11967	272	370	12.91-06.96	■
40.372DF (D 2866 LF15)		Diesel		11967	272	370	12.91-06.96	■
40.372DFA (D 2866 LF03)		Diesel		11967	272	370	12.91-06.96	■
40.372DFA (D 2866 LF05)		Diesel		11967	272	370	12.91-06.96	■
40.372DFA (D 2866 LF15)		Diesel		11967	272	370	12.91-06.96	■
41.372VF (D 2866 LF03)		Diesel		11967	272	370	02.90-06.96	■
41.372VF (D 2866 LF05)		Diesel		11967	272	370	02.90-06.96	■
41.372VF (D 2866 LF15)		Diesel		11967	272	370	02.90-06.96	■
19.402 F,19.402 FL,19.402 FLL (D 2866 LF16)		Diesel		11967	294	400	05.94-05.95	■

LISTA DE APLICACIONES - BUYERS GUIDE

19.402 FA (D 2866 LF16)	Diesel	11967	294	400	05.94-06.96	■
24.402 FNL,24.402 FNLL (D 2866 LF16)	Diesel	11967	294	400	05.94-05.95	■
26.402 DF,26.402 DFL (D 2866 LF16)	Diesel	11967	294	400	05.94-06.96	■
26.402 FNL,26.402 FNLL,26.402 FVL (D 2866 LF16)	Diesel	11967	294	400	05.94-06.96	■
26.402 FNL,26.402 FNLL,26.402 FVL	Diesel	11967	294	400	05.94-06.96	■ ■
33.402 DF (D 2866 LF16)	Diesel	11967	294	400	05.94-06.96	■
33.402DFA (D 2866 LF16)	Diesel	11967	294	400	05.94-06.96	■
35.402VF (D 2866 LF16)	Diesel	11967	294	400	05.94-06.96	■
35.402VF (D 2866 LF16)	Diesel	11967	294	400	05.94-12.97	■
40.402DF (D 2866 LF16)	Diesel	11967	294	400	05.95-06.96	■
40.402DFA (D 2866 LF16)	Diesel	11967	294	400	05.95-06.96	■
41.402 VF (D 2866 LF16)	Diesel	11967	294	400	05.94-06.96	■
19.422 F,19.422 FL,19.422 FLL (D 2866 LF06)	Diesel	11967	309	420	02.90-05.95	■
19.422 F,19.422 FL,19.422 FLL (D 2866 LF09)	Diesel	11967	309	420	02.90-05.95	■
19.422 F,19.422 FL,19.422 FLL (D 2866 LF10)	Diesel	11967	309	420	02.90-05.95	■
19.422FA (D 2866 LF06)	Diesel	11967	309	420	02.90-06.96	■
19.422FA (D 2866 LF09)	Diesel	11967	309	420	02.90-06.96	■
24.422DF (D 2866 LF06)	Diesel	11967	309	420	02.90-12.90	■
24.422 FNL,24.422 FNLL,24.422 FVL (D 2866 LF06)	Diesel	11967	309	420	02.90-05.95	■
24.422 FNL,24.422 FNLL,24.422 FVL (D 2866 LF09)	Diesel	11967	309	420	02.90-05.95	■
24.422 FNL,24.422 FNLL,24.422 FVL	Diesel	11967	309	420	02.90-05.95	■ ■
25.422DF (D 2866 LF06)	Diesel	11967	309	420	09.90-12.92	■
25.422DF (D 2866 LF09)	Diesel	11967	309	420	09.90-12.92	■
25.422 FNL,25.422 FNLL (D 2866 LF06)	Diesel	11967	309	420	09.90-12.92	■
25.422 FNL,25.422 FNLL (D 2866 LF09)	Diesel	11967	309	420	09.90-12.92	■
26.422 DF,26.422 DFL (D 2866 LF06)	Diesel	11967	309	420	02.90-06.96	■
26.422 DF,26.422 DFL (D 2866 LF09)	Diesel	11967	309	420	02.90-06.96	■
26.422DFA (D 2866 LF06)	Diesel	11967	309	420	02.90-12.92	■
26.422DFA (D 2866 LF09)	Diesel	11967	309	420	02.90-12.92	■
26.422 FNL,26.422 FNLL,26.422 FVL (D 2866 LF06)	Diesel	11967	309	420	09.90-12.95	■
26.422 FNL,26.422 FNLL,26.422 FVL (D 2866 LF09)	Diesel	11967	309	420	09.90-12.95	■
26.422 FNL,26.422 FNLL,26.422 FVL	Diesel	11967	309	420	09.90-12.95	■ ■
32.422VF (D 2866 LF06)	Diesel	11967	309	420	02.90-06.96	■
32.422VF (D 2866 LF09)	Diesel	11967	309	420	02.90-06.96	■
33.422 DF (D 2866 LF06)	Diesel	11967	309	420	09.91-06.96	■
33.422 DF (D 2866 LF09)	Diesel	11967	309	420	09.91-06.96	■
33.422DFA (D 2866 LF06)	Diesel	11967	309	420	09.91-06.96	■
33.422DFA (D 2866 LF09)	Diesel	11967	309	420	09.91-06.96	■
35.422VF (D 2866 LF06)	Diesel	11967	309	420	02.90-06.96	■
35.422VF (D 2866 LF09)	Diesel	11967	309	420	02.90-06.96	■
35.422VF (D 2866 LF06)	Diesel	11967	309	420	02.90-12.97	■
35.422VF (D 2866 LF09)	Diesel	11967	309	420	02.90-12.97	■
40.422DF (D 2866 LF06)	Diesel	11967	309	420	12.91-06.96	■
40.422DF (D 2866 LF09)	Diesel	11967	309	420	12.91-06.96	■
40.422DFA (D 2866 LF06)	Diesel	11967	309	420	12.91-06.96	■
40.422DFA (D 2866 LF09)	Diesel	11967	309	420	12.91-06.96	■
41.422VF (D 2866 LF06)	Diesel	11967	309	420	02.90-06.96	■
41.422VF (D 2866 LF09)	Diesel	11967	309	420	02.90-06.96	■
19.462 F,19.462 FL (D 2840 LF 460)	Diesel	18273	338	460	05.87-02.90	■

LISTA DE APLICACIONES - BUYERS GUIDE

22.462		Diesel		18273	338	460	01.89-06.92	■
24.462DF (D 2840 LF 460)		Diesel		18273	338	460	02.89-02.90	■
24.462FNL (D 2840 LF 460)		Diesel		18273	338	460	04.89-02.90	■
25.462		Diesel		18273	338	460	01.91-06.92	■
26.462DF (D 2840 LF 460)		Diesel		18273	338	460	02.89-02.90	■
26.462DFA (D 2840 LF 460)		Diesel		18273	338	460	08.89-02.90	■
33.462 DF (D 2840 LF 460)		Diesel		18273	338	460	07.89-02.90	■
33.462DFA (D 2840 LF 460)		Diesel		18273	338	460	07.89-02.90	■
40.462DFA (D 2840 LF 460)		Diesel		18273	338	460	07.89-02.90	■
19.502 F,19.502 FL,19.502 FLL (D 2840 LF01)		Diesel		18273	368	500	02.90-06.96	■
19.502 F,19.502 FL,19.502 FLL (D 2840 LF04)		Diesel		18273	368	500	02.90-06.96	■
19.502 F,19.502 FL,19.502 FLL (D 2840 LF06)		Diesel		18273	368	500	02.90-06.96	■
22.502		Diesel		18273	368	500	04.90-03.97	■
24.502 DF (D 2840 LF01)		Diesel		18273	368	500	02.90-12.90	■
24.502 FNL (D 2840 LF01)		Diesel		18273	368	500	02.90-12.90	■
25.502 DF (D 2840 LF01)		Diesel		18273	368	500	09.90-12.92	■
25.502 DF (D 2840 LF04)		Diesel		18273	368	500	09.90-12.92	■
25.502FNL (D 2840 LF01)		Diesel		18273	368	500	09.90-12.92	■
25.502FNL (D 2840 LF04)		Diesel		18273	368	500	09.90-12.92	■
26.502 DF (D 2840 LF01)		Diesel		18273	368	500	02.90-06.96	■
26.502 DF (D 2840 LF04)		Diesel		18273	368	500	02.90-06.96	■
26.502 DF (D 2840 LF06)		Diesel		18273	368	500	02.90-06.96	■
26.502 DFA (D 2840 LF01)		Diesel		18273	368	500	02.90-12.92	■
26.502 DFA (D 2840 LF04)		Diesel		18273	368	500	02.90-12.92	■
26.502 FNL,26.502 FNLL (D 2840 LF01)		Diesel		18273	368	500	09.91-06.96	■
26.502 FNL,26.502 FNLL (D 2840 LF04)		Diesel		18273	368	500	09.91-06.96	■
26.502 FNL,26.502 FNLL (D 2840 LF06)		Diesel		18273	368	500	09.91-06.96	■
33.502 DF (D 2840 LF01)		Diesel		18273	368	500	09.91-06.96	■
33.502 DF (D 2840 LF04)		Diesel		18273	368	500	09.91-06.96	■
33.502 DF (D 2840 LF06)		Diesel		18273	368	500	09.91-06.96	■
33.502DFA (D 2840 LF01)		Diesel		18273	368	500	09.91-06.96	■
33.502DFA (D 2840 LF04)		Diesel		18273	368	500	09.91-06.96	■
33.502DFA (D 2840 LF06)		Diesel		18273	368	500	09.91-06.96	■
40.502DFA (D 2840 LF01)		Diesel		18273	368	500	02.90-06.96	■
40.502DFA (D 2840 LF04)		Diesel		18273	368	500	02.90-06.96	■
40.502DFA (D 2840 LF06)		Diesel		18273	368	500	02.90-06.96	■
F90 06.86-12.97								Truck Tractor
19.262FAS (D 2865 LF/260)		Diesel		9973	191	260	02.89-02.90	■
19.262 FS,19.262 FLS,19.262 FLLS (D 2865 LF/260)		Diesel		9973	191	260	01.88-02.90	■
24.262 DFS,24.262 DFSL (D 2865 LF/260)		Diesel		9973	191	260	01.88-02.90	■
26.262DFAS (D 2865 LF/260)		Diesel		9973	191	260	02.89-02.90	■
26.262DFS (D 2865 LF/260)		Diesel		9973	191	260	01.88-02.90	■
19.272FAS (D 2865 LF02)		Diesel		9973	198	269	02.90-05.95	■
19.272FAS (D 2865 LF05)		Diesel		9973	198	269	02.90-05.95	■
19.272 FS,19.272 FLS,19.272 FLLS (D 2865 LF02)		Diesel		9973	198	269	02.90-05.95	■
19.272 FS,19.272 FLS,19.272 FLLS (D 2865 LF05)		Diesel		9973	198	269	02.90-05.95	■
24.272 DFS,24.272 DFSL (D 2865 LF02)		Diesel		9973	198	269	02.90-04.95	■
24.272 FNLS,24.272 FVLS (D 2865 LF02)		Diesel		9973	198	269	02.90-05.95	■
24.272 FNLS,24.272 FVLS (D 2865 LF05)		Diesel		9973	198	269	02.90-05.95	■
24.272 FNLS,24.272 FVLS		Diesel		9973	198	269	02.90-05.95	■ ■

LISTA DE APLICACIONES - BUYERS GUIDE

25.272 DFS,25.272 DFLS (D 2865 LF02)	Diesel	9973	198	269	09.90-12.92	■
25.272 DFS,25.272 DFLS (D 2865 LF05)	Diesel	9973	198	269	09.90-12.92	■
26.272DFAS (D 2865 LF02)	Diesel	9973	198	269	02.90-12.92	■
26.272DFAS (D 2865 LF05)	Diesel	9973	198	269	02.90-12.92	■
26.272 DFS,26.272 DFLS (D 2865 LF02)	Diesel	9973	198	269	02.90-06.96	■
26.272 DFS,26.272 DFLS (D 2865 LF05)	Diesel	9973	198	269	02.90-06.96	■
26.272 FNLS,26.272 FVLS (D 2865 LF02)	Diesel	9973	198	269	09.90-12.95	■
26.272 FNLS,26.272 FVLS (D 2865 LF05)	Diesel	9973	198	269	09.90-12.95	■
26.272 FNLS,26.272 FVLS	Diesel	9973	198	269	09.90-12.95	■ ■
19.322FAS (D 2865 LF03)	Diesel	9973	235	320	02.90-06.96	■
19.322FAS (D 2865 LF06)	Diesel	9973	235	320	02.90-06.96	■
19.322 FS,19.322 FLS,19.322 FLLS (D 2865 LF03)	Diesel	9973	235	320	02.90-05.95	■
19.322 FS,19.322 FLS,19.322 FLLS (D 2865 LF06)	Diesel	9973	235	320	02.90-05.95	■
24.322 DFS,24.322 DFLS (D 2865 LF03)	Diesel	9973	235	320	02.90-12.90	■
24.322 FNLS,24.322 FVLS (D 2865 LF03)	Diesel	9973	235	320	02.90-05.95	■
24.322 FNLS,24.322 FVLS (D 2865 LF06)	Diesel	9973	235	320	02.90-05.95	■
24.322 FNLS,24.322 FVLS	Diesel	9973	235	320	02.90-05.95	■ ■
25.322 DFS, 25.322 DFLS (D 2865 LF03)	Diesel	9973	235	320	09.90-12.92	■
25.322 DFS, 25.322 DFLS (D 2865 LF06)	Diesel	9973	235	320	09.90-12.92	■
25.322 FNLS,25.322 FVLS (D 2865 LF03)	Diesel	9973	235	320	09.90-12.92	■
25.322 FNLS,25.322 FVLS (D 2865 LF06)	Diesel	9973	235	320	09.90-12.92	■
25.322 FNLS,25.322 FVLS	Diesel	9973	235	320	09.90-12.92	■ ■
26.322DFAS (D 2865 LF03)	Diesel	9973	235	320	02.90-12.92	■
26.322DFAS (D 2865 LF06)	Diesel	9973	235	320	02.90-12.92	■
26.322 DFS,26.322 DFLS (D 2865 LF03)	Diesel	9973	235	320	02.90-06.96	■
26.322 DFS,26.322 DFLS (D 2865 LF06)	Diesel	9973	235	320	02.90-06.96	■
26.322 FNLS,26.322 FVLS (D 2865 LF03)	Diesel	9973	235	320	09.90-12.95	■
26.322 FNLS,26.322 FVLS (D 2865 LF06)	Diesel	9973	235	320	09.90-12.95	■
26.322 FNLS,26.322 FVLS	Diesel	9973	235	320	09.90-12.95	■ ■
19.342FAS (D 2865 LF09)	Diesel	9973	250	340	05.94-06.96	■
19.342 FS,19.342 FLS,19.342 FLLS (D 2865 LF09)	Diesel	9973	250	340	05.94-05.95	■
26.342DFS (D 2865 LF09)	Diesel	9973	250	340	04.94-06.96	■
19.242 FS,19.242 FLS,19.242 FLLS (D 2866 F/240)	Diesel	11967	177	241	01.88-01.89	■
24.242DFS (D 2866 F/240)	Diesel	11967	177	241	01.88-07.89	■
26.242DFS (D 2866 F/240)	Diesel	11967	177	241	02.90-06.97	■
19.292FAS (D 2866 LF/290)	Diesel	11967	213	290	05.88-02.90	■
19.292 FS,19.292 FLS,19.292 FLLS (D 2866 LF/290)	Diesel	11967	213	290	07.86-02.90	■
24.292 DFS,24.292 DFLS (D 2866 LF/290)	Diesel	11967	213	290	04.87-02.90	■
24.292 FNLS,24.292 FVLS (D 2866 LF/290)	Diesel	11967	213	290	10.86-02.90	■
26.292DFAS (D 2866 LF/290)	Diesel	11967	213	290	05.88-02.90	■
26.292DFS (D 2866 LF/290)	Diesel	11967	213	290	09.87-02.90	■
33.292DFAS (D 2866 LF/290)	Diesel	11967	213	290	05.88-02.90	■
33.292DFS (D 2866 LF/290)	Diesel	11967	213	290	09.87-02.90	■
24.302 DFS,24.302 DFLS (D 2866 LF04)	Diesel	11967	221	299	05.90-04.95	■
25.302 DFS, 25.302 DFLS (D 2866 LF04)	Diesel	11967	221	299	09.90-12.91	■
25.302 FNLS, 25.302 FVLS (D 2866 LF04)	Diesel	11967	221	299	09.90-12.91	■
25.302 FNLS, 25.302 FVLS	Diesel	11967	221	299	09.90-12.91	■ ■
26.302DFAS (D 2866 LF04)	Diesel	11967	221	299	05.90-12.91	■
26.302DFS (D 2866 LF04)	Diesel	11967	221	299	05.90-12.91	■

LISTA DE APLICACIONES - BUYERS GUIDE

26.302 FNLS,26.302 FVLS (D 2866 LF04)	Diesel	11967	221	299	09.90-12.91	■	
26.302 FNLS,26.302 FVLS	Diesel	11967	221	299	09.90-12.91	■	■
19.332FAS (D 2866 LF/330)	Diesel	11967	243	330	05.88-02.90	■	
19.332 FS,19.332 FLS,19.332 FLLS (D 2866 LF/330)	Diesel	11967	243	330	07.86-02.90	■	
24.332 DFS,24.332 DFLS (D 2866 LF/330)	Diesel	11967	243	330	04.87-02.90	■	
24.332 FNLS,24.332 FVLS (D 2866 LF/330)	Diesel	11967	243	330	10.86-02.90	■	
26.332DFAS (D 2866 LF/330)	Diesel	11967	243	330	05.88-02.90	■	
26.332DFS (D 2866 LF/330)	Diesel	11967	243	330	09.87-02.90	■	
33.332DFAS (D 2866 LF/330)	Diesel	11967	243	330	05.88-02.90	■	
33.332DFS (D 2866 LF/330)	Diesel	11967	243	330	09.87-02.90	■	
19.372 FS,19.372 FLS,19.372 FLLS (D 2866 LXF)	Diesel	11967	249	339	05.90-04.95	■	
24.372DFS (D 2866 LXF)	Diesel	11967	249	339	05.90-12.90	■	
24.372FVLS (D 2866 LXF)	Diesel	11967	249	339	05.90-12.90	■	
25.372DFS (D 2866 LXF)	Diesel	11967	249	339	09.90-12.92	■	
25.372FVLS (D 2866 LXF)	Diesel	11967	249	339	09.90-10.93	■	
19.362FAS (D 2866 LXF)	Diesel	11967	265	360	05.88-02.90	■	
19.362 FS,19.362 FLS,19.362 FLLS (D 2866 KF)	Diesel	11967	265	360	07.86-02.90	■	
19.362 FS,19.362 FLS,19.362 FLLS (D 2866 LXF)	Diesel	11967	265	360	07.86-02.90	■	
24.362 DFS,24.362 DFLS (D 2866 KF)	Diesel	11967	265	360	04.87-02.90	■	
24.362 DFS,24.362 DFLS (D 2866 LXF)	Diesel	11967	265	360	04.87-02.90	■	
24.362 FNLS,24.362 FVLS (D 2866 KF)	Diesel	11967	265	360	10.86-02.90	■	
24.362 FNLS,24.362 FVLS (D 2866 LXF)	Diesel	11967	265	360	10.86-02.90	■	
26.362DFAS (D 2866 LXF)	Diesel	11967	265	360	05.88-02.90	■	
26.362DFS (D 2866 KF)	Diesel	11967	265	360	09.87-02.90	■	
26.362DFS (D 2866 LXF)	Diesel	11967	265	360	09.87-02.90	■	
33.362DFAS (D 2866 LXF)	Diesel	11967	265	360	05.88-02.90	■	
33.362DFS (D 2866 KF)	Diesel	11967	265	360	09.87-02.90	■	
33.362DFS (D 2866 LXF)	Diesel	11967	265	360	09.87-02.90	■	
19.372 FS,19.372 FLS,19.372 FLLS (D 2866 LF03)	Diesel	11967	272	370	02.90-05.95	■	
19.372 FS,19.372 FLS,19.372 FLLS (D 2866 LF05)	Diesel	11967	272	370	02.90-05.95	■	
19.372 FS,19.372 FLS,19.372 FLLS (D 2866 LF15)	Diesel	11967	272	370	02.90-05.95	■	
24.372 FNLS,24.372 FVLS (D 2866 LF03)	Diesel	11967	272	370	02.90-05.95	■	
24.372 FNLS,24.372 FVLS (D 2866 LF15)	Diesel	11967	272	370	02.90-05.95	■	
24.372 FNLS,24.372 FVLS	Diesel	11967	272	370	02.90-05.95	■	■
25.372 DFS,25.372 DFLS (D 2866 LF03)	Diesel	11967	272	370	09.90-12.92	■	
25.372 DFS,25.372 DFLS (D 2866 LF05)	Diesel	11967	272	370	09.90-12.92	■	
25.372 FNLS,25.372 FVLS (D 2866 LF03)	Diesel	11967	272	370	09.90-10.93	■	
25.372 FNLS,25.372 FVLS (D 2866 LF05)	Diesel	11967	272	370	09.90-10.93	■	
25.372 FNLS,25.372 FVLS	Diesel	11967	272	370	09.90-10.93	■	■
26.372DFAS (D 2866 LF03)	Diesel	11967	272	370	02.90-12.92	■	
26.372DFAS (D 2866 LF05)	Diesel	11967	272	370	02.90-12.92	■	
26.372DFS (D 2866 LF03)	Diesel	11967	272	370	02.90-06.96	■	
26.372DFS (D 2866 LF05)	Diesel	11967	272	370	02.90-06.96	■	
26.372DFS (D 2866 LF15)	Diesel	11967	272	370	02.90-06.96	■	
26.372 FNLS,26.372 FVLS (D 2866 LF03)	Diesel	11967	272	370	01.92-06.96	■	
26.372 FNLS,26.372 FVLS (D 2866 LF05)	Diesel	11967	272	370	01.92-06.96	■	
26.372 FNLS,26.372 FVLS (D 2866 LF15)	Diesel	11967	272	370	01.92-06.96	■	
26.372 FNLS,26.372 FVLS	Diesel	11967	272	370	01.92-06.96	■	■

LISTA DE APLICACIONES - BUYERS GUIDE

33.372DFS (D 2866 LF03)		Diesel		11967	272	370	09.91-06.96	■
33.372DFS (D 2866 LF05)		Diesel		11967	272	370	09.91-06.96	■
33.372DFS (D 2866 LF15)		Diesel		11967	272	370	09.91-06.96	■
19.402FAS (D 2866 LF16)		Diesel		11967	294	400	05.94-06.96	■
19.402 FS,19.402 FLS,19.402 FLLS (D 2866 LF16)		Diesel		11967	294	400	05.94-05.95	■
26.402DFS (D 2866 LF16)		Diesel		11967	294	400	05.94-12.95	■
26.402 FNLS,26.402 FVLS (D 2866 LF16)		Diesel		11967	294	400	05.94-06.96	■
26.402 FNLS,26.402 FVLS		Diesel		11967	294	400	05.94-06.96	■ ■
33.402DFS (D 2866 LF16)		Diesel		11967	294	400	05.94-06.96	■
19.422FAS (D 2866 LF06)		Diesel		11967	309	420	02.90-06.96	■
19.422FAS (D 2866 LF09)		Diesel		11967	309	420	02.90-06.96	■
19.422 FS,19.422 FLS,19.422 FLLS (D 2866 LF06)		Diesel		11967	309	420	02.90-05.95	■
19.422 FS,19.422 FLS,19.422 FLLS (D 2866 LF09)		Diesel		11967	309	420	02.90-05.95	■
19.422 FS,19.422 FLS,19.422 FLLS (D 2866 LF10)		Diesel		11967	309	420	02.90-05.95	■
24.422 DFS,24.422 DFLS (D 2866 LF06)		Diesel		11967	309	420	02.90-12.90	■
25.422 DFS,25.422 DFLS (D 2866 LF06)		Diesel		11967	309	420	09.90-12.92	■
25.422 DFS,25.422 DFLS (D 2866 LF09)		Diesel		11967	309	420	09.90-12.92	■
25.422 FNLS,25.422 FVLS (D 2866 LF06)		Diesel		11967	309	420	09.90-12.92	■
25.422 FNLS,25.422 FVLS (D 2866 LF09)		Diesel		11967	309	420	09.90-12.92	■
25.422 FNLS,25.422 FVLS		Diesel		11967	309	420	09.90-12.92	■ ■
26.422DFAS (D 2866 LF06)		Diesel		11967	309	420	02.90-12.92	■
26.422DFAS (D 2866 LF09)		Diesel		11967	309	420	02.90-12.92	■
26.422DFS (D 2866 LF06)		Diesel		11967	309	420	02.90-12.95	■
26.422DFS (D 2866 LF09)		Diesel		11967	309	420	02.90-12.95	■
26.422 FNLS,26.422 FVLS (D 2866 LF06)		Diesel		11967	309	420	01.92-12.95	■
26.422 FNLS,26.422 FVLS (D 2866 LF09)		Diesel		11967	309	420	01.92-12.95	■
26.422 FNLS,26.422 FVLS		Diesel		11967	309	420	01.92-12.95	■ ■
33.422DFS (D 2866 LF06)		Diesel		11967	309	420	01.94-06.96	■
33.422DFS (D 2866 LF09)		Diesel		11967	309	420	01.94-06.96	■
19.462 FS,19.462 FLS (D 2840 LF 460)		Diesel		18273	338	460	05.87-02.90	■
22.462		Diesel		18273	338	460	01.89-06.92	■
24.462 DFS (D 2840 LF 460)		Diesel		18273	338	460	02.89-02.90	■
25.462		Diesel		18273	338	460	01.91-06.92	■
26.462DFAS (D 2840 LF 460)		Diesel		18273	338	460	08.89-02.90	■
26.462DFS (D 2840 LF 460)		Diesel		18273	338	460	02.89-02.90	■
19.502 FS,19.502 FLS,19.502 FLLS (D 2840 LF01)		Diesel		18273	368	500	02.90-06.96	■
19.502 FS,19.502 FLS,19.502 FLLS (D 2840 LF04)		Diesel		18273	368	500	02.90-06.96	■
19.502 FS,19.502 FLS,19.502 FLLS (D 2840 LF06)		Diesel		18273	368	500	02.90-06.96	■
22.502		Diesel		18273	368	500	04.90-01.97	■
24.502 DFS (D 2840 LF01)		Diesel		18273	368	500	02.90-12.90	■
25.502 DFS (D 2840 LF01)		Diesel		18273	368	500	09.90-12.92	■
25.502 DFS (D 2840 LF04)		Diesel		18273	368	500	09.90-12.92	■
26.502 DFAS (D 2840 LF01)		Diesel		18273	368	500	02.90-12.92	■
26.502 DFAS (D 2840 LF04)		Diesel		18273	368	500	02.90-12.92	■
26.502 DFS,26.502 DFLS (D 2840 LF04)		Diesel		18273	368	500	02.90-06.96	■
26.502 DFS,26.502 DFLS (D 2840 LF06)		Diesel		18273	368	500	02.90-06.96	■
FOCL								Bus
12.240 (D 0836 LOH 56)		Diesel		6871	176	240	08.07-	■

LISTA DE APLICACIONES - BUYERS GUIDE

12.250 (D 0836 LOH 65)	Diesel	6871	184	250	08.04-	■
HOCL						Bus
13.210	Diesel	6871	157	213	07.94-10.97	■
12.220 HOCL/R-NL (D 0826 LOH 15)	Diesel	6871	162	220	04.99-05.09	■
12.220 HOCL/R-NL (D 0826 LOH 17)	Diesel	6871	162	220	04.99-05.09	■
14.220 HOCL/R-NL (D 0826 LOH 15)	Diesel	6871	162	220	01.98-	■
14.220 HOCL/R-NL (D 0826 LOH 17)	Diesel	6871	162	220	01.98-	■
14.220 HOCL/R-NL (D 0826 LUH 11)	Diesel	6871	162	220	01.98-	■
18.220 HOCL/R-NL, HOCL/SKD(SL) (D 0826 LOH 03)	Diesel	6871	162	220	10.98-05.01	■
18.220 HOCL/R-NL, HOCL/SKD(SL) (D 0826 LOH 04)	Diesel	6871	162	220	10.98-05.01	■
18.220 HOCL/R-NL, HOCL/SKD(SL) (D 0826 LOH 05)	Diesel	6871	162	220	10.98-05.01	■
18.220 HOCL/R-NL, HOCL/SKD(SL) (D 0826 LOH 15)	Diesel	6871	162	220	10.98-05.01	■
18.220 HOCL/R-NL, HOCL/SKD(SL) (D 0826 LOH 17)	Diesel	6871	162	220	10.98-05.01	■
18.220 HOCL/R-NL, HOCL/SKD(SL) (D 0836 LOH 03)	Diesel	6871	162	220	10.98-05.01	■
13.230	Diesel	6871	169	230	07.94-10.97	■
12.240 HOCL-NL (D 0836 LOH 52)	Diesel	6871	176	240	05.00-	■
12.240 HOCL-NL (D 0836 LOH 56)	Diesel	6871	176	240	05.00-	■
14.240 HOCL-NL (D 0836 LOH 52)	Diesel	6871	176	240	05.00-	■
14.240 HOCL-NL (D 0836 LOH 56)	Diesel	6871	176	240	05.00-	■
18.240 HOCL-NL (D 0836 LOH 52)	Diesel	6871	176	240	08.02-10.09	■
18.240 HOCL-NL (D 0836 LOH 56)	Diesel	6871	176	240	08.02-10.09	■
14.250 HOCL-NL (D 0836 LOH 61)	Diesel	6871	184	250	05.07-	■
18.250 HOCL-NL, HOCL-SKD(SL) (D 0826 LOH 10)	Diesel	6871	184	250	05.07-12.14	■
18.250 HOCL-NL, HOCL-SKD(SL) (D 0836 LOH 61)	Diesel	6871	184	250	05.07-12.14	■
18.260	Diesel	6871	191	260	05.07-12.14	■ ■
14.280 HOCL (D 0836 LOH 40)	Diesel	6871	206	280	08.02-12.14	■
14.280 HOCL (D 0836 LOH 51)	Diesel	6871	206	280	08.02-12.14	■
14.280 HOCL (D 0836 LOH 55)	Diesel	6871	206	280	08.02-12.14	■
14.280 HOCL (D 0836 LOH 40)	Diesel	6871	206	280	08.02-12.14	■
14.280 HOCL (D 0836 LOH 55)	Diesel	6871	206	280	08.02-12.14	■
18.280 HOCL-NL (D 0836 LOH 01)	Diesel	6871	206	280	05.02-08.08	■
18.280 HOCL-NL (D 0836 LOH 02)	Diesel	6871	206	280	05.02-08.08	■
18.280 HOCL-NL (D 0836 LOH 51)	Diesel	6871	206	280	05.02-08.08	■
18.280 HOCL-NL (D 0836 LOH 55)	Diesel	6871	206	280	05.02-08.08	■
14.290 HOCL-NL (D 0836 LFL 61)	Diesel	6871	213	290	05.07-	■
18.290 HOCL-NL (D 0836 LOH 60)	Diesel	6871	213	290	05.07-12.14	■
18.310 HOCL-NL (D 2066 LUH 07)	Diesel	10518	228	310	01.06-10.09	■
18.310 HOCL-NL (D 2066 LUH 12)	Diesel	10518	228	310	01.06-10.09	■
18.310 HOCL-NL (D 2066 LUH 22)	Diesel	10518	228	310	01.06-10.09	■
18.320 HOCL-NL (D 2066 LUH 42)	Diesel	10518	235	320	05.07-12.14	■
18.350	Diesel	10518	257	349	01.06-10.09	■ ■
18.360 HOCL (D 2066 LOH 02)	Diesel	10518	265	360	01.06-12.14	■
18.360 HOCL (D 2066 LOH 06)	Diesel	10518	265	360	01.06-12.14	■
18.360 HOCL (D 2066 LOH 27)	Diesel	10518	265	360	01.06-12.14	■
18.400 HOCL (D 2066 LOH 03)	Diesel	10518	294	400	01.06-12.14	■
18.400 HOCL (D 2066 LOH 28)	Diesel	10518	294	400	01.06-12.14	■
18.430 HOCL (D 2066 LOH 10)	Diesel	10518	316	430	01.06-10.09	■

LISTA DE APLICACIONES - BUYERS GUIDE

24.440 HOCLN (D 2066 LOH 10)		Diesel		10518	316	430	01.06-10.09	■	
18.440 HOCL (D 2066 LOH 04)		Diesel		10518	324	440	01.06-10.09	■	
18.440 HOCL (D 2066 LOH 08)		Diesel		10518	324	440	01.06-10.09	■	
24.440 HOCLN (D 2066 LOH 04)		Diesel		10518	324	440	01.06-10.09	■	
24.440 HOCLN (D 2066 LOH 08)		Diesel		10518	324	440	01.06-10.09	■	
18.310		Diesel		11967	228	310	05.00-10.06	■	■
18.310 HOCL/R (D 2866 LOH 25)		Diesel		11967	228	310	01.92-	■	
18.310 HOCL/R (D 2866 LOH 27)		Diesel		11967	228	310	01.92-	■	
18.460 HOCL (D 2676 LOH 10)		Diesel		12419	338	460	03.06-10.09	■	
24.460 HOCLN (D 2676 LOH 18)		Diesel		12419	338	460	03.06-12.14	■	
18.480 HOCL (D 2676 LOH 04)		Diesel		12419	353	480	05.07-12.14	■	
18.480 HOCL (D 2676 LOH 27)		Diesel		12419	353	480	05.07-12.14	■	
24.480 HOCLN (D 2676 LOH 04)		Diesel		12419	353	480	05.07-12.14	■	
HOCL								Bus	
18.270 CNG		Gasolina		12816	200	272	05.07-	■	■
18.310 HOCL-NL (E 2876 LUH 02)		Gasolina		12816	228	310	05.07-	■	
HOCL									
12.245		Diesel		6871	180	245	05.04-08.08	■	■
12.260		Diesel		6871	191	260	06.05-10.09	■	■
14.260		Diesel		6871	191	260	06.05-10.09	■	■
18.350		Diesel		10518	257	349	01.06-10.09	■	■
25.360		Diesel		10518	265	360	01.06-10.09	■	■
25.400		Diesel		10518	294	400	01.06-07.14	■	■
18.360		Diesel		11967	265	360	05.04-10.06	■	■
18.410		Diesel		11967	301	409	05.04-10.06	■	■
18.440		Diesel		12419	324	441	08.07-	■	■
20.440		Diesel		12419	324	441	05.07-	■	■
24.440		Diesel		12419	324	441	05.11-	■	■
25.440		Diesel		12419	324	441	05.07-07.14	■	■
26.440		Diesel		12419	324	441	04.09-	■	■
18.505		Diesel		12419	371	504	08.09-	■	■
20.505		Diesel		12419	371	504	05.07-	■	■
24.505		Diesel		12419	371	504	05.11-	■	■
25.505		Diesel		12419	371	504	05.07-07.14	■	■
26.505		Diesel		12419	371	504	04.09-	■	■
18.410		Diesel		12816	301	409	05.04-10.06	■	■
25.410		Diesel		12816	301	409	03.05-10.06	■	■
18.460		Diesel		12816	338	460	05.04-10.06	■	■
25.460		Diesel		12816	338	460	03.05-10.06	■	■
LION'S CITY 03.96-								Bus	
19.240 (D 0836 LOH 52)		Diesel		6871	176	240	05.04-10.09	■	
Lions City		Diesel		6871	176	239	05.04-10.09	■	■
Lions City		Diesel		6871	191	260	05.07-12.14	■	■
19.280 (D 0836 LOH 40)		Diesel		6871	206	280	05.04-	■	
19.280 (D 0836 LOH 51)		Diesel		6871	206	280	05.04-	■	
Lions City		Diesel		6871	206	280	05.04-10.06	■	■
19.290 (D 0836 LOH 64)		Diesel		6871	213	290	05.04-	■	
Lions City		Diesel		10518	228	310	01.06-10.09	■	■
Lions City		Diesel		10518	235	320	05.07-	■	■
Lions City		Diesel		10518	257	349	01.06-10.09	■	■

LISTA DE APLICACIONES - BUYERS GUIDE

Lions City		Diesel		10518	265	360	05.07-	■	■
Lions City		Diesel		10518	294	400	08.12-	■	■
Lions City		Diesel		11967	191	260	05.04-10.09	■	■
Lions City		Diesel		11967	228	310	05.04-10.09	■	■
LION'S CITY 05.04-								Bus	
Lions City CNG		Gasolina		11967	180	245	05.07-12.14	■	■
Lions City CNG		Gasolina		11967	228	310	05.04-01.09	■	■
Lions City CNG		Gasolina		12816	200	272	05.07-	■	■
Lions City LPG		Gasolina		12816	200	272	01.05-12.14	■	■
LION'S COACH 09.95-								Bus	
400 (D 2066 LOH 32)		Diesel		10518	294	400	10.15-	■	■
FRH 352,RH 353 (D 2866 LOH 26)		Diesel		11967	257	350	06.96-10.01	■	■
FRH 402,RH 403 (D 2866 LOH 23)		Diesel		11967	294	400	09.95-	■	■
RH 403 (D 2866 LOH 23)		Diesel		11967	294	400	09.98-	■	■
RH 413 (D 2866 LOH 29)		Diesel		11967	301	410	01.00-	■	■
RHC 414 (D 2866 LOH 34)		Diesel		11967	301	410	06.02-	■	■
420		Diesel		12419	309	420	10.16-	■	■
430		Diesel		12419	316	430	08.19-	■	■
440 (D 2676 LOH 30)		Diesel		12419	323	439	10.15-	■	■
C 440, L 440 (D 2676 LOH 30)		Diesel		12419	323	439	10.15-	■	■
460		Diesel		12419	338	460	10.16-	■	■
L 460		Diesel		12419	338	460	10.16-	■	■
470		Diesel		12419	346	470	08.19-	■	■
L 470		Diesel		12419	346	470	08.19-	■	■
C 480, L 480 (D 2676 LOH 31)		Diesel		12419	353	480	10.15-	■	■
L 500		Diesel		12419	368	500	10.16-	■	■
L 505		Diesel		12419	371	504	08.12-	■	■
L 510		Diesel		12419	375	510	08.19-	■	■
RH 463, RHC 464 (D 2876 LOH 01)		Diesel		12816	338	460	01.00-	■	■
RH 463, RHC 464 (D 2876 LOH 02)		Diesel		12816	338	460	01.00-	■	■
RH 463, RHC 464 (D 2876 LOH 03)		Diesel		12816	338	460	01.00-	■	■
LION'S COMFORT 09.96-								Bus	
RN 313 (D 2866 LUH 20)		Diesel		11967	228	310	09.96-	■	■
RN 313 (D 2866 LUH26)		Diesel		11967	228	310	09.96-	■	■
RN 353 (D 2866 LUH 21)		Diesel		11967	257	350	06.97-	■	■
LION'S STAR 03.91-								Bus	
FRH 352,RH 353 (D 2866 LOH 26)		Diesel		11967	257	350	09.95-02.02	■	■
FRH 402,RH 403 (D 2866 LOH 23)		Diesel		11967	294	400	09.95-10.01	■	■
RH 414, RHS 414 (D 2866 LOH 34)		Diesel		11967	301	410	06.00-04.07	■	■
RH 414, RHS 414 (D 2866 LOH 34)		Diesel		11967	301	410	06.00-04.07	■	■
FRH 422 (D 2866 LOH 20)		Diesel		11967	309	420	01.93-09.96	■	■
RH 464, RHS 464 (D 2876 LOH 03)		Diesel		12816	338	460	06.00-04.07	■	■
RH 464, RHS 464 (D 2876 LOH 03)		Diesel		12816	338	460	06.00-04.07	■	■
RH 484, RHS 484		Diesel		12816	353	480	08.04-04.07	■	■
RH 484, RHS 484		Diesel		12816	353	480	08.04-04.07	■	■
M 2000 L 04.95-								Concrete Mixer	
26.284 DL-TM, DLR-TM		Diesel		6871	206	280	05.01-	■	■
26.285 DL-TM, DLR-TM		Diesel		6871	206	280	05.01-	■	■

LISTA DE APLICACIONES - BUYERS GUIDE

M 2000 L 04.95-					Dump Truck			
14.163		Diesel		4580	118	160	04.95-03.05	■
15.163		Diesel		4580	118	160	07.95-04.02	■
14.224 LAK, LARK, LAK-L (D 0826 LFL03)		Diesel		6871	162	220	08.95-	■
14.224 LAK, LARK, LAK-L (D 0826 LFL10)		Diesel		6871	162	220	08.95-	■
14.224 LK, LRK (D 0826 LFL03)		Diesel		6871	162	220	08.95-	■
14.224 LK, LRK (D 0826 LFL10)		Diesel		6871	162	220	08.95-	■
15.224 LK, LRK, LK-L (D 0826 LFL03)		Diesel		6871	162	220	08.95-	■
15.224 LK, LRK, LK-L (D 0826 LFL10)		Diesel		6871	162	220	08.95-	■
18.224, 18.225, LAK, LARK, LAK-L (D 0826 LFL03)		Diesel		6871	162	220	08.95-	■
18.224, 18.225, LAK, LARK, LAK-L (D 0826 LFL10)		Diesel		6871	162	220	08.95-	■
18.224, 18.225, LK, LK-L, LLK, LLK-L, LLRK, LRK (D 0826 LFL03)		Diesel		6871	162	220	08.95-	■
18.224, 18.225, LK, LK-L, LLK, LLK-L, LLRK, LRK (D 0826 LFL10)		Diesel		6871	162	220	08.95-	■
19.224		Diesel		6871	162	220	04.95-08.06	■
19.225		Diesel		6871	162	220	04.95-08.06	■
18.255 LAK, LARK, LAK-L		Diesel		6871	180	245	05.01-	■ ■
18.255 LK, LK-L, LLK, LLK-L, LLRK, LRK		Diesel		6871	180	245	11.02-	■ ■
19.255		Diesel		6871	180	245	04.95-08.06	■
26.224, 26.225, DL-HK, DLR-HK		Diesel		6871	180	245	11.02-	■ ■
26.255 DL-HK, DLR-HK		Diesel		6871	180	245	11.02-	■ ■
18.255		Diesel		6871	188	256	03.95-02.07	■
19.255		Diesel		6871	188	256	04.95-08.06	■
26.255		Diesel		6871	188	256	01.99-08.06	■
14.263, 14.264 LAK, LARK, LAK-L (D 0826 LFL09)		Diesel		6871	191	260	08.95-	■
14.263, 14.264 LK, LRK (D 0826 LFL09)		Diesel		6871	191	260	08.95-	■
15.263, 15.264 LK, LRK, LK-L (D 0826 LFL09)		Diesel		6871	191	260	08.95-	■
18.263, 18.264, LAK, LARK, LAK-L (D 0826 LFL09)		Diesel		6871	191	260	08.95-	■
18.263, 18.264, LK, LK-L, LLK, LLK-L, LLRK, LRK (D 0826 LFL09)		Diesel		6871	191	260	08.95-	■
19.264		Diesel		6871	191	260	04.95-08.06	■
18.263		Diesel		6871	196	266	03.95-04.02	■
18.264		Diesel		6871	196	266	03.95-02.07	■
19.264		Diesel		6871	196	266	04.95-08.06	■
14.284, 14.285, LAK, LARK, LAK-L (D 0836 LF 01)		Diesel		6871	206	280	06.98-	■
14.284, 14.285, LK, LRK (D 0836 LF 01)		Diesel		6871	206	280	10.98-	■
15.284 LK, LRK, LK-L (D 0836 LF 01)		Diesel		6871	206	280	06.98-	■
18.284, 18.285, LK, LK-L, LLK, LLK-L, LLRK, LRK (D 0836 LF 01)		Diesel		6871	206	280	06.98-	■
18.284 LAK, LARK, LAK-L (D 0836 LF 01)		Diesel		6871	206	280	06.98-	■
18.285 LAK, LARK, LAK-L, (LE280B) (D 0836 LFL 03)		Diesel		6871	206	280	09.99-	■ ■
19.284		Diesel		6871	206	280	04.95-08.06	■
19.285		Diesel		6871	206	280	04.95-08.06	■
26.284, 26.285, DL-HK, DLR-HK		Diesel		6871	206	280	11.02-	■ ■
M 2000 L 04.95-					Municipal Vehicle			
18.224, 18.225, L-KO, LR-KO		Diesel		6871	162	220	05.01-	■
18.255 L-KO, LR-KO		Diesel		6871	180	245	05.01-	■
18.255		Diesel		6871	188	256	03.95-02.07	■
18.263		Diesel		6871	191	260	03.95-04.02	■

LISTA DE APLICACIONES - BUYERS GUIDE

18.263, 18.264, L-KO, LR-KO	Diesel		6871	191	260	05.01-	■
18.263	Diesel		6871	196	266	03.95-04.02	■
18.264	Diesel		6871	196	266	03.95-02.07	■
14.284, 14.285, LA-LF (D 0836 LF 01)	Diesel		6871	206	280	06.98-	■
18.284, 18.285, L-KO, LR-KO (D 0836 LF 01)	Diesel		6871	206	280	06.98-	■
18.285	Diesel		6871	206	280	03.95-02.07	■
M 2000 L 04.95-							Platform/Chassis
15.163 LC, LLC, LLLC, LLLRC, LLRC, LRC (D 0824 LFL 06)	Diesel		4580	114	155	08.95-	■
15.163 LC, LLC, LLLC, LLLRC, LLRC, LRC (D 0824 LFL 09)	Diesel		4580	114	155	08.95-	■
14.163	Diesel		4580	118	160	04.95-03.05	■
14.163	Diesel		4580	118	160	02.97-04.01	■
15.163	Diesel		4580	118	160	07.95-04.02	■
15.185 LC, LLC, LLLC, LLLRC, LLRC, LRC	Diesel		4580	132	180	05.01-	■
14.224 LAC, LARC (D 0826 LFL03)	Diesel		6871	162	220	08.95-	■
14.224 LAC, LARC (D 0826 LFL10)	Diesel		6871	162	220	08.95-	■
15.224 LC, LLC, LLLC, LRC, LLRC, LLLRC (D 0826 LFL03)	Diesel		6871	162	220	08.95-	■
15.224 LC, LLC, LLLC, LRC, LLRC, LLLRC (D 0826 LFL10)	Diesel		6871	162	220	08.95-	■
15.225 LC, LLC, LLLC, LRC, LLRC, LLLRC, (LE220B) (D 0836 LFL 02)	Diesel		6871	162	220	09.99-	■
18.224, 18.225, LAC, LARC (D 0826 LFL03)	Diesel		6871	162	220	08.95-	■
18.224, 18.225, LAC, LARC (D 0826 LFL10)	Diesel		6871	162	220	08.95-	■
18.224, 18.225, LAC, LARC (D 0836 LFL 02)	Diesel		6871	162	220	08.95-	■
18.224, 18.225, LC, LLC, LLLC, LRC, LLRC, LLLRC (D 0826 LFL03)	Diesel		6871	162	220	08.95-	■
18.224, 18.225, LC, LLC, LLLC, LRC, LLRC, LLLRC (D 0826 LFL10)	Diesel		6871	162	220	08.95-	■
18.224, 18.225, LC, LLC, LLLC, LRC, LLRC, LLLRC (D 0836 LFL 02)	Diesel		6871	162	220	08.95-	■
19.224, 19.225, LC, LLC, LLLC, LLLRC, LLRC, LRC	Diesel		6871	162	224	05.01-	■
20.224, 20.225 LNLC, LNLLC	Diesel		6871	162	224	05.01-	■
20.224 LNLC, LNLLC	Diesel		6871	162	224	05.01-	■
26.224	Diesel		6871	162	220	01.99-02.07	■
26.225	Diesel		6871	162	220	01.99-02.07	■
15.255 LC, LLC, LLLC, LRC, LLRC, LLLRC, (LE250B) (D 0836 LFL 05)	Diesel		6871	180	245	09.99-	■
18.255 LAC, LARC (D 0836 LFL 05)	Diesel		6871	180	245	05.01-	■
18.255 LC, LLC, LLLC, LRC, LLRC, LLLRC, (LE250B) (D 0836 LFL 05)	Diesel		6871	180	245	09.99-	■
19.255 LC, LLC, LLLC, LLLRC, LLRC, LRC	Diesel		6871	180	245	05.01-	■
20.255 LNLC, LNLLC	Diesel		6871	180	245	05.01-	■
26.255	Diesel		6871	180	245	01.99-02.07	■
15.255	Diesel		6871	188	256	04.95-08.06	■
18.255	Diesel		6871	188	256	03.95-02.07	■
19.255	Diesel		6871	188	256	04.95-08.06	■
20.255	Diesel		6871	188	256	07.95-08.06	■
26.255	Diesel		6871	188	256	01.99-08.06	■
14.263, 14.264 LAC, LARC (D 0826 LFL09)	Diesel		6871	191	260	08.95-	■
15.263, 15.264 LC, LLC, LLLC, LRC, LLRC, LLLRC (D 0826 LFL09)	Diesel		6871	191	260	08.95-	■
18.263, 18.264, LAC, LARC (D 0826 LFL09)	Diesel		6871	191	260	08.95-	■
18.263, 18.264, LC, LLC, LLLC, LRC, LLRC, LLLRC (D 0826 LFL09)	Diesel		6871	191	260	08.95-	■
19.264 LC, LLC, LLLC, LLLRC, LLRC, LRC	Diesel		6871	191	260	05.01-	■

LISTA DE APLICACIONES - BUYERS GUIDE

20.264 LNLC, LNLLC		Diesel		6871	191	260	05.01-	■
15.263		Diesel		6871	196	266	04.95-08.06	■
15.264		Diesel		6871	196	266	04.95-08.06	■
18.263		Diesel		6871	196	266	03.95-04.02	■
18.264		Diesel		6871	196	266	03.95-02.07	■
19.264		Diesel		6871	196	266	04.95-08.06	■
20.264		Diesel		6871	196	266	07.95-08.06	■
14.284, 14.285, LAC, LARC (D 0836 LF 01)		Diesel		6871	206	280	06.98-	■
15.284 LC, LLC, LLLC, LRC, LLRC, LLLRC (D 0836 LF 01)		Diesel		6871	206	280	06.98-	■
15.285 LC, LLC, LLLC, LRC, LLRC, LLLRC, (LE280B) (D 0836 LFL 03)		Diesel		6871	206	280	09.99-	■
18.284 LAC, LARC (D 0836 LF 01)		Diesel		6871	206	280	06.98-	■
18.284 LC, LLC, LLLC, LRC, LLRC, LLLRC (D 0836 LF 01)		Diesel		6871	206	280	06.98-	■
18.285 LAC, LARC (LE280B) (D 0836 LFL 03)		Diesel		6871	206	280	09.99-	■ ■
18.285 LC, LLC, LLLC, LRC, LLRC, LLLRC, (LE280B) (D 0836 LFL 03)		Diesel		6871	206	280	09.99-	■
19.284, 19.285, LC, LLC, LLLC, LLLRC, LLRC, LRC (D 0836 LFL 03)		Diesel		6871	206	280	05.01-	■
20.284, 20.285, LNLC, LNLLC		Diesel		6871	206	280	05.01-	■
26.284		Diesel		6871	206	280	01.99-02.07	■
26.285		Diesel		6871	206	280	01.99-02.07	■
M 2000 M 08.95-12.05								Dump Truck
14.224 MAK, MAK-L, MARK (D 0826 LF15)		Diesel		6871	162	220	08.95-12.05	■
14.224 MAK, MAK-L, MARK (D 0826 LF18)		Diesel		6871	162	220	08.95-12.05	■
14.224 MK (D 0826 LF15)		Diesel		6871	162	220	08.95-12.05	■
14.224 MK (D 0826 LF18)		Diesel		6871	162	220	08.95-12.05	■
18.224 MAK, MAK-L, MARK (D 0826 LF15)		Diesel		6871	162	220	08.95-12.05	■
18.224 MAK, MAK-L, MARK (D 0826 LF18)		Diesel		6871	162	220	08.95-12.05	■
18.224 MK, MK-L, MLK, MLRK, MRK (D 0826 LF15)		Diesel		6871	162	220	08.95-12.05	■
18.224 MK, MK-L, MLK, MLRK, MRK (D 0826 LF18)		Diesel		6871	162	220	08.95-12.05	■
18.225 MK, MK-L, MLK, MLRK, MRK		Diesel		6871	162	220	10.00-12.05	■ ■
18.255 MAK, MAK-L, MARK		Diesel		6871	180	245	10.00-12.05	■ ■
18.255 MK, MK-L, MLK, MLRK, MRK		Diesel		6871	180	245	11.02-12.05	■ ■
18.264 MAK, MAK-L, MARK (D 0826 LF17)		Diesel		6871	191	260	08.95-12.05	■
18.264 MK, MK-L, MLK, MLRK, MRK (D 0826 LF17)		Diesel		6871	191	260	08.95-12.05	■
18.264		Diesel		6871	196	266	03.95-07.05	■
14.284 MAK, MAK-L, MARK (D 0836 LF 01)		Diesel		6871	206	280	06.98-12.05	■
18.284 MAK, MAK-L, MARK (D 0836 LF 01)		Diesel		6871	206	280	06.98-12.05	■
18.284 MK, MK-L, MLK, MLRK, MRK (D 0836 LF 01)		Diesel		6871	206	280	06.98-12.05	■
18.285 MK, MK-L, MLK, MLRK, MRK		Diesel		6871	206	280	02.03-12.05	■ ■
M 2000 M 08.95-12.05								Municipal Vehicle
18.224 M-KO, MR-KO		Diesel		6871	162	220	02.00-12.05	■
18.225 M-KO, MR-KO		Diesel		6871	162	220	02.03-12.05	■
18.255 M-KO, MR-KO		Diesel		6871	180	245	10.00-12.05	■
18.264 M-KO, MR-KO		Diesel		6871	191	260	02.00-12.05	■
18.264		Diesel		6871	196	266	03.95-07.05	■
14.284 MA-KO, MA-LF (D 0836 LF 01)		Diesel		6871	206	280	06.98-12.05	■
18.284 M-KO, MR-KO		Diesel		6871	206	280	02.00-12.05	■
18.285 M-KO, MR-KO		Diesel		6871	206	280	02.03-12.05	■

LISTA DE APLICACIONES - BUYERS GUIDE

M 2000 M 08.95-12.05					Platform/Chassis			
18.224 MAC, MARC (D 0826 LF15)	Diesel		6871	162	220	08.95-12.05	■	
18.224 MAC, MARC (D 0826 LF18)	Diesel		6871	162	220	08.95-12.05	■	
18.224 MC, MLC, MLLC, MRC, MLRC, MLLRC (D 0826 LF15)	Diesel		6871	162	220	08.95-12.05	■	
18.224 MC, MLC, MLLC, MRC, MLRC, MLLRC (D 0826 LF18)	Diesel		6871	162	220	08.95-12.05	■	
23.224	Diesel		6871	162	220	05.95-07.05	■	
23.225	Diesel		6871	162	220	05.95-07.05	■	
25.224 MNLC, MNLLC, MNLRC, MNLLRC, MVLC (D 0826 LF15)	Diesel		6871	162	220	08.95-12.05	■	
25.224 MNLC, MNLLC, MNLRC, MNLLRC, MVLC (D 0826 LF18)	Diesel		6871	162	220	08.95-12.05	■	
25.224 MNLC, MNLLC, MNLRC, MNLLRC, MVLC (D 0826 LFL10)	Diesel		6871	162	220	08.95-12.05	■	
26.224	Diesel		6871	162	220	05.95-03.04	■	
26.225	Diesel		6871	162	220	05.95-03.04	■	
18.255 MAC, MARC (D 0836 LF 05)	Diesel		6871	180	245	10.00-12.05	■	
18.255 MC, MLC, MLLC, MLRC, MRC, MLLRC (D 0836 LF 05)	Diesel		6871	180	245	10.00-12.05	■	
23.255	Diesel		6871	180	245	05.95-07.05	■	
25.255 MNLC, MNLLC, MNLRC, MNLLRC, MVLC (D 0836 LF 05)	Diesel		6871	180	245	10.00-12.05	■	
25.255 MNLC, MNLLC, MNLRC, MNLLRC, MVLC (D 0836 LFL 05)	Diesel		6871	180	245	10.00-12.05	■	
26.255	Diesel		6871	180	245	05.95-03.04	■	
18.264 MAC, MARC (D 0826 LF17)	Diesel		6871	191	260	08.95-12.05	■	
18.264 MC, MLC, MLLC, MRC, MLRC, MLLRC (D 0826 LF17)	Diesel		6871	191	260	08.95-12.05	■	
23.264	Diesel		6871	191	260	05.95-07.05	■	
25.264 MNLC, MNLLC, MNLRC, MNLLRC, MVLC (D 0826 LF17)	Diesel		6871	191	260	08.95-12.05	■	
18.264	Diesel		6871	196	266	03.95-07.05	■	
23.264	Diesel		6871	196	266	05.95-07.05	■	
25.264	Diesel		6871	196	266	05.95-07.05	■	
25.264	Diesel		6871	196	266	05.95-03.04	■	
18.284 MAC, MARC (D 0836 LF 01)	Diesel		6871	206	280	06.98-12.05	■	
18.284 MC, MLC, MLLC, MLRC, MRC, MLLRC (D 0836 LF 01)	Diesel		6871	206	280	06.98-12.05	■	
23.284	Diesel		6871	206	280	05.95-07.05	■	
23.285	Diesel		6871	206	280	05.95-07.05	■	
25.284 MNLC, MNLLC, MNLRC, MNLLRC, MVLC (D 0836 LF 01)	Diesel		6871	206	280	02.00-12.05	■	
26.284	Diesel		6871	206	280	05.95-03.04	■	
26.285	Diesel		6871	206	280	05.95-03.04	■	
M 2000 M 08.95-12.05					Truck Tractor			
18.224 MLS, MLRS (D 0826 LF15)	Diesel		6871	162	220	08.95-12.05	■	
18.224 MLS, MLRS (D 0826 LF18)	Diesel		6871	162	220	08.95-12.05	■	
18.225 MLS, MLRS	Diesel		6871	162	220	02.03-12.05	■	
18.255 MLS, MLRS (D 0836 LF 05)	Diesel		6871	180	245	10.00-12.05	■	
18.264 MLS, MLRS (D 0826 LF17)	Diesel		6871	191	260	08.95-12.05	■	
18.264	Diesel		6871	196	266	04.95-07.05	■	
18.284 MLS, MLRS (D 0836 LF 01)	Diesel		6871	206	280	06.98-12.05	■	
NG 08.92-					Bus			
NG 262, NG 272 (D 0826 LUH 01)	Diesel		6871	191	260	08.92-07.98	■ ■	
NG 262 (D 2865 LUH09)	Diesel		9973	191	260	06.97-07.98	■ ■	
NG 312 (D 2865 LUH07)	Diesel		9973	228	310	09.95-07.98	■ ■	

LISTA DE APLICACIONES - BUYERS GUIDE

NG 313 (D 2066 LUH 12)		Diesel		10518	228	310	01.06-10.09	■	
NG 313 (D 2066 LUH 22)		Diesel		10518	228	310	01.06-10.09	■	
NG 323 (D 2066 LUH 42)		Diesel		10518	235	320	05.07-12.14	■	
NG 353 (D 2066 LUH 13)		Diesel		10518	257	350	05.07-12.14	■	
NG 353 (D 2066 LUH 23)		Diesel		10518	257	350	05.07-12.14	■	
NG 363 (D 2066 LUH 48)		Diesel		10518	264	360	05.07-12.14	■	
NG 262, NG 263 (D 2866 LUH 22)		Diesel		11967	191	260	07.98-	■	■
NG 312, NG 313 (D 2866 LUH26)		Diesel		11967	228	310	07.98-	■	■
NG 08.92-								Bus	
NG 313 (E 2876 LUH 02)		Gasolina		12816	228	310	05.07-12.14	■	
NL 09.88-								Bus	
210		Diesel		6871	157	213	08.91-10.97	■	■
NL 202, NL 222, NL 223 (D 0826 LUH 03)		Diesel		6871	157	214	08.92-	■	■
NL 202, NL 222, NL 223 (D 0826 LUH 12)		Diesel		6871	157	214	08.92-	■	■
220		Diesel		6871	162	220	05.95-07.02	■	■
240		Diesel		6871	176	239	06.03-12.04	■	■
250		Diesel		6871	184	250	08.91-10.97	■	■
252		Diesel		6871	184	250	08.91-10.97	■	■
NL 202, NL 262, NL 263 (D 0826 LUH)		Diesel		6871	184	250	04.91-	■	■
260		Diesel		6871	191	260	05.95-10.01	■	■
262		Diesel		6871	191	260	05.95-02.01	■	■
280		Diesel		6871	206	280	05.00-12.04	■	■
280		Diesel		6871	206	280	06.03-12.04	■	■
262		Diesel		9973	191	260	09.91-09.00	■	■
NL 262 (D 2865 LUH09)		Diesel		9973	191	260	06.97-	■	■
270		Diesel		9973	198	269	09.91-10.97	■	■
NL 312 (D 2865 LUH07)		Diesel		9973	228	310	11.95-07.98	■	■
320		Diesel		9973	235	320	09.91-10.97	■	■
NL 273 (D 2066 LUH 11)		Diesel		10518	199	271	01.06-10.09	■	■
NL 273 (D 2066 LUH 21)		Diesel		10518	199	271	01.06-10.09	■	■
NL 283 (D 2066 LUH 41)		Diesel		10518	206	280	08.12-	■	
NL 313 (D 2066 LUH 12)		Diesel		10518	228	310	01.06-10.09	■	
NL 313 (D 2066 LUH 22)		Diesel		10518	228	310	01.06-10.09	■	
NL 323 (D 2066 LUH 42)		Diesel		10518	235	320	05.07-	■	
260		Diesel		11967	191	260	02.96-10.01	■	■
263		Diesel		11967	191	260	06.96-10.01	■	■
263		Diesel		11967	191	260	05.99-06.02	■	■
NL 262, NL 263 (D 2866 LUH 22)		Diesel		11967	191	260	07.98-	■	■
313		Diesel		11967	228	310	06.96-10.01	■	■
NL 313 (D 2866 LUH26)		Diesel		11967	228	310	07.98-	■	
NL 09.88-								Bus	
NL 243 (E 2866 DUH 03)		Gasolina		11967	180	245	05.07-12.14	■	■
NL 243 (E 2866 DUH 04)		Gasolina		11967	180	245	05.07-12.14	■	■
NL 313 (E 2876 LUH 02)		Gasolina		12816	228	310	05.07-12.14	■	
NL 09.88-								Bus	
313		Diesel		11967	230	313	01.95-10.97	■	■
350		Diesel		11967	257	349	01.95-10.01	■	■
370		Diesel		11967	272	370	01.92-10.97	■	■
400		Diesel		11967	294	400	01.95-03.08	■	■
420		Diesel		11967	309	420	01.92-10.97	■	■

LISTA DE APLICACIONES - BUYERS GUIDE

460		Diesel		12816	338	460	05.99-02.07	■	■
NM 08.87-								Bus	
NM 222, NM 223 (D 0826 LOH 15)		Diesel		6871	162	220	02.96-	■	
NM 222, NM 223 (D 0826 LUH 12)		Diesel		6871	162	220	02.96-	■	
NÜ 03.96-								Bus	
NÜ 263 (D 0826 LUH 13)		Diesel		6871	191	260	07.98-	■	■
NÜ 263 (D 2865 LUH09)		Diesel		9973	191	260	09.96-07.98	■	■
NÜ 263 (D 2866 LUH 22)		Diesel		11967	191	260	07.98-	■	■
NÜ 313 (D 2866 LUH26)		Diesel		11967	228	310	07.98-	■	■
NÜ 313 15M (D 2866 LUH26)		Diesel		11967	228	310	07.98-	■	■
NÜ 353 15M (D 2866 LUH 21)		Diesel		11967	257	350	07.98-	■	■
TGA 03.00-								Concrete Mixer	
26.310		Diesel		10518	228	310	09.01-09.08	■	■
50.350		Diesel		10518	257	349	04.03-09.08	■	■
33.350		Diesel		10518	265	360	09.01-03.11	■	■
35.350		Diesel		10518	265	360	06.05-09.08	■	■
50.350		Diesel		10518	265	360	04.03-09.08	■	■
50.360		Diesel		10518	265	360	04.03-09.08	■	■
50.390		Diesel		10518	287	390	04.03-09.08	■	■
50.400		Diesel		10518	294	400	04.03-09.08	■	■
33.430 (D 2066 LF 01)		Diesel		10518	316	430	09.07-	■	
50.430		Diesel		10518	316	430	04.03-09.08	■	■
26.440		Diesel		10518	321	436	09.01-09.08	■	■
32.440		Diesel		10518	321	436	01.04-09.08	■	■
33.440		Diesel		10518	321	436	09.01-03.11	■	■
35.440		Diesel		10518	321	436	03.03-09.08	■	■
37.440		Diesel		10518	321	436	04.03-09.08	■	■
41.440		Diesel		10518	321	436	04.03-03.11	■	■
50.440		Diesel		10518	321	436	04.03-09.08	■	■
33.440		Diesel		10518	324	441	09.01-03.11	■	■
50.440		Diesel		10518	324	441	04.03-09.08	■	■
26.310 (D 2866 LF26)		Diesel		11967	228	310	10.00-	■	
26.360 (D 2866 LF27)		Diesel		11967	265	360	01.01-	■	
33.360 (D 2866 LF27)		Diesel		11967	265	360	01.01-	■	
50.360		Diesel		11967	265	360	08.01-05.07	■	■
26.410 (D 2866 LF28)		Diesel		11967	301	410	01.01-	■	
33.410 (D 2866 LF28)		Diesel		11967	301	410	10.00-	■	
50.410		Diesel		11967	301	409	08.01-05.07	■	■
50.480		Diesel		12419	353	480	03.06-09.08	■	■
26.460 (D 2876 LF 04)		Diesel		12816	338	460	01.01-	■	
26.460 (D 2876 LF 07)		Diesel		12816	338	460	01.01-	■	
50.460		Diesel		12816	338	460	08.01-05.07	■	■
50.480		Diesel		12816	353	480	04.02-05.07	■	■
26.510		Diesel		12816	375	510	01.01-07.07	■	■
33.510		Diesel		12816	375	510	01.01-07.07	■	■
26.530		Diesel		12816	390	530	04.02-07.07	■	■
33.530		Diesel		12816	390	530	04.02-07.07	■	■
50.530		Diesel		12816	390	530	04.02-05.07	■	■
TGA 03.00-								Dump Truck	
32.350		Diesel		10518	257	349	01.04-09.08	■	■

LISTA DE APLICACIONES - BUYERS GUIDE

50.350		Diesel		10518	257	349	04.03-09.08	■	■
28.350		Diesel		10518	265	360	01.04-10.08	■	■
32.350		Diesel		10518	265	360	01.04-09.08	■	■
32.360		Diesel		10518	265	360	01.04-09.08	■	■
35.350		Diesel		10518	265	360	06.05-09.08	■	■
50.350		Diesel		10518	265	360	04.03-09.08	■	■
50.360		Diesel		10518	265	360	04.03-09.08	■	■
32.390		Diesel		10518	287	390	01.04-09.08	■	■
50.390		Diesel		10518	287	390	04.03-09.08	■	■
28.400		Diesel		10518	294	400	01.04-10.08	■	■
32.400		Diesel		10518	294	400	01.04-09.08	■	■
50.400		Diesel		10518	294	400	04.03-09.08	■	■
32.430		Diesel		10518	316	430	01.04-09.08	■	■
50.430		Diesel		10518	316	430	04.03-09.08	■	■
18.440		Diesel		10518	321	436	08.01-09.08	■	■
18.440		Diesel		10518	321	436	05.03-03.09	■	
26.440		Diesel		10518	321	436	09.01-09.08	■	■
28.440		Diesel		10518	321	436	01.04-10.08	■	■
32.440		Diesel		10518	321	436	01.04-09.08	■	■
33.440		Diesel		10518	321	436	09.01-03.11	■	■
35.440		Diesel		10518	321	436	06.05-09.08	■	■
35.440		Diesel		10518	321	436	09.03-10.08	■	■
35.440		Diesel		10518	321	436	03.03-09.08	■	■
37.440		Diesel		10518	321	436	04.03-09.08	■	■
40.440		Diesel		10518	321	436	01.05-03.11	■	■
41.440		Diesel		10518	321	436	08.03-10.08	■	■
41.440		Diesel		10518	321	436	09.03-10.08	■	■
41.440		Diesel		10518	321	436	04.03-03.11	■	■
50.440		Diesel		10518	321	436	04.03-09.08	■	■
32.440		Diesel		10518	324	441	01.04-09.08	■	■
35.440		Diesel		10518	324	440	07.06-	■	
40.440		Diesel		10518	324	441	01.05-03.11	■	■
50.440		Diesel		10518	324	441	04.03-09.08	■	■
18.310, 18.320 (D 2866 LF26)		Diesel		11967	228	310	12.00-	■	■
18.310, 18.320 (D 2866 LF36)		Diesel		11967	228	310	12.00-	■	■
18.360 (D 2866 LF27)		Diesel		11967	265	360	12.00-	■	■
18.360 (D 2866 LF37)		Diesel		11967	265	360	12.00-	■	■
33.360 (D 2866 LF27)		Diesel		11967	265	360	01.01-	■	
33.360 (D 2866 LF37)		Diesel		11967	265	360	01.01-	■	
50.360		Diesel		11967	265	360	08.01-03.09	■	■
18.410, 18.420 (D 2866 LF28)		Diesel		11967	301	410	12.00-	■	■
18.410, 18.420 (D 2866 LF32)		Diesel		11967	301	410	12.00-	■	■
26.410 (D 2866 LF28)		Diesel		11967	301	410	09.01-	■	
26.410 (D 2866 LF32)		Diesel		11967	301	410	09.01-	■	
26.410 (D 2866 LF28)		Diesel		11967	301	410	02.02-	■	
33.410 (D 2866 LF28)		Diesel		11967	301	410	10.00-	■	
33.410 (D 2866 LF32)		Diesel		11967	301	410	10.00-	■	
50.410		Diesel		11967	301	409	08.01-03.09	■	■
32.480		Diesel		12419	353	480	03.06-09.08	■	■
50.480		Diesel		12419	353	480	03.06-09.08	■	■
18.540		Diesel		12419	397	540	03.06-09.08	■	■

LISTA DE APLICACIONES - BUYERS GUIDE

18.460 (D 2876 LF 04)		Diesel		12816	338	460	12.00-	■	■
18.460 (D 2876 LF 07)		Diesel		12816	338	460	12.00-	■	■
26.460 (D 2876 LF 04)		Diesel		12816	338	460	01.01-	■	■
26.460 (D 2876 LF 07)		Diesel		12816	338	460	01.01-	■	■
50.460		Diesel		12816	338	460	11.99-03.09	■	■
50.480		Diesel		12816	353	480	04.02-03.09	■	■
18.510		Diesel		12816	375	510	06.99-03.09	■	■
26.510		Diesel		12816	375	510	01.01-03.08	■	■
33.510		Diesel		12816	375	510	01.01-03.08	■	■
50.510		Diesel		12816	375	510	01.03-03.09	■	■
18.530		Diesel		12816	390	530	04.02-03.09	■	■
50.530		Diesel		12816	390	530	04.02-03.09	■	■
TGA 03.00-							Municipal Vehicle		
26.350		Diesel		10518	257	349	07.04-09.08	■	■
26.350		Diesel		10518	257	349	03.03-03.09	■	■
26.350		Diesel		10518	265	360	03.03-03.09	■	■
26.350		Diesel		10518	265	360	03.03-03.09	■	■
26.350		Diesel		10518	265	360	07.04-09.08	■	■
26.360		Diesel		10518	265	360	03.03-03.09	■	■
26.360		Diesel		10518	265	360	07.04-09.08	■	■
26.360		Diesel		10518	265	360	03.03-03.09	■	■
26.390		Diesel		10518	287	390	07.04-09.08	■	■
26.390		Diesel		10518	287	390	03.03-03.09	■	■
26.400		Diesel		10518	294	400	03.03-03.09	■	■
26.400		Diesel		10518	294	400	07.04-09.08	■	■
26.430		Diesel		10518	316	430	07.04-09.08	■	■
26.430		Diesel		10518	316	430	03.03-03.09	■	■
26.430, 26.440		Diesel		10518	316	430	06.05-	■	■
26.440		Diesel		10518	321	436	07.04-09.08	■	■
26.440		Diesel		10518	321	436	07.04-09.08	■	■
26.440		Diesel		10518	321	436	03.03-03.09	■	■
26.440		Diesel		10518	324	441	03.03-03.09	■	■
26.440		Diesel		10518	324	441	07.04-09.08	■	■
26.310 (D 2866 LF26)		Diesel		11967	228	310	12.00-	■	■
26.310 (D 2866 LF36)		Diesel		11967	228	310	12.00-	■	■
26.310		Diesel		11967	228	310	03.00-05.07	■	■
26.360 (D 2866 LF27)		Diesel		11967	265	360	12.00-	■	■
26.360 (D 2866 LF37)		Diesel		11967	265	360	12.00-	■	■
26.360		Diesel		11967	265	360	03.00-05.07	■	■
26.410 (D 2866 LF28)		Diesel		11967	301	410	12.00-	■	■
26.410 (D 2866 LF32)		Diesel		11967	301	410	12.00-	■	■
26.410		Diesel		11967	301	409	03.00-05.07	■	■
26.480		Diesel		12419	353	480	03.06-03.09	■	■
26.480		Diesel		12419	353	480	03.06-09.08	■	■
26.460 (D 2876 LF 04)		Diesel		12816	338	460	12.00-	■	■
26.460 (D 2876 LF 07)		Diesel		12816	338	460	12.00-	■	■
26.460		Diesel		12816	338	460	03.00-05.07	■	■
26.480		Diesel		12816	353	480	04.02-05.07	■	■
TGA 03.00-							Platform/Chassis		
18.280		Diesel		6871	206	280	03.01-09.01	■	■
18.330		Diesel		6871	240	326	03.01-09.01	■	■

LISTA DE APLICACIONES - BUYERS GUIDE

26.310		Diesel		10518	228	310	07.04-09.08	■	■
28.310		Diesel		10518	228	310	07.06-	■	
28.320		Diesel		10518	228	310	07.06-	■	■
26.320		Diesel		10518	235	320	07.04-09.08	■	■
28.350, 28.360		Diesel		10518	257	350	06.04-	■	■
35.350		Diesel		10518	257	349	03.03-09.08	■	■
35.350		Diesel		10518	257	349	06.05-09.08	■	■
35.350		Diesel		10518	257	349	04.03-10.08	■	■
50.350		Diesel		10518	257	349	04.03-09.08	■	■
26.350		Diesel		10518	265	360	03.03-03.09	■	■
26.350		Diesel		10518	265	360	07.04-09.08	■	■
28.350		Diesel		10518	265	360	07.03-10.08	■	■
28.350		Diesel		10518	265	360	09.02-10.08	■	■
28.350		Diesel		10518	265	360	01.04-10.08	■	■
35.350		Diesel		10518	265	360	04.03-10.08	■	■
35.350		Diesel		10518	265	360	04.03-10.08	■	■
35.350		Diesel		10518	265	360	06.05-09.08	■	■
35.360		Diesel		10518	265	360	07.06-	■	
35.360		Diesel		10518	265	360	06.05-09.08	■	■
35.360		Diesel		10518	265	360	04.03-10.08	■	■
50.350		Diesel		10518	265	360	04.03-09.08	■	■
50.360		Diesel		10518	265	360	04.03-09.08	■	■
26.390		Diesel		10518	287	390	07.04-09.08	■	■
28.390 (D 2066 LF 02)		Diesel		10518	287	390	07.06-	■	
28.390 (D 2066 LF 12)		Diesel		10518	287	390	07.06-	■	
28.390, 28.400		Diesel		10518	287	390	06.04-	■	■
35.390		Diesel		10518	287	390	08.03-10.08	■	■
35.390		Diesel		10518	287	390	04.03-10.08	■	■
50.390		Diesel		10518	287	390	04.03-09.08	■	■
26.400		Diesel		10518	294	400	07.04-09.08	■	■
28.400 (D 2066 LF 26)		Diesel		10518	294	400	07.06-	■	
28.400 (D 2066 LF 37)		Diesel		10518	294	400	07.06-	■	
35.400		Diesel		10518	294	400	11.06-	■	
35.400		Diesel		10518	294	400	08.03-10.08	■	■
35.400		Diesel		10518	294	400	04.03-10.08	■	■
50.400		Diesel		10518	294	400	04.03-09.08	■	■
26.430, 26.440		Diesel		10518	316	430	05.04-	■	■
28.430		Diesel		10518	316	430	09.02-10.08	■	
35.430		Diesel		10518	316	430	04.03-10.08	■	■
35.430		Diesel		10518	316	430	08.03-10.08	■	■
50.430		Diesel		10518	316	430	04.03-09.08	■	■
18.440		Diesel		10518	321	436	05.03-03.09	■	
18.440		Diesel		10518	321	436	08.01-09.08	■	■
24.440		Diesel		10518	321	436	03.03-03.09	■	■
24.440		Diesel		10518	321	436	03.03-09.08	■	■
26.440		Diesel		10518	321	436	07.04-09.08	■	■
26.440		Diesel		10518	321	436	03.03-03.09	■	■
26.440		Diesel		10518	321	436	03.03-03.09	■	■
26.440		Diesel		10518	321	436	09.01-03.11	■	■
28.440		Diesel		10518	321	436	09.02-10.08	■	■
28.440		Diesel		10518	321	436	07.03-10.08	■	■

LISTA DE APLICACIONES - BUYERS GUIDE

28.440		Diesel		10518	321	436	01.04-10.08	■	■
32.440		Diesel		10518	321	436	01.04-09.08	■	■
33.440		Diesel		10518	321	436	09.01-03.11	■	■
35.440		Diesel		10518	321	436	04.03-10.08	■	■
35.440		Diesel		10518	321	436	08.03-10.08	■	■
35.440		Diesel		10518	321	436	03.03-10.08	■	■
35.440		Diesel		10518	321	436	04.03-10.08	■	■
37.440		Diesel		10518	321	436	04.03-09.08	■	■
41.440		Diesel		10518	321	436	04.03-03.11	■	■
50.440		Diesel		10518	321	436	04.03-09.08	■	■
28.440		Diesel		10518	324	440	07.06-	■	
35.440		Diesel		10518	324	440	11.06-	■	
35.440		Diesel		10518	324	441	04.03-10.08	■	■
35.440		Diesel		10518	324	441	08.03-10.08	■	■
50.440		Diesel		10518	324	441	04.03-09.08	■	■
18.310, 18.320 (D 2866 LF26)		Diesel		11967	228	310	04.00-	■	■
18.310, 18.320 (D 2866 LF36)		Diesel		11967	228	310	04.00-	■	■
26.310 (D 2866 LF26)		Diesel		11967	228	310	09.00-	■	■
26.310 (D 2866 LF36)		Diesel		11967	228	310	09.00-	■	■
26.310 (D 2866 LF26)		Diesel		11967	228	310	01.01-	■	
28.310		Diesel		11967	228	310	07.06-	■	
33.310		Diesel		11967	228	310	06.00-06.07	■	■
18.360 (D 2866 LF27)		Diesel		11967	265	360	04.00-	■	■
18.360 (D 2866 LF37)		Diesel		11967	265	360	04.00-	■	■
24.360 (D 2866 LF27)		Diesel		11967	265	360	09.01-	■	
26.360 (D 2866 LF27)		Diesel		11967	265	360	09.00-	■	■
26.360 (D 2866 LF37)		Diesel		11967	265	360	09.00-	■	■
26.360		Diesel		11967	265	360	09.00-	■	■
28.360		Diesel		11967	265	360	07.06-	■	
33.360 (D 2866 LF27)		Diesel		11967	265	360	10.00-	■	
33.360 (D 2866 LF37)		Diesel		11967	265	360	10.00-	■	
33.360		Diesel		11967	265	360	06.00-06.07	■	■
35.360		Diesel		11967	265	360	10.01-08.06	■	■
50.360		Diesel		11967	265	360	08.01-03.09	■	■
18.410, 18.420 (D 2866 LF28)		Diesel		11967	301	410	04.00-	■	■
18.410, 18.420 (D 2866 LF32)		Diesel		11967	301	410	04.00-	■	■
24.410 (D 2866 LF28)		Diesel		11967	301	410	09.01-	■	
26.410 (D 2866 LF28)		Diesel		11967	301	410	04.00-	■	■
26.410 (D 2866 LF32)		Diesel		11967	301	410	04.00-	■	■
26.410 (D 2866 LF28)		Diesel		11967	301	410	01.01-	■	
26.410 (D 2866 LF32)		Diesel		11967	301	410	01.01-	■	
28.410		Diesel		11967	301	410	07.06-	■	
33.410 (D 2866 LF28)		Diesel		11967	301	410	10.00-	■	
33.410 (D 2866 LF32)		Diesel		11967	301	410	10.00-	■	
33.410		Diesel		11967	301	409	06.00-06.07	■	■
35.410		Diesel		11967	301	409	10.01-08.06	■	■
35.410		Diesel		11967	301	409	03.02-09.08	■	■
41.410		Diesel		11967	301	409	03.02-09.08	■	■
50.410		Diesel		11967	301	409	08.01-03.09	■	■
26.480		Diesel		12419	353	480	02.06-	■	■
26.480		Diesel		12419	353	480	03.06-09.08	■	■

LISTA DE APLICACIONES - BUYERS GUIDE

35.480		Diesel		12419	353	480	11.06-	■	
35.480		Diesel		12419	353	480	07.08-04.12	■	■
35.480		Diesel		12419	353	480	03.06-10.08	■	■
41.480		Diesel		12419	353	480	07.08-04.12	■	■
50.480		Diesel		12419	353	480	03.06-09.08	■	■
26.540		Diesel		12419	397	540	08.06-	■	■
18.460 (D 2876 LF 04)		Diesel		12816	338	460	04.00-	■	■
18.460 (D 2876 LF 07)		Diesel		12816	338	460	04.00-	■	■
24.460 (D 2876 LF 04)		Diesel		12816	338	460	09.01-	■	
26.460 (D 2876 LF 04)		Diesel		12816	338	460	04.00-	■	■
26.460 (D 2876 LF 07)		Diesel		12816	338	460	04.00-	■	■
26.460 (D 2876 LF 04)		Diesel		12816	338	460	01.01-	■	
26.460 (D 2876 LF 07)		Diesel		12816	338	460	01.01-	■	
26.460 (D 2876 LF 04)		Diesel		12816	338	460	02.01-	■	
26.460 (D 2876 LF 07)		Diesel		12816	338	460	02.01-	■	
33.460		Diesel		12816	338	460	06.00-06.07	■	■
35.460		Diesel		12816	338	460	10.01-08.06	■	■
50.460		Diesel		12816	338	460	11.99-03.09	■	■
26.480		Diesel		12816	353	480	09.02-	■	■
33.480		Diesel		12816	353	480	04.02-06.07	■	■
35.480		Diesel		12816	353	480	04.02-09.08	■	■
35.480		Diesel		12816	353	480	04.02-08.06	■	■
41.480		Diesel		12816	353	480	04.02-09.08	■	■
50.480		Diesel		12816	353	480	04.02-03.09	■	■
18.510 (D 2876 LF 05)		Diesel		12816	375	510	09.00-	■	■
24.510 (D 2876 LF 05)		Diesel		12816	375	510	09.01-	■	
26.510 (D 2876 LF 05)		Diesel		12816	375	510	12.00-	■	■
26.510 (D 2876 LF 05)		Diesel		12816	375	510	01.01-	■	
26.510		Diesel		12816	375	510	12.00-	■	■
33.510		Diesel		12816	375	510	06.00-06.07	■	■
50.510		Diesel		12816	375	510	01.03-03.09	■	■
24.530 (D 2876 LF 13)		Diesel		12816	390	530	09.01-	■	
26.530 (D 2876 LF 13)		Diesel		12816	390	530	01.01-	■	
26.530		Diesel		12816	390	530	09.02-	■	■
33.530		Diesel		12816	390	530	04.02-06.07	■	■
35.530		Diesel		12816	390	530	04.02-09.08	■	■
35.530		Diesel		12816	390	530	04.02-08.06	■	■
41.530		Diesel		12816	390	530	04.02-09.08	■	■
50.530		Diesel		12816	390	530	04.02-03.09	■	■
33.680		Diesel		16162	500	680	07.07-04.08	■	■
TGA 03.00-									Truck Tractor
18.280		Diesel		6871	206	280	03.01-09.01	■	■
18.330		Diesel		6871	240	326	03.01-09.01	■	■
26.310		Diesel		10518	228	310	03.03-03.09	■	■
26.310		Diesel		10518	228	310	07.04-09.08	■	■
35.310		Diesel		10518	228	310	03.03-09.08	■	■
26.320		Diesel		10518	235	320	03.03-03.09	■	■
26.320		Diesel		10518	235	320	07.04-09.08	■	■
35.320		Diesel		10518	235	320	03.03-09.08	■	■
35.350		Diesel		10518	257	349	03.03-09.08	■	■
18.350		Diesel		10518	265	360	08.01-09.08	■	■

LISTA DE APLICACIONES - BUYERS GUIDE

19.350		Diesel		10518	265	360	03.05-03.11	■	■
24.360		Diesel		10518	265	360	03.03-03.09	■	■
26.350		Diesel		10518	265	360	03.03-03.09	■	■
26.350		Diesel		10518	265	360	07.04-09.08	■	■
26.360		Diesel		10518	265	360	03.03-03.09	■	■
28.350		Diesel		10518	265	360	07.03-10.08	■	■
35.350		Diesel		10518	265	360	03.03-09.08	■	■
35.360		Diesel		10518	265	360	03.03-09.08	■	■
26.390		Diesel		10518	287	390	07.04-09.08	■	■
35.390		Diesel		10518	287	390	03.03-09.08	■	■
26.400		Diesel		10518	294	400	07.04-09.08	■	■
35.400		Diesel		10518	294	400	03.03-09.08	■	■
26.430		Diesel		10518	316	430	07.04-09.08	■	■
35.430		Diesel		10518	316	430	03.03-09.08	■	■
18.440		Diesel		10518	321	436	08.01-09.08	■	■
18.440		Diesel		10518	321	436	05.03-03.09	■	■
19.440		Diesel		10518	321	436	03.05-03.11	■	■
24.440		Diesel		10518	321	436	03.03-03.09	■	■
26.440		Diesel		10518	321	436	07.04-09.08	■	■
26.440		Diesel		10518	321	436	03.03-03.09	■	■
26.440		Diesel		10518	321	436	03.03-03.09	■	■
26.440		Diesel		10518	321	436	09.01-03.11	■	■
28.440		Diesel		10518	321	436	07.03-10.08	■	■
33.440		Diesel		10518	321	436	09.01-03.11	■	■
35.440		Diesel		10518	321	436	03.03-09.08	■	■
40.440		Diesel		10518	321	436	01.05-03.11	■	■
19.440		Diesel		10518	324	441	03.05-03.11	■	■
26.440		Diesel		10518	324	441	07.04-09.08	■	■
35.440		Diesel		10518	324	441	03.03-09.08	■	■
40.440		Diesel		10518	324	441	01.05-03.11	■	■
18.310 (D 2866 LF26)		Diesel		11967	228	310	04.00-	■	■
18.310 (D 2866 LF36)		Diesel		11967	228	310	04.00-	■	■
26.310 (D 2866 LF26)		Diesel		11967	228	310	12.00-	■	■
26.310 (D 2866 LF36)		Diesel		11967	228	310	12.00-	■	■
26.310 (D 2866 LF26)		Diesel		11967	228	310	01.01-	■	■
26.310		Diesel		11967	228	310	12.00-	■	■
33.310		Diesel		11967	228	310	06.00-06.07	■	■
18.360 (D 2866 LF27)		Diesel		11967	265	360	04.00-	■	■
18.360 (D 2866 LF37)		Diesel		11967	265	360	04.00-	■	■
26.360 (D 2866 LF27)		Diesel		11967	265	360	12.00-	■	■
26.360 (D 2866 LF37)		Diesel		11967	265	360	12.00-	■	■
26.360		Diesel		11967	265	360	12.00-	■	■
33.360		Diesel		11967	265	360	06.00-06.07	■	■
18.410 (D 2866 LF28)		Diesel		11967	301	410	04.00-	■	■
18.410 (D 2866 LF32)		Diesel		11967	301	410	04.00-	■	■
26.410 (D 2866 LF28)		Diesel		11967	301	410	12.00-	■	■
26.410 (D 2866 LF32)		Diesel		11967	301	410	12.00-	■	■
26.410 (D 2866 LF28)		Diesel		11967	301	410	06.01-	■	■
26.410 (D 2866 LF32)		Diesel		11967	301	410	06.01-	■	■
33.410 (D 2866 LF28)		Diesel		11967	301	410	10.00-	■	■
33.410 (D 2866 LF32)		Diesel		11967	301	410	10.00-	■	■

LISTA DE APLICACIONES - BUYERS GUIDE

33.410		Diesel		11967	301	409	06.00-06.07	■	■
35.410		Diesel		11967	301	409	03.02-09.08	■	■
41.410		Diesel		11967	301	409	03.02-09.08	■	■
26.480		Diesel		12419	353	480	03.06-09.08	■	■
26.480		Diesel		12419	353	480	03.06-03.11	■	■
35.480		Diesel		12419	353	480	03.06-09.08	■	■
41.480		Diesel		12419	353	480	03.06-07.08	■	■
26.540		Diesel		12419	397	540	03.06-09.08	■	■
26.540		Diesel		12419	397	540	03.06-09.08	■	■
18.460 (D 2876 LF 04)		Diesel		12816	338	460	04.00-	■	■
18.460 (D 2876 LF 07)		Diesel		12816	338	460	04.00-	■	■
26.460 (D 2876 LF 04)		Diesel		12816	338	460	12.00-	■	■
26.460 (D 2876 LF 07)		Diesel		12816	338	460	12.00-	■	■
26.460 (D 2876 LF 04)		Diesel		12816	338	460	06.01-	■	■
26.460 (D 2876 LF 07)		Diesel		12816	338	460	06.01-	■	■
26.460		Diesel		12816	338	460	12.00-	■	■
33.460		Diesel		12816	338	460	06.00-06.07	■	■
26.480		Diesel		12816	353	480	09.02-	■	■
33.480		Diesel		12816	353	480	04.02-06.07	■	■
41.480		Diesel		12816	353	480	04.02-09.08	■	■
18.510 (D 2876 LF 05)		Diesel		12816	375	510	04.00-	■	■
26.510 (D 2876 LF 05)		Diesel		12816	375	510	12.00-	■	■
26.510 (D 2876 LF 05)		Diesel		12816	375	510	01.01-	■	■
26.510		Diesel		12816	375	510	12.00-	■	■
33.510		Diesel		12816	375	510	06.00-06.07	■	■
26.530 (D 2876 LF 13)		Diesel		12816	390	530	01.01-	■	■
26.530		Diesel		12816	390	530	09.02-	■	■
33.530		Diesel		12816	390	530	04.02-06.07	■	■
35.530		Diesel		12816	390	530	04.02-09.08	■	■
41.530		Diesel		12816	390	530	04.02-09.08	■	■
18.680		Diesel		16162	500	680	04.07-06.08	■	■
ÜL 09.89-								Bus	
ÜL 312,ÜL 322 (D 2865 LUH07)		Diesel		9973	228	310	04.92-09.96	■	■
ÜL 312,ÜL 322 (D 2865 LUH08)		Diesel		9973	228	310	04.92-09.96	■	■
ÜL 313 (D 2866 LUH 20)		Diesel		11967	228	310	09.96-	■	■
ÜL 313 (D 2866 LUH26)		Diesel		11967	228	310	09.96-	■	■
ÜL 353 (D 2866 LUH 21)		Diesel		11967	257	350	06.97-	■	■
MERCEDES-BENZ									
O 340 01.91-12.95								Bus	
O 340 (OM 441.994)		Diesel		10964	250	340	01.91-06.95	■	■
O 340 (OM 441.995)		Diesel		10964	250	340	01.91-06.95	■	■
Tourismo (OM 402.984)		Diesel		12763	280	381	08.92-08.95	■	■
Tourismo (OM 402.995)		Diesel		12763	280	381	08.92-08.95	■	■
O 350 TOURISMO (O 350) 09.94-								Bus	
Tourismo RHD, SHD (OM 441.980)		Diesel		10964	250	340	08.95-	■	■
Tourismo RHD, SHD (OM 445.934)		Diesel		10964	250	340	08.95-	■	■
Tourismo (OM 402.970)		Diesel		12763	280	381	08.95-	■	■
Tourismo (OM 446.938)		Diesel		14618	280	381	08.95-	■	■
O 404 01.91-12.99								Bus	
O 404 (OM 401.974)		Diesel		9570	200	272	09.91-10.99	■	■

LISTA DE APLICACIONES - BUYERS GUIDE

O 404 (OM 401.974)		Diesel		9570	200	272	09.91-10.99	■	■
O 404 (OM 401.970)		Diesel		9570	213	290	09.91-10.99	■	■
O 404 (OM 401.970)		Diesel		9570	213	290	09.91-10.99	■	■
O 404 (OM 401.970)		Diesel		9570	213	290	09.91-10.99	■	■
O 404 (OM 445.935)		Diesel		10964	213	290	09.94-10.99	■	■
O 404 (OM 445.935)		Diesel		10964	213	290	09.94-10.99	■	■
O 404 (OM 445.935)		Diesel		10964	213	290	09.94-10.99	■	■
O 404 (OM 441.980)		Diesel		10964	250	340	09.91-10.99	■	■
O 404 (OM 445.934)		Diesel		10964	250	340	09.91-10.99	■	■
O 404 (OM 441.980)		Diesel		10964	250	340	09.91-10.99	■	■
O 404 (OM 445.934)		Diesel		10964	250	340	09.91-10.99	■	■
O 404 (OM 441.922)		Diesel		11309	151	205	09.91-01.92	■	■
O 404 (OM 441.921)		Diesel		11309	165	224	09.91-01.92	■	■
O 404 (OM 402.970)		Diesel		12763	280	381	09.91-10.99	■	■
O 404 (OM 402.970)		Diesel		12763	280	381	09.91-10.99	■	■
O 404 (OM 402.974)		Diesel		12763	280	381	09.91-10.99	■	■
O 404		Diesel		12763	295	401	01.91-12.99	■	■
O 404 (OM 446.938)		Diesel		14618	280	381	09.94-10.99	■	■
O 404 (OM 446.934)		Diesel		14618	280	381	09.94-10.99	■	■
O 404 (OM 446.938)		Diesel		14618	280	381	09.94-10.99	■	■
O 404 (OM 446.938)		Diesel		14618	280	381	09.94-10.99	■	■
O 404 (OM 442.931)		Diesel		15078	195	265	09.91-01.92	■	■
O 404 (OM 442.930)		Diesel		15078	213	290	09.91-01.92	■	■
O 550 INTEGRO (O 550) 09.96-								Bus	
L		Diesel			184	250	09.96-	■	
L		Diesel			220	299	09.96-	■	
L		Diesel			260	354	09.96-	■	
RENAULT TRUCKS									
04.96-03.05								Truck Tractor	
AE 560.18T (MACK-EE9-560)		Diesel		16361	412	560	04.96-	■	
AE 560.19T (MACK-EE9-560)		Diesel		16361	412	560	04.96-	■	
AE 560.26T (MACK-EE9-560)		Diesel		16361	412	560	01.97-	■	
AE 560.26T (MACK-EE9-560)		Diesel		16361	412	560	01.98-	■	
Agora 01.96-								Bus	
All models		Diesel					01.96-	■	
Agora (MIDR 06.20.45 I41)		Diesel		9840	186	253	01.96-	■	
Agora (MIDR 06.20.45 I41)		Diesel		9840	186	253	01.96-	■	
Iliade 01.97-								Bus	
TE, RTC		Diesel			222	302	01.97-	■	■
RT, RTX, GTC		Diesel			250	340	01.97-	■	■
GTX		Diesel			280	381	01.97-	■	■
Magnum 01.90-04.99								Platform/Chassis	
AE 390.18 (MIDR 06.24.65 A/42)		Diesel		11929	287	390	09.96-	■	
AE 390.19 (MIDR 06.24.65 A/42)		Diesel		11929	287	390	09.96-	■	
AE 390.26 (MIDR 06.24.65 A/42)		Diesel		11929	287	390	09.96-	■	
AE 430.18 (MIDR 06.24.65 B/42)		Diesel		11929	316	430	09.96-	■	
AE 430.19 (MIDR 06.24.65 B/42)		Diesel		11929	316	430	09.96-	■	
AE 430.26 (MIDR 06.24.65 B/42)		Diesel		11929	316	430	09.96-	■	
AE 470.18 (MIDR 06.24.65 C/42)		Diesel		11929	346	471	11.96-	■	

LISTA DE APLICACIONES - BUYERS GUIDE

AE 470.19 (MIDR 06.24.65 C/42)		Diesel		11929	346	471	11.96-	■
AE 470.26 (MIDR 06.24.65 C/42)		Diesel		11929	346	471	01.97-	■
AE 385ti.18 (MIDR 06.35.40 N/3)		Diesel		12024	283	385	02.92-10.96	■
AE 385ti.19 (MIDR 06.35.40 N/3)		Diesel		12024	283	385	02.92-10.96	■
AE 385ti.26 (MIDR 06.35.40 N/3)		Diesel		12024	283	385	02.92-10.96	■
AE 420ti.18 (MIDR 06.35.40 J/3)		Diesel		12024	305	415	10.92-12.96	■
AE 420ti.18 (MIDR 06.35.40 P/41)		Diesel		12024	305	415	10.92-12.96	■
AE 420ti.24 (MIDR 06.35.40 J/3)		Diesel		12024	305	415	10.92-12.96	■
AE 420ti.24 (MIDR 06.35.40 P/41)		Diesel		12024	305	415	10.92-12.96	■
AE 420ti.26 (MIDR 06.35.40 J/3)		Diesel		12024	305	415	10.92-12.96	■
AE 420ti.26 (MIDR 06.35.40 P/41)		Diesel		12024	305	415	10.92-12.96	■
AE 520.18 (MACK-EE9-530)		Diesel		16361	390	530	10.92-05.96	■
AE 520.19 (MACK-EE9-530)		Diesel		16361	390	530	10.92-05.96	■
AE 520.24 (MACK-EE9-530)		Diesel		16361	390	530	10.92-05.96	■
AE 520.26 (MACK-EE9-530)		Diesel		16361	390	530	10.92-	■
AE 560.18 (MACK-EE9-560)		Diesel		16361	412	560	04.96-	■
AE 560.19 (MACK-EE9-560)		Diesel		16361	412	560	04.96-	■
AE 560.26 (MACK-EE9-560)		Diesel		16361	412	560	04.96-	■
Magnum 01.90-04.99					Truck Tractor			
AE 390.18T (MIDR 06.24.65 A/42)		Diesel		11929	287	390	09.96-	■
AE 390.19T (MIDR 06.24.65 A/42)		Diesel		11929	287	390	09.96-	■
AE 430.18T (MIDR 06.24.65 B/42)		Diesel		11929	316	430	09.96-	■
AE 430.19T (MIDR 06.24.65 B/42)		Diesel		11929	316	430	09.96-	■
AE 430.26T (MIDR 06.24.65 B/42)		Diesel		11929	316	430	01.98-	■
AE 430.26T (MIDR 06.24.65 B/42)		Diesel		11929	316	430	01.97-	■
AE 470.18T (MIDR 06.24.65 C/42)		Diesel		11929	346	471	11.96-	■
AE 470.19T (MIDR 06.24.65 C/42)		Diesel		11929	346	471	11.96-	■
AE 470.26T (MIDR 06.24.65 C/42)		Diesel		11929	346	471	01.98-	■
AE 385ti.18T (MIDR 06.35.40 N/3)		Diesel		12024	283	385	02.92-10.96	■
AE 385ti.19T (MIDR 06.35.40 N/3)		Diesel		12024	283	385	02.92-10.96	■
AE 420ti.18T (MIDR 06.35.40 J/3)		Diesel		12024	305	415	10.92-12.96	■
AE 420ti.18T (MIDR 06.35.40 P/41)		Diesel		12024	305	415	10.92-12.96	■
AE 420ti.19T (MIDR 06.35.40 J/3)		Diesel		12024	305	415	10.92-12.96	■
AE 420ti.19T (MIDR 06.35.40 P/41)		Diesel		12024	305	415	10.92-12.96	■
AE 420ti.22T (MIDR 06.35.40 J/3)		Diesel		12024	305	415	10.92-10.96	■
AE 420ti.22T (MIDR 06.35.40 P/41)		Diesel		12024	305	415	10.92-10.96	■
AE 420ti.24T (MIDR 06.35.40 J/3)		Diesel		12024	305	415	10.92-12.96	■
AE 420ti.24T (MIDR 06.35.40 P/41)		Diesel		12024	305	415	10.92-12.96	■
AE 420ti.26T (MIDR 06.35.40 J/3)		Diesel		12024	305	415	10.92-12.96	■
AE 420ti.26T (MIDR 06.35.40 P/41)		Diesel		12024	305	415	10.92-12.96	■
AE 520.18T (MACK-EE9-530)		Diesel		16361	390	530	10.92-05.96	■
AE 520.19T (MACK-EE9-530)		Diesel		16361	390	530	10.92-05.96	■
AE 520.22T (MACK-EE9-530)		Diesel		16361	390	530	10.92-05.96	■
AE 520.24T (MACK-EE9-530)		Diesel		16361	390	530	10.92-05.96	■
AE 520.26T (MACK-EE9-530)		Diesel		16361	390	530	10.92-05.96	■
Major 05.91-10.96					Dump Truck			
R 385ti.18,R 380.18 (MIDR 06.35.40 H)		Diesel		12024	275	374	05.91-10.96	■
R 385ti.18,R 380.18 (MIDR 06.35.40 L1)		Diesel		12024	275	374	05.91-10.96	■
R 385ti.18,R 380.18 (MIDR 06.35.40 N/3)		Diesel		12024	275	374	05.91-10.96	■

LISTA DE APLICACIONES - BUYERS GUIDE

Major 05.91-10.96						Platform/Chassis				
R 385ti.17,R 380.17 (MIDR 06.35.40 H)	Diesel		12024	275	374	05.91-10.96	■			
R 385ti.17,R 380.17 (MIDR 06.35.40 L1)	Diesel		12024	275	374	05.91-10.96	■			
R 385ti.17,R 380.17 (MIDR 06.35.40 N/3)	Diesel		12024	275	374	05.91-10.96	■			
R 385ti.18,R 380.18 (MIDR 06.35.40 H)	Diesel		12024	275	374	05.91-10.96	■			
R 385ti.18,R 380.18 (MIDR 06.35.40 L1)	Diesel		12024	275	374	05.91-10.96	■			
R 385ti.18,R 380.18 (MIDR 06.35.40 N/3)	Diesel		12024	275	374	05.91-10.96	■			
R 385ti.18,R 380.18 (MIDR 06.35.40 H)	Diesel		12024	275	374	05.91-10.96	■			
R 385ti.18,R 380.18 (MIDR 06.35.40 L1)	Diesel		12024	275	374	05.91-10.96	■			
R 385ti.18,R 380.18 (MIDR 06.35.40 N/3)	Diesel		12024	275	374	05.91-10.96	■			
R 385ti.26,R 380.26 (MIDR 06.35.40 H)	Diesel		12024	275	374	05.91-10.96	■			
R 385ti.26,R 380.26 (MIDR 06.35.40 L1)	Diesel		12024	275	374	05.91-10.96	■			
R 385ti.26,R 380.26 (MIDR 06.35.40 N/3)	Diesel		12024	275	374	05.91-10.96	■			
Major 05.91-10.96						Truck Tractor				
R 385ti.18/T,R 380.18/T (MIDR 06.35.40 H)	Diesel		12024	275	374	05.91-10.96	■			
R 385ti.18/T,R 380.18/T (MIDR 06.35.40 L1)	Diesel		12024	275	374	05.91-10.96	■			
R 385ti.18/T,R 380.18/T (MIDR 06.35.40 N/3)	Diesel		12024	275	374	05.91-10.96	■			
R 385ti.19/T,R 380.19/T (MIDR 06.35.40 H)	Diesel		12024	275	374	05.91-10.96	■			
R 385ti.19/T,R 380.19/T (MIDR 06.35.40 L1)	Diesel		12024	275	374	05.91-10.96	■			
R 385ti.19/T,R 380.19/T (MIDR 06.35.40 N/3)	Diesel		12024	275	374	05.91-10.96	■			
Premium 04.96-						Platform/Chassis				
Distribution 210.18D, 220.18 (DCI 6W)	Diesel		6177	154	209	04.96-	■			
Distribution 210.18D, 220.18 (MIDR 06.02.26 W/4)	Diesel		6177	154	209	04.96-	■			
Distribution 250.18D (MIDR 06.02.26 Y/41)	Diesel		6177	184	250	04.96-	■			
Distribution 270.18 (DCI 6A)	Diesel		6177	195	265	08.00-	■	■		
Distribution 300.18D (MIDR 06.20.45 D/41)	Diesel		9839	219	298	04.96-	■			
Distribution 300.26D (MIDR 06.20.45 D/41)	Diesel		9839	219	298	04.96-	■			
Route 300.18 (MIDR 06.20.45 D/41)	Diesel		9839	219	298	09.96-	■			
Distribution 340.18D (MIDR 06.20.45 E/41)	Diesel		9839	249	339	04.96-	■			
Distribution 340.26D (MIDR 06.20.45 E/41)	Diesel		9839	249	339	04.96-	■			
Route 340.18 (MIDR 06.20.45 E/41)	Diesel		9839	249	339	04.96-	■			
Route 340.26 (MIDR 06.20.45 E/41)	Diesel		9839	249	339	04.96-	■			
Distribution 320.18 D (DCI 11G)	Diesel		11123	230	313	08.00-	■			
Distribution 320.24D (DCI 11G)	Diesel		11123	230	313	08.00-	■			
Distribution 320.26D (DCI 11G)	Diesel		11123	230	313	08.00-	■			
Route 320.18 (DCI 11G)	Diesel		11123	230	313	08.00-	■			
Distribution 370.18D (DCI 11E)	Diesel		11123	266	362	08.00-	■			
Distribution 370.24D (DCI 11E)	Diesel		11123	266	362	08.00-	■			
Distribution 370.26D (DCI 11E)	Diesel		11123	266	362	08.00-	■			
Route 370.18 (DCI 11E)	Diesel		11123	266	362	08.00-	■			
Route 370.24 (DCI 11E)	Diesel		11123	266	362	08.00-	■			
Route 370.26 (DCI 11E)	Diesel		11123	266	362	08.00-	■			
Route 385.18,400.18 (MIDR 06.23.56 A/41)	Diesel		11123	280	381	04.96-	■			
Route 385.18,400.18 (MIDR 06.23.56 B/41)	Diesel		11123	280	381	04.96-	■			
Route 385.24,400.24 (MIDR 06.23.56 A/41)	Diesel		11123	280	381	04.96-	■			
Route 385.24,400.24 (MIDR 06.23.56 B/41)	Diesel		11123	280	381	04.96-	■			
Route 385.26 (MIDR 06.23.56 A/41)	Diesel		11123	280	381	04.96-	■			
Route 385.26,400.26 (MIDR 06.23.56 A/41)	Diesel		11123	280	381	04.96-	■			
Route 385.26,400.26 (MIDR 06.23.56 B/41)	Diesel		11123	280	381	04.96-	■			
Distribution 420.18D (DCI 11C)	Diesel		11123	303	412	08.00-	■			

LISTA DE APLICACIONES - BUYERS GUIDE

Route 420.18 (DCI 11C)	Diesel		11123	303	412	08.00-	■
Route 420.24 (DCI 11C)	Diesel		11123	303	412	08.00-	■
Route 420.26 (DCI 11C)	Diesel		11123	303	412	08.00-	■
Premium 04.96-							Truck Tractor
Distribution 300.18D/T (MIDR 06.20.45 D/41)	Diesel		9839	219	298	04.96-	■
Route 300.18T (MIDR 06.20.45 D/41)	Diesel		9839	219	298	09.96-	■
Distribution 340.18D/T (MIDR 06.20.45 E/41)	Diesel		9839	249	339	04.96-	■
Route 340.18T (MIDR 06.20.45 E/41)	Diesel		9839	249	339	04.96-	■
Distribution 320.18 (DCI 11G)	Diesel		11123	230	313	08.00-	■
Route 320.18 (DCI 11G)	Diesel		11123	230	313	08.00-	■
Distribution 370.18 (DCI 11E)	Diesel		11123	266	362	08.00-	■
Route 370.18 (DCI 11E)	Diesel		11123	266	362	08.00-	■
Route 385.18T,400.18T (MIDR 06.23.56 A/41)	Diesel		11123	280	381	04.96-	■
Route 385.18T,400.18T (MIDR 06.23.56 B/41)	Diesel		11123	280	381	04.96-	■
Route 385.24T,400.24T (MIDR 06.23.56 A/41)	Diesel		11123	280	381	09.96-	■
Route 385.24T,400.24T (MIDR 06.23.56 B/41)	Diesel		11123	280	381	09.96-	■
Distribution 420.18 (DCI 11C)	Diesel		11123	303	412	08.00-	■
Route 420.24 (DCI 11C)	Diesel		11123	303	412	08.00-	■
Route 420.25 (DCI 11C)	Diesel		11123	303	412	08.00-	■
SETRA							
200 Series 09.72-12.91							Bus
S 215 NR disc 045-041 mm	Diesel					09.72-	■
300 Series 09.91-02.02							Bus
S 316 HDS disc 045-041 mm	Diesel			280	381	09.91-	■
S309HD	Diesel		9570	213	290	09.91-02.02	■
S312HD, S315H, S315GT, S315HD, S315HDH (OM 441.961)	Diesel		10964	250	340	09.91-02.02	■
S300N, S300NC (D 2866 OH)	Diesel		11967	177	241	09.91-02.02	■
S313UL, S315H, S315UL, S315NF	Diesel		11967	220	299	09.91-02.02	■
S321UL	Diesel		11967	220	299	09.91-02.02	■
S319NF, S319UL	Diesel		11967	257	350	09.91-02.02	■
S315GT, S315GT-HD, S315HD, S315HDH (OM 446.930)	Diesel		14618	280	381	09.91-02.02	■
S315GT, S315GT-HD, S315HD, S315HDH (OM 446.931)	Diesel		14618	280	381	09.91-02.02	■
S317GT-HD, S317HD, S317HDH, S319GT-HD (OM 442.980)	Diesel		14618	320	435	09.91-02.02	■
TEMSA							
Diamond 01.06-							Bus
14 (D 2066 LOH 04)	Diesel		10518	324	440	01.06-	■
VAN HOOL							
T Series 10.95-							Bus
T 815	Diesel					10.95-	■
T 911 (PR 265 S)	Diesel		9186	265	360	10.06-	■
T 911 (D 2066 LF 27)	Diesel		10518	265	360	10.05-	■
T 915, T 916 (D 2066 LOH 28)	Diesel		10518	294	400	10.05-	■
T 917 (D 2676 LOH 26)	Diesel		12412	324	440	10.05-	■
T 916, T 917, T 918, T 919 (D 2676 LOH 27)	Diesel		12412	353	480	10.05-	■
TD 925, TD 927 (D 2676 LOH 27)	Diesel		12412	353	480	10.06-	■
T 915, T 916 (MX 300)	Diesel		12903	300	408	10.05-	■
T 916, T 917, T 918, T 919 (MX 340)	Diesel		12903	340	462	10.05-	■

LISTA DE APLICACIONES - BUYERS GUIDE

TD 925, TD 927 (MX 375)	Diesel	12903	375	510	10.05-
-------------------------	--------	-------	-----	-----	--------

