

LISTA DE APLICACIONES - BUYERS GUIDE


151427



Qty: 660

Weight: 11.212

O.E.M.	MAKE
1 078 439	VOLVO
2 076 809 2	VOLVO
2 091 889 1	VOLVO
2 093 134 30	VOLVO
3 095 396	VOLVO
MDP1388	MERITOR



151427

E 9 90R-01178/663



Meritor D-DUCO

249.2x111x29

WVA	FMSI
29125	D1560-8771
29222	
29224	
29277	

MAKE
MERITOR
PLAXTON
VOLVO

151427-066



1 - 690129 E



1 - 690136 E



Trac.	CC	Kw	CV



MERITOR

LMC								Trailer Axle	
LMC								01.53-	■
TA								Trailer Axle	
TA								01.53-	■
TAC								Trailer Axle	
TAC								01.53-	■
TM								Trailer Axle	
TM								01.53-	■
TM								01.53-	■

PLAXTON

ELITE 11.08-								Bus	
ELITE (DH12E420)		Diesel		12130	309	420	01.09-	■	■
PANTHER 10.99-								Bus	
PANTHER (D 2066 LOH 02)		Diesel		10518	265	360	01.06-	■	■
PANTHER (D 2066 LOH 03)		Diesel		10518	294	400	01.06-	■	■

VOLVO

09.03-12.05								Platform/Chassis	
240 (7A240)		Diesel		7118	176	239	01.03-	■	■
240 (7A240)		Diesel		7118	176	239	01.03-	■	■
260 (7A260)		Diesel		7118	191	260	01.06-12.11	■	■

LISTA DE APLICACIONES - BUYERS GUIDE

					Truck Tractor					
01.06-12.11										
310 (7A310)		Diesel		7118	228	310	01.06-	■	■	
7300 01.99-					Bus					
7300		Diesel		12130	280	381	01.99-	■	■	
7300		Diesel		12130	280	381	01.99-	■	■	
9700 04.01-					Bus					
9700 (DH12D340)		Diesel		12130	250	340	04.01-	■	■	
9700 (DH12E340)		Diesel		12130	250	340	04.01-	■	■	
9700 (DH12D340)		Diesel		12130	250	340	10.01-	■	■	
9700 (DH12E340)		Diesel		12130	250	340	10.01-	■	■	
9700 (DH12D380)		Diesel		12130	280	380	04.01-	■	■	
9700 (DH12E380)		Diesel		12130	280	380	04.01-	■	■	
9700 (DH12D380)		Diesel		12130	280	380	10.01-	■	■	
9700 (DH12E380)		Diesel		12130	280	380	10.01-	■	■	
9700		Diesel		12130	280	381	04.01-	■	■	
9700 (DH12D420)		Diesel		12130	309	420	04.01-	■	■	
9700 (DH12E420)		Diesel		12130	309	420	04.01-	■	■	
9700 (DH12D420)		Diesel		12130	309	420	10.01-	■	■	
9700 (DH12E420)		Diesel		12130	309	420	10.01-	■	■	
9900 01.99-					Bus					
9900		Diesel		12130	280	381	01.99-	■	■	
9900		Diesel		12130	280	381	01.99-	■	■	
9900 (DH12D420)		Diesel		12130	309	420	10.01-	■	■	
9900 (DH12E420)		Diesel		12130	309	420	10.01-	■	■	
9900 (DH12D420)		Diesel		12130	309	420	10.01-	■	■	
9900 (DH12E420)		Diesel		12130	309	420	10.01-	■	■	
B12 01.91-					Bus					
B12		Diesel		11980	224	305	01.91-12.06	■	■	
B12 (DH12E340)		Diesel		12130	250	340	02.06-	■	■	
B12 (DH12D340)		Diesel		12130	250	340	02.06-	■	■	
B12 (DH12E340)		Diesel		12130	250	340	02.06-	■	■	
B12		Diesel		12130	250	340	10.10-	■	■	
B12 (DH12E380)		Diesel		12130	280	380	02.06-	■	■	
B12 (DH12E380)		Diesel		12130	280	380	02.06-	■	■	
B12		Diesel		12130	305	415	01.91-12.06	■	■	
B12 (D12C420)		Diesel		12130	309	420	02.06-	■	■	
B12 (D12D420)		Diesel		12130	309	420	02.06-	■	■	
B12 (DH12E420)		Diesel		12130	309	420	02.06-	■	■	
B12 (D12C420)		Diesel		12130	309	420	02.06-	■	■	
B12 (D12D420)		Diesel		12130	309	420	02.06-	■	■	
B12 (DH12E420)		Diesel		12130	309	420	02.06-	■	■	
B12 (DH12E460)		Diesel		12130	338	460	02.06-	■	■	
B12 (DH12E460)		Diesel		12130	338	460	02.06-	■	■	
B9 01.02-					Bus					
B9 (D9B260)		Diesel		9364	191	260	09.05-	■	■	
B9 (D9B260)		Diesel		9364	191	260	09.05-	■	■	
B9 (D9B310)		Diesel		9364	228	310	09.05-	■	■	
B9 (D9B310)		Diesel		9364	228	310	09.05-	■	■	
B9 (D9B360)		Diesel		9364	265	360	09.05-	■	■	

LISTA DE APLICACIONES - BUYERS GUIDE

FH 12/460 (D12D460)		Diesel		12130	338	460	08.98-	■	■
FH 12/460 (D12C460)		Diesel		12130	338	460	08.98-	■	■
FH 12/460 (D12D460)		Diesel		12130	338	460	08.98-	■	■
FH 12/500		Diesel		12130	368	500	09.01-	■	■
FH 12/500		Diesel		12130	368	500	09.01-	■	■
FH 12/380		Diesel		12132	279	379	08.93-09.05	■	■
FH 12/380		Diesel		12132	279	379	08.93-09.05	■	■
FH 12/380		Diesel		12132	279	379	08.93-09.05	■	■
FH 12/380		Diesel		12132	279	379	08.93-09.05	■	■
FH 12/380		Diesel		12132	279	379	08.93-09.05	■	■
FH 12/390		Diesel		12132	287	390	09.01-09.05	■	■
FH 12/420		Diesel		12132	309	420	08.93-09.05	■	■
FH 12/420		Diesel		12132	309	420	08.93-09.05	■	■
FH 12/420		Diesel		12132	309	420	08.93-09.05	■	■
FH 12/420		Diesel		12132	309	420	08.93-09.05	■	■
FH 12/420		Diesel		12132	309	420	08.93-09.05	■	■
FH 12/430		Diesel		12132	316	430	09.01-09.05	■	■
FH 12/460		Diesel		12132	338	460	09.98-09.05	■	■
FH 12/460		Diesel		12132	338	460	09.98-09.05	■	■
FH 12/460		Diesel		12132	338	460	09.98-09.05	■	■
FH 12/460		Diesel		12132	338	460	09.98-09.05	■	■
FH 12/460		Diesel		12132	338	460	09.98-09.05	■	■
FH 12/500		Diesel		12132	368	500	09.01-09.05	■	■
FH 12/500		Diesel		12132	368	500	09.01-09.05	■	■
FH 12/500		Diesel		12132	368	500	09.98-09.05	■	■
FH 12/500		Diesel		12132	368	500	09.98-09.05	■	■
FH 12/500		Diesel		12132	368	500	09.01-09.05	■	■
FH 12/500		Diesel		12132	368	500	09.01-09.05	■	■
FH 12/500		Diesel		12132	368	500	09.01-09.05	■	■
FH 12/500		Diesel		12132	368	500	09.01-09.05	■	■
FH 12/500		Diesel		12132	368	500	09.01-09.05	■	■
FH 12/500		Diesel		12132	368	500	09.01-09.05	■	■
FH 12/500		Diesel		12132	368	500	09.01-09.05	■	■
FH 12/500		Diesel		12132	368	500	09.98-09.05	■	■
FH 12/500		Diesel		12132	368	500	09.98-09.05	■	■
FH12 08.93-							Truck Tractor		
FH 12/340 (D12A340)		Diesel		12130	250	340	08.93-	■	■
FH 12/340 (D12C340)		Diesel		12130	250	340	08.93-	■	■
FH 12/340 (D12D340)		Diesel		12130	250	340	08.93-	■	■
FH 12/340 (D12A340)		Diesel		12130	250	340	01.95-	■	■
FH 12/340 (D12C340)		Diesel		12130	250	340	01.95-	■	■
FH 12/340 (D12D340)		Diesel		12130	250	340	01.95-	■	■
FH 12/340 (D12A340)		Diesel		12130	250	340	08.93-	■	■
FH 12/340 (D12C340)		Diesel		12130	250	340	08.93-	■	■
FH 12/340 (D12D340)		Diesel		12130	250	340	08.93-	■	■
FH 12/340 (D12A340)		Diesel		12130	250	340	08.93-	■	■
FH 12/340 (D12C340)		Diesel		12130	250	340	08.93-	■	■
FH 12/340 (D12D340)		Diesel		12130	250	340	08.93-	■	■
FH 12/340		Diesel		12130	250	340	08.93-	■	■
FH 12/380 (D12A380)		Diesel		12130	279	379	08.93-	■	■
FH 12/380 (D12C380)		Diesel		12130	279	379	08.93-	■	■
FH 12/380 (D12D380)		Diesel		12130	279	379	08.93-	■	■

LISTA DE APLICACIONES - BUYERS GUIDE

FH 12/420		Diesel		12132	309	420	08.93-09.05	■	■
FH 12/420		Diesel		12132	309	420	08.93-09.05	■	■
FH 12/420		Diesel		12132	309	420	08.93-09.05	■	■
FH 12/420		Diesel		12132	309	420	08.93-09.05	■	■
FH 12/420		Diesel		12132	309	420	08.93-09.05	■	■
FH 12/430		Diesel		12132	316	430	09.01-09.05	■	■
FH 12/430		Diesel		12132	316	430	09.01-09.05	■	■
FH 12/430		Diesel		12132	316	430	09.01-09.05	■	■
FH 12/430		Diesel		12132	316	430	09.01-09.05	■	■
FH 12/430		Diesel		12132	316	430	09.01-09.05	■	■
FH 12/430		Diesel		12132	316	430	09.01-09.05	■	■
FH 12/430		Diesel		12132	316	430	09.01-09.05	■	■
FH 12/430		Diesel		12132	316	430	09.01-09.05	■	■
FH 12/430		Diesel		12132	316	430	09.01-09.05	■	■
FH 12/460		Diesel		12132	338	460	09.98-09.05	■	■
FH 12/460		Diesel		12132	338	460	09.98-09.05	■	■
FH 12/460		Diesel		12132	338	460	09.98-09.05	■	■
FH 12/460		Diesel		12132	338	460	09.98-09.05	■	■
FH 12/460		Diesel		12132	338	460	09.98-09.05	■	■
FH 12/460		Diesel		12132	338	460	09.98-09.05	■	■
FH 12/460		Diesel		12132	338	460	09.98-09.05	■	■
FH 12/460		Diesel		12132	338	460	09.98-09.05	■	■
FH 12/500		Diesel		12132	368	500	09.01-09.05	■	■
FH 12/500		Diesel		12132	368	500	09.01-09.05	■	■
FH 12/500		Diesel		12132	368	500	09.98-09.05	■	■
FH 12/500		Diesel		12132	368	500	09.98-09.05	■	■
FH 12/500		Diesel		12132	368	500	09.01-09.05	■	■
FH 12/500		Diesel		12132	368	500	09.01-09.05	■	■
FH 12/500		Diesel		12132	368	500	09.01-09.05	■	■
FH 12/500		Diesel		12132	368	500	09.01-09.05	■	■
FH 12/500		Diesel		12132	368	500	09.01-09.05	■	■
FH 12/500		Diesel		12132	368	500	09.01-09.05	■	■
FH 12/500		Diesel		12132	368	500	09.01-09.05	■	■
FH 12/500		Diesel		12132	368	500	09.98-09.05	■	■
FH 12/500		Diesel		12132	368	500	09.98-09.05	■	■
FH16 08.93-								Platform/Chassis	
FH 16/470 (D16A470)		Diesel		16120	346	470	08.93-12.99	■	■
FH 16/470 (D16A470)		Diesel		16120	346	470	08.93-12.99	■	■
FH 16/470 (D16A470)		Diesel		16120	346	470	08.93-12.99	■	■
FH 16/520 (D16A520)		Diesel		16120	382	520	08.93-12.02	■	■
FH 16/520 (D16B520)		Diesel		16120	382	520	08.93-12.02	■	■
FH 16/520 (D16A520)		Diesel		16120	382	520	08.93-12.02	■	■
FH 16/520 (D16B520)		Diesel		16120	382	520	08.93-12.02	■	■
FH 16/520 (D16A520)		Diesel		16120	382	520	08.93-12.02	■	■
FH 16/520 (D16B520)		Diesel		16120	382	520	08.93-12.02	■	■
FH 16/520 (D16A520)		Diesel		16120	382	520	01.95-	■	■
FH 16/520 (D16B520)		Diesel		16120	382	520	01.95-	■	■
FH 16/540, FH 16/550 (D16C550)		Diesel		16120	396	540	01.03-	■	■
FH 16/540, FH 16/550 (D16E540)		Diesel		16120	396	540	01.03-	■	■
FH 16/540, FH 16/550 (D16G540)		Diesel		16120	396	540	01.03-	■	■
FH 16/540, FH 16/550 (D16C550)		Diesel		16120	396	540	01.03-	■	■
FH 16/540, FH 16/550 (D16E540)		Diesel		16120	396	540	01.03-	■	■
FH 16/540, FH 16/550 (D16G540)		Diesel		16120	396	540	01.03-	■	■

LISTA DE APLICACIONES - BUYERS GUIDE

FH 16/540, FH 16/550 (D16C550)	Diesel	16120	396	540	01.03-	■	■
FH 16/540, FH 16/550 (D16E540)	Diesel	16120	396	540	01.03-	■	■
FH 16/540, FH 16/550 (D16G540)	Diesel	16120	396	540	01.03-	■	■
FH 16/540, FH 16/550 (D16C550)	Diesel	16120	396	540	01.03-	■	■
FH 16/540, FH 16/550 (D16E540)	Diesel	16120	396	540	01.03-	■	■
FH 16/540, FH 16/550 (D16C550)	Diesel	16120	396	540	01.03-	■	■
FH 16/540, FH 16/550 (D16E540)	Diesel	16120	396	540	01.03-	■	■
FH 16/550	Diesel	16120	396	540	05.05-	■	■
FH 16/610 (D16C610)	Diesel	16120	449	610	01.03-	■	■
FH 16/610 (D16C610)	Diesel	16120	449	610	01.03-	■	■
FH 16/610 (D16C610)	Diesel	16120	449	610	01.03-	■	■
FH 16/610 (D16C610)	Diesel	16120	449	610	01.03-	■	■
FH 16/610 (D16C610)	Diesel	16120	449	610	01.03-	■	■
FH 16/470	Diesel	16125	346	470	08.93-12.02	■	■
FH 16/470	Diesel	16125	346	470	08.93-12.02	■	■
FH 16/470	Diesel	16125	346	470	08.93-12.02	■	■
FH 16/470	Diesel	16125	346	470	08.93-12.02	■	■
FH 16/470	Diesel	16125	346	470	08.93-12.02	■	■
FH 16/470	Diesel	16125	346	470	08.93-12.02	■	■
FH 16/470	Diesel	16125	346	470	08.93-12.02	■	■
FH 16/470	Diesel	16125	346	470	08.93-12.02	■	■
FH 16/470	Diesel	16125	346	470	08.93-12.02	■	■
FH 16/520	Diesel	16125	382	519	08.93-12.02	■	■
FH 16/520	Diesel	16125	382	519	08.93-12.02	■	■
FH 16/520	Diesel	16125	382	519	08.93-12.02	■	■
FH 16/520	Diesel	16125	382	519	08.93-12.02	■	■
FH 16/520	Diesel	16125	382	519	08.93-12.02	■	■
FH 16/520	Diesel	16125	382	519	08.93-12.02	■	■
FH 16/520	Diesel	16125	382	519	08.93-12.02	■	■
FH 16/520	Diesel	16125	382	519	08.93-12.02	■	■
FH 16/550	Diesel	16125	405	551	01.03-	■	■
FH 16/550	Diesel	16125	405	551	01.03-	■	■
FH 16/600	Diesel	16125	441	600	01.08-	■	■
FH 16/600	Diesel	16125	441	600	01.08-	■	■
FH 16/600	Diesel	16125	441	600	01.08-	■	■
FH 16/600	Diesel	16125	441	600	01.08-	■	■
FH 16/600	Diesel	16125	441	600	01.08-	■	■
FH 16/600	Diesel	16125	441	600	01.08-	■	■
FH 16/600	Diesel	16125	441	600	01.08-	■	■
FH 16/610	Diesel	16125	449	610	01.03-	■	■
FH 16/660	Diesel	16125	485	659	01.05-	■	■
FH 16/700	Diesel	16125	515	700	01.09-	■	■
FH 16/700	Diesel	16125	515	700	01.09-	■	■
FH 16/700	Diesel	16125	515	700	01.09-	■	■
FH 16/700	Diesel	16125	515	700	01.09-	■	■
FH 16/700	Diesel	16125	515	700	01.09-	■	■
FH 16/700	Diesel	16125	515	700	01.09-	■	■
FH16 08.93-				Truck Tractor			
FH 16/470 (D16A470)	Diesel	16120	346	470	08.93-12.99	■	■
FH 16/470 (D16A470)	Diesel	16120	346	470	08.93-12.99	■	■
FH 16/520 (D16A520)	Diesel	16120	382	520	08.93-12.02	■	■
FH 16/520 (D16B520)	Diesel	16120	382	520	08.93-12.02	■	■
FH 16/520 (D16A520)	Diesel	16120	382	520	08.93-12.02	■	■

LISTA DE APLICACIONES - BUYERS GUIDE

FH 16/600		Diesel		16125	441	600	01.08-	■	■
FH 16/600		Diesel		16125	441	600	01.08-	■	■
FH 16/600		Diesel		16125	441	600	01.08-	■	■
FH 16/600		Diesel		16125	441	600	01.08-	■	■
FH 16/600		Diesel		16125	441	600	01.08-	■	■
FH 16/600		Diesel		16125	441	600	01.08-	■	■
FH 16/600		Diesel		16125	441	600	01.08-	■	■
FH 16/600		Diesel		16125	441	600	01.08-	■	■
FH 16/610		Diesel		16125	449	610	01.03-	■	■
FH 16/610		Diesel		16125	449	610	01.03-	■	■
FH 16/610		Diesel		16125	449	610	01.03-	■	■
FH 16/610		Diesel		16125	449	610	01.03-	■	■
FH 16/660		Diesel		16125	485	659	01.05-	■	■
FH 16/660		Diesel		16125	485	659	01.05-	■	■
FH 16/660		Diesel		16125	485	659	01.05-	■	■
FH 16/660		Diesel		16125	485	659	01.05-	■	■
FH 16/660		Diesel		16125	485	659	01.05-	■	■
FH 16/660		Diesel		16125	485	659	01.05-	■	■
FH 16/700		Diesel		16125	515	700	01.09-	■	■
FH 16/700		Diesel		16125	515	700	01.09-	■	■
FH 16/700		Diesel		16125	515	700	01.09-	■	■
FH 16/700		Diesel		16125	515	700	01.09-	■	■
FH 16/700		Diesel		16125	515	700	01.09-	■	■
FH 16/700		Diesel		16125	515	700	01.09-	■	■
FL 03.00-								Platform/Chassis	
FL 180-16		Diesel		5476	132	179	05.00-08.06	■	■
FL 180-17		Diesel		5476	132	179	05.00-08.06	■	■
FL 180-18		Diesel		5476	132	179	05.00-08.06	■	■
FL 180-19		Diesel		5476	132	179	05.00-08.06	■	■
FL 180-21		Diesel		5476	132	179	05.00-08.06	■	■
FL 180-26		Diesel		5476	132	179	05.00-08.06	■	■
FL 220-16		Diesel		5476	162	220	05.00-08.06	■	■
FL 220-17		Diesel		5476	162	220	05.00-08.06	■	■
FL 220-18		Diesel		5476	162	220	05.00-08.06	■	■
FL 220-19		Diesel		5476	162	220	05.00-08.06	■	■
FL 220-21		Diesel		5476	162	220	05.00-08.06	■	■
FL 220-26		Diesel		5476	162	220	05.00-08.06	■	■
FL 250-16		Diesel		5476	185	252	05.00-08.06	■	■
FL 250-17		Diesel		5476	185	252	05.00-08.06	■	■
FL 250-18		Diesel		5476	185	252	05.00-08.06	■	■
FL 250-19		Diesel		5476	185	252	05.00-08.06	■	■
FL 250-21		Diesel		5476	185	252	05.00-08.06	■	■
FL 250-26		Diesel		5476	185	252	05.00-08.06	■	■
FL 180-18 (D6B)		Diesel		5480	132	180	03.00-	■	■
FL 220-18 (D6B)		Diesel		5480	162	220	03.00-	■	■
FL 250-18 (D6B)		Diesel		5480	184	250	03.00-	■	■
FL 03.00-								Truck Tractor	
FL 180-16		Diesel		5476	132	179	05.00-08.06	■	■
FL 180-17		Diesel		5476	132	179	05.00-08.06	■	■
FL 180-18		Diesel		5476	132	179	05.00-08.06	■	■
FL 180-19		Diesel		5476	132	179	05.00-08.06	■	■

LISTA DE APLICACIONES - BUYERS GUIDE

FL 180-21		Diesel		5476	132	179	05.00-08.06	■	■
FL 180-26		Diesel		5476	132	179	05.00-08.06	■	■
FL 220-16		Diesel		5476	162	220	05.00-08.06	■	■
FL 220-17		Diesel		5476	162	220	05.00-08.06	■	■
FL 220-18		Diesel		5476	162	220	05.00-08.06	■	■
FL 220-19		Diesel		5476	162	220	05.00-08.06	■	■
FL 220-21		Diesel		5476	162	220	05.00-08.06	■	■
FL 220-26		Diesel		5476	162	220	05.00-08.06	■	■
FL 250-16		Diesel		5476	185	252	05.00-08.06	■	■
FL 250-17		Diesel		5476	185	252	05.00-08.06	■	■
FL 250-18		Diesel		5476	185	252	05.00-08.06	■	■
FL 250-19		Diesel		5476	185	252	05.00-08.06	■	■
FL 250-21		Diesel		5476	185	252	05.00-08.06	■	■
FL 250-26		Diesel		5476	185	252	05.00-08.06	■	■
FL6 09.85-08.00								Dump Truck	
FL 618 (D6A180)		Diesel		5480	132	180	11.91-03.00	■	■
FL 618 (TD 63 E)		Diesel		5480	132	180	11.91-03.00	■	■
FL 618 (D6A210)		Diesel		5480	154	209	11.91-03.00	■	■
FL 618 (TD 63 ES)		Diesel		5480	154	209	11.91-03.00	■	■
FL 618 (D6A230)		Diesel		5480	169	230	12.95-03.00	■	■
FL 618 (D6A250)		Diesel		5480	184	250	12.95-03.00	■	■
FL6 09.85-08.00								Platform/Chassis	
FL 618 (D6A180)		Diesel		5480	132	180	11.91-03.00	■	■
FL 618 (TD 63 E)		Diesel		5480	132	180	11.91-03.00	■	■
FL 618 (D6A210)		Diesel		5480	154	209	11.91-03.00	■	■
FL 618 (TD 63 ES)		Diesel		5480	154	209	11.91-03.00	■	■
FL 618 (D6A230)		Diesel		5480	169	230	12.95-03.00	■	■
FL 618 (D6A250)		Diesel		5480	184	250	12.95-03.00	■	■
FM 09.05-								Dump Truck	
FM 300		Diesel		9366	221	300	09.05-	■	■
FM 300		Diesel		9366	221	300	09.05-	■	■
FM 300		Diesel		9366	221	300	09.05-	■	■
FM 340		Diesel		9366	250	340	09.05-	■	■
FM 340		Diesel		9366	250	340	09.05-	■	■
FM 340		Diesel		9366	250	340	09.05-	■	■
FM 380		Diesel		9366	280	381	09.05-	■	■
FM 380		Diesel		9366	280	381	09.05-	■	■
FM 380		Diesel		9366	280	381	09.05-	■	■
FM 09.05-								Platform/Chassis	
FM 300		Diesel		9366	221	300	09.05-	■	■
FM 340		Diesel		9366	250	340	09.05-	■	■
FM 380		Diesel		9366	280	381	09.05-	■	■
FM 430		Diesel		10837	316	430	09.05-	■	■
FM 09.05-								Truck Tractor	
FM 300		Diesel		9366	221	300	09.05-	■	■
FM 300		Diesel		9366	221	300	09.05-	■	■
FM 300		Diesel		9366	221	300	09.05-	■	■
FM 340		Diesel		9366	250	340	09.05-	■	■
FM 340		Diesel		9366	250	340	09.05-	■	■
FM 380		Diesel		9366	280	381	09.05-	■	■

LISTA DE APLICACIONES - BUYERS GUIDE

FM 380		Diesel		9366	280	381	09.05-	■	■
FM 330		Diesel		10837	243	330	09.05-	■	■
FM 370		Diesel		10837	272	370	09.05-	■	■
FM 410		Diesel		10837	302	411	09.05-	■	■
FM 430		Diesel		10837	316	430	09.05-	■	■
FM 450		Diesel		10837	332	451	09.05-	■	■
FM10 09.98-12.03					Platform/Chassis				
FM 10/320 (D10B320)		Diesel		9600	235	320	04.99-12.01	■	■
FM 10/320 (D10B320)		Diesel		9600	235	320	04.99-12.01	■	■
FM 10/360 (D10B360)		Diesel		9600	265	360	04.99-12.01	■	■
FM 10/360 (D10B360)		Diesel		9600	265	360	04.99-12.01	■	■
FM12 08.98-11.08					Dump Truck				
FM 12H/340 (D12C340)		Diesel		12130	250	340	08.98-09.05	■	■
FM 12H/340 (D12D340)		Diesel		12130	250	340	08.98-09.05	■	■
FM 12H/380 (D12C380)		Diesel		12130	279	379	08.98-09.05	■	■
FM 12H/380 (D12D380)		Diesel		12130	279	379	08.98-09.05	■	■
FM 12H/420 (D12C420)		Diesel		12130	309	420	08.98-09.05	■	■
FM 12H/420 (D12D420)		Diesel		12130	309	420	08.98-09.05	■	■
FM 12/340		Diesel		12132	250	340	08.98-11.08	■	■
FM 12/340		Diesel		12132	250	340	08.98-11.08	■	■
FM 12/340		Diesel		12132	250	340	08.98-11.08	■	■
FM 12/340		Diesel		12132	250	340	08.98-11.08	■	■
FM 12/340		Diesel		12132	250	340	08.98-11.08	■	■
FM 12/340		Diesel		12132	250	340	08.98-11.08	■	■
FM 12/380		Diesel		12132	279	379	08.98-11.08	■	■
FM 12/380		Diesel		12132	279	379	08.98-11.08	■	■
FM 12/380		Diesel		12132	279	379	08.98-11.08	■	■
FM 12/380		Diesel		12132	279	379	08.98-11.08	■	■
FM 12/380		Diesel		12132	279	379	08.98-11.08	■	■
FM 12/380		Diesel		12132	279	379	08.98-11.08	■	■
FM 12/380		Diesel		12132	279	379	08.98-11.08	■	■
FM 12/420		Diesel		12132	309	420	08.98-11.08	■	■
FM 12/420		Diesel		12132	309	420	08.98-11.08	■	■
FM 12/420		Diesel		12132	309	420	08.98-11.08	■	■
FM 12/420		Diesel		12132	309	420	08.98-11.08	■	■
FM 12/420		Diesel		12132	309	420	08.98-11.08	■	■
FM 12/460		Diesel		12132	338	460	08.98-11.08	■	■
FM 12/460		Diesel		12132	338	460	08.98-11.08	■	■
FM12 08.98-11.08					Platform/Chassis				
FM 12/340 (D12C340)		Diesel		12130	250	340	08.98-09.05	■	■
FM 12/340 (D12D340)		Diesel		12130	250	340	08.98-09.05	■	■
FM 12/340 (D12C340)		Diesel		12130	250	340	08.98-09.05	■	■
FM 12/340 (D12D340)		Diesel		12130	250	340	08.98-09.05	■	■
FM 12/340 (D12C340)		Diesel		12130	250	340	08.98-09.05	■	■
FM 12/340 (D12D340)		Diesel		12130	250	340	08.98-09.05	■	■
FM 12/340 (D12C340)		Diesel		12130	250	340	08.98-09.05	■	■
FM 12/340 (D12D340)		Diesel		12130	250	340	08.98-09.05	■	■
FM 12/340 (D12C340)		Diesel		12130	250	340	08.98-09.05	■	■
FM 12/340 (D12D340)		Diesel		12130	250	340	08.98-09.05	■	■
FM 12/340 (D12C340)		Diesel		12130	250	340	08.98-09.05	■	■

LISTA DE APLICACIONES - BUYERS GUIDE

FM 12/460 (D12C460)		Diesel		12130	338	460	08.98-09.05	■	■	
FM 12/460		Diesel		12130	338	460	08.98-09.05	■	■	
FM 12/340		Diesel		12132	250	340	08.98-11.08	■	■	
FM 12/340		Diesel		12132	250	340	08.98-11.08	■	■	
FM 12/340		Diesel		12132	250	340	08.98-11.08	■	■	
FM 12/380		Diesel		12132	279	379	08.98-11.08	■	■	
FM 12/380		Diesel		12132	279	379	08.98-11.08	■	■	
FM 12/380		Diesel		12132	279	379	08.98-11.08	■	■	
FM 12/420		Diesel		12132	309	420	08.98-11.08	■	■	
FM 12/420		Diesel		12132	309	420	08.98-11.08	■	■	
FM 12/420		Diesel		12132	309	420	08.98-11.08	■	■	
FM 12/460		Diesel		12132	338	460	08.98-11.08	■	■	
FM 12/460		Diesel		12132	338	460	08.98-11.08	■	■	
FM 12/460		Diesel		12132	338	460	08.98-11.08	■	■	
FM7 08.98-12.01							Dump Truck			
FM 7/250 (D7C250)		Diesel		7284	184	250	08.98-12.01	■	■	
FM 7/250 (D7C250)		Diesel		7284	184	250	08.98-12.01	■	■	
FM 7/290 (D7C290)		Diesel		7284	213	290	08.98-12.01	■	■	
FM 7/290 (D7C290)		Diesel		7284	213	290	08.98-12.01	■	■	
FM7 08.98-12.01							Platform/Chassis			
FM 7/250 (D7C250)		Diesel		7284	184	250	08.98-12.01	■	■	
FM 7/250 (D7C250)		Diesel		7284	184	250	08.98-12.01	■	■	
FM 7/250 (D7C250)		Diesel		7284	184	250	08.98-12.01	■	■	
FM 7/290 (D7C290)		Diesel		7284	213	290	08.98-12.01	■	■	
FM 7/290 (D7C290)		Diesel		7284	213	290	08.98-12.01	■	■	
FM 7/290 (D7C290)		Diesel		7284	213	290	08.98-12.01	■	■	
FM 7/290		Diesel		7284	213	290	08.98-12.01	■	■	
FM7 08.98-12.01							Truck Tractor			
FM 7/250 (D7C250)		Diesel		7284	184	250	08.98-12.01	■	■	
FM 7/290 (D7C290)		Diesel		7284	213	290	08.98-12.01	■	■	
FM 7/290		Diesel		7284	213	290	08.98-12.01	■	■	
FM9 12.01-09.05							Platform/Chassis			
FM 9/260 (D9A260)		Diesel		9364	191	260	12.01-09.05	■	■	
FM 9/260 (D9A260)		Diesel		9364	191	260	12.01-09.05	■	■	
FM 9/300 (D9B300)		Diesel		9364	220	299	12.01-09.05	■	■	
FM 9/300 (D9A300)		Diesel		9364	221	300	12.01-09.05	■	■	
FM 9/300 (D9A300)		Diesel		9364	221	300	12.01-09.05	■	■	
FM 9/340 (D9A340)		Diesel		9364	250	340	12.01-09.05	■	■	
FM 9/340 (D9A340)		Diesel		9364	250	340	12.01-09.05	■	■	
FM 9/340 (D9A340)		Diesel		9364	250	340	12.01-09.05	■	■	
FM 9/340 (D9A340)		Diesel		9364	250	340	12.01-09.05	■	■	
FM 9/380 (D9A380)		Diesel		9364	279	380	12.01-09.05	■	■	
FM 9/380 (D9A380)		Diesel		9364	279	380	12.01-09.05	■	■	
FM9 12.01-09.05							Truck Tractor			
FM 9/260 (D9A260)		Diesel		9364	191	260	12.01-09.05	■	■	
FM 9/260 (D9A260)		Diesel		9364	191	260	12.01-09.05	■	■	
FM 9/300 (D9A300)		Diesel		9364	221	300	12.01-09.05	■	■	
FM 9/300 (D9A300)		Diesel		9364	221	300	12.01-09.05	■	■	
FM 9/340 (D9A340)		Diesel		9364	250	340	12.01-09.05	■	■	
FM 9/340 (D9A340)		Diesel		9364	250	340	12.01-09.05	■	■	

LISTA DE APLICACIONES - BUYERS GUIDE

FM 9/380 (D9A380)		Diesel		9364	279	380	12.01-09.05	■	■	
FM 9/380 (D9A380)		Diesel		9364	279	380	12.01-09.05	■	■	
NH12 01.97-							Platform/Chassis			
NH 12/380 (D12C380)		Diesel		12130	279	379	05.99-	■	■	
NH12 01.97-							Truck Tractor			
NH 12/380 (D12C380)		Diesel		12130	279	379	05.99-	■	■	
NH 12/380 (D12C380)		Diesel		12130	279	379	05.99-	■	■	
NH 12/420 (D12C420)		Diesel		12130	309	420	05.99-	■	■	
VM 01.12-12.13							Platform/Chassis			
240 (7A240)		Diesel		7118	176	239	01.12-	■	■	
260 (7A260)		Diesel		7118	191	260	01.12-	■	■	
270 (7B270)		Diesel		7118	200	272	01.12-	■	■	