

LISTA DE APLICACIONES - BUYERS GUIDE

181121




8 424073 018038

Qty: 300

Weight: 1.251

O.E.M.	MAKE
16 114 584 80	PEUGEOT
16 172 523 80	PEUGEOT
16 172 524 80	PEUGEOT
4151.88	PEUGEOT
4251.21	PEUGEOT
4251.34	PEUGEOT
4251.38	PEUGEOT
4251.39	PEUGEOT
4251.42	PEUGEOT
4251.67	PEUGEOT
4251.70	PEUGEOT
4252.67	CITROËN
4253.04	PEUGEOT
4253.06	CITROËN
4253.16	PEUGEOT
4254.50	PEUGEOT
4254.82	PEUGEOT
86 60 004 613	RENAULT
86 71 016 517	RENAULT
E172513	CITROËN



181121



90R-01101/054



Ate - Teves

140.25x47.4x17.3

141.4x47.4x17.3

WVA

21430

21826

21827

25928

FMSI

D1483-8681

MAKE

CITROËN

PEUGEOT



Trac.

CC

Kw

CV



Front / Rear

CITROËN

SAXO / CHANSON (S0, S1) 02.96-04.04

					Hatchback (Supermini car-B Segment)				
1.1 X, SX (HDZ (TU1M))		Gasolina	FWD	1124	44	60	05.96-09.03		■
1.1 X, SX (HFX (TU1JP))		Gasolina	FWD	1124	44	60	05.96-09.03		■
1.4 VTS (KFW (TU3JP))		Gasolina	FWD	1360	55	75	05.96-06.03		■
1.4 VTS (KFX (TU3JP))		Gasolina	FWD	1360	55	75	05.96-06.03		■
1.6 VTL, VTR (NFZ (TU5JP))		Gasolina	FWD	1587	65	88	05.96-06.03		■
1.6 (NFZ (TU5JP))		Gasolina	FWD	1587	66	90	02.96-06.03		■
1.6 VTS (NFT (TU5JP))		Gasolina	FWD	1587	72	98	09.00-09.03		■
1.6 (NFT (TU5JP))		Gasolina	FWD	1587	74	101	02.01-04.04		■
1.6 VTR		Gasolina	FWD	1587	80	109	05.96-07.99		■
1.6 VTS (NFX (TU5JP4))		Gasolina	FWD	1587	87	118	06.96-09.03		■
1.6 (NFX (TU5JP4))		Gasolina	FWD	1587	88	120	02.96-04.04		■
Electric (SA13)		Eléctrico	FWD		20	27	11.96-06.03		■
1.5 D (VJY (TUD5))		Diesel	FWD	1527	40	54	09.96-09.03		■
1.5 D (VJZ (TUD5))		Diesel	FWD	1527	42	57	09.96-06.01		■

SAXO / CHANSON Van (S3_) 10.97-06.03

					Hatchback Van (Supermini car-B Segment)				
1.5 D (VJZ (TUD5))		Diesel	FWD	1527	42	57	08.99-06.01		■

XSARA (N0) 01.98-04.05

					Coupe (Compact car-C Segment)				
1.4 i (KFW (TU3JP))	-12/00	Gasolina	FWD	1360	55	75	03.98-03.05		■
1.4 i (KFX (TU3JP))	-12/00	Gasolina	FWD	1360	55	75	03.98-03.05		■
1.6 i (NFZ (TU5JP))		Gasolina	FWD	1587	65	88	02.98-09.00		■
1.6 16V (NFU (TU5JP4))		Gasolina	FWD	1587	80	109	09.00-03.05		■
1.8 i (LFX (XU7JB))		Gasolina	FWD	1761	66	90	02.98-09.00		■

LISTA DE APLICACIONES - BUYERS GUIDE

1.8 i (LFZ (XU7JP))		Gasolina	FWD	1761	74	101	02.98-09.00	■
2.0 i 16V (RFS (XU10J4RS))		Gasolina	FWD	1998	120	163	02.98-03.05	■
1.9 D (WJY (DW8B))	-12/00	Diesel	FWD	1868	51	70	02.99-03.05	■
1.9 D (WJZ (DW8))	-12/00	Diesel	FWD	1868	51	70	02.99-03.05	■
1.9 D (DJY (XUD9A))		Diesel	FWD	1905	50	68	02.98-09.00	■
1.9 D (DHV (XUD9BSD))		Diesel	FWD	1905	55	75	02.98-05.99	■
1.9 TD (DHY (XUD9TE/Y))		Diesel	FWD	1905	66	90	02.98-09.00	■
XSARA 05.98-08.05					Estate Van (Compact car-C Segment)			
1.8 D (A9A (XUD7))		Diesel	FWD	1769	43	58	05.98-05.99	■
1.9 D (WJZ (DW8))		Diesel	FWD	1868	51	69	06.99-08.05	■
XSARA (N2) 10.97-03.10					Estate (Compact car-C Segment)			
1.4 i (KFW (TU3JP))	-12/00	Gasolina	FWD	1360	55	75	10.97-08.05	■
1.4 i (KFX (TU3JP))	-12/00	Gasolina	FWD	1360	55	75	10.97-08.05	■
1.6 i (NFZ (TU5JP))		Gasolina	FWD	1587	65	88	10.97-09.00	■
1.6 16V (NFU (TU5JP4))		Gasolina	FWD	1587	80	109	09.00-08.05	■
1.4 LPG (KFW (TU3JP))		Gasol./G as (LPG)	FWD	1360	55	75	05.98-08.00	■
1.4 LPG (KFX (TU3JP))		Gasol./G as (LPG)	FWD	1360	55	75	05.98-08.00	■
1.5 D (VJZ (TUD5))	for ABS	Diesel	FWD	1527	42	57	10.97-09.00	■
1.8 D (A9A (XUD7))		Diesel	FWD	1769	43	58	10.97-09.00	■
1.9 D (WJY (DW8B))	-12/00	Diesel	FWD	1868	51	70	07.98-08.05	■
1.9 D (WJZ (DW8))	-12/00	Diesel	FWD	1868	51	70	07.98-08.05	■
1.9 D (DJY (XUD9A))		Diesel	FWD	1905	50	68	10.97-09.00	■
1.9 D (DHV (XUD9BSD))		Diesel	FWD	1905	55	75	01.98-09.00	■
XSARA (N3_) 05.98-03.05					Hatchback Van (Compact car-C Segment)			
1.4 (KFX (TU3JP))		Gasolina	FWD	1360	55	75	05.98-10.04	■
1.4 LPG (KFX (TU3JP))		Gasol./G as (LPG)	FWD	1360	55	75	06.99-08.00	■
1.8 D (A9A (XUD7))		Diesel	FWD	1769	43	58	05.98-05.99	■
1.9 D (WJZ (DW8))		Diesel	FWD	1868	51	69	06.99-03.05	■
1.9 D (DHY (XUD9TE/Y))		Diesel	FWD	1905	65	88	05.98-08.00	■
XSARA (N1) 04.97-12.05					Hatchback (Compact car-C Segment)			
1.4 i (KFW (TU3JP))	-12/00	Gasolina	FWD	1360	55	75	04.97-03.05	■
1.4 i (KFX (TU3JP))	-12/00	Gasolina	FWD	1360	55	75	04.97-03.05	■
1.6 i (NFZ (TU5JP))		Gasolina	FWD	1587	65	88	04.97-09.00	■
1.6 16V (NFU (TU5JP4))		Gasolina	FWD	1587	80	109	09.00-03.05	■
1.8 i (LFX (XU7JB))		Gasolina	FWD	1761	66	90	04.97-09.00	■
1.8 i Aut. (LFZ (XU7JP))		Gasolina	FWD	1761	74	101	04.97-09.00	■
1.4 LPG (KFW (TU3JP))		Gasol./G as (LPG)	FWD	1360	55	75	05.98-08.00	■
1.5 D (VJZ (TUD5))		Diesel	FWD	1527	42	57	04.97-09.00	■
1.8 TD		Diesel	RWD	1761	66	90	10.97-09.00	■
1.8 D (161A (XUD7))		Diesel	FWD	1769	43	58	04.97-09.00	■
1.8 D (A9A (XUD7))		Diesel	FWD	1769	43	58	04.97-09.00	■
1.9 D (WJY (DW8B))	-12/00	Diesel	FWD	1868	51	70	07.98-03.05	■
1.9 D (WJZ (DW8))	-12/00	Diesel	FWD	1868	51	70	07.98-03.05	■
1.9 D (WJY (DW8B))		Diesel	FWD	1868	52	72	04.00-04.05	■
1.9 D (DJY (XUD9A))		Diesel	FWD	1905	50	68	04.97-09.00	■
1.9 SD (DHV (XUD9BSD))		Diesel	FWD	1905	55	75	01.98-09.00	■
1.9 TD (DHY (XUD9TE/Y))		Diesel	FWD	1905	66	90	04.97-09.00	■

LISTA DE APLICACIONES - BUYERS GUIDE

PEUGEOT								
106 (1S_) 08.91-03.96					Hatchback Van (Supermini car-B Segment)			
1.4 D (K9Y (TUD3Y))		Diesel	FWD	1360	37	50	08.91-03.96	■
106 (1A, 1C) 08.91-04.96					Hatchback (Supermini car-B Segment)			
1.3 (TU2J2)	01/95-	Gasolina	FWD	1294	72	98	10.93-04.96	■
1.4 (K5A (TU3))	01/95-	Gasolina	FWD	1360	51	69	08.91-03.96	■
1.4 (KDX (TU3MC))		Gasolina	FWD	1360	55	75	09.91-04.96	■
1.4 (KDY (TU3M))		Gasolina	FWD	1360	55	75	09.91-04.96	■
1.4 Le Mans (KFZ (TU3J2/Z))		Gasolina	FWD	1361	69	94	09.91-11.94	■
1.6 (NFZ (TU5JP))	01/95-	Gasolina	FWD	1587	65	88	06.93-04.96	■
1.6 (NFY (TU5J2))	01/95-	Gasolina	FWD	1587	76	103	11.94-04.96	■
1.4 D (K9Y (TUD3Y))	01/95-	Diesel	FWD	1361	37	50	09.92-04.96	■
1.5 D (VJY (TUD5))	01/95-	Diesel	FWD	1527	40	54	06.94-04.96	■
1.5 D (VJY (TUD5))	01/95-	Diesel	FWD	1527	43	58	06.94-04.96	■
1.5 D (VJZ (TUD5))	01/95-	Diesel	FWD	1527	43	58	06.94-04.96	■
106 II (1S_) 04.96-03.01					Hatchback Van (LCVs-N1 Segment)			
1.0 (CDY (TU9M))		Gasolina	FWD	954	33	45	04.96-03.01	■
1.0 (TU9)		Gasolina	FWD	954	33	45	04.96-03.01	■
Electric		Eléctrico	FWD		20	27	04.96-03.01	■
1.5 D (VJY (TUD5))		Diesel	FWD	1527	40	55	05.96-03.01	■
1.5 D (VJX (TUD5))		Diesel	FWD	1527	42	57	06.96-03.01	■
106 II (1A_, 1C_) 04.96-05.05					Hatchback (Supermini car-B Segment)			
1.0 i (CDY (TU9M))		Gasolina	FWD	954	33	45	05.96-10.99	■
1.0 i (CDZ (TU9M))		Gasolina	FWD	954	37	50	04.96-03.01	■
1.1 i (HDY (TU1M+))		Gasolina	FWD	1124	40	54	01.97-03.01	■
1.1 i (HDZ (TU1M+))		Gasolina	FWD	1124	44	60	05.96-07.04	■
1.1 i (HFX (TU1JP))		Gasolina	FWD	1124	44	60	05.96-07.04	■
1.4 i (KFW (TU3JP))		Gasolina	FWD	1360	55	75	05.96-07.04	■
1.4 i (KFX (TU3JP))		Gasolina	FWD	1360	55	75	05.96-07.04	■
1.6 i (NFZ (TU5JP))		Gasolina	FWD	1587	65	89	05.96-10.99	■
1.6 i (NFW (TU5J2))	-12/99	Gasolina	FWD	1587	74	101	05.96-01.01	■
1.6 i (NFY (TU5J2))	-12/99	Gasolina	FWD	1587	74	101	05.96-01.01	■
1.6 S16 (NFX (TU5J4))	-12/99	Gasolina	FWD	1587	87	118	05.96-07.04	■
1.1 BiFuel (HDZ (TU1M+))		Gasol./Gas (LPG)	FWD	1124	44	60	04.96-03.01	■
Electric (SA13)		Eléctrico	FWD		20	27	04.96-07.04	■
1.5 D (VJY (TUD5))		Diesel	FWD	1527	40	55	05.96-03.01	■
1.5 D (VJX (TUD5))		Diesel	FWD	1527	42	57	04.98-07.04	■
1.5 D (VJY (TUD5))		Diesel	FWD	1527	42	57	04.98-07.04	■
1.5 D (VJZ (TUD5))		Diesel	FWD	1527	42	57	04.98-07.04	■
205 (741B, 20D) 03.86-11.95					Convertible (Supermini car-B Segment)			
1.9 CTI (DKZ (XU9JAZ))		Gasolina	FWD	1905	92	125	08.90-07.92	■
205 08.90-05.97					Hatchback Van (LCVs-N1 Segment)			
1.7 Diesel (161A (XUD7))	-12/96	Diesel	FWD	1769	44	60	03.94-05.97	■
205 (20A/C) 01.87-12.00					Hatchback (Supermini car-B Segment)			
1.1 XA (E1)		Gasolina	FWD	1118	40	54	07.87-10.88	■
1.2 (F1)		Gasolina	FWD	1204	47	64	01.87-12.90	■
1.6 (B1E (XU51C))		Gasolina	FWD	1580	53	72	10.87-09.98	■

LISTA DE APLICACIONES - BUYERS GUIDE

306 (7D, N3, N5) 01.94-04.02					Convertible (Compact car-C Segment)			
1.6 (NFZ (TU5JP))	01/97-, not for ABS	Gasolina	FWD	1587	65	89	04.96-10.00	■
1.6 (NFT (TU5JP))	-12/01, not for ABS	Gasolina	FWD	1587	72	98	10.00-04.02	■
1.8 (L6A (XU7JP))	01/97-	Gasolina	FWD	1761	74	101	03.94-04.02	■
1.8 (LFZ (XU7JP))	01/97-	Gasolina	FWD	1761	74	101	03.94-04.02	■
1.8 (LFZ (XU7JP))		Gasolina	FWD	1761	74	101	05.97-04.99	■
306 (N_, 7_) 07.93-08.02					Estate Van (Compact car-C Segment)			
1.4 (KFW (TU3JP))		Gasolina	FWD	1360	55	75	03.96-07.01	■
1.8 D (A9A (XUD7))		Diesel	FWD	1769	44	60	05.97-06.00	■
1.9 D (XUD9)		Diesel	FWD	1905	50	68	05.97-05.99	■
1.9 STD (XUD9)		Diesel	FWD	1905	51	69	02.94-05.99	■
1.9 D (XUD9TE)		Diesel	FWD	1905	68	92	02.94-04.99	■
306 (7E, N3, N5) 06.94-12.02					Estate (Compact car-C Segment)			
1.4 (KFW (TU3JP))	-12/00	Gasolina	FWD	1360	55	75	03.97-04.02	■
1.4 (KFX (TU3JP))	-12/00	Gasolina	FWD	1360	55	75	03.97-04.02	■
1.6 (NFZ (TU5JP))	discØ 347, Vented disc, not for ABS	Gasolina	FWD	1587	65	89	03.97-10.00	■
1.6 (NFT (TU5JP))	-12/01	Gasolina	FWD	1587	72	98	10.00-04.02	■
1.8 (LFZ (XU7JP))	-12/99	Gasolina	FWD	1761	74	101	03.97-04.02	■
1.8 D		Diesel	RWD	1769	44	60	05.97-06.00	■
1.8 D (A9A (XUD7))		Diesel	FWD	1769	44	60	05.97-06.00	■
1.9 D (WJY (DW8B))	-12/01	Diesel	FWD	1868	51	69	09.98-04.02	■
1.9 D (WJZ (DW8))	-12/01	Diesel	FWD	1868	51	69	09.98-04.02	■
1.9 D (DJY (XUD9A))	-12/01	Diesel	FWD	1905	50	68	03.97-04.02	■
1.9 D (DJY (XUD9A))		Diesel	FWD	1905	51	69	05.97-05.99	■
1.9 TD (DJY (XUD9A))	vehicles without ABS	Diesel	FWD	1905	52	71	07.95-08.00	■
1.9 D (DHV (XUD9BSD))		Diesel	FWD	1905	55	75	03.98-04.02	■
1.9 TD (D8A (XUD9TE))		Diesel	FWD	1905	66	90	02.97-04.02	■
1.9 TD (DHY (XUD9TE))		Diesel	FWD	1905	66	90	02.97-04.02	■
1.9 TD (DHY (XUD9TE))		Diesel	FWD	1905	67	92	01.99-04.02	■
2.0 HDI 90 (RHY (DW10TD))	-12/00	Diesel	FWD	1997	66	90	06.99-04.02	■
306 04.93-08.01					Hatchback Van (Compact car-C Segment)			
1.4 (KFX (TU3JP))		Gasolina	FWD	1360	55	75	03.96-07.01	■
1.8 D (A9A (XUD7))		Diesel	FWD	1769	44	60	04.93-05.99	■
1.9 D (WJY (DW8B))		Diesel	FWD	1868	51	69	02.99-08.01	■
1.9 D (WJZ (DW8))		Diesel	FWD	1868	51	69	02.99-08.01	■
1.9 D (DJY (XUD9A))		Diesel	FWD	1905	50	68	05.97-05.99	■
306 (7A, 7C, N3, N5) 01.93-10.03					Hatchback (Compact car-C Segment)			
1.1 (HDZ (TU1M))		Gasolina	FWD	1124	44	60	05.93-05.01	■
1.4 (KDX (TU3MC))	01/97-	Gasolina	FWD	1360	55	75	04.93-07.01	■
1.4 (KFW (TU3JP))	01/97-	Gasolina	FWD	1360	55	75	04.93-07.01	■
1.4 (KFX (TU3JP))	01/97-	Gasolina	FWD	1360	55	75	04.93-07.01	■
1.6 (NFZ (TU5JP))	01/97-	Gasolina	FWD	1587	65	89	05.93-10.00	■
1.6 (NFZ (TU5JP))		Gasolina	FWD	1587	66	90	07.00-05.01	■
1.6 (NFT (TU5JP))		Gasolina	FWD	1587	72	98	10.00-05.01	■
1.8 (LFZ (XU7JP))	01/97-	Gasolina	FWD	1761	74	101	05.93-05.01	■
1.8 (LFZ (XU7JP))		Gasolina	FWD	1761	74	101	05.93-05.01	■
1.8 D (A9A (XUD7))	01/97-	Diesel	FWD	1769	43	58	05.93-05.01	■
1.9 D (WJY (DW8B))		Diesel	FWD	1868	51	69	09.98-05.01	■

LISTA DE APLICACIONES - BUYERS GUIDE

1.9 D (WJZ (DW8))		Diesel	FWD	1868	51	69	09.98-05.01	■
1.9 D (WJZ (DW8))	discØ 247, -Org. 09002, vehicles without ABS	Diesel	FWD	1868	52	71	01.99-08.03	■
1.9 D (DJZ (XUD9A))	01/97-	Diesel	FWD	1905	47	64	05.93-05.01	■
1.9 D (DJY (XUD9A))	01/97-	Diesel	FWD	1905	50	68	06.94-05.01	■
1.9 D (D9B (XUD9A))		Diesel	FWD	1905	51	69	04.93-05.99	■
1.9 D (DJY (XUD9A))		Diesel	FWD	1905	51	69	04.93-05.99	■
1.9 D (XUD9)		Diesel	FWD	1905	51	69	04.93-05.99	■
1.9 TD (DJY (XUD9A))	Vented disc	Diesel	FWD	1905	52	71	07.95-08.00	■
1.9 D (DHV (XUD9BSD))		Diesel	FWD	1905	55	75	03.98-05.01	■
1.9 DT (DHY (XUD9TE))		Diesel	FWD	1905	66	90	05.93-05.01	■
1.9 D (D8A (XUD9TE))		Diesel	FWD	1905	68	92	01.93-12.97	■
2.0 HDI 90 (RHY (DW10TD))	-12/00	Diesel	FWD	1997	66	90	06.99-12.02	■
306 (7B, N3, N5) 04.93-10.03					Saloon (Compact car-C Segment)			
1.1 (HDZ (TU1M))		Gasolina	FWD	1124	44	60	06.94-05.01	■
1.4 SL (KDX (TU3MC))	01/97-	Gasolina	FWD	1360	55	75	06.94-05.01	■
1.4 SL (KFW (TU3JP))	01/97-	Gasolina	FWD	1360	55	75	06.94-05.01	■
1.4 SL (KFX (TU3JP))	01/97-	Gasolina	FWD	1360	55	75	06.94-05.01	■
1.6 SR (NFZ (TU5JP))	01/97-	Gasolina	FWD	1587	65	89	06.94-10.00	■
1.6 (NFZ (TU5JP))	vehicles with ABS, Vented disc	Gasolina	FWD	1587	66	90	07.00-05.01	■
1.6 (NFT (TU5JP))		Gasolina	FWD	1587	72	98	10.00-05.01	■
1.8 (LFZ (XU7JP))		Gasolina	FWD	1761	74	101	06.94-05.01	■
1.8 ST (LFZ (XU7JP))	01/97-	Gasolina	FWD	1761	74	101	06.94-05.01	■
1.8 D (A9A (XUD7))		Diesel	FWD	1769	44	60	05.97-06.00	■
1.9 D (WJY (DW8B))	-12/00	Diesel	FWD	1868	51	69	09.98-05.01	■
1.9 D (WJZ (DW8))	-12/00	Diesel	FWD	1868	51	69	09.98-05.01	■
1.9 SLD (DJZ (XUD9A))	01/97-	Diesel	FWD	1905	47	64	06.94-05.01	■
1.9 SLD (DJY (XUD9A))	01/97-	Diesel	FWD	1905	50	68	06.94-05.01	■
1.9 STD (D9B (XUD9A))		Diesel	FWD	1905	51	69	02.94-10.95	■
1.9 STD (XUD9)		Diesel	FWD	1905	51	69	02.94-10.95	■
1.9 D (DHV (XUD9BSD))		Diesel	FWD	1905	55	75	03.98-05.01	■
1.9 SRDT (DHY (XUD9TE))		Diesel	FWD	1905	66	90	06.94-05.01	■
1.9 D (D8A (XUD9TE))		Diesel	FWD	1905	68	92	02.94-12.97	■
2.0 HDI 90 (RHY (DW10TD))	-12/00	Diesel	FWD	1997	66	90	06.99-12.01	■