

LISTA DE APLICACIONES - BUYERS GUIDE


181664-700




Qty: 944

Weight: 900

O.E.M.	MAKE
34 21 2 288 889	BMW
34 21 2 288 890	BMW
34 21 6 767 145	BMW
34 21 6 767 146	BMW
34 21 6 774 417	BMW
34 21 6 777 240	BMW
34 21 6 779 294	BMW
34 21 6 788 183	BMW



181664-700



1-690022

181664-700



E 90R-01110/976

Trw

95.3x44.7x17.4

95.3x50.95x17.4

WVA	FMSI
23623	D1226-8345
23624	
MAKE	
BMW	



Trac.	CC	Kw	CV	
				Front / Rear

BMW

1 Serie (E82) 10.06-10.13

					Coupe (Compact car-C Segment)			
120 i (N43 B20 A)	-12/10	Gasolina	RWD	1995	125	170	10.07-10.13	■

1 Serie (E87) 02.03-01.13

					Hatchback (Compact car-C Segment)			
116 i (N45 B16 A)	not M technique	Gasolina	RWD	1596	85	115	06.04-06.11	■
116 i (N45 B16 A)	-12/10	Gasolina	RWD	1596	85	115	09.07-12.11	■
116 i	not M technique	Gasolina	RWD	1599	89	121	03.07-06.11	■
116 i (N43 B16 AA)	not M technique	Gasolina	RWD	1599	90	122	09.07-06.11	■
116 i (N43 B16 AA)	-12/10	Gasolina	RWD	1599	90	122	03.07-12.11	■
116 i (N43 B20 A)	not M technique	Gasolina	RWD	1995	90	122	01.09-06.11	■
116 i (N43 B20 A)	01/09-	Gasolina	RWD	1995	90	122	11.08-12.11	■
118 i (N46 B20 B)	not M technique	Gasolina	RWD	1995	95	129	07.04-02.07	■
118 i	-12/10	Gasolina	FWD	1995	95	129	09.06-09.12	■
118 i (N46 B20 B)		Gasolina	RWD	1995	95	129	09.06-02.08	■
118 i (N46 B20 B)	not M technique	Gasolina	RWD	1995	100	136	10.06-06.11	■
118 i (N46 B20 B)	01/07-, discØ 296, Syst. Standard	Gasolina	RWD	1995	100	136	09.06-12.11	■
118 i (N43 B20 A)	not M technique	Gasolina	RWD	1995	105	143	09.06-06.11	■
118 i (N43 B20 A)	01/07-	Gasolina	RWD	1995	105	143	09.06-12.11	■
120 i (N46 B20 B)	not M technique	Gasolina	RWD	1995	110	150	06.04-02.07	■
120 i (N46 B20 BD)	not M technique	Gasolina	RWD	1995	110	150	06.04-02.07	■
120 i (N46 B20 C)	not M technique	Gasolina	RWD	1995	110	150	06.04-02.07	■
120 i (N46 B20 CC)	not M technique	Gasolina	RWD	1995	110	150	06.04-02.07	■
120 i	-12/10	Gasolina	FWD	1995	110	150	09.06-09.12	■
120 i (N46 B20 A)	not M technique	Gasolina	RWD	1995	115	156	03.07-06.11	■

LISTA DE APLICACIONES - BUYERS GUIDE

120 i (N46 B20 B)	not M technique	Gasolina	RWD	1995	115	156	03.07-06.11	■
120 i (N46 B20 BD)	not M technique	Gasolina	RWD	1995	115	156	03.07-06.11	■
120 i (N46 B20 C)	not M technique	Gasolina	RWD	1995	115	156	03.07-06.11	■
120 i (N46 B20 CC)	not M technique	Gasolina	RWD	1995	115	156	03.07-06.11	■
120 i (N46 B20 B)		Gasolina	RWD	1995	115	156	03.07-12.11	■
120 i (N46 B20 C)		Gasolina	RWD	1995	115	156	03.07-12.11	■
120 i (N43 B20 A)	not M technique	Gasolina	RWD	1995	120	163	03.07-06.11	■
120 i (N43 B20 A)		Gasolina	RWD	1995	120	163	03.07-12.11	■
118 i (N43 B20 A)	not M technique, discØ 296, Syst. Standard	Gasolina	RWD	1995	125	170	03.07-12.07	■
120 i (N43 B20 A)	not M technique	Gasolina	RWD	1995	125	170	03.07-06.11	■
120 i (N43 B20 A)		Gasolina	RWD	1995	125	170	03.07-09.12	■
116 d (N47 D20 C)	not M technique	Diesel	RWD	1995	66	90	01.11-12.11	■
116 d (N47 D20 A)		Diesel	RWD	1995	66	90	01.11-12.11	■
116 d (N47 D20 C)		Diesel	RWD	1995	66	90	01.11-12.11	■
116 d (N47 D20 A)	not M technique	Diesel	RWD	1995	85	116	03.09-06.11	■
116 d (N47 D20 C)	not M technique	Diesel	RWD	1995	85	116	03.09-06.11	■
116 d (N47 D20 A)	01/09-	Diesel	RWD	1995	85	116	11.08-12.11	■
116 d (N47 D20 C)	01/09-	Diesel	RWD	1995	85	116	11.08-12.11	■
118 d (M47 D20 (204D4))	not M technique	Diesel	RWD	1995	90	122	06.04-02.07	■
118 d	-12/10	Diesel	RWD	1995	90	122	09.06-09.12	■
118 d (N47 D20 A)	01/07-	Diesel	RWD	1995	100	136	09.06-12.11	■
118 d (N47 D20 C)	01/07-	Diesel	RWD	1995	100	136	09.06-12.11	■
3 Serie IV (E46) 04.00-12.07					Convertible (Compact executive car-D Segment)			
318 Ci (N46 B20 A)		Gasolina	RWD	1995	110	150	03.04-08.06	■
318 Ci (N46 B20 C)		Gasolina	RWD	1995	110	150	03.04-08.06	■
3 Serie V (E93) 05.06-12.13					Convertible (Compact executive car-D Segment)			
320i		Gasolina	RWD	1995	110	149	01.07-08.13	■
3 Serie V (E92) 01.05-12.13					Coupe (Compact executive car-D Segment)			
316 i (N43 B16 AA)		Gasolina	RWD	1599	90	122	09.07-06.13	■
320i		Gasolina	RWD	1995	110	150	11.06-06.07	■
3 Serie V (E90) 02.04-02.12					Saloon (Compact executive car-D Segment)			
316 i (N45 B16 A)		Gasolina	RWD	1596	85	115	09.05-10.11	■
316 i (N45 B16 AC)		Gasolina	RWD	1596	85	115	09.05-10.11	■
316 i (N43 B16 A)		Gasolina	RWD	1599	90	122	09.07-10.11	■
316 i (N43 B16 AA)		Gasolina	RWD	1599	90	122	09.07-10.11	■
1.8 316 i 15"	01/05-	Gasolina	FWD	1795			02.04-	■
1.8 316 i 15"	01/05-	Gasolina	FWD	1795			02.04-	■
318i (N46 B20 B)		Gasolina	RWD	1995	95	129	09.05-08.07	■
318i (N46 B20 B)		Gasolina	RWD	1995	100	136	09.07-10.11	■
318i (N46 B20 C)		Gasolina	RWD	1995	100	136	09.07-10.11	■
318i (N46 B20 CC)		Gasolina	RWD	1995	100	136	09.07-10.11	■
318i (N46 B20 CD)		Gasolina	RWD	1995	100	136	09.07-10.11	■
318i (N46 B20 E)		Gasolina	RWD	1995	100	136	09.07-10.11	■
320i (N46 B20 B)		Gasolina	RWD	1995	110	150	12.04-08.07	■
320i (N46 B20 BD)		Gasolina	RWD	1995	110	150	12.04-08.07	■
320i (N46 B20 C)		Gasolina	RWD	1995	110	150	12.04-08.07	■
320i (N46 B20 CB)		Gasolina	RWD	1995	110	150	12.04-08.07	■
320i (N46 B20 B)		Gasolina	RWD	1995	115	156	02.07-12.11	■
320i (N46 B20 C)		Gasolina	RWD	1995	115	156	02.07-12.11	■

LISTA DE APLICACIONES - BUYERS GUIDE

320i (N46 B20 CC)		Gasolina	RWD	1995	115	156	02.07-12.11	■
320i (N46 B20 CD)		Gasolina	RWD	1995	115	156	02.07-12.11	■
320i (N46 B20 E)		Gasolina	RWD	1995	115	156	02.07-12.11	■
316 d (N47 D20 C)		Diesel	RWD	1995	85	116	07.09-12.11	■
318 d (M47 D20 (204D4))		Diesel	RWD	1995	90	122	03.05-08.07	■
318 d (N47 D20 A)		Diesel	RWD	1995	100	136	09.07-10.11	■
318 d (N47 D20 C)		Diesel	RWD	1995	100	136	09.07-10.11	■
3 Serie V Touring (E91) 12.04-12.12					Estate (Compact executive car-D Segment)			
318i (N46 B20 B)		Gasolina	RWD	1995	95	129	01.06-08.07	■
320i (N46 B20 B)		Gasolina	RWD	1995	110	150	09.05-06.12	■
320i (N46 B20 C)		Gasolina	RWD	1995	110	150	09.05-06.12	■
318 d (M47 D20 (204D4))		Diesel	RWD	1995	90	122	09.05-08.07	■
318 d (N47 D20 A)		Diesel	RWD	1995	100	136	07.07-06.12	■
318 d (N47 D20 C)		Diesel	RWD	1995	100	136	07.07-06.12	■