

# LISTA DE APLICACIONES - BUYERS GUIDE

## 21 9494 00



8 424073 077530

Qty: 850



Weight: 7.600

O.E.M.

MAKE

617 423 17 30

MERCEDES-BENZ



## 21 9494 00



163x17x178- Ø410

WVA

19486

19494

MAKE

MAN

MERCEDES-BENZ



Trac.

CC

Kw

CV



Front / Rear

### MAN

#### F90 06.86-12.97

27.272 DF/DFA	01/93-	Diesel			198	270	06.86-	■
27.272 DF/DFA	01/93-	Diesel			198	270	06.86-	■
27.272 DFK/DFAK	01/93-	Diesel			198	270	06.86-	■
27.272 DFK/DFAK	01/93-	Diesel			198	270	06.86-	■
27.272 DFS/DFAS	01/93-	Diesel			198	270	06.86-	■
27.272 DFS/DFAS	01/93-	Diesel			198	270	06.86-	■
27.422 DFK/DFAK	01/93-	Diesel			198	270	06.86-	■
27.422 DFK/DFAK	01/93-	Diesel			198	270	06.86-	■
27.422 DFS/DFAS	01/93-	Diesel			198	270	06.86-	■
27.422 DFS/DFAS	01/93-	Diesel			198	270	06.86-	■
27.472 DF/DFA	01/93-	Diesel			198	270	06.86-	■
27.472 DF/DFA	01/93-	Diesel			198	270	06.86-	■
27.322 DF/DFA	01/93-	Diesel			235	320	06.86-	■
27.322 DF/DFA	01/93-	Diesel			235	320	06.86-	■
27.322 DFK/DFAK	01/93-	Diesel			235	320	06.86-	■
27.322 DFK/DFAK	01/93-	Diesel			235	320	06.86-	■
27.322 DFS/DFAS	01/93-	Diesel			235	320	06.86-	■
27.322 DFS/DFAS	01/93-	Diesel			235	320	06.86-	■
27.372 DF/DFA	01/93-	Diesel			272	370	06.86-	■
27.372 DF/DFA	01/93-	Diesel			272	370	06.86-	■
27.372 DFK/DFAK	01/93-	Diesel			272	370	06.86-	■
27.372 DFK/DFAK	01/93-	Diesel			272	370	06.86-	■
27.372 DFS/DFAS	01/93-	Diesel			272	370	06.86-	■

# LISTA DE APLICACIONES - BUYERS GUIDE

27.372 DFS/DFAS	01/93-	Diesel			272	370	06.86-	■
27.502 DFA	01/93-	Diesel			368	500	06.86-	■
27.502 DFA	01/93-	Diesel			368	500	06.86-	■
27.502 DFAS	01/93-	Diesel			368	500	06.86-	■
27.502 DFAS	01/93-	Diesel			368	500	06.86-	■
41.262VFAK	01/93-	Diesel		10000	191	260	06.86-	■
41.262VFAK	01/93-	Diesel		10000	191	260	06.86-	■
19.272FA	01/93-	Diesel		10000	198	269	06.86-	■
19.272FA	01/93-	Diesel		10000	198	269	06.86-	■
19.272FAK	01/93-	Diesel		10000	198	269	06.86-	■
19.272FAK	01/93-	Diesel		10000	198	269	06.86-	■
19.272FAS	01/93-	Diesel		10000	198	269	06.86-	■
19.272FAS	01/93-	Diesel		10000	198	269	06.86-	■
26.272DF	01/93-	Diesel		10000	198	269	06.86-	■
26.272DF	01/93-	Diesel		10000	198	269	06.86-	■
26.272DFK	01/93-	Diesel		10000	198	269	06.86-	■
26.272DFK	01/93-	Diesel		10000	198	269	06.86-	■
26.272DFS/DFLS	01/93-	Diesel		10000	198	269	06.86-	■
26.272DFS/DFLS	01/93-	Diesel		10000	198	269	06.86-	■
33.272DFA	01/93-	Diesel		10000	198	269	06.86-	■
33.272DFA	01/93-	Diesel		10000	198	269	06.86-	■
19.322FA	01/93-	Diesel		10000	235	320	06.86-	■
19.322FA	01/93-	Diesel		10000	235	320	06.86-	■
19.322FAK	01/93-	Diesel		10000	235	320	06.86-	■
19.322FAK	01/93-	Diesel		10000	235	320	06.86-	■
19.322FAS	01/93-	Diesel		10000	235	320	06.86-	■
19.322FAS	01/93-	Diesel		10000	235	320	06.86-	■
26.322DF	01/93-	Diesel		10000	235	320	06.86-	■
26.322DF	01/93-	Diesel		10000	235	320	06.86-	■
26.322DFK	01/93-	Diesel		10000	235	320	06.86-	■
26.322DFK	01/93-	Diesel		10000	235	320	06.86-	■
26.322DFS/DFLS	01/93-	Diesel		10000	235	320	06.86-	■
26.322DFS/DFLS	01/93-	Diesel		10000	235	320	06.86-	■
26.322UNL/UNLL	01/93-	Diesel		10000	235	320	06.86-	■
26.322UNL/UNLL	01/93-	Diesel		10000	235	320	06.86-	■
33.322DFA	01/93-	Diesel		10000	235	320	06.86-	■
33.322DFA	01/93-	Diesel		10000	235	320	06.86-	■
35.322VF	01/93-	Diesel		10000	235	320	06.86-	■
35.322VF	01/93-	Diesel		10000	235	320	06.86-	■
35.322VFAK	01/93-	Diesel		10000	235	320	06.86-	■
35.322VFAK	01/93-	Diesel		10000	235	320	06.86-	■
35.322VFK	01/93-	Diesel		10000	235	320	06.86-	■
35.322VFK	01/93-	Diesel		10000	235	320	06.86-	■
35.322VFKK	01/93-	Diesel		10000	235	320	06.86-	■
35.322VFKK	01/93-	Diesel		10000	235	320	06.86-	■
41.322VF	01/93-	Diesel		10000	235	320	06.86-	■
41.322VF	01/93-	Diesel		10000	235	320	06.86-	■
19.342FA	01/94-	Diesel		10000	250	340	06.86-	■
19.342FA	01/94-	Diesel		10000	250	340	06.86-	■
19.342FAK	01/94-	Diesel		10000	250	340	06.86-	■
19.342FAK	01/94-	Diesel		10000	250	340	06.86-	■

# LISTA DE APLICACIONES - BUYERS GUIDE

19.342FAS	01/94-	Diesel		10000	250	340	06.86-	■
19.342FAS	01/94-	Diesel		10000	250	340	06.86-	■
26.342DF/DFL	01/94-	Diesel		10000	250	340	06.86-	■
26.342DF/DFL	01/94-	Diesel		10000	250	340	06.86-	■
26.342DFK/DFLK	01/94-	Diesel		10000	250	340	06.86-	■
26.342DFK/DFLK	01/94-	Diesel		10000	250	340	06.86-	■
26.342DFS	01/94-	Diesel		10000	250	340	06.86-	■
26.342DFS	01/94-	Diesel		10000	250	340	06.86-	■
33.342DFA	01/94-	Diesel		10000	250	340	06.86-	■
33.342DFA	01/94-	Diesel		10000	250	340	06.86-	■
35.342VF	01/94-	Diesel		10000	250	340	06.86-	■
35.342VF	01/94-	Diesel		10000	250	340	06.86-	■
35.342VFK	01/94-	Diesel		10000	250	340	06.86-	■
35.342VFK	01/94-	Diesel		10000	250	340	06.86-	■
41.342VF	01/94-	Diesel		10000	250	340	06.86-	■
41.342VF	01/94-	Diesel		10000	250	340	06.86-	■
35.292VF	01/93-	Diesel		11995	213	290	06.86-	■
35.292VF	01/93-	Diesel		11995	213	290	06.86-	■
35.292VFK	01/93-	Diesel		11995	213	290	06.86-	■
35.292VFK	01/93-	Diesel		11995	213	290	06.86-	■
41.292VFAK	01/93-	Diesel		11995	213	290	06.86-	■
41.292VFAK	01/93-	Diesel		11995	213	290	06.86-	■
41.322VFAK	01/93-	Diesel		11995	235	320	06.86-	■
41.322VFAK	01/93-	Diesel		11995	235	320	06.86-	■
35.332VF	01/93-	Diesel		11995	243	330	06.86-	■
35.332VF	01/93-	Diesel		11995	243	330	06.86-	■
35.332VFK	01/93-	Diesel		11995	243	330	06.86-	■
35.332VFK	01/93-	Diesel		11995	243	330	06.86-	■
41.332VFAK	01/93-	Diesel		11995	243	330	06.86-	■
41.332VFAK	01/93-	Diesel		11995	243	330	06.86-	■
35.372VF	01/93-	Diesel		11995	249	339	06.86-	■
35.372VF	01/93-	Diesel		11995	249	339	06.86-	■
35.372VFK	01/93-	Diesel		11995	249	339	06.86-	■
35.372VFK	01/93-	Diesel		11995	249	339	06.86-	■
41.362VFAK	01/93-	Diesel		11995	265	360	06.86-	■
41.362VFAK	01/93-	Diesel		11995	265	360	06.86-	■
19.372FA	01/93-	Diesel		11995	272	370	06.86-	■
19.372FA	01/93-	Diesel		11995	272	370	06.86-	■
19.372FAK	01/93-	Diesel		11995	272	370	06.86-	■
19.372FAK	01/93-	Diesel		11995	272	370	06.86-	■
19.372FAS	01/93-	Diesel		11995	272	370	06.86-	■
19.372FAS	01/93-	Diesel		11995	272	370	06.86-	■
26.372DF/DFL	01/93-	Diesel		11995	272	370	06.86-	■
26.372DF/DFL	01/93-	Diesel		11995	272	370	06.86-	■
26.372DFAK	01/93-	Diesel		11995	272	370	06.86-	■
26.372DFAK	01/93-	Diesel		11995	272	370	06.86-	■
26.372DFK	01/93-	Diesel		11995	272	370	06.86-	■
26.372DFK	01/93-	Diesel		11995	272	370	06.86-	■
26.372DFS	01/93-	Diesel		11995	272	370	06.86-	■
26.372DFS	01/93-	Diesel		11995	272	370	06.86-	■
33.372DFA	01/93-	Diesel		11995	272	370	06.86-	■

# LISTA DE APLICACIONES - BUYERS GUIDE

33.372DFA	01/93-	Diesel		11995	272	370	06.86-	■
33.372DFAK	01/93-	Diesel		11995	272	370	06.86-	■
33.372DFAK	01/93-	Diesel		11995	272	370	06.86-	■
35.372VF	01/93-	Diesel		11995	272	370	06.86-	■
35.372VF	01/93-	Diesel		11995	272	370	06.86-	■
35.372VF	01/93-	Diesel		11995	272	370	06.86-	■
35.372VF	01/93-	Diesel		11995	272	370	06.86-	■
35.372VFK	01/93-	Diesel		11995	272	370	06.86-	■
35.372VFK	01/93-	Diesel		11995	272	370	06.86-	■
35.372VFK	01/93-	Diesel		11995	272	370	06.86-	■
35.372VFK	01/93-	Diesel		11995	272	370	06.86-	■
40.372DFA	01/93-	Diesel		11995	272	370	06.86-	■
40.372DFA	01/93-	Diesel		11995	272	370	06.86-	■
41.372VF	01/93-	Diesel		11995	272	370	06.86-	■
41.372VF	01/93-	Diesel		11995	272	370	06.86-	■
41.372VFAK	01/93-	Diesel		11995	272	370	06.86-	■
41.372VFAK	01/93-	Diesel		11995	272	370	06.86-	■
19.4022FA	01/94-	Diesel		11995	294	400	06.86-	■
19.4022FA	01/94-	Diesel		11995	294	400	06.86-	■
19.402FAK	01/94-	Diesel		11995	294	400	06.86-	■
19.402FAK	01/94-	Diesel		11995	294	400	06.86-	■
19.402FAS	01/94-	Diesel		11995	294	400	06.86-	■
19.402FAS	01/94-	Diesel		11995	294	400	06.86-	■
26.402DF/DFL	01/94-	Diesel		11995	294	400	06.86-	■
26.402DF/DFL	01/94-	Diesel		11995	294	400	06.86-	■
26.402DFK/DFLK	01/94-	Diesel		11995	294	400	06.86-	■
26.402DFK/DFLK	01/94-	Diesel		11995	294	400	06.86-	■
26.402DFS	01/94-	Diesel		11995	294	400	06.86-	■
26.402DFS	01/94-	Diesel		11995	294	400	06.86-	■
33.402DFA	01/94-	Diesel		11995	294	400	06.86-	■
33.402DFA	01/94-	Diesel		11995	294	400	06.86-	■
33.402DFAK	01/94-	Diesel		11995	294	400	06.86-	■
33.402DFAK	01/94-	Diesel		11995	294	400	06.86-	■
35.402VF	01/94-	Diesel		11995	294	400	06.86-	■
35.402VF	01/94-	Diesel		11995	294	400	06.86-	■
35.402VF	01/94-	Diesel		11995	294	400	06.86-	■
35.402VF	01/94-	Diesel		11995	294	400	06.86-	■
35.402VFK	01/94-	Diesel		11995	294	400	06.86-	■
35.402VFK	01/94-	Diesel		11995	294	400	06.86-	■
35.402VFK	01/94-	Diesel		11995	294	400	06.86-	■
35.402VFK	01/94-	Diesel		11995	294	400	06.86-	■
40.402DFA	01/95-	Diesel		11995	294	400	06.86-	■
40.402DFA	01/95-	Diesel		11995	294	400	06.86-	■
41.4022VF	01/94-	Diesel		11995	294	400	06.86-	■
41.4022VF	01/94-	Diesel		11995	294	400	06.86-	■
19.422FA	01/93-	Diesel		11995	309	420	06.86-	■
19.422FA	01/93-	Diesel		11995	309	420	06.86-	■
19.422FAK	01/93-	Diesel		11995	309	420	06.86-	■
19.422FAK	01/93-	Diesel		11995	309	420	06.86-	■
19.422FAS	01/93-	Diesel		11995	309	420	06.86-	■
19.422FAS	01/93-	Diesel		11995	309	420	06.86-	■

# LISTA DE APLICACIONES - BUYERS GUIDE

26.422DF/DFL	01/93-	Diesel		11995	309	420	06.86-	■
26.422DF/DFL	01/93-	Diesel		11995	309	420	06.86-	■
26.422DFK	01/93-	Diesel		11995	309	420	06.86-	■
26.422DFK	01/93-	Diesel		11995	309	420	06.86-	■
26.422DFS	01/93-	Diesel		11995	309	420	06.86-	■
26.422DFS	01/93-	Diesel		11995	309	420	06.86-	■
33.422DFA	01/93-	Diesel		11995	309	420	06.86-	■
33.422DFA	01/93-	Diesel		11995	309	420	06.86-	■
33.422DFAK	01/94-	Diesel		11995	309	420	06.86-	■
33.422DFAK	01/94-	Diesel		11995	309	420	06.86-	■
35.422VF	01/93-	Diesel		11995	309	420	06.86-	■
35.422VF	01/93-	Diesel		11995	309	420	06.86-	■
35.422VF	01/93-	Diesel		11995	309	420	06.86-	■
35.422VF	01/93-	Diesel		11995	309	420	06.86-	■
35.422VF	01/93-	Diesel		11995	309	420	06.86-	■
35.422VF	01/93-	Diesel		11995	309	420	06.86-	■
35.422VFK	01/93-	Diesel		11995	309	420	06.86-	■
35.422VFK	01/93-	Diesel		11995	309	420	06.86-	■
40.422DFA	01/93-	Diesel		11995	309	420	06.86-	■
40.422DFA	01/93-	Diesel		11995	309	420	06.86-	■
41.422VF	01/93-	Diesel		11995	309	420	06.86-	■
41.422VF	01/93-	Diesel		11995	309	420	06.86-	■
41.422VFAK	01/93-	Diesel		11995	309	420	06.86-	■
41.422VFAK	01/93-	Diesel		11995	309	420	06.86-	■
48.502VFA	01/93-	Diesel		11995	368	500	06.86-	■
48.502VFA	01/93-	Diesel		11995	368	500	06.86-	■
48.502VFAK	01/93-	Diesel		11995	368	500	06.86-	■
48.502VFAK	01/93-	Diesel		11995	368	500	06.86-	■
27.502 DF/DFS	01/00-	Diesel		18195	368	500	06.86-	■
27.502 DF/DFS	01/00-	Diesel		18195	368	500	06.86-	■
33.502DFA	01/93-	Diesel		18295	368	500	06.86-	■
33.502DFA	01/93-	Diesel		18295	368	500	06.86-	■
40.502DFA	01/93-	Diesel		18295	368	500	06.86-	■
40.502DFA	01/93-	Diesel		18295	368	500	06.86-	■
<b>F90 06.86-12.97</b>					<b>Platform/Chassis</b>			
26.502 DF (D 2840 LF01)	01/93-	Diesel		18273	368	500	02.90-06.96	■
26.502 DF (D 2840 LF01)	01/93-	Diesel		18273	368	500	02.90-06.96	■
26.502 DF (D 2840 LF04)	01/93-	Diesel		18273	368	500	02.90-06.96	■
26.502 DF (D 2840 LF04)	01/93-	Diesel		18273	368	500	02.90-06.96	■
26.502 DF (D 2840 LF06)	01/93-	Diesel		18273	368	500	02.90-06.96	■
26.502 DF (D 2840 LF06)	01/93-	Diesel		18273	368	500	02.90-06.96	■
<b>F90 06.86-12.97</b>					<b>Truck Tractor</b>			
26.502 DFS,26.502 DFLS (D 2840 LF04)	01/93-	Diesel		18273	368	500	02.90-06.96	■
26.502 DFS,26.502 DFLS (D 2840 LF04)	01/93-	Diesel		18273	368	500	02.90-06.96	■
26.502 DFS,26.502 DFLS (D 2840 LF06)	01/93-	Diesel		18273	368	500	02.90-06.96	■
26.502 DFS,26.502 DFLS (D 2840 LF06)	01/93-	Diesel		18273	368	500	02.90-06.96	■
<b>M 2000 L 04.95-</b>								
15.163LK	01/95-	Diesel		4595	114	155	04.95-	■
15.163LK	01/95-	Diesel		4595	114	155	04.95-	■
15.224LK	01/95-	Diesel		6895	162	220	04.95-	■

# LISTA DE APLICACIONES - BUYERS GUIDE

15.224LK	01/95-	Diesel		6895	162	220	04.95-	■
18.224LAC	01/95-	Diesel		6895	162	220	04.95-	■
18.224LAC	01/95-	Diesel		6895	162	220	04.95-	■
18.224LAK	01/95-	Diesel		6895	162	220	04.95-	■
18.224LAK	01/95-	Diesel		6895	162	220	04.95-	■
18.224LK/LLK	01/95-	Diesel		6895	162	220	04.95-	■
18.224LK/LLK	01/95-	Diesel		6895	162	220	04.95-	■
18.224MAC	01/95-	Diesel		6895	162	220	04.95-	■
18.224MAC	01/95-	Diesel		6895	162	220	04.95-	■
18.224MAK	01/95-	Diesel		6895	162	220	04.95-	■
18.224MAK	01/95-	Diesel		6895	162	220	04.95-	■
18.224MK/MLK	01/95-	Diesel		6895	162	220	04.95-	■
18.224MK/MLK	01/95-	Diesel		6895	162	220	04.95-	■
15.264LK	01/95-	Diesel		6895	191	260	04.95-	■
15.264LK	01/95-	Diesel		6895	191	260	04.95-	■
18.264LAK	01/95-	Diesel		6895	191	260	04.95-	■
18.264LAK	01/95-	Diesel		6895	191	260	04.95-	■
18.264LK/LLK	01/95-	Diesel		6895	191	260	04.95-	■
18.264LK/LLK	01/95-	Diesel		6895	191	260	04.95-	■
18.264MAC	01/95-	Diesel		6895	191	260	04.95-	■
18.264MAC	01/95-	Diesel		6895	191	260	04.95-	■
18.264MAK	01/95-	Diesel		6895	191	260	04.95-	■
18.264MAK	01/95-	Diesel		6895	191	260	04.95-	■
18.264MK/MLK	01/95-	Diesel		6895	191	260	04.95-	■
18.264MK/MLK	01/95-	Diesel		6895	191	260	04.95-	■
15.284LK	01/98-	Diesel		6895	206	280	04.95-	■
15.284LK	01/98-	Diesel		6895	206	280	04.95-	■
18.284LAC	01/98-	Diesel		6895	206	280	04.95-	■
18.284LAC	01/98-	Diesel		6895	206	280	04.95-	■
18.284LAK	01/98-	Diesel		6895	206	280	04.95-	■
18.284LAK	01/98-	Diesel		6895	206	280	04.95-	■
18.284LK/LLK	01/98-	Diesel		6895	206	280	04.95-	■
18.284LK/LLK	01/98-	Diesel		6895	206	280	04.95-	■
18.284MAC	01/98-	Diesel		6895	206	280	04.95-	■
18.284MAC	01/98-	Diesel		6895	206	280	04.95-	■
18.284MAK	01/98-	Diesel		6895	206	280	04.95-	■
18.284MAK	01/98-	Diesel		6895	206	280	04.95-	■
18.284MK/MLK	01/98-	Diesel		6895	206	280	04.95-	■
18.284MK/MLK	01/98-	Diesel		6895	206	280	04.95-	■
<b>M90 08.88-12.98</b>								
17.192F/FL	01/93-	Diesel		6895	140	190	08.88-	■
17.192F/FL	01/93-	Diesel		6895	140	190	08.88-	■
17.192FA	01/93-	Diesel		6895	140	190	08.88-	■
17.192FA	01/93-	Diesel		6895	140	190	08.88-	■
17.192FAK	01/93-	Diesel		6895	140	190	08.88-	■
17.192FAK	01/93-	Diesel		6895	140	190	08.88-	■
17.192FS/FLS	01/93-	Diesel		6895	140	190	08.88-	■
17.192FS/FLS	01/93-	Diesel		6895	140	190	08.88-	■
18.192F/FL/FLL	01/93-	Diesel		6895	140	190	08.88-	■
18.192F/FL/FLL	01/93-	Diesel		6895	140	190	08.88-	■
18.192FK	01/93-	Diesel		6895	140	190	08.88-	■

# LISTA DE APLICACIONES - BUYERS GUIDE

18.192FK	01/93-	Diesel		6895	140	190	08.88-	■
24.192FNL/FNLL	01/93-	Diesel		6895	140	190	08.88-	■
24.192FNL/FNLL	01/93-	Diesel		6895	140	190	08.88-	■
17.232F/FL	01/93-	Diesel		6895	160	218	08.88-	■
17.232F/FL	01/93-	Diesel		6895	160	218	08.88-	■
17.232FA	01/93-	Diesel		6895	160	218	08.88-	■
17.232FA	01/93-	Diesel		6895	160	218	08.88-	■
17.232FAK	01/93-	Diesel		6895	160	218	08.88-	■
17.232FAK	01/93-	Diesel		6895	160	218	08.88-	■
17.232FS/FLS	01/93-	Diesel		6895	160	218	08.88-	■
17.232FS/FLS	01/93-	Diesel		6895	160	218	08.88-	■
24.232FNL	01/93-	Diesel		6895	160	218	08.88-	■
24.232FNL	01/93-	Diesel		6895	160	218	08.88-	■
17.222FA	01/94-	Diesel		6895	162	220	08.88-	■
17.222FA	01/94-	Diesel		6895	162	220	08.88-	■
17.222FAK	01/94-	Diesel		6895	162	220	08.88-	■
17.222FAK	01/94-	Diesel		6895	162	220	08.88-	■
18.222F/FL/FLL	01/94-	Diesel		6895	162	220	08.88-	■
18.222F/FL/FLL	01/94-	Diesel		6895	162	220	08.88-	■
18.222FK	01/94-	Diesel		6895	162	220	08.88-	■
18.222FK	01/94-	Diesel		6895	162	220	08.88-	■
24.222FNL/FNLL	01/94-	Diesel		6895	162	220	08.88-	■
24.222FNL/FNLL	01/94-	Diesel		6895	162	220	08.88-	■
17.192FS/FLS	01/93-	Diesel		6895	169	230	08.88-	■
17.192FS/FLS	01/93-	Diesel		6895	169	230	08.88-	■
17.232F/FL	01/93-	Diesel		6895	169	230	08.88-	■
17.232F/FL	01/93-	Diesel		6895	169	230	08.88-	■
17.232FA	01/93-	Diesel		6895	169	230	08.88-	■
17.232FA	01/93-	Diesel		6895	169	230	08.88-	■
17.232FAK	01/93-	Diesel		6895	169	230	08.88-	■
17.232FAK	01/93-	Diesel		6895	169	230	08.88-	■
18.232F/FL/FLL	01/93-	Diesel		6895	169	230	08.88-	■
18.232F/FL/FLL	01/93-	Diesel		6895	169	230	08.88-	■
18.232FK	01/93-	Diesel		6895	169	230	08.88-	■
18.232FK	01/93-	Diesel		6895	169	230	08.88-	■
24.232FNL/FNLL	01/93-	Diesel		6895	169	230	08.88-	■
24.232FNL/FNLL	01/93-	Diesel		6895	169	230	08.88-	■
18.262F/FL/FLL	01/95-	Diesel		6895	191	260	08.88-	■
18.262F/FL/FLL	01/95-	Diesel		6895	191	260	08.88-	■
18.262FK	01/95-	Diesel		6895	191	260	08.88-	■
18.262FK	01/95-	Diesel		6895	191	260	08.88-	■
17.272FLS	01/93-	Diesel		6895	198	269	08.88-	■
17.272FLS	01/93-	Diesel		6895	198	269	08.88-	■
18.272F/FL/FLL	01/93-	Diesel		6895	198	269	08.88-	■
18.272F/FL/FLL	01/93-	Diesel		6895	198	269	08.88-	■
18.272FK	01/93-	Diesel		6895	198	269	08.88-	■
18.272FK	01/93-	Diesel		6895	198	269	08.88-	■
24.272FNL/FNLL	01/93-	Diesel		6895	198	269	08.88-	■
24.272FNL/FNLL	01/93-	Diesel		6895	198	269	08.88-	■
17.272FLS	01/93-	Diesel		10000	198	269	08.88-	■
17.272FLS	01/93-	Diesel		10000	198	269	08.88-	■

# LISTA DE APLICACIONES - BUYERS GUIDE

18.272F/FL/FLL	01/93-	Diesel		10000	198	269	08.88-	■
18.272F/FL/FLL	01/93-	Diesel		10000	198	269	08.88-	■
18.272FK	01/93-	Diesel		10000	198	269	08.88-	■
18.272FK	01/93-	Diesel		10000	198	269	08.88-	■
24.272FNL/FNLL	01/93-	Diesel		10000	198	269	08.88-	■
24.272FNL/FNLL	01/93-	Diesel		10000	198	269	08.88-	■
MERCEDES-BENZ								
<b>ATEGO 01.98-10.04</b>					<b>Concrete Mixer</b>			
1325 AF (OM 906.919)		Diesel		6374	180	244	01.98-10.04	■
1325 AF (OM 906.919)		Diesel		6374	180	244	01.98-10.04	■
1325 AF (OM 906.939)		Diesel		6374	180	244	01.98-10.04	■
1325 AF (OM 906.939)		Diesel		6374	180	244	01.98-10.04	■
<b>ATEGO 01.98-10.04</b>					<b>Dump Truck</b>			
1317AK (OM 900.913)		Diesel		4249	125	170	01.98-10.04	■
1317AK (OM 900.913)		Diesel		4249	125	170	01.98-10.04	■
1317AK (OM 904.911)		Diesel		4249	125	170	01.98-10.04	■
1317AK (OM 904.911)		Diesel		4249	125	170	01.98-10.04	■
1317AK (OM 904.917)		Diesel		4249	125	170	01.98-10.04	■
1317AK (OM 904.917)		Diesel		4249	125	170	01.98-10.04	■
1523 AK (OM 906.910)		Diesel		6374	170	231	01.98-10.04	■
1523 AK (OM 906.910)		Diesel		6374	170	231	01.98-10.04	■
1523 AK (OM 906.915)		Diesel		6374	170	231	01.98-10.04	■
1523 AK (OM 906.915)		Diesel		6374	170	231	01.98-10.04	■
<b>ATEGO 01.98-10.04</b>					<b>Municipal Vehicle</b>			
1225 AF (OM 906.919)		Diesel		6374	180	245	01.98-10.04	■
1225 AF (OM 906.919)		Diesel		6374	180	245	01.98-10.04	■
1225 AF (OM 906.939)		Diesel		6374	180	245	01.98-10.04	■
1225 AF (OM 906.939)		Diesel		6374	180	245	01.98-10.04	■
1525 AF (OM 906.919)		Diesel		6374	180	245	01.98-10.04	■
1525 AF (OM 906.919)		Diesel		6374	180	245	01.98-10.04	■
1525 AF (OM 906.939)		Diesel		6374	180	245	01.98-10.04	■
1525 AF (OM 906.939)		Diesel		6374	180	245	01.98-10.04	■
1328 AF (OM 906.911)		Diesel		6374	205	279	01.98-10.04	■
1328 AF (OM 906.911)		Diesel		6374	205	279	01.98-10.04	■
1328 AF (OM 906.916)		Diesel		6374	205	279	01.98-10.04	■
1328 AF (OM 906.916)		Diesel		6374	205	279	01.98-10.04	■
1528 AF (OM 906.911)		Diesel		6374	205	279	01.98-10.04	■
1528 AF (OM 906.911)		Diesel		6374	205	279	01.98-10.04	■
1528 AF (OM 906.916)		Diesel		6374	205	279	01.98-10.04	■
1528 AF (OM 906.916)		Diesel		6374	205	279	01.98-10.04	■
<b>ATEGO 01.98-10.04</b>					<b>Platform/Chassis</b>			
1317 A (OM 904.911)		Diesel		4249	125	170	01.98-10.04	■
1317 A (OM 904.911)		Diesel		4249	125	170	01.98-10.04	■
1317 A (OM 904.917)		Diesel		4249	125	170	01.98-10.04	■
1317 A (OM 904.917)		Diesel		4249	125	170	01.98-10.04	■
1517 A (OM 904.911)		Diesel		4249	125	170	01.98-10.04	■
1517 A (OM 904.911)		Diesel		4249	125	170	01.98-10.04	■
1517 A (OM 904.917)		Diesel		4249	125	170	01.98-10.04	■
1517 A (OM 904.917)		Diesel		4249	125	170	01.98-10.04	■
1523 A (OM 906.910)		Diesel		6374	170	231	01.98-10.04	■



# LISTA DE APLICACIONES - BUYERS GUIDE

1523 A (OM 906.910)		Diesel		6374	170	231	01.98-10.04	■	
1523 A (OM 906.915)		Diesel		6374	170	231	01.98-10.04	■	
1523 A (OM 906.915)		Diesel		6374	170	231	01.98-10.04	■	
<b>MK 12.87-12.05</b>					<b>Dump Truck</b>				
1827 K (OM 445.926)		Diesel		10964	200	272	01.94-09.96	■	
1827 K (OM 445.926)		Diesel		10964	200	272	01.94-09.96	■	
<b>MK 12.87-12.05</b>					<b>Municipal Vehicle</b>				
1231 AF (OM 401.986)	-12/92	Diesel		9570	230	313	01.92-09.96	■	
1231 AF (OM 401.986)	-12/92	Diesel		9570	230	313	01.92-09.96	■	
1227 AF, 1227 LAF (OM 445.933)		Diesel		10964	200	272	01.92-07.92	■	
1227 AF, 1227 LAF (OM 445.933)		Diesel		10964	200	272	01.92-07.92	■	
1627 AF (OM 442.914)		Diesel		15078	195	265	01.92-09.96	■	■
1627 AF (OM 442.914)		Diesel		15078	195	265	01.92-09.96	■	■
1627 AF (OM 442.920)		Diesel		15078	195	265	01.92-09.96	■	■
1627 AF (OM 442.920)		Diesel		15078	195	265	01.92-09.96	■	■
1627 AF (OM 442.932)		Diesel		15078	195	265	01.92-09.96	■	■
1627 AF (OM 442.932)		Diesel		15078	195	265	01.92-09.96	■	■
1627 AF (OM 442.933)		Diesel		15078	195	265	01.92-09.96	■	■
1627 AF (OM 442.933)		Diesel		15078	195	265	01.92-09.96	■	■
1429 AF (OM 442.926)		Diesel		15078	213	290	01.92-09.96	■	■
1429 AF (OM 442.926)		Diesel		15078	213	290	01.92-09.96	■	■
<b>MK 12.87-12.05</b>					<b>Platform/Chassis</b>				
1417	01/93-	Diesel		5995	121	165	07.89-09.96	■	■
1417	01/93-	Diesel		5995	121	165	07.89-09.96	■	■
1417A	01/93-	Diesel		5995	121	165	12.87-	■	■
1417A	01/93-	Diesel		5995	121	165	12.87-	■	■
1417AK	01/93-	Diesel		5995	121	165	12.87-	■	■
1417AK	01/93-	Diesel		5995	121	165	12.87-	■	■
1417K	01/93-	Diesel		5995	121	165	12.87-	■	■
1417K	01/93-	Diesel		5995	121	165	12.87-	■	■
1717AK	01/93-	Diesel		5995	129	175	12.87-	■	
1717AK	01/93-	Diesel		5995	129	175	12.87-	■	
1420/L	01/93-	Diesel		5995	155	211	12.87-	■	■
1420/L	01/93-	Diesel		5995	155	211	12.87-	■	■
1420LS	01/93-	Diesel		5995	155	211	12.87-	■	■
1420LS	01/93-	Diesel		5995	155	211	12.87-	■	■
1820AK	01/93-	Diesel		5995	155	211	12.87-	■	
1820AK	01/93-	Diesel		5995	155	211	12.87-	■	
1820K	01/93-	Diesel		5995	155	211	12.87-	■	
1820K	01/93-	Diesel		5995	155	211	12.87-	■	
1422F	01/93-	Diesel		5995	177	220	12.87-	■	■
1422F	01/93-	Diesel		5995	177	220	12.87-	■	■
1722AK	01/93-	Diesel		5995	177	241	12.87-	■	
1722AK	01/93-	Diesel		5995	177	241	12.87-	■	
1422F	01/93-	Diesel		9595	180	220	12.87-	■	■
1422F	01/93-	Diesel		9595	180	220	12.87-	■	■
1424/L	01/93-	Diesel		9595	180	245	12.87-	■	■
1424/L	01/93-	Diesel		9595	180	245	12.87-	■	■
1424S/LS	01/93-	Diesel		9595	180	245	12.87-	■	■
1424S/LS	01/93-	Diesel		9595	180	245	12.87-	■	■

# LISTA DE APLICACIONES - BUYERS GUIDE

1820AK	01/93-	Diesel		9595	180	245	12.87-	■	
1820AK	01/93-	Diesel		9595	180	245	12.87-	■	
1824K	01/93-	Diesel		9595	180	245	12.87-	■	
1824K	01/93-	Diesel		9595	180	245	12.87-	■	
2024	01/93-	Diesel		9595	180	245	12.87-	■	
2024	01/93-	Diesel		9595	180	245	12.87-	■	
2024AK	01/93-	Diesel		9595	180	245	12.87-	■	
2024AK	01/93-	Diesel		9595	180	245	12.87-	■	
2024K	01/93-	Diesel		9595	180	245	12.87-	■	
2024K	01/93-	Diesel		9595	180	245	12.87-	■	
1422LS	01/93-	Diesel		9595	200	220	12.87-	■	■
1422LS	01/93-	Diesel		9595	200	220	12.87-	■	■
1427F	01/93-	Diesel		9595	200	272	12.87-	■	■
1427F	01/93-	Diesel		9595	200	272	12.87-	■	■
1722AK	01/93-	Diesel		9595	200	272	12.87-	■	
1722AK	01/93-	Diesel		9595	200	272	12.87-	■	
1422	01/93-	Diesel		9595	230	218	12.87-	■	■
1422	01/93-	Diesel		9595	230	218	12.87-	■	■
1831AK	01/93-	Diesel		9595	230	313	12.87-	■	
1831AK	01/93-	Diesel		9595	230	313	12.87-	■	
1831K	01/93-	Diesel		9595	230	313	12.87-	■	
1831K	01/93-	Diesel		9595	230	313	12.87-	■	
2031	01/93-	Diesel		9595	230	313	12.87-	■	
2031	01/93-	Diesel		9595	230	313	12.87-	■	
2031A	01/93-	Diesel		9595	230	313	12.87-	■	
2031A	01/93-	Diesel		9595	230	313	12.87-	■	
2031AS	01/93-	Diesel		9595	230	313	12.87-	■	
2031AS	01/93-	Diesel		9595	230	313	12.87-	■	
2031S	01/93-	Diesel		9595	230	313	12.87-	■	
2031S	01/93-	Diesel		9595	230	313	12.87-	■	
2631A	01/93-	Diesel		9595	230	313	12.87-	■	
2631A	01/93-	Diesel		9595	230	313	12.87-	■	
2631AK	01/93-	Diesel		9595	230	313	12.87-	■	
2631AK	01/93-	Diesel		9595	230	313	12.87-	■	
2631AS	01/93-	Diesel		9595	230	313	12.87-	■	
2631AS	01/93-	Diesel		9595	230	313	12.87-	■	
1424/L	01/95-	Diesel		10995	180	245	12.87-	■	■
1424/L	01/95-	Diesel		10995	180	245	12.87-	■	■
1424S/LS	01/95-	Diesel		10995	180	245	12.87-	■	■
1424S/LS	01/95-	Diesel		10995	180	245	12.87-	■	■
1824AK	01/94-	Diesel		10995	180	245	12.87-	■	
1824AK	01/94-	Diesel		10995	180	245	12.87-	■	
1824K	01/94-	Diesel		10995	180	245	12.87-	■	
1824K	01/94-	Diesel		10995	180	245	12.87-	■	
2024	01/94-	Diesel		10995	180	245	12.87-	■	
2024	01/94-	Diesel		10995	180	245	12.87-	■	
2024AK	01/94-	Diesel		10995	180	245	12.87-	■	
2024AK	01/94-	Diesel		10995	180	245	12.87-	■	
2024K	01/94-	Diesel		10995	180	245	12.87-	■	
2024K	01/94-	Diesel		10995	180	245	12.87-	■	
1831AK	01/94-	Diesel		10995	230	313	12.87-	■	

# LISTA DE APLICACIONES - BUYERS GUIDE

1831AK	01/94-	Diesel		10995	230	313	12.87-	■	
1831K	01/93-	Diesel		10995	230	313	12.87-	■	
1831K	01/93-	Diesel		10995	230	313	12.87-	■	
2031A	01/94-	Diesel		10995	230	313	12.87-	■	
2031A	01/94-	Diesel		10995	230	313	12.87-	■	
2631A	01/94-	Diesel		10995	230	313	12.87-	■	
2631A	01/94-	Diesel		10995	230	313	12.87-	■	
2631AK	01/94-	Diesel		10995	230	313	12.87-	■	
2631AK	01/94-	Diesel		10995	230	313	12.87-	■	
2534/L	01/93-, Auxiliary Axle	Diesel		10995	250	340	12.87-		■
2534/L	01/93-, Auxiliary Axle	Diesel		10995	250	340	12.87-		■
1722AK	01/93-	Diesel		11295	151	205	12.87-	■	
1722AK	01/93-	Diesel		11295	151	205	12.87-	■	
1422/L	01/93-	Diesel		11295	160	218	12.87-	■	■
1422/L	01/93-	Diesel		11295	160	218	12.87-	■	■
1422F	01/93-	Diesel		11295	160	218	12.87-	■	■
1422F	01/93-	Diesel		11295	160	218	12.87-	■	■
1422S/LS	01/93-	Diesel		11295	160	220	12.87-	■	■
1422S/LS	01/93-	Diesel		11295	160	220	12.87-	■	■
1922AK	01/93-	Diesel		11295	160	218	12.87-	■	
1922AK	01/93-	Diesel		11295	160	218	12.87-	■	
1838AK	01/93-	Diesel		12795	280	381	12.87-	■	
1838AK	01/93-	Diesel		12795	280	381	12.87-	■	
1838K	01/93-	Diesel		12795	280	381	12.87-	■	
1838K	01/93-	Diesel		12795	280	381	12.87-	■	
2031A	01/93-	Diesel		12795	280	381	12.87-	■	
2031A	01/93-	Diesel		12795	280	381	12.87-	■	
2038	01/93-	Diesel		12795	280	381	12.87-	■	
2038	01/93-	Diesel		12795	280	381	12.87-	■	
2038AS	01/93-	Diesel		12795	280	381	12.87-	■	
2038AS	01/93-	Diesel		12795	280	381	12.87-	■	
2038S	01/93-	Diesel		12795	280	381	12.87-	■	
2038S	01/93-	Diesel		12795	280	381	12.87-	■	
2538	01/93-, Auxiliary Axle	Diesel		12795	280	381	12.87-		■
2538	01/93-, Auxiliary Axle	Diesel		12795	280	381	12.87-		■
2538/L	01/93-, Auxiliary Axle	Diesel		12795	280	381	12.87-		■
2538/L	01/93-, Auxiliary Axle	Diesel		12795	280	381	12.87-		■
2638AK	01/93-	Diesel		12795	280	381	12.87-	■	
2638AK	01/93-	Diesel		12795	280	381	12.87-	■	
2638AS	01/93-	Diesel		12795	280	381	12.87-	■	
2638AS	01/93-	Diesel		12795	280	381	12.87-	■	
2031A	01/93-	Diesel		12795	320	435	12.87-	■	
2031A	01/93-	Diesel		12795	320	435	12.87-	■	
1935AK	01/93-	Diesel		14595	250	340	12.87-	■	
1935AK	01/93-	Diesel		14595	250	340	12.87-	■	
1935AS	01/93-	Diesel		14595	250	340	12.87-	■	
1935AS	01/93-	Diesel		14595	250	340	12.87-	■	
1735AK	01/93-	Diesel		14595	260	354	12.87-	■	
1735AK	01/93-	Diesel		14595	260	354	12.87-	■	
2635AS	01/93-	Diesel		14595	266	362	12.87-	■	
2635AS	01/93-	Diesel		14595	266	362	12.87-	■	

# LISTA DE APLICACIONES - BUYERS GUIDE

1838AK	01/94-	Diesel		14595	280	381	12.87-	■	
1838AK	01/94-	Diesel		14595	280	381	12.87-	■	
2031A	01/94-	Diesel		14595	280	381	12.87-	■	
2031A	01/94-	Diesel		14595	280	381	12.87-	■	
2038AS	01/94-	Diesel		14595	280	381	12.87-	■	
2038AS	01/94-	Diesel		14595	280	381	12.87-	■	
2538/L	01/94-, Auxiliary Axle	Diesel		14595	280	381	12.87-		■
2538/L	01/94-, Auxiliary Axle	Diesel		14595	280	381	12.87-		■
2638AK	01/94-	Diesel		14595	280	381	12.87-	■	
2638AK	01/94-	Diesel		14595	280	381	12.87-	■	
2638AS	01/94-	Diesel		14595	280	381	12.87-	■	
2638AS	01/94-	Diesel		14595	280	381	12.87-	■	
1838AK	01/93-	Diesel		14595	320	435	12.87-	■	
1838AK	01/93-	Diesel		14595	320	435	12.87-	■	
1838K	01/95-	Diesel		14595	320	435	12.87-	■	
1838K	01/95-	Diesel		14595	320	435	12.87-	■	
20344S	01/93-	Diesel		14595	320	435	12.87-	■	
20344S	01/93-	Diesel		14595	320	435	12.87-	■	
2038AS	01/93-	Diesel		14595	320	435	12.87-	■	
2038AS	01/93-	Diesel		14595	320	435	12.87-	■	
2044	01/93-	Diesel		14595	320	435	12.87-	■	
2044	01/93-	Diesel		14595	320	435	12.87-	■	
2538/L	01/93-, Auxiliary Axle	Diesel		14595	320	435	12.87-		■
2538/L	01/93-, Auxiliary Axle	Diesel		14595	320	435	12.87-		■
2544/L	01/93-, Auxiliary Axle	Diesel		14595	320	435	12.87-		■
2544/L	01/93-, Auxiliary Axle	Diesel		14595	320	435	12.87-		■
2544S	01/93-, Auxiliary Axle	Diesel		14595	320	435	12.87-		■
2544S	01/93-, Auxiliary Axle	Diesel		14595	320	435	12.87-		■
2638AK	01/93-	Diesel		14595	320	435	12.87-	■	
2638AK	01/93-	Diesel		14595	320	435	12.87-	■	
2638AS	01/93-	Diesel		14595	320	435	12.87-	■	
2638AS	01/93-	Diesel		14595	320	435	12.87-	■	
2050	01/93-	Diesel		14595	362	492	12.87-	■	
2050	01/93-	Diesel		14595	362	492	12.87-	■	
2050S	01/93-	Diesel		14595	362	492	12.87-	■	
2050S	01/93-	Diesel		14595	362	492	12.87-	■	
1838AK	01/93-	Diesel		14595	370	503	12.87-	■	
1838AK	01/93-	Diesel		14595	370	503	12.87-	■	
2538	01/93-, Auxiliary Axle	Diesel		14595	370	503	12.87-		■
2538	01/93-, Auxiliary Axle	Diesel		14595	370	503	12.87-		■
2550/L	01/93-, Auxiliary Axle	Diesel		14595	370	503	12.87-		■
2550/L	01/93-, Auxiliary Axle	Diesel		14595	370	503	12.87-		■
2638AK	01/93-	Diesel		14595	370	503	12.87-	■	
2638AK	01/93-	Diesel		14595	370	503	12.87-	■	
2638AS	01/93-	Diesel		14595	370	503	12.87-	■	
2638AS	01/93-	Diesel		14595	370	503	12.87-	■	
1853AK	01/96-	Diesel		14595	390	530	12.87-	■	
1853AK	01/96-	Diesel		14595	390	530	12.87-	■	
2553/L	01/96-, Auxiliary Axle	Diesel		14595	390	530	12.87-		■
2553/L	01/96-, Auxiliary Axle	Diesel		14595	390	530	12.87-		■
1426S/LS	01/93-	Diesel		15095	191	260	12.87-	■	■

# LISTA DE APLICACIONES - BUYERS GUIDE

1426S/LS	01/93-	Diesel		15095	191	260	12.87-	■	■
1726AK	01/93-	Diesel		15095	195	265	12.87-	■	
1726AK	01/93-	Diesel		15095	195	265	12.87-	■	
1929A	01/93-	Diesel		15095	210	286	12.87-	■	
1929A	01/93-	Diesel		15095	210	286	12.87-	■	
1929AK	01/93-	Diesel		15095	210	286	12.87-	■	
1929AK	01/93-	Diesel		15095	210	286	12.87-	■	
1729AK	01/93-	Diesel		15095	213	290	12.87-	■	
1729AK	01/93-	Diesel		15095	213	290	12.87-	■	
1929AS	01/93-	Diesel		15095	213	290	12.87-	■	
1929AS	01/93-	Diesel		15095	213	290	12.87-	■	
1929A	01/93-	Diesel		15095	269	366	12.87-	■	
1929A	01/93-	Diesel		15095	269	366	12.87-	■	
1929A	01/93-	Diesel		18295	340	462	12.87-	■	
1929A	01/93-	Diesel		18295	340	462	12.87-	■	
<b>NG 08.73-03.98</b>									
3229B	01/93-	Diesel		14595	213	290	08.73-	■	■
3229B	01/93-	Diesel		14595	213	290	08.73-	■	■
3229K	01/93-	Diesel		14595	213	290	08.73-	■	■
3229K	01/93-	Diesel		14595	213	290	08.73-	■	■
3236A	01/93-	Diesel		14595	261	355	08.73-	■	■
3236A	01/93-	Diesel		14595	261	355	08.73-	■	■
3250A	01/93-	Diesel		18295	368	500	08.73-	■	■
3250A	01/93-	Diesel		18295	368	500	08.73-	■	■
3250AF	01/93-	Diesel		18295	368	500	08.73-	■	
3250AF	01/93-	Diesel		18295	368	500	08.73-	■	