


LISTA DE APLICACIONES - BUYERS GUIDE

21 9495 00



Qty: 850

Weight: 8.600



21 9495 00



183x17x178- Ø410

WVA

19487

19495

MAKE

MAN

MERCEDES-BENZ

STEYR



Trac.

CC

Kw

CV



Front / Rear

MAN

F2000 01.94-

48.343VF/VFA	01/94-	Diesel			250	340	01.94-	■	
48.343VF/VFA	01/94-	Diesel			250	340	01.94-	■	
40.403 DFAS	01/94-	Diesel			294	400	01.94-	■	■
40.403 DFAS	01/94-	Diesel			294	400	01.94-	■	■
40.403 DFK/DFAK	01/94-	Diesel			294	400	01.94-	■	■
40.403 DFK/DFAK	01/94-	Diesel			294	400	01.94-	■	■
40.403 DFS	01/00-	Diesel			294	400	01.94-		■
40.403 DFS	01/00-	Diesel			294	400	01.94-		■
40.403 DFS	01/94-	Diesel			294	400	01.94-		■
40.403 DFS	01/94-	Diesel			294	400	01.94-		■
40.403 DFS	01/94-	Diesel			294	400	01.94-		■
48.403VF/VFA	01/94-	Diesel			294	400	01.94-	■	
48.403VF/VFA	01/94-	Diesel			294	400	01.94-	■	
40.403 DFK/DFAK	01/94-	Diesel			338	460	01.94-	■	■
40.403 DFK/DFAK	01/94-	Diesel			338	460	01.94-	■	■
40.463 DFAS	01/94-	Diesel			338	460	01.94-	■	■
40.463 DFAS	01/94-	Diesel			338	460	01.94-	■	■
40.463 DFS	01/00-	Diesel			338	460	01.94-		■
40.463 DFS	01/00-	Diesel			338	460	01.94-		■
40.463 DFS	01/94-	Diesel			338	460	01.94-		■
40.463 DFS	01/94-	Diesel			338	460	01.94-		■

LISTA DE APLICACIONES - BUYERS GUIDE

40.463 DFS	01/94-	Diesel			338	460	01.94-		■
48.463VF/VFA	01/94-	Diesel			338	460	01.94-	■	
48.463VF/VFA	01/94-	Diesel			338	460	01.94-	■	
27.273DFK	01/94-	Diesel		10000	140	190	01.94-	■	■
27.273DFK	01/94-	Diesel		10000	140	190	01.94-	■	■
19.273FA	01/94-	Diesel		10000	198	269	01.94-	■	
19.273FA	01/94-	Diesel		10000	198	269	01.94-	■	
19.273FAK	01/94-	Diesel		10000	198	269	01.94-	■	
19.273FAK	01/94-	Diesel		10000	198	269	01.94-	■	
19.273FK	01/94-	Diesel		10000	198	269	01.94-	■	
19.273FK	01/94-	Diesel		10000	198	269	01.94-	■	
26.273DFK/DFLK	01/94-	Diesel		10000	198	269	01.94-	■	■
26.273DFK/DFLK	01/94-	Diesel		10000	198	269	01.94-	■	■
27.273DFAC	01/94-	Diesel		10000	198	269	01.94-	■	■
27.273DFAC	01/94-	Diesel		10000	198	269	01.94-	■	■
27.273DFAK	01/94-	Diesel		10000	198	269	01.94-	■	■
27.273DFAK	01/94-	Diesel		10000	198	269	01.94-	■	■
27.273DFAS	01/94-	Diesel		10000	198	269	01.94-	■	■
27.273DFAS	01/94-	Diesel		10000	198	269	01.94-	■	■
27.273DFK	01/94-	Diesel		10000	198	269	01.94-	■	■
27.273DFK	01/94-	Diesel		10000	198	269	01.94-	■	■
19.293FAC	01/94-	Diesel		10000	213	290	01.94-	■	
19.293FAC	01/94-	Diesel		10000	213	290	01.94-	■	
19.293FAS	01/94-	Diesel		10000	213	290	01.94-	■	
19.293FAS	01/94-	Diesel		10000	213	290	01.94-	■	
19.293FK	01/94-	Diesel		10000	213	290	01.94-	■	
19.293FK	01/94-	Diesel		10000	213	290	01.94-	■	
19.293FK/FLK	01/94-	Diesel		10000	213	290	01.94-	■	
19.293FK/FLK	01/94-	Diesel		10000	213	290	01.94-	■	
26.293DFK/DFLK	01/94-	Diesel		10000	213	290	01.94-	■	■
26.293DFK/DFLK	01/94-	Diesel		10000	213	290	01.94-	■	■
27.293DFAC	01/94-	Diesel		10000	213	290	01.94-	■	■
27.293DFAC	01/94-	Diesel		10000	213	290	01.94-	■	■
27.293DFAK	01/94-	Diesel		10000	213	290	01.94-	■	■
27.293DFAK	01/94-	Diesel		10000	213	290	01.94-	■	■
27.293DFAS	01/94-	Diesel		10000	213	290	01.94-	■	■
27.293DFAS	01/94-	Diesel		10000	213	290	01.94-	■	■
32.293VFC	01/95-	Diesel		10000	213	290	01.94-	■	■
32.293VFC	01/95-	Diesel		10000	213	290	01.94-	■	■
19.323FAC	01/94-	Diesel		10000	235	320	01.94-	■	
19.323FAC	01/94-	Diesel		10000	235	320	01.94-	■	
19.323FAK	01/94-	Diesel		10000	235	320	01.94-	■	
19.323FAK	01/94-	Diesel		10000	235	320	01.94-	■	
19.323FAS	01/94-	Diesel		10000	235	320	01.94-	■	
19.323FAS	01/94-	Diesel		10000	235	320	01.94-	■	
26.323DFK/DFLK	01/94-	Diesel		10000	235	320	01.94-	■	■
26.323DFK/DFLK	01/94-	Diesel		10000	235	320	01.94-	■	■
27.323DFAC	01/94-	Diesel		10000	235	320	01.94-	■	■
27.323DFAC	01/94-	Diesel		10000	235	320	01.94-	■	■
27.323DFAK	01/94-	Diesel		10000	235	320	01.94-	■	■
27.323DFAK	01/94-	Diesel		10000	235	320	01.94-	■	■

LISTA DE APLICACIONES - BUYERS GUIDE

27.323DFAS	01/94-	Diesel		10000	235	320	01.94-	■	■
27.323DFAS	01/94-	Diesel		10000	235	320	01.94-	■	■
27.323DFK	01/94-	Diesel		10000	235	320	01.94-	■	■
27.323DFK	01/94-	Diesel		10000	235	320	01.94-	■	■
33.323 DFAC	01/94-	Diesel		10000	235	320	01.94-	■	■
33.323 DFAC	01/94-	Diesel		10000	235	320	01.94-	■	■
33.323 DFAK	01/94-	Diesel		10000	235	320	01.94-	■	■
33.323 DFAK	01/94-	Diesel		10000	235	320	01.94-	■	■
33.323 DFAS	01/94-	Diesel		10000	235	320	01.94-	■	■
33.323 DFAS	01/94-	Diesel		10000	235	320	01.94-	■	■
19.343FAC	01/94-	Diesel		10000	250	340	01.94-	■	
19.343FAC	01/94-	Diesel		10000	250	340	01.94-	■	
19.343FAK	01/94-	Diesel		10000	250	340	01.94-	■	
19.343FAK	01/94-	Diesel		10000	250	340	01.94-	■	
19.343FAS	01/94-	Diesel		10000	250	340	01.94-	■	
19.343FAS	01/94-	Diesel		10000	250	340	01.94-	■	
26.343DFK/DFLK	01/94-	Diesel		10000	250	340	01.94-	■	■
26.343DFK/DFLK	01/94-	Diesel		10000	250	340	01.94-	■	■
27.343DFAC	01/94-	Diesel		10000	250	340	01.94-	■	■
27.343DFAC	01/94-	Diesel		10000	250	340	01.94-	■	■
27.343DFAK	01/94-	Diesel		10000	250	340	01.94-	■	■
27.343DFAK	01/94-	Diesel		10000	250	340	01.94-	■	■
27.343DFAS	01/94-	Diesel		10000	250	340	01.94-	■	■
27.343DFAS	01/94-	Diesel		10000	250	340	01.94-	■	■
27.343DFK	01/94-	Diesel		10000	250	340	01.94-	■	■
27.343DFK	01/94-	Diesel		10000	250	340	01.94-	■	■
32.343VFC	01/95-	Diesel		10000	250	340	01.94-	■	■
32.343VFC	01/95-	Diesel		10000	250	340	01.94-	■	■
32.343VFK	01/95-	Diesel		10000	250	340	01.94-	■	■
32.343VFK	01/95-	Diesel		10000	250	340	01.94-	■	■
33.343 DFAC	01/94-	Diesel		10000	250	340	01.94-	■	■
33.343 DFAC	01/94-	Diesel		10000	250	340	01.94-	■	■
33.343 DFAK	01/94-	Diesel		10000	250	340	01.94-	■	■
33.343 DFAK	01/94-	Diesel		10000	250	340	01.94-	■	■
33.343 DFAS	01/94-	Diesel		10000	250	340	01.94-	■	■
33.343 DFAS	01/94-	Diesel		10000	250	340	01.94-	■	■
35.343VFC	01/95-	Diesel		10000	250	340	01.94-	■	
35.343VFC	01/95-	Diesel		10000	250	340	01.94-	■	
35.343VFK	01/95-	Diesel		10000	250	340	01.94-	■	
35.343VFK	01/95-	Diesel		10000	250	340	01.94-	■	
41.343VFC	01/95-	Diesel		10000	250	340	01.94-	■	
41.343VFC	01/95-	Diesel		10000	250	340	01.94-	■	
41.343VFK	01/95-	Diesel		10000	250	340	01.94-	■	
41.343VFK	01/95-	Diesel		10000	250	340	01.94-	■	
19.373FAC	01/94-	Diesel		11995	200	272	01.94-	■	
19.373FAC	01/94-	Diesel		11995	200	272	01.94-	■	
19.314FAS	01/98-	Diesel		11995	228	310	01.94-	■	
19.314FAS	01/98-	Diesel		11995	228	310	01.94-	■	
19.314FK/FLK	01/98-	Diesel		11995	228	310	01.94-	■	
19.314FK/FLK	01/98-	Diesel		11995	228	310	01.94-	■	
19.323FK/FLK	01/94-	Diesel		11995	235	320	01.94-	■	

LISTA DE APLICACIONES - BUYERS GUIDE

19.323FK/FLK	01/94-	Diesel		11995	235	320	01.94-	■	
19.343FK/FLK	01/94-	Diesel		11995	250	340	01.94-	■	
19.343FK/FLK	01/94-	Diesel		11995	250	340	01.94-	■	
19.364FAC	01/98-	Diesel		11995	265	360	01.94-	■	
19.364FAC	01/98-	Diesel		11995	265	360	01.94-	■	
19.364FAK	01/98-	Diesel		11995	265	360	01.94-	■	
19.364FAK	01/98-	Diesel		11995	265	360	01.94-	■	
19.364FAS	01/98-	Diesel		11995	265	360	01.94-	■	
19.364FAS	01/98-	Diesel		11995	265	360	01.94-	■	
19.364FK/FLK	01/98-	Diesel		11995	265	360	01.94-	■	
19.364FK/FLK	01/98-	Diesel		11995	265	360	01.94-	■	
19.373FAK	01/94-	Diesel		11995	272	370	01.94-	■	
19.373FAK	01/94-	Diesel		11995	272	370	01.94-	■	
19.373FAS	01/94-	Diesel		11995	272	370	01.94-	■	
19.373FAS	01/94-	Diesel		11995	272	370	01.94-	■	
19.373FK/FLK	01/94-	Diesel		11995	272	370	01.94-	■	
19.373FK/FLK	01/94-	Diesel		11995	272	370	01.94-	■	
26.373DFK/DFLK	01/94-	Diesel		11995	272	370	01.94-	■	■
26.373DFK/DFLK	01/94-	Diesel		11995	272	370	01.94-	■	■
27.373DFAC	01/94-	Diesel		11995	272	370	01.94-	■	■
27.373DFAC	01/94-	Diesel		11995	272	370	01.94-	■	■
27.373DFAK	01/94-	Diesel		11995	272	370	01.94-	■	■
27.373DFAK	01/94-	Diesel		11995	272	370	01.94-	■	■
27.373DFAS	01/94-	Diesel		11995	272	370	01.94-	■	■
27.373DFAS	01/94-	Diesel		11995	272	370	01.94-	■	■
27.373DFK	01/94-	Diesel		11995	272	370	01.94-	■	■
27.373DFK	01/94-	Diesel		11995	272	370	01.94-	■	■
33.373 DFAC	01/94-	Diesel		11995	272	370	01.94-	■	■
33.373 DFAC	01/94-	Diesel		11995	272	370	01.94-	■	■
33.373 DFAK	01/94-	Diesel		11995	272	370	01.94-	■	■
33.373 DFAK	01/94-	Diesel		11995	272	370	01.94-	■	■
33.373 DFAS	01/94-	Diesel		11995	272	370	01.94-	■	■
33.373 DFAS	01/94-	Diesel		11995	272	370	01.94-	■	■
19.403FAC	01/94-	Diesel		11995	294	400	01.94-	■	
19.403FAC	01/94-	Diesel		11995	294	400	01.94-	■	
19.403FAK	01/94-	Diesel		11995	294	400	01.94-	■	
19.403FAK	01/94-	Diesel		11995	294	400	01.94-	■	
19.403FAS	01/94-	Diesel		11995	294	400	01.94-	■	
19.403FAS	01/94-	Diesel		11995	294	400	01.94-	■	
19.403FK/FLK	01/94-	Diesel		11995	294	400	01.94-	■	
19.403FK/FLK	01/94-	Diesel		11995	294	400	01.94-	■	
26.403DFK/DFLK	01/94-	Diesel		11995	294	400	01.94-	■	■
26.403DFK/DFLK	01/94-	Diesel		11995	294	400	01.94-	■	■
27.403DFAC	01/94-	Diesel		11995	294	400	01.94-	■	■
27.403DFAC	01/94-	Diesel		11995	294	400	01.94-	■	■
27.403DFAK	01/94-	Diesel		11995	294	400	01.94-	■	■
27.403DFAK	01/94-	Diesel		11995	294	400	01.94-	■	■
27.403DFAS	01/94-	Diesel		11995	294	400	01.94-	■	■
27.403DFAS	01/94-	Diesel		11995	294	400	01.94-	■	■
27.403DFK	01/94-	Diesel		11995	294	400	01.94-	■	■
27.403DFK	01/94-	Diesel		11995	294	400	01.94-	■	■

LISTA DE APLICACIONES - BUYERS GUIDE

32.403VFC	01/95-	Diesel		11995	294	400	01.94-	■	■
32.403VFC	01/95-	Diesel		11995	294	400	01.94-	■	■
32.403VFK	01/95-	Diesel		11995	294	400	01.94-	■	■
32.403VFK	01/95-	Diesel		11995	294	400	01.94-	■	■
33.403 DFAC	01/94-	Diesel		11995	294	400	01.94-	■	■
33.403 DFAC	01/94-	Diesel		11995	294	400	01.94-	■	■
33.403 DFAK	01/94-	Diesel		11995	294	400	01.94-	■	■
33.403 DFAK	01/94-	Diesel		11995	294	400	01.94-	■	■
33.403 DFAS	01/94-	Diesel		11995	294	400	01.94-	■	■
33.403 DFAS	01/94-	Diesel		11995	294	400	01.94-	■	■
35.403VFC	01/95-	Diesel		11995	294	400	01.94-	■	
35.403VFC	01/95-	Diesel		11995	294	400	01.94-	■	
35.403VFK	01/95-	Diesel		11995	294	400	01.94-	■	
35.403VFK	01/95-	Diesel		11995	294	400	01.94-	■	
41.403VFC	01/95-	Diesel		11995	294	400	01.94-	■	
41.403VFC	01/95-	Diesel		11995	294	400	01.94-	■	
41.403VFK	01/95-	Diesel		11995	294	400	01.94-	■	
41.403VFK	01/95-	Diesel		11995	294	400	01.94-	■	
19.414FAC	01/98-	Diesel		11995	301	409	01.94-	■	
19.414FAC	01/98-	Diesel		11995	301	409	01.94-	■	
19.414FAK	01/98-	Diesel		11995	301	409	01.94-	■	
19.414FAK	01/98-	Diesel		11995	301	409	01.94-	■	
19.414FAS	01/98-	Diesel		11995	301	409	01.94-	■	
19.414FAS	01/98-	Diesel		11995	301	409	01.94-	■	
19.414FK/FLK	01/98-	Diesel		11995	301	409	01.94-	■	
19.414FK/FLK	01/98-	Diesel		11995	301	409	01.94-	■	
19.423FAC	01/94-	Diesel		11995	309	420	01.94-	■	
19.423FAC	01/94-	Diesel		11995	309	420	01.94-	■	
19.423FAK	01/94-	Diesel		11995	309	420	01.94-	■	
19.423FAK	01/94-	Diesel		11995	309	420	01.94-	■	
19.423FAS	01/94-	Diesel		11995	309	420	01.94-	■	
19.423FAS	01/94-	Diesel		11995	309	420	01.94-	■	
19.423FK/FLK	01/94-	Diesel		11995	309	420	01.94-	■	
19.423FK/FLK	01/94-	Diesel		11995	309	420	01.94-	■	
26.423DFK/DFLK	01/94-	Diesel		11995	309	420	01.94-	■	■
26.423DFK/DFLK	01/94-	Diesel		11995	309	420	01.94-	■	■
27.423DFAC	01/94-	Diesel		11995	309	420	01.94-	■	■
27.423DFAC	01/94-	Diesel		11995	309	420	01.94-	■	■
27.423DFAK	01/94-	Diesel		11995	309	420	01.94-	■	■
27.423DFAK	01/94-	Diesel		11995	309	420	01.94-	■	■
27.423DFAS	01/94-	Diesel		11995	309	420	01.94-	■	■
27.423DFAS	01/94-	Diesel		11995	309	420	01.94-	■	■
27.423DFK	01/94-	Diesel		11995	309	420	01.94-	■	■
27.423DFK	01/94-	Diesel		11995	309	420	01.94-	■	■
33.423 DFAC	01/94-	Diesel		11995	309	420	01.94-	■	■
33.423 DFAC	01/94-	Diesel		11995	309	420	01.94-	■	■
33.423 DFAK	01/94-	Diesel		11995	309	420	01.94-	■	■
33.423 DFAK	01/94-	Diesel		11995	309	420	01.94-	■	■
33.423 DFAS	01/94-	Diesel		11995	309	420	01.94-	■	■
33.423 DFAS	01/94-	Diesel		11995	309	420	01.94-	■	■
19.463FAC	01/94-	Diesel		11995	338	460	01.94-	■	

LISTA DE APLICACIONES - BUYERS GUIDE

19.463FAC	01/94-	Diesel		11995	338	460	01.94-	■	
27.463DFK	01/94-	Diesel		11995	338	460	01.94-	■	■
27.463DFK	01/94-	Diesel		11995	338	460	01.94-	■	■
19.463FAK	01/94-	Diesel		12795	338	460	01.94-	■	
19.463FAK	01/94-	Diesel		12795	338	460	01.94-	■	
19.463FAS	01/94-	Diesel		12795	338	460	01.94-	■	
19.463FAS	01/94-	Diesel		12795	338	460	01.94-	■	
19.463FK/FLK	01/94-	Diesel		12795	338	460	01.94-	■	
19.463FK/FLK	01/94-	Diesel		12795	338	460	01.94-	■	
19.464FAK	01/98-	Diesel		12795	338	460	01.94-	■	
19.464FAK	01/98-	Diesel		12795	338	460	01.94-	■	
19.464FAS	01/98-	Diesel		12795	338	460	01.94-	■	
19.464FAS	01/98-	Diesel		12795	338	460	01.94-	■	
19.464FK/FLK	01/98-	Diesel		12795	338	460	01.94-	■	
19.464FK/FLK	01/98-	Diesel		12795	338	460	01.94-	■	
26.463DFK/DFLK	01/94-	Diesel		12795	338	460	01.94-	■	■
26.463DFK/DFLK	01/94-	Diesel		12795	338	460	01.94-	■	■
27.463DFAC	01/94-	Diesel		12795	338	460	01.94-	■	■
27.463DFAC	01/94-	Diesel		12795	338	460	01.94-	■	■
27.463DFAK	01/94-	Diesel		12795	338	460	01.94-	■	■
27.463DFAK	01/94-	Diesel		12795	338	460	01.94-	■	■
27.463DFAS	01/94-	Diesel		12795	338	460	01.94-	■	■
27.463DFAS	01/94-	Diesel		12795	338	460	01.94-	■	■
32.463VFC	01/95-	Diesel		12795	338	460	01.94-	■	■
32.463VFC	01/95-	Diesel		12795	338	460	01.94-	■	■
32.463VFK	01/95-	Diesel		12795	338	460	01.94-	■	■
32.463VFK	01/95-	Diesel		12795	338	460	01.94-	■	■
33.463 DFAC	01/94-	Diesel		12795	338	460	01.94-	■	■
33.463 DFAC	01/94-	Diesel		12795	338	460	01.94-	■	■
33.463 DFAK	01/94-	Diesel		12795	338	460	01.94-	■	■
33.463 DFAK	01/94-	Diesel		12795	338	460	01.94-	■	■
33.463 DFAS	01/94-	Diesel		12795	338	460	01.94-	■	■
33.463 DFAS	01/94-	Diesel		12795	338	460	01.94-	■	■
35.463VFC	01/95-	Diesel		12795	338	460	01.94-	■	
35.463VFC	01/95-	Diesel		12795	338	460	01.94-	■	
35.463VFK	01/95-	Diesel		12795	338	460	01.94-	■	
35.463VFK	01/95-	Diesel		12795	338	460	01.94-	■	
41.463VFC	01/95-	Diesel		12795	338	460	01.94-	■	
41.463VFC	01/95-	Diesel		12795	338	460	01.94-	■	
41.463VFK	01/95-	Diesel		12795	338	460	01.94-	■	
41.463VFK	01/95-	Diesel		12795	338	460	01.94-	■	
26.603DFK/DFLK	01/96-	Diesel		18195	441	600	01.94-	■	■
26.603DFK/DFLK	01/96-	Diesel		18195	441	600	01.94-	■	■
33.603 DFAC	01/96-	Diesel		18295	441	600	01.94-	■	■
33.603 DFAC	01/96-	Diesel		18295	441	600	01.94-	■	■
33.603 DFAS	01/96-	Diesel		18295	441	600	01.94-	■	■
33.603 DFAS	01/96-	Diesel		18295	441	600	01.94-	■	■
F2000 01.94-					Dump Truck				
33.323 DFK (D 2865 LF23)		Diesel		9973	235	320	01.94-12.95		■
33.323 DFK (D 2865 LF23)		Diesel		9973	235	320	01.94-12.95		■
33.343 DFK (D 2865 LF21)		Diesel		9973	250	340	01.94-		■

LISTA DE APLICACIONES - BUYERS GUIDE

33.343 DFK (D 2865 LF21)		Diesel		9973	250	340	01.94-	■
33.373 DFK, DF-KI (D 2866 LF21)	-12/95	Diesel		11967	272	370	01.94-	■
33.373 DFK, DF-KI (D 2866 LF21)	-12/95	Diesel		11967	272	370	01.94-	■
33.403 DFK, DF-KI (D 2866 LF20)		Diesel		11967	294	400	01.94-	■
33.403 DFK, DF-KI (D 2866 LF20)		Diesel		11967	294	400	01.94-	■
33.423 DFK, DF-KI (D 2866 LF22)	-12/95	Diesel		11967	309	420	01.94-	■
33.423 DFK, DF-KI (D 2866 LF22)	-12/95	Diesel		11967	309	420	01.94-	■
33.463 DFK, DF-KI (D 2876 LF 02)		Diesel		12816	338	460	01.94-	■
33.463 DFK, DF-KI (D 2876 LF 02)		Diesel		12816	338	460	01.94-	■
F2000 01.94-					Platform/Chassis			
26.273 DFC,26.273 DFLC (D 2865 LF22)		Diesel		9973	198	269	01.94-12.95	■
26.273 DFC,26.273 DFLC (D 2865 LF22)		Diesel		9973	198	269	01.94-12.95	■
27.273 DFC (D 2865 LF22)		Diesel		9973	198	269	01.94-12.95	■
27.273 DFC (D 2865 LF22)		Diesel		9973	198	269	01.94-12.95	■
26.293 DFC,26.293 DFLC (D 2865 LF20)		Diesel		9973	213	290	01.94-	■
26.293 DFC,26.293 DFLC (D 2865 LF20)		Diesel		9973	213	290	01.94-	■
26.293 DFC,26.293 DFLC (D 2865 LF24)		Diesel		9973	213	290	01.94-	■
26.293 DFC,26.293 DFLC (D 2865 LF24)		Diesel		9973	213	290	01.94-	■
27.293 DFC (D 2865 LF20)		Diesel		9973	213	290	01.94-	■
27.293 DFC (D 2865 LF20)		Diesel		9973	213	290	01.94-	■
27.293 DFC (D 2865 LF24)		Diesel		9973	213	290	01.94-	■
27.293 DFC (D 2865 LF24)		Diesel		9973	213	290	01.94-	■
26.323 DFC,26.323 DFLC (D 2865 LF23)		Diesel		9973	235	320	01.94-12.95	■
26.323 DFC,26.323 DFLC (D 2865 LF23)		Diesel		9973	235	320	01.94-12.95	■
27.323 DFC (D 2865 LF23)		Diesel		9973	235	320	01.94-12.95	■
27.323 DFC (D 2865 LF23)		Diesel		9973	235	320	01.94-12.95	■
33.323 DFC (D 2865 LF23)		Diesel		9973	235	320	01.94-12.95	■
33.323 DFC (D 2865 LF23)		Diesel		9973	235	320	01.94-12.95	■
26.343 DFC,26.343 DFLC (D 2865 LF21)		Diesel		9973	250	340	01.94-	■
26.343 DFC,26.343 DFLC (D 2865 LF21)		Diesel		9973	250	340	01.94-	■
27.343 DFC (D 2865 LF21)		Diesel		9973	250	340	01.94-	■
27.343 DFC (D 2865 LF21)		Diesel		9973	250	340	01.94-	■
33.343 DFC (D 2865 LF21)		Diesel		9973	250	340	01.94-	■
33.343 DFC (D 2865 LF21)		Diesel		9973	250	340	01.94-	■
26.373 DFC,26.373 DFLC (D 2866 LF21)		Diesel		11967	272	370	01.94-12.95	■
26.373 DFC,26.373 DFLC (D 2866 LF21)		Diesel		11967	272	370	01.94-12.95	■
27.373 DFC (D 2866 LF21)	-12/95	Diesel		11967	272	370	01.94-	■
27.373 DFC (D 2866 LF21)	-12/95	Diesel		11967	272	370	01.94-	■
33.373 DFC (D 2866 LF21)	-12/95	Diesel		11967	272	370	01.94-	■
33.373 DFC (D 2866 LF21)	-12/95	Diesel		11967	272	370	01.94-	■
26.403 DFC,26.403 DFLC (D 2866 LF20)		Diesel		11967	294	400	01.94-	■
26.403 DFC,26.403 DFLC (D 2866 LF20)		Diesel		11967	294	400	01.94-	■
27.403 DFC (D 2866 LF20)		Diesel		11967	294	400	01.94-	■
27.403 DFC (D 2866 LF20)		Diesel		11967	294	400	01.94-	■
33.403 DFC (D 2866 LF20)		Diesel		11967	294	400	01.94-	■
33.403 DFC (D 2866 LF20)		Diesel		11967	294	400	01.94-	■
26.423 DFC,26.423 DFLC (D 2866 LF22)		Diesel		11967	309	420	01.94-12.95	■
26.423 DFC,26.423 DFLC (D 2866 LF22)		Diesel		11967	309	420	01.94-12.95	■
27.423 DFC (D 2866 LF22)	-12/95	Diesel		11967	309	420	01.94-	■
27.423 DFC (D 2866 LF22)	-12/95	Diesel		11967	309	420	01.94-	■
33.423 DFC (D 2866 LF22)	-12/95	Diesel		11967	309	420	01.94-	■

LISTA DE APLICACIONES - BUYERS GUIDE

33.423 DFC (D 2866 LF22)	-12/95	Diesel		11967	309	420	01.94-	■
26.463 DFC, DFLC (D 2876 LF 02)		Diesel		12816	338	460	01.94-	■
26.463 DFC, DFLC (D 2876 LF 02)		Diesel		12816	338	460	01.94-	■
27.463 DFC (D 2876 LF 02)		Diesel		12816	338	460	01.94-	■
27.463 DFC (D 2876 LF 02)		Diesel		12816	338	460	01.94-	■
33.463 DFC (D 2876 LF 02)		Diesel		12816	338	460	01.94-	■
33.463 DFC (D 2876 LF 02)		Diesel		12816	338	460	01.94-	■
26.603 DFC, DFLC (D 2840 LF20)		Diesel		18273	441	600	06.96-	■
26.603 DFC, DFLC (D 2840 LF20)		Diesel		18273	441	600	06.96-	■
33.603 DFC (D 2840 LF20)		Diesel		18273	441	600	06.96-	■
33.603 DFC (D 2840 LF20)		Diesel		18273	441	600	06.96-	■
F2000 01.94-					Platform/Chassis			
26.233 FVLC CNG (E 2866 DF 01)		Gasolina		11967	170	231	09.96-	■
26.233 FVLC CNG (E 2866 DF 01)		Gasolina		11967	170	231	09.96-	■
F2000 01.94-					Truck Tractor			
26.273 DFS,26.273 DFLS (D 2865 LF22)		Diesel		9973	198	269	01.94-12.95	■
26.273 DFS,26.273 DFLS (D 2865 LF22)		Diesel		9973	198	269	01.94-12.95	■
27.273 DFS (D 2865 LF22)		Diesel		9973	198	269	01.94-12.95	■
27.273 DFS (D 2865 LF22)		Diesel		9973	198	269	01.94-12.95	■
26.293 DFS,26.293 DFLS (D 2865 LF20)		Diesel		9973	213	290	01.94-	■
26.293 DFS,26.293 DFLS (D 2865 LF20)		Diesel		9973	213	290	01.94-	■
26.293 DFS,26.293 DFLS (D 2865 LF24)		Diesel		9973	213	290	01.94-	■
26.293 DFS,26.293 DFLS (D 2865 LF24)		Diesel		9973	213	290	01.94-	■
27.293 DFS (D 2865 LF20)		Diesel		9973	213	290	01.94-	■
27.293 DFS (D 2865 LF20)		Diesel		9973	213	290	01.94-	■
27.293 DFS (D 2865 LF24)		Diesel		9973	213	290	01.94-	■
27.293 DFS (D 2865 LF24)		Diesel		9973	213	290	01.94-	■
26.323 DFS,26.323 DFLS (D 2865 LF23)		Diesel		9973	235	320	01.94-12.95	■
26.323 DFS,26.323 DFLS (D 2865 LF23)		Diesel		9973	235	320	01.94-12.95	■
27.323 DFS (D 2865 LF23)		Diesel		9973	235	320	01.94-12.95	■
27.323 DFS (D 2865 LF23)		Diesel		9973	235	320	01.94-12.95	■
33.323 DFS (D 2865 LF23)		Diesel		9973	235	320	01.94-12.95	■
33.323 DFS (D 2865 LF23)		Diesel		9973	235	320	01.94-12.95	■
26.343 DFS,26.343 DFLS (D 2865 LF21)		Diesel		9973	250	340	01.94-	■
26.343 DFS,26.343 DFLS (D 2865 LF21)		Diesel		9973	250	340	01.94-	■
27.343 DFS (D 2865 LF21)		Diesel		9973	250	340	01.94-	■
27.343 DFS (D 2865 LF21)		Diesel		9973	250	340	01.94-	■
33.343 DFS (D 2865 LF21)		Diesel		9973	250	340	01.94-	■
33.343 DFS (D 2865 LF21)		Diesel		9973	250	340	01.94-	■
26.373 DFS,26.373 DFLS (D 2866 LF21)		Diesel		11967	272	370	01.94-12.95	■
26.373 DFS,26.373 DFLS (D 2866 LF21)		Diesel		11967	272	370	01.94-12.95	■
27.373 DFS (D 2866 LF21)	-12/95	Diesel		11967	272	370	01.94-	■
27.373 DFS (D 2866 LF21)	-12/95	Diesel		11967	272	370	01.94-	■
33.373 DFS, DFRS (D 2866 LF21)	-12/95	Diesel		11967	272	370	01.94-	■
33.373 DFS, DFRS (D 2866 LF21)	-12/95	Diesel		11967	272	370	01.94-	■
26.403 DFS,26.403 DFLS (D 2866 LF20)		Diesel		11967	294	400	01.94-	■
26.403 DFS,26.403 DFLS (D 2866 LF20)		Diesel		11967	294	400	01.94-	■
27.403 DFS (D 2866 LF20)		Diesel		11967	294	400	01.94-	■
27.403 DFS (D 2866 LF20)		Diesel		11967	294	400	01.94-	■
33.403 DFS, DFRS (D 2866 LF20)		Diesel		11967	294	400	01.94-	■
33.403 DFS, DFRS (D 2866 LF20)		Diesel		11967	294	400	01.94-	■

LISTA DE APLICACIONES - BUYERS GUIDE

26.423 DFS,26.423 DFLS (D 2866 LF22)		Diesel		11967	309	420	01.94-12.95	■
26.423 DFS,26.423 DFLS (D 2866 LF22)		Diesel		11967	309	420	01.94-12.95	■
27.423 DFS (D 2866 LF22)	-12/95	Diesel		11967	309	420	01.94-	■
27.423 DFS (D 2866 LF22)	-12/95	Diesel		11967	309	420	01.94-	■
33.423 DFS, DFRS (D 2866 LF22)	-12/95	Diesel		11967	309	420	01.94-	■
33.423 DFS, DFRS (D 2866 LF22)	-12/95	Diesel		11967	309	420	01.94-	■
26.463 DFS, DFLS (D 2876 LF 02)		Diesel		12816	338	460	01.94-	■
26.463 DFS, DFLS (D 2876 LF 02)		Diesel		12816	338	460	01.94-	■
27.463 DFS (D 2876 LF 02)		Diesel		12816	338	460	01.94-	■
27.463 DFS (D 2876 LF 02)		Diesel		12816	338	460	01.94-	■
33.463 DFS, DFRS (D 2876 LF 02)		Diesel		12816	338	460	01.94-	■
33.463 DFS, DFRS (D 2876 LF 02)		Diesel		12816	338	460	01.94-	■
26.603 DFS, DFLS (D 2840 LF20)		Diesel		18273	441	600	06.96-	■
26.603 DFS, DFLS (D 2840 LF20)		Diesel		18273	441	600	06.96-	■
27.603 DFAS (D 2840 LF20)		Diesel		18273	441	600	01.96-	■
27.603 DFAS (D 2840 LF20)		Diesel		18273	441	600	01.96-	■
27.603 DFS (D 2840 LF20)		Diesel		18273	441	600	01.96-	■
27.603 DFS (D 2840 LF20)		Diesel		18273	441	600	01.96-	■
33.603 DFS, DFRS (D 2840 LF20)		Diesel		18273	441	600	06.96-	■
33.603 DFS, DFRS (D 2840 LF20)		Diesel		18273	441	600	06.96-	■
F90 06.86-12.97								
24.262FNL/FNLL	01/95-	Diesel		6895	191	260	06.86-	■
24.262FNL/FNLL	01/95-	Diesel		6895	191	260	06.86-	■
19.272F/FL/FLL	01/93-	Diesel		10000	198	269	06.86-	■
19.272F/FL/FLL	01/93-	Diesel		10000	198	269	06.86-	■
19.272FK	01/93-	Diesel		10000	198	269	06.86-	■
19.272FK	01/93-	Diesel		10000	198	269	06.86-	■
19.272FS/FLS/FL	01/93-	Diesel		10000	198	269	06.86-	■
19.272FS/FLS/FL	01/93-	Diesel		10000	198	269	06.86-	■
24.272DFS/DFLS	01/93-	Diesel		10000	198	269	06.86-	■
24.272DFS/DFLS	01/93-	Diesel		10000	198	269	06.86-	■
24.272FNL/FNLL	01/93-	Diesel		10000	198	269	06.86-	■
24.272FNL/FNLL	01/93-	Diesel		10000	198	269	06.86-	■
24.272FNL/FNLL	01/93-	Diesel		10000	198	269	06.86-	■
24.272FNL/FNLL	01/93-	Diesel		10000	198	269	06.86-	■
25.272FNL/FNLL	01/93-	Diesel		10000	198	269	06.86-	■
25.272FNL/FNLL	01/93-	Diesel		10000	198	269	06.86-	■
26.272FNLS/FVLS	01/93-	Diesel		10000	198	269	06.86-	■
26.272FNLS/FVLS	01/93-	Diesel		10000	198	269	06.86-	■
32.272VF	01/93-	Diesel		10000	198	269	06.86-	■
32.272VF	01/93-	Diesel		10000	198	269	06.86-	■
32.272VFK	01/93-	Diesel		10000	198	269	06.86-	■
32.272VFK	01/93-	Diesel		10000	198	269	06.86-	■
33.272 DF	01/93-	Diesel		10000	198	269	06.86-	■
33.272 DF	01/93-	Diesel		10000	198	269	06.86-	■
19.322F/FL/FLL	01/93-	Diesel		10000	235	320	06.86-	■
19.322F/FL/FLL	01/93-	Diesel		10000	235	320	06.86-	■
19.322FK	01/93-	Diesel		10000	235	320	06.86-	■
19.322FK	01/93-	Diesel		10000	235	320	06.86-	■
19.322FS/FLS/FL	01/93-	Diesel		10000	235	320	06.86-	■
19.322FS/FLS/FL	01/93-	Diesel		10000	235	320	06.86-	■

LISTA DE APLICACIONES - BUYERS GUIDE

19.322U/ULL	01/93-	Diesel		10000	235	320	06.86-	■
19.322U/ULL	01/93-	Diesel		10000	235	320	06.86-	■
24.322FNL/FNLL	01/93-	Diesel		10000	235	320	06.86-	■
24.322FNL/FNLL	01/93-	Diesel		10000	235	320	06.86-	■
24.322FNL/FNLL	01/93-	Diesel		10000	235	320	06.86-	■
24.322FNL/FNLL	01/93-	Diesel		10000	235	320	06.86-	■
26.322FNL/FNLL	01/93-	Diesel		10000	235	320	06.86-	■
26.322FNL/FNLL	01/93-	Diesel		10000	235	320	06.86-	■
26.322FNLS/FVLS	01/93-	Diesel		10000	235	320	06.86-	■
26.322FNLS/FVLS	01/93-	Diesel		10000	235	320	06.86-	■
32.322VF	01/93-	Diesel		10000	235	320	06.86-	■
32.322VF	01/93-	Diesel		10000	235	320	06.86-	■
32.322VFK	01/93-	Diesel		10000	235	320	06.86-	■
32.322VFK	01/93-	Diesel		10000	235	320	06.86-	■
33.322 DF	01/93-	Diesel		10000	235	320	06.86-	■
33.322 DF	01/93-	Diesel		10000	235	320	06.86-	■
35.322VF	01/93-	Diesel		10000	235	320	06.86-	■
35.322VF	01/93-	Diesel		10000	235	320	06.86-	■
35.322VFK	01/93-	Diesel		10000	235	320	06.86-	■
35.322VFK	01/93-	Diesel		10000	235	320	06.86-	■
35.322VFKK	01/93-	Diesel		10000	235	320	06.86-	■
35.322VFKK	01/93-	Diesel		10000	235	320	06.86-	■
41.322VF	01/93-	Diesel		10000	235	320	06.86-	■
41.322VF	01/93-	Diesel		10000	235	320	06.86-	■
19.372FS/FLS/FL	01/93-	Diesel		10000	249	339	06.86-	■
19.372FS/FLS/FL	01/93-	Diesel		10000	249	339	06.86-	■
19.342F/FL/FLL	01/94-	Diesel		10000	250	340	06.86-	■
19.342F/FL/FLL	01/94-	Diesel		10000	250	340	06.86-	■
19.342FK	01/94-	Diesel		10000	250	340	06.86-	■
19.342FK	01/94-	Diesel		10000	250	340	06.86-	■
19.342FS/FLS/FL	01/94-	Diesel		10000	250	340	06.86-	■
19.342FS/FLS/FL	01/94-	Diesel		10000	250	340	06.86-	■
24.342FNL/FNLL	01/94-	Diesel		10000	250	340	06.86-	■
24.342FNL/FNLL	01/94-	Diesel		10000	250	340	06.86-	■
32.342VFK	01/94-	Diesel		10000	250	340	06.86-	■
32.342VFK	01/94-	Diesel		10000	250	340	06.86-	■
33.342 DF	01/94-	Diesel		10000	250	340	06.86-	■
33.342 DF	01/94-	Diesel		10000	250	340	06.86-	■
35.342VF	01/94-	Diesel		10000	250	340	06.86-	■
35.342VF	01/94-	Diesel		10000	250	340	06.86-	■
35.342VFK	01/94-	Diesel		10000	250	340	06.86-	■
35.342VFK	01/94-	Diesel		10000	250	340	06.86-	■
41.342VF	01/94-	Diesel		10000	250	340	06.86-	■
41.342VF	01/94-	Diesel		10000	250	340	06.86-	■
19.372FS/FLS/FL	01/93-	Diesel		10000	272	370	06.86-	■
19.372FS/FLS/FL	01/93-	Diesel		10000	272	370	06.86-	■
19.402FS/FLS/FL	01/94-	Diesel		10000	294	400	06.86-	■
19.402FS/FLS/FL	01/94-	Diesel		10000	294	400	06.86-	■
19.422FS/FLS/FL	01/93-	Diesel		10000	309	420	06.86-	■
19.422FS/FLS/FL	01/93-	Diesel		10000	309	420	06.86-	■
35.292VF	01/93-	Diesel		11995	213	290	06.86-	■

LISTA DE APLICACIONES - BUYERS GUIDE

35.292VF	01/93-	Diesel		11995	213	290	06.86-	■
35.292VFK	01/93-	Diesel		11995	213	290	06.86-	■
35.292VFK	01/93-	Diesel		11995	213	290	06.86-	■
24.302DFS/DFLS	01/93-	Diesel		11995	220	299	06.86-	■
24.302DFS/DFLS	01/93-	Diesel		11995	220	299	06.86-	■
35.332VF	01/93-	Diesel		11995	243	330	06.86-	■
35.332VF	01/93-	Diesel		11995	243	330	06.86-	■
35.332VFK	01/93-	Diesel		11995	243	330	06.86-	■
35.332VFK	01/93-	Diesel		11995	243	330	06.86-	■
19.372F/FL/FLL	01/93-	Diesel		11995	249	339	06.86-	■
19.372F/FL/FLL	01/93-	Diesel		11995	249	339	06.86-	■
19.372FK	01/93-	Diesel		11995	249	339	06.86-	■
19.372FK	01/93-	Diesel		11995	249	339	06.86-	■
25.372FVLS	01/93-	Diesel		11995	249	339	06.86-	■
25.372FVLS	01/93-	Diesel		11995	249	339	06.86-	■
32.372VF	01/93-	Diesel		11995	249	339	06.86-	■
32.372VF	01/93-	Diesel		11995	249	339	06.86-	■
32.372VFK	01/93-	Diesel		11995	249	339	06.86-	■
32.372VFK	01/93-	Diesel		11995	249	339	06.86-	■
35.372VF	01/93-	Diesel		11995	249	339	06.86-	■
35.372VF	01/93-	Diesel		11995	249	339	06.86-	■
35.372VFK	01/93-	Diesel		11995	249	339	06.86-	■
35.372VFK	01/93-	Diesel		11995	249	339	06.86-	■
19.372F/FL/FLL	01/93-	Diesel		11995	272	370	06.86-	■
19.372F/FL/FLL	01/93-	Diesel		11995	272	370	06.86-	■
19.372FK	01/93-	Diesel		11995	272	370	06.86-	■
19.372FK	01/93-	Diesel		11995	272	370	06.86-	■
19.372U/ULL	01/93-	Diesel		11995	272	370	06.86-	■
19.372U/ULL	01/93-	Diesel		11995	272	370	06.86-	■
24.372DFS/DFLS	01/93-	Diesel		11995	272	370	06.86-	■
24.372DFS/DFLS	01/93-	Diesel		11995	272	370	06.86-	■
24.372FNL/FNLL	01/93-	Diesel		11995	272	370	06.86-	■
24.372FNL/FNLL	01/93-	Diesel		11995	272	370	06.86-	■
24.372FNL/FNLL	01/93-	Diesel		11995	272	370	06.86-	■
24.372FNL/FNLL	01/93-	Diesel		11995	272	370	06.86-	■
25.372FNLS/FVLS	01/93-	Diesel		11995	272	370	06.86-	■
25.372FNLS/FVLS	01/93-	Diesel		11995	272	370	06.86-	■
26.372FNL/FNLL	01/93-	Diesel		11995	272	370	06.86-	■
26.372FNL/FNLL	01/93-	Diesel		11995	272	370	06.86-	■
26.372FNLS/FVLS	01/93-	Diesel		11995	272	370	06.86-	■
26.372FNLS/FVLS	01/93-	Diesel		11995	272	370	06.86-	■
32.372VF	01/93-	Diesel		11995	272	370	06.86-	■
32.372VF	01/93-	Diesel		11995	272	370	06.86-	■
32.372VFK	01/93-	Diesel		11995	272	370	06.86-	■
32.372VFK	01/93-	Diesel		11995	272	370	06.86-	■
33.372 DF	01/93-	Diesel		11995	272	370	06.86-	■
33.372 DF	01/93-	Diesel		11995	272	370	06.86-	■
33.372DFK	01/93-	Diesel		11995	272	370	06.86-	■
33.372DFK	01/93-	Diesel		11995	272	370	06.86-	■
33.372DFS	01/93-	Diesel		11995	272	370	06.86-	■
33.372DFS	01/93-	Diesel		11995	272	370	06.86-	■

LISTA DE APLICACIONES - BUYERS GUIDE

35.372VF	01/93-	Diesel		11995	272	370	06.86-	■
35.372VF	01/93-	Diesel		11995	272	370	06.86-	■
35.372VF	01/93-	Diesel		11995	272	370	06.86-	■
35.372VF	01/93-	Diesel		11995	272	370	06.86-	■
35.372VFK	01/93-	Diesel		11995	272	370	06.86-	■
35.372VFK	01/93-	Diesel		11995	272	370	06.86-	■
35.372VFK	01/93-	Diesel		11995	272	370	06.86-	■
35.372VFK	01/93-	Diesel		11995	272	370	06.86-	■
40.372DF	01/93-	Diesel		11995	272	370	06.86-	■
40.372DF	01/93-	Diesel		11995	272	370	06.86-	■
41.372VF	01/93-	Diesel		11995	272	370	06.86-	■
41.372VF	01/93-	Diesel		11995	272	370	06.86-	■
19.402F/FL/FLL	01/94-	Diesel		11995	294	400	06.86-	■
19.402F/FL/FLL	01/94-	Diesel		11995	294	400	06.86-	■
19.402FK	01/94-	Diesel		11995	294	400	06.86-	■
19.402FK	01/94-	Diesel		11995	294	400	06.86-	■
24.402FNL/FNLL	01/94-	Diesel		11995	294	400	06.86-	■
24.402FNL/FNLL	01/94-	Diesel		11995	294	400	06.86-	■
26.402FNL/FNLL	01/94-	Diesel		11995	294	400	06.86-	■
26.402FNL/FNLL	01/94-	Diesel		11995	294	400	06.86-	■
26.402FNLS/FVLS	01/94-	Diesel		11995	294	400	06.86-	■
26.402FNLS/FVLS	01/94-	Diesel		11995	294	400	06.86-	■
32.402VFK	01/94-	Diesel		11995	294	400	06.86-	■
32.402VFK	01/94-	Diesel		11995	294	400	06.86-	■
33.402 DF	01/94-	Diesel		11995	294	400	06.86-	■
33.402 DF	01/94-	Diesel		11995	294	400	06.86-	■
33.402DFK	01/94-	Diesel		11995	294	400	06.86-	■
33.402DFK	01/94-	Diesel		11995	294	400	06.86-	■
33.402DFS	01/94-	Diesel		11995	294	400	06.86-	■
33.402DFS	01/94-	Diesel		11995	294	400	06.86-	■
35.402VF	01/94-	Diesel		11995	294	400	06.86-	■
35.402VF	01/94-	Diesel		11995	294	400	06.86-	■
35.402VF	01/94-	Diesel		11995	294	400	06.86-	■
35.402VF	01/94-	Diesel		11995	294	400	06.86-	■
35.402VFK	01/94-	Diesel		11995	294	400	06.86-	■
35.402VFK	01/94-	Diesel		11995	294	400	06.86-	■
35.402VFK	01/94-	Diesel		11995	294	400	06.86-	■
35.402VFK	01/94-	Diesel		11995	294	400	06.86-	■
40.402DF	01/95-	Diesel		11995	294	400	06.86-	■
40.402DF	01/95-	Diesel		11995	294	400	06.86-	■
41.4022VF	01/94-	Diesel		11995	294	400	06.86-	■
41.4022VF	01/94-	Diesel		11995	294	400	06.86-	■
19.422F/FL/FLL	01/93-	Diesel		11995	309	420	06.86-	■
19.422F/FL/FLL	01/93-	Diesel		11995	309	420	06.86-	■
19.422FK	01/93-	Diesel		11995	309	420	06.86-	■
19.422FK	01/93-	Diesel		11995	309	420	06.86-	■
19.422U/ULL	01/93-	Diesel		11995	309	420	06.86-	■
19.422U/ULL	01/93-	Diesel		11995	309	420	06.86-	■
24.422FNL/FNLL	01/93-	Diesel		11995	309	420	06.86-	■
24.422FNL/FNLL	01/93-	Diesel		11995	309	420	06.86-	■
26.402FNLS/FVLS	01/93-	Diesel		11995	309	420	06.86-	■

LISTA DE APLICACIONES - BUYERS GUIDE

26.402FNLS/FVLS	01/93-	Diesel		11995	309	420	06.86-	■
26.422FNL/FNLL	01/93-	Diesel		11995	309	420	06.86-	■
26.422FNL/FNLL	01/93-	Diesel		11995	309	420	06.86-	■
32.422VF	01/93-	Diesel		11995	309	420	06.86-	■
32.422VF	01/93-	Diesel		11995	309	420	06.86-	■
32.422VFK	01/93-	Diesel		11995	309	420	06.86-	■
32.422VFK	01/93-	Diesel		11995	309	420	06.86-	■
33.422 DF	01/93-	Diesel		11995	309	420	06.86-	■
33.422 DF	01/93-	Diesel		11995	309	420	06.86-	■
33.422DFK	01/94-	Diesel		11995	309	420	06.86-	■
33.422DFK	01/94-	Diesel		11995	309	420	06.86-	■
33.422DFS	01/94-	Diesel		11995	309	420	06.86-	■
33.422DFS	01/94-	Diesel		11995	309	420	06.86-	■
35.422VF	01/93-	Diesel		11995	309	420	06.86-	■
35.422VF	01/93-	Diesel		11995	309	420	06.86-	■
35.422VF	01/93-	Diesel		11995	309	420	06.86-	■
35.422VF	01/93-	Diesel		11995	309	420	06.86-	■
35.422VF	01/93-	Diesel		11995	309	420	06.86-	■
35.422VF	01/93-	Diesel		11995	309	420	06.86-	■
35.422VFK	01/93-	Diesel		11995	309	420	06.86-	■
35.422VFK	01/93-	Diesel		11995	309	420	06.86-	■
40.422DF	01/93-	Diesel		11995	309	420	06.86-	■
40.422DF	01/93-	Diesel		11995	309	420	06.86-	■
41.422VF	01/93-	Diesel		11995	309	420	06.86-	■
41.422VF	01/93-	Diesel		11995	309	420	06.86-	■
48.502VF	01/93-	Diesel		18195	368	500	06.86-	■
48.502VF	01/93-	Diesel		18195	368	500	06.86-	■
F90 06.86-12.97					Platform/Chassis			
19.502 F,19.502 FL,19.502 FLL (D 2840 LF01)	01/93-	Diesel		18273	368	500	02.90-06.96	■
19.502 F,19.502 FL,19.502 FLL (D 2840 LF01)	01/93-	Diesel		18273	368	500	02.90-06.96	■
19.502 F,19.502 FL,19.502 FLL (D 2840 LF04)	01/93-	Diesel		18273	368	500	02.90-06.96	■
19.502 F,19.502 FL,19.502 FLL (D 2840 LF04)	01/93-	Diesel		18273	368	500	02.90-06.96	■
19.502 F,19.502 FL,19.502 FLL (D 2840 LF06)	01/93-	Diesel		18273	368	500	02.90-06.96	■
19.502 F,19.502 FL,19.502 FLL (D 2840 LF06)	01/93-	Diesel		18273	368	500	02.90-06.96	■
24.502 DF (D 2840 LF01)		Diesel		18273	368	500	02.90-12.90	■
24.502 DF (D 2840 LF01)		Diesel		18273	368	500	02.90-12.90	■
26.502 FNL,26.502 FNLL (D 2840 LF01)	01/93-	Diesel		18273	368	500	09.91-06.96	■
26.502 FNL,26.502 FNLL (D 2840 LF01)	01/93-	Diesel		18273	368	500	09.91-06.96	■
26.502 FNL,26.502 FNLL (D 2840 LF04)	01/93-	Diesel		18273	368	500	09.91-06.96	■
26.502 FNL,26.502 FNLL (D 2840 LF04)	01/93-	Diesel		18273	368	500	09.91-06.96	■
26.502 FNL,26.502 FNLL (D 2840 LF06)	01/93-	Diesel		18273	368	500	09.91-06.96	■
26.502 FNL,26.502 FNLL (D 2840 LF06)	01/93-	Diesel		18273	368	500	09.91-06.96	■
33.502 DF (D 2840 LF01)	01/93-	Diesel		18273	368	500	09.91-06.96	■
33.502 DF (D 2840 LF01)	01/93-	Diesel		18273	368	500	09.91-06.96	■
33.502 DF (D 2840 LF04)	01/93-	Diesel		18273	368	500	09.91-06.96	■
33.502 DF (D 2840 LF04)	01/93-	Diesel		18273	368	500	09.91-06.96	■
33.502 DF (D 2840 LF06)	01/93-	Diesel		18273	368	500	09.91-06.96	■
33.502 DF (D 2840 LF06)	01/93-	Diesel		18273	368	500	09.91-06.96	■
F90 06.86-12.97					Truck Tractor			
19.502 FS,19.502 FLS,19.502 FLLS (D 2840 LF01)	01/93-	Diesel		18273	368	500	02.90-06.96	■

LISTA DE APLICACIONES - BUYERS GUIDE

19.502 FS,19.502 FLS,19.502 FLLS (D 2840 LF01)	01/93-	Diesel		18273	368	500	02.90-06.96	■
19.502 FS,19.502 FLS,19.502 FLLS (D 2840 LF04)	01/93-	Diesel		18273	368	500	02.90-06.96	■
19.502 FS,19.502 FLS,19.502 FLLS (D 2840 LF04)	01/93-	Diesel		18273	368	500	02.90-06.96	■
19.502 FS,19.502 FLS,19.502 FLLS (D 2840 LF06)	01/93-	Diesel		18273	368	500	02.90-06.96	■
19.502 FS,19.502 FLS,19.502 FLLS (D 2840 LF06)	01/93-	Diesel		18273	368	500	02.90-06.96	■
LOW Chassis 01.86-								
24.332U/UL	01/93-	Diesel					01.86-	■
24.332U/UL	01/93-	Diesel					01.86-	■
24.362U/UL	01/93-	Diesel					01.86-	■
24.362U/UL	01/93-	Diesel					01.86-	■
14.272U	01/93-	Diesel			198	269	01.86-	■
14.272U	01/93-	Diesel			198	269	01.86-	■
19.322U/UL	01/93-	Diesel			235	320	01.86-	■
19.322U/UL	01/93-	Diesel			235	320	01.86-	■
26.322U/UL	01/93-	Diesel			235	320	01.86-	■
26.322U/UL	01/93-	Diesel			235	320	01.86-	■
19.372U/UL	01/93-	Diesel			272	370	01.86-	■
19.372U/UL	01/93-	Diesel			272	370	01.86-	■
19.422U/UL	01/93-	Diesel			309	420	01.86-	■
19.422U/UL	01/93-	Diesel			309	420	01.86-	■
26.372U/UL	01/93-	Diesel		11995	272	370	01.86-	■
26.372U/UL	01/93-	Diesel		11995	272	370	01.86-	■
26.422U/UL	01/93-	Diesel		11995	309	420	01.86-	■
26.422U/UL	01/93-	Diesel		11995	309	420	01.86-	■
M 2000 L 04.95-								
15.163LK	01/95-	Diesel		4595	114	155	04.95-	■
15.163LK	01/95-	Diesel		4595	114	155	04.95-	■
15.224LK	01/95-	Diesel		6895	162	220	04.95-	■
15.224LK	01/95-	Diesel		6895	162	220	04.95-	■
18.224LAC	01/95-	Diesel		6895	162	220	04.95-	■
18.224LAC	01/95-	Diesel		6895	162	220	04.95-	■
18.224LAK	01/95-	Diesel		6895	162	220	04.95-	■
18.224LAK	01/95-	Diesel		6895	162	220	04.95-	■
18.224LK/LLK	01/95-	Diesel		6895	162	220	04.95-	■
18.224LK/LLK	01/95-	Diesel		6895	162	220	04.95-	■
18.224MAC	01/95-	Diesel		6895	162	220	04.95-	■
18.224MAC	01/95-	Diesel		6895	162	220	04.95-	■
18.224MAK	01/95-	Diesel		6895	162	220	04.95-	■
18.224MAK	01/95-	Diesel		6895	162	220	04.95-	■
18.224MK/MLK	01/95-	Diesel		6895	162	220	04.95-	■
18.224MK/MLK	01/95-	Diesel		6895	162	220	04.95-	■
15.264LK	01/95-	Diesel		6895	191	260	04.95-	■
15.264LK	01/95-	Diesel		6895	191	260	04.95-	■
18.264LAK	01/95-	Diesel		6895	191	260	04.95-	■
18.264LAK	01/95-	Diesel		6895	191	260	04.95-	■
18.264LK/LLK	01/95-	Diesel		6895	191	260	04.95-	■
18.264LK/LLK	01/95-	Diesel		6895	191	260	04.95-	■
18.264MAC	01/95-	Diesel		6895	191	260	04.95-	■

LISTA DE APLICACIONES - BUYERS GUIDE

18.264MAC	01/95-	Diesel		6895	191	260	04.95-	■
18.264MAK	01/95-	Diesel		6895	191	260	04.95-	■
18.264MAK	01/95-	Diesel		6895	191	260	04.95-	■
18.264MK/MLK	01/95-	Diesel		6895	191	260	04.95-	■
18.264MK/MLK	01/95-	Diesel		6895	191	260	04.95-	■
15.284LK	01/98-	Diesel		6895	206	280	04.95-	■
15.284LK	01/98-	Diesel		6895	206	280	04.95-	■
18.284LAC	01/98-	Diesel		6895	206	280	04.95-	■
18.284LAC	01/98-	Diesel		6895	206	280	04.95-	■
18.284LAK	01/98-	Diesel		6895	206	280	04.95-	■
18.284LAK	01/98-	Diesel		6895	206	280	04.95-	■
18.284LK/LLK	01/98-	Diesel		6895	206	280	04.95-	■
18.284LK/LLK	01/98-	Diesel		6895	206	280	04.95-	■
18.284MAC	01/98-	Diesel		6895	206	280	04.95-	■
18.284MAC	01/98-	Diesel		6895	206	280	04.95-	■
18.284MAK	01/98-	Diesel		6895	206	280	04.95-	■
18.284MAK	01/98-	Diesel		6895	206	280	04.95-	■
18.284MK/MLK	01/98-	Diesel		6895	206	280	04.95-	■
18.284MK/MLK	01/98-	Diesel		6895	206	280	04.95-	■
M 2000 L 04.95-					Platform/Chassis			
15.163 LC, LLC, LLLC, LLLRC, LLRC, LRC (D 0824 LFL 06)		Diesel		4580	114	155	08.95-	■
15.163 LC, LLC, LLLC, LLLRC, LLRC, LRC (D 0824 LFL 06)		Diesel		4580	114	155	08.95-	■
15.163 LC, LLC, LLLC, LLLRC, LLRC, LRC (D 0824 LFL 09)		Diesel		4580	114	155	08.95-	■
15.163 LC, LLC, LLLC, LLLRC, LLRC, LRC (D 0824 LFL 09)		Diesel		4580	114	155	08.95-	■
15.224 LC, LLC, LLLC, LRC, LLRC, LLLRC (D 0826 LFL03)		Diesel		6871	162	220	08.95-	■
15.224 LC, LLC, LLLC, LRC, LLRC, LLLRC (D 0826 LFL03)		Diesel		6871	162	220	08.95-	■
15.224 LC, LLC, LLLC, LRC, LLRC, LLLRC (D 0826 LFL10)		Diesel		6871	162	220	08.95-	■
15.224 LC, LLC, LLLC, LRC, LLRC, LLLRC (D 0826 LFL10)		Diesel		6871	162	220	08.95-	■
18.224, 18.225, LC, LLC, LLLC, LRC, LLRC, LLLRC (D 0826 LFL03)		Diesel		6871	162	220	08.95-	■
18.224, 18.225, LC, LLC, LLLC, LRC, LLRC, LLLRC (D 0826 LFL03)		Diesel		6871	162	220	08.95-	■
18.224, 18.225, LC, LLC, LLLC, LRC, LLRC, LLLRC (D 0826 LFL10)		Diesel		6871	162	220	08.95-	■
18.224, 18.225, LC, LLC, LLLC, LRC, LLRC, LLLRC (D 0826 LFL10)		Diesel		6871	162	220	08.95-	■
18.224, 18.225, LC, LLC, LLLC, LRC, LLRC, LLLRC (D 0836 LFL 02)		Diesel		6871	162	220	08.95-	■
18.224, 18.225, LC, LLC, LLLC, LRC, LLRC, LLLRC (D 0836 LFL 02)		Diesel		6871	162	220	08.95-	■
15.263, 15.264 LC, LLC, LLLC, LRC, LLRC, LLLRC (D 0826 LFL09)		Diesel		6871	191	260	08.95-	■
15.263, 15.264 LC, LLC, LLLC, LRC, LLRC, LLLRC (D 0826 LFL09)		Diesel		6871	191	260	08.95-	■
18.263, 18.264, LC, LLC, LLLC, LRC, LLRC, LLLRC (D 0826 LFL09)		Diesel		6871	191	260	08.95-	■
18.263, 18.264, LC, LLC, LLLC, LRC, LLRC, LLLRC (D 0826 LFL09)		Diesel		6871	191	260	08.95-	■
15.284 LC, LLC, LLLC, LRC, LLRC, LLLRC (D 0836 LF 01)		Diesel		6871	206	280	06.98-	■
15.284 LC, LLC, LLLC, LRC, LLRC, LLLRC (D 0836 LF 01)		Diesel		6871	206	280	06.98-	■
18.284 LC, LLC, LLLC, LRC, LLRC, LLLRC (D 0836 LF 01)		Diesel		6871	206	280	06.98-	■

LISTA DE APLICACIONES - BUYERS GUIDE

18.284 LC, LLC, LLLC, LRC, LLRC, LLLRC (D 0836 LF 01)		Diesel		6871	206	280	06.98-	■
M 2000 M 08.95-12.05					Platform/Chassis			
18.224 MC, MLC, MLLC, MRC, MLRC, MLLRC (D 0826 LF15)		Diesel		6871	162	220	08.95-12.05	■
18.224 MC, MLC, MLLC, MRC, MLRC, MLLRC (D 0826 LF15)		Diesel		6871	162	220	08.95-12.05	■
18.224 MC, MLC, MLLC, MRC, MLRC, MLLRC (D 0826 LF18)		Diesel		6871	162	220	08.95-12.05	■
18.224 MC, MLC, MLLC, MRC, MLRC, MLLRC (D 0826 LF18)		Diesel		6871	162	220	08.95-12.05	■
25.224 MNLC, MNLLC, MNLRC, MNLLRC, MVLC (D 0826 LF15)		Diesel		6871	162	220	08.95-12.05	■
25.224 MNLC, MNLLC, MNLRC, MNLLRC, MVLC (D 0826 LF15)		Diesel		6871	162	220	08.95-12.05	■
25.224 MNLC, MNLLC, MNLRC, MNLLRC, MVLC (D 0826 LF18)		Diesel		6871	162	220	08.95-12.05	■
25.224 MNLC, MNLLC, MNLRC, MNLLRC, MVLC (D 0826 LF18)		Diesel		6871	162	220	08.95-12.05	■
25.224 MNLC, MNLLC, MNLRC, MNLLRC, MVLC (D 0826 LFL10)		Diesel		6871	162	220	08.95-12.05	■
25.224 MNLC, MNLLC, MNLRC, MNLLRC, MVLC (D 0826 LFL10)		Diesel		6871	162	220	08.95-12.05	■
18.264 MC, MLC, MLLC, MRC, MLRC, MLLRC (D 0826 LF17)		Diesel		6871	191	260	08.95-12.05	■
18.264 MC, MLC, MLLC, MRC, MLRC, MLLRC (D 0826 LF17)		Diesel		6871	191	260	08.95-12.05	■
25.264 MNLC, MNLLC, MNLRC, MNLLRC, MVLC (D 0826 LF17)		Diesel		6871	191	260	08.95-12.05	■
25.264 MNLC, MNLLC, MNLRC, MNLLRC, MVLC (D 0826 LF17)		Diesel		6871	191	260	08.95-12.05	■
18.284 MC, MLC, MLLC, MLRC, MRC, MLLRC (D 0836 LF 01)		Diesel		6871	206	280	06.98-12.05	■
18.284 MC, MLC, MLLC, MLRC, MRC, MLLRC (D 0836 LF 01)		Diesel		6871	206	280	06.98-12.05	■
M 2000 M 08.95-12.05					Truck Tractor			
18.224 MLS, MLRS (D 0826 LF15)		Diesel		6871	162	220	08.95-12.05	■
18.224 MLS, MLRS (D 0826 LF15)		Diesel		6871	162	220	08.95-12.05	■
18.224 MLS, MLRS (D 0826 LF18)		Diesel		6871	162	220	08.95-12.05	■
18.224 MLS, MLRS (D 0826 LF18)		Diesel		6871	162	220	08.95-12.05	■
18.264 MLS, MLRS (D 0826 LF17)		Diesel		6871	191	260	08.95-12.05	■
18.264 MLS, MLRS (D 0826 LF17)		Diesel		6871	191	260	08.95-12.05	■
18.284 MLS, MLRS (D 0836 LF 01)		Diesel		6871	206	280	06.98-12.05	■
18.284 MLS, MLRS (D 0836 LF 01)		Diesel		6871	206	280	06.98-12.05	■
M90 08.88-12.98								
18.192F/FL/FLL	01/93-	Diesel		6895	140	190	08.88-	■
18.192F/FL/FLL	01/93-	Diesel		6895	140	190	08.88-	■
18.192FK	01/93-	Diesel		6895	140	190	08.88-	■
18.192FK	01/93-	Diesel		6895	140	190	08.88-	■
24.192FNL/FNLL	01/93-	Diesel		6895	140	190	08.88-	■
24.192FNL/FNLL	01/93-	Diesel		6895	140	190	08.88-	■
24.232FNL	01/93-	Diesel		6895	160	218	08.88-	■
24.232FNL	01/93-	Diesel		6895	160	218	08.88-	■
18.222F/FL/FLL	01/94-	Diesel		6895	162	220	08.88-	■
18.222F/FL/FLL	01/94-	Diesel		6895	162	220	08.88-	■
18.222FK	01/94-	Diesel		6895	162	220	08.88-	■
18.222FK	01/94-	Diesel		6895	162	220	08.88-	■
24.222FNL/FNLL	01/94-	Diesel		6895	162	220	08.88-	■
24.222FNL/FNLL	01/94-	Diesel		6895	162	220	08.88-	■
18.232F/FL/FLL	01/93-	Diesel		6895	169	230	08.88-	■

LISTA DE APLICACIONES - BUYERS GUIDE

18.232F/FL/FLL	01/93-	Diesel		6895	169	230	08.88-	■
18.232FK	01/93-	Diesel		6895	169	230	08.88-	■
18.232FK	01/93-	Diesel		6895	169	230	08.88-	■
24.232FNL/FNLL	01/93-	Diesel		6895	169	230	08.88-	■
24.232FNL/FNLL	01/93-	Diesel		6895	169	230	08.88-	■
18.262F/FL/FLL	01/95-	Diesel		6895	191	260	08.88-	■
18.262F/FL/FLL	01/95-	Diesel		6895	191	260	08.88-	■
18.262FK	01/95-	Diesel		6895	191	260	08.88-	■
18.262FK	01/95-	Diesel		6895	191	260	08.88-	■
18.272F/FL/FLL	01/93-	Diesel		6895	198	269	08.88-	■
18.272F/FL/FLL	01/93-	Diesel		6895	198	269	08.88-	■
18.272FK	01/93-	Diesel		6895	198	269	08.88-	■
18.272FK	01/93-	Diesel		6895	198	269	08.88-	■
24.272FNL/FNLL	01/93-	Diesel		6895	198	269	08.88-	■
24.272FNL/FNLL	01/93-	Diesel		6895	198	269	08.88-	■
18.272F/FL/FLL	01/93-	Diesel		10000	198	269	08.88-	■
18.272F/FL/FLL	01/93-	Diesel		10000	198	269	08.88-	■
18.272FK	01/93-	Diesel		10000	198	269	08.88-	■
18.272FK	01/93-	Diesel		10000	198	269	08.88-	■
24.272FNL/FNLL	01/93-	Diesel		10000	198	269	08.88-	■
24.272FNL/FNLL	01/93-	Diesel		10000	198	269	08.88-	■
MERCEDES-BENZ								
ACTROS 04.96-10.03					Concrete Mixer			
2631B (OM 541.920)		Diesel		11946	230	313	04.97-10.02	■
2631B (OM 541.920)		Diesel		11946	230	313	04.97-10.02	■
2631B (OM 541.940)		Diesel		11946	230	313	04.97-10.02	■
2631B (OM 541.940)		Diesel		11946	230	313	04.97-10.02	■
3331 B (OM 541.920)		Diesel		11946	230	313	04.97-10.02	■
3331 B (OM 541.920)		Diesel		11946	230	313	04.97-10.02	■
3331 B (OM 541.940)		Diesel		11946	230	313	04.97-10.02	■
3331 B (OM 541.940)		Diesel		11946	230	313	04.97-10.02	■
2635 B (OM 541.922)		Diesel		11946	260	354	04.97-10.02	■
2635 B (OM 541.922)		Diesel		11946	260	354	04.97-10.02	■
2635 B (OM 541.942)		Diesel		11946	260	354	04.97-10.02	■
2635 B (OM 541.942)		Diesel		11946	260	354	04.97-10.02	■
3335 B (OM 541.922)		Diesel		11946	260	354	04.97-10.02	■
3335 B (OM 541.922)		Diesel		11946	260	354	04.97-10.02	■
3335 B (OM 541.942)		Diesel		11946	260	354	04.97-10.02	■
3335 B (OM 541.942)		Diesel		11946	260	354	04.97-10.02	■
2640 B (OM 541.923)		Diesel		11946	290	394	04.97-10.02	■
2640 B (OM 541.923)		Diesel		11946	290	394	04.97-10.02	■
2640 B (OM 541.944)		Diesel		11946	290	394	04.97-10.02	■
2640 B (OM 541.944)		Diesel		11946	290	394	04.97-10.02	■
3340 B (OM 541.923)		Diesel		11946	290	394	04.97-10.02	■
3340 B (OM 541.923)		Diesel		11946	290	394	04.97-10.02	■
3340 B (OM 541.944)		Diesel		11946	290	394	04.97-10.02	■
3340 B (OM 541.944)		Diesel		11946	290	394	04.97-10.02	■
2643 B (OM 541.925)		Diesel		11946	315	428	04.97-10.02	■
2643 B (OM 541.925)		Diesel		11946	315	428	04.97-10.02	■
2643 B (OM 541.946)		Diesel		11946	315	428	04.97-10.02	■
2643 B (OM 541.946)		Diesel		11946	315	428	04.97-10.02	■

LISTA DE APLICACIONES - BUYERS GUIDE

ACTROS 04.96-10.03					Dump Truck			
1831AK (OM 541.926)		Diesel		11946	230	313	04.97-10.02	■
1831AK (OM 541.926)		Diesel		11946	230	313	04.97-10.02	■
1831AK (OM 541.941)		Diesel		11946	230	313	04.97-10.02	■
1831AK (OM 541.941)		Diesel		11946	230	313	04.97-10.02	■
1831K (OM 541.920)		Diesel		11946	230	313	04.97-10.02	■
1831K (OM 541.920)		Diesel		11946	230	313	04.97-10.02	■
1831K (OM 541.940)		Diesel		11946	230	313	04.97-10.02	■
1831K (OM 541.940)		Diesel		11946	230	313	04.97-10.02	■
2031 AK (OM 541.926)		Diesel		11946	230	313	09.96-10.02	■
2031 AK (OM 541.926)		Diesel		11946	230	313	09.96-10.02	■
2031 AK (OM 541.941)		Diesel		11946	230	313	09.96-10.02	■
2031 AK (OM 541.941)		Diesel		11946	230	313	09.96-10.02	■
2031 K (OM 541.920)		Diesel		11946	230	313	04.97-10.02	■
2031 K (OM 541.920)		Diesel		11946	230	313	04.97-10.02	■
2031 K (OM 541.940)		Diesel		11946	230	313	04.97-10.02	■
2031 K (OM 541.940)		Diesel		11946	230	313	04.97-10.02	■
2631 K (OM 541.920)		Diesel		11946	230	313	04.97-10.02	■
2631 K (OM 541.920)		Diesel		11946	230	313	04.97-10.02	■
2631 K (OM 541.940)		Diesel		11946	230	313	04.97-10.02	■
2631 K (OM 541.940)		Diesel		11946	230	313	04.97-10.02	■
3331 AK (OM 541.926)		Diesel		11946	230	313	04.97-10.02	■
3331 AK (OM 541.926)		Diesel		11946	230	313	04.97-10.02	■
3331 AK (OM 541.941)		Diesel		11946	230	313	04.97-10.02	■
3331 AK (OM 541.941)		Diesel		11946	230	313	04.97-10.02	■
3331 K (OM 541.920)		Diesel		11946	230	313	04.97-10.02	■
3331 K (OM 541.920)		Diesel		11946	230	313	04.97-10.02	■
3331 K (OM 541.940)		Diesel		11946	230	313	04.97-10.02	■
3331 K (OM 541.940)		Diesel		11946	230	313	04.97-10.02	■
1835 AK (OM 541.927)		Diesel		11946	260	354	04.97-10.02	■
1835 AK (OM 541.927)		Diesel		11946	260	354	04.97-10.02	■
1835 AK (OM 541.943)		Diesel		11946	260	354	04.97-10.02	■
1835 AK (OM 541.943)		Diesel		11946	260	354	04.97-10.02	■
1835 K (OM 541.922)		Diesel		11946	260	354	04.97-10.02	■
1835 K (OM 541.922)		Diesel		11946	260	354	04.97-10.02	■
1835 K (OM 541.942)		Diesel		11946	260	354	04.97-10.02	■
1835 K (OM 541.942)		Diesel		11946	260	354	04.97-10.02	■
2635 K, 2635 LK (OM 541.922)		Diesel		11946	260	354	04.97-10.02	■
2635 K, 2635 LK (OM 541.922)		Diesel		11946	260	354	04.97-10.02	■
2635 K, 2635 LK (OM 541.942)		Diesel		11946	260	354	04.97-10.02	■
2635 K, 2635 LK (OM 541.942)		Diesel		11946	260	354	04.97-10.02	■
3335 K (OM 541.922)		Diesel		11946	260	354	04.97-10.02	■
3335 K (OM 541.922)		Diesel		11946	260	354	04.97-10.02	■
3335 K (OM 541.942)		Diesel		11946	260	354	04.97-10.02	■
3335 K (OM 541.942)		Diesel		11946	260	354	04.97-10.02	■
1840 AK (OM 541.924)		Diesel		11946	290	394	04.97-10.02	■
1840 AK (OM 541.924)		Diesel		11946	290	394	04.97-10.02	■
1840 AK (OM 541.945)		Diesel		11946	290	394	04.97-10.02	■
1840 AK (OM 541.945)		Diesel		11946	290	394	04.97-10.02	■
1840 K (OM 541.923)		Diesel		11946	290	394	04.97-10.02	■
1840 K (OM 541.923)		Diesel		11946	290	394	04.97-10.02	■

LISTA DE APLICACIONES - BUYERS GUIDE

1840 K (OM 541.944)	Diesel	11946	290	394	04.97-10.02	■
1840 K (OM 541.944)	Diesel	11946	290	394	04.97-10.02	■
2040 AK (OM 541.924)	Diesel	11946	290	394	09.96-10.02	■
2040 AK (OM 541.924)	Diesel	11946	290	394	09.96-10.02	■
2040 AK (OM 541.945)	Diesel	11946	290	394	09.96-10.02	■
2040 AK (OM 541.945)	Diesel	11946	290	394	09.96-10.02	■
2640 K, 2640 LK (OM 541.923)	Diesel	11946	290	394	04.97-10.02	■
2640 K, 2640 LK (OM 541.923)	Diesel	11946	290	394	04.97-10.02	■
2640 K, 2640 LK (OM 541.944)	Diesel	11946	290	394	04.97-10.02	■
2640 K, 2640 LK (OM 541.944)	Diesel	11946	290	394	04.97-10.02	■
3340 AK (OM 541.924)	Diesel	11946	290	394	04.97-10.02	■
3340 AK (OM 541.924)	Diesel	11946	290	394	04.97-10.02	■
3340 AK (OM 541.945)	Diesel	11946	290	394	04.97-10.02	■
3340 AK (OM 541.945)	Diesel	11946	290	394	04.97-10.02	■
3340 K (OM 541.923)	Diesel	11946	290	394	04.97-10.02	■
3340 K (OM 541.923)	Diesel	11946	290	394	04.97-10.02	■
3340 K (OM 541.944)	Diesel	11946	290	394	04.97-10.02	■
3340 K (OM 541.944)	Diesel	11946	290	394	04.97-10.02	■
1843 AK (OM 541.921)	Diesel	11946	315	428	04.97-10.02	■
1843 AK (OM 541.921)	Diesel	11946	315	428	04.97-10.02	■
1843 AK (OM 541.947)	Diesel	11946	315	428	04.97-10.02	■
1843 AK (OM 541.947)	Diesel	11946	315	428	04.97-10.02	■
1843 K (OM 541.925)	Diesel	11946	315	428	04.97-10.02	■
1843 K (OM 541.925)	Diesel	11946	315	428	04.97-10.02	■
1843 K (OM 541.946)	Diesel	11946	315	428	04.97-10.02	■
1843 K (OM 541.946)	Diesel	11946	315	428	04.97-10.02	■
2643 K, 2643 LK (OM 541.925)	Diesel	11946	315	428	04.97-10.02	■
2643 K, 2643 LK (OM 541.925)	Diesel	11946	315	428	04.97-10.02	■
2643 K, 2643 LK (OM 541.946)	Diesel	11946	315	428	04.97-10.02	■
2643 K, 2643 LK (OM 541.946)	Diesel	11946	315	428	04.97-10.02	■
3343 AK (OM 541.921)	Diesel	11946	315	428	04.97-10.02	■
3343 AK (OM 541.921)	Diesel	11946	315	428	04.97-10.02	■
3343 AK (OM 541.947)	Diesel	11946	315	428	04.97-10.02	■
3343 AK (OM 541.947)	Diesel	11946	315	428	04.97-10.02	■
3343 K (OM 541.925)	Diesel	11946	315	428	04.97-10.02	■
3343 K (OM 541.925)	Diesel	11946	315	428	04.97-10.02	■
3343 K (OM 541.946)	Diesel	11946	315	428	04.97-10.02	■
3343 K (OM 541.946)	Diesel	11946	315	428	04.97-10.02	■
1848 AK (OM 542.925)	Diesel	15928	350	476	04.97-10.02	■
1848 AK (OM 542.925)	Diesel	15928	350	476	04.97-10.02	■
1848 K (OM 542.921)	Diesel	15928	350	476	04.97-10.02	■
1848 K (OM 542.921)	Diesel	15928	350	476	04.97-10.02	■
1848 K (OM 542.940)	Diesel	15928	350	476	04.97-10.02	■
1848 K (OM 542.940)	Diesel	15928	350	476	04.97-10.02	■
2648 K, 2648 LK (OM 542.921)	Diesel	15928	350	476	04.97-10.02	■
2648 K, 2648 LK (OM 542.921)	Diesel	15928	350	476	04.97-10.02	■
2648 K, 2648 LK (OM 542.940)	Diesel	15928	350	476	04.97-10.02	■
2648 K, 2648 LK (OM 542.940)	Diesel	15928	350	476	04.97-10.02	■
3348 AK (OM 542.925)	Diesel	15928	350	476	04.97-10.02	■
3348 AK (OM 542.925)	Diesel	15928	350	476	04.97-10.02	■
3348 K (OM 542.921)	Diesel	15928	350	476	04.97-10.02	■

LISTA DE APLICACIONES - BUYERS GUIDE

3348 K (OM 542.921)		Diesel		15928	350	476	04.97-10.02	■
3348 K (OM 542.940)		Diesel		15928	350	476	04.97-10.02	■
3348 K (OM 542.940)		Diesel		15928	350	476	04.97-10.02	■
2653 K, 2653 LK (OM 542.920)		Diesel		15928	390	530	04.97-10.02	■
2653 K, 2653 LK (OM 542.920)		Diesel		15928	390	530	04.97-10.02	■
2653 K, 2653 LK (OM 542.942)		Diesel		15928	390	530	04.97-10.02	■
2653 K, 2653 LK (OM 542.942)		Diesel		15928	390	530	04.97-10.02	■
2657 K, 2657 LK (OM 542.922)		Diesel		15928	420	571	04.97-10.02	■
2657 K, 2657 LK (OM 542.922)		Diesel		15928	420	571	04.97-10.02	■
2657 K, 2657 LK (OM 542.944)		Diesel		15928	420	571	04.97-10.02	■
2657 K, 2657 LK (OM 542.944)		Diesel		15928	420	571	04.97-10.02	■
ACTROS 04.96-10.03					Platform/Chassis			
1831, 1831 L (OM 541.920)		Diesel		11946	230	313	04.96-10.02	■
1831, 1831 L (OM 541.920)		Diesel		11946	230	313	04.96-10.02	■
2031 (OM 541.920)		Diesel		11946	230	313	04.97-10.02	■
2031 (OM 541.920)		Diesel		11946	230	313	04.97-10.02	■
2031A (OM 541.926)		Diesel		11946	230	313	04.97-10.02	■
2031A (OM 541.926)		Diesel		11946	230	313	04.97-10.02	■
2531, 2531 L (OM 541.920)		Diesel		11946	230	313	09.96-10.02	■
2531, 2531 L (OM 541.920)		Diesel		11946	230	313	09.96-10.02	■
2531, 2531 L (OM 541.940)		Diesel		11946	230	313	09.96-10.02	■
2531, 2531 L (OM 541.940)		Diesel		11946	230	313	09.96-10.02	■
2631, 2631 L (OM 541.920)	01/97-	Diesel		11946	230	313	04.96-10.02	■
2631, 2631 L (OM 541.920)	01/97-	Diesel		11946	230	313	04.96-10.02	■
3331 (OM 541.920)		Diesel		11946	230	313	04.97-10.02	■
3331 (OM 541.920)		Diesel		11946	230	313	04.97-10.02	■
3331 A (OM 541.926)		Diesel		11946	230	313	04.97-10.02	■
3331 A (OM 541.926)		Diesel		11946	230	313	04.97-10.02	■
1835, 1835 L (OM 541.922)		Diesel		11946	260	354	04.96-10.02	■
1835, 1835 L (OM 541.922)		Diesel		11946	260	354	04.96-10.02	■
2035 A (OM 541.927)		Diesel		11946	260	354	04.97-10.02	■
2035 A (OM 541.927)		Diesel		11946	260	354	04.97-10.02	■
2035 A (OM 541.943)		Diesel		11946	260	354	04.97-10.02	■
2035 A (OM 541.943)		Diesel		11946	260	354	04.97-10.02	■
2535 L (OM 541.922)		Diesel		11946	260	354	09.96-10.02	■
2535 L (OM 541.922)		Diesel		11946	260	354	09.96-10.02	■
2535 L (OM 541.942)		Diesel		11946	260	354	09.96-10.02	■
2535 L (OM 541.942)		Diesel		11946	260	354	09.96-10.02	■
2635, 2635 L (OM 541.922)	01/97-	Diesel		11946	260	354	04.96-10.02	■
2635, 2635 L (OM 541.922)	01/97-	Diesel		11946	260	354	04.96-10.02	■
3335 (OM 541.922)		Diesel		11946	260	354	04.97-10.02	■
3335 (OM 541.922)		Diesel		11946	260	354	04.97-10.02	■
1840, 1840 L (OM 541.923)		Diesel		11946	290	394	04.96-10.02	■
1840, 1840 L (OM 541.923)		Diesel		11946	290	394	04.96-10.02	■
2040 (OM 541.923)		Diesel		11946	290	394	09.96-10.02	■
2040 (OM 541.923)		Diesel		11946	290	394	09.96-10.02	■
2540, 2540 L (OM 541.923)		Diesel		11946	290	394	09.96-10.02	■
2540, 2540 L (OM 541.923)		Diesel		11946	290	394	09.96-10.02	■
2540, 2540 L (OM 541.944)		Diesel		11946	290	394	09.96-10.02	■
2540, 2540 L (OM 541.944)		Diesel		11946	290	394	09.96-10.02	■
2640, 2640 L (OM 541.923)	01/97-	Diesel		11946	290	394	04.96-10.02	■

LISTA DE APLICACIONES - BUYERS GUIDE

2640, 2640 L (OM 541.923)	01/97-	Diesel		11946	290	394	04.96-10.02	■
3340 (OM 541.923)		Diesel		11946	290	394	04.97-10.02	■
3340 (OM 541.923)		Diesel		11946	290	394	04.97-10.02	■
3340 A (OM 541.924)		Diesel		11946	290	394	04.97-10.02	■
3340 A (OM 541.924)		Diesel		11946	290	394	04.97-10.02	■
1843, 1843 L (OM 541.925)		Diesel		11946	315	428	04.96-10.02	■
1843, 1843 L (OM 541.925)		Diesel		11946	315	428	04.96-10.02	■
2543, 2543 L (OM 541.925)		Diesel		11946	315	428	09.96-10.02	■
2543, 2543 L (OM 541.925)		Diesel		11946	315	428	09.96-10.02	■
2543, 2543 L (OM 541.946)		Diesel		11946	315	428	09.96-10.02	■
2543, 2543 L (OM 541.946)		Diesel		11946	315	428	09.96-10.02	■
2643, 2643 L (OM 541.925)	01/97-	Diesel		11946	315	428	04.96-10.02	■
2643, 2643 L (OM 541.925)	01/97-	Diesel		11946	315	428	04.96-10.02	■
3343 (OM 541.925)		Diesel		11946	315	428	04.97-10.02	■
3343 (OM 541.925)		Diesel		11946	315	428	04.97-10.02	■
3346 (OM 541.948)		Diesel		11946	335	456	04.97-10.02	■
3346 (OM 541.948)		Diesel		11946	335	456	04.97-10.02	■
1848, 1848 L (OM 542.921)		Diesel		15928	350	476	04.96-10.02	■
1848, 1848 L (OM 542.921)		Diesel		15928	350	476	04.96-10.02	■
2548, 2548 L (OM 542.921)		Diesel		15928	350	476	09.96-10.02	■
2548, 2548 L (OM 542.921)		Diesel		15928	350	476	09.96-10.02	■
2648, 2648 L (OM 542.921)		Diesel		15928	350	476	04.96-10.02	■
2648, 2648 L (OM 542.921)		Diesel		15928	350	476	04.96-10.02	■
3348 (OM 542.921)		Diesel		15928	350	476	04.97-10.02	■
3348 (OM 542.921)		Diesel		15928	350	476	04.97-10.02	■
1853, 1853 L (OM 542.920)		Diesel		15928	390	530	04.96-10.02	■
1853, 1853 L (OM 542.920)		Diesel		15928	390	530	04.96-10.02	■
2553, 2553 L (OM 542.920)		Diesel		15928	390	530	09.96-10.02	■
2553, 2553 L (OM 542.920)		Diesel		15928	390	530	09.96-10.02	■
2653, 2653 L (OM 542.920)	01/97-	Diesel		15928	390	530	04.96-10.02	■
2653, 2653 L (OM 542.920)	01/97-	Diesel		15928	390	530	04.96-10.02	■
3353 (OM 542.920)		Diesel		15928	390	530	04.97-10.02	■
3353 (OM 542.920)		Diesel		15928	390	530	04.97-10.02	■
3353 AS (OM 542.920)		Diesel		15928	390	530	04.97-10.02	■
3353 AS (OM 542.920)		Diesel		15928	390	530	04.97-10.02	■
3353 AS (OM 542.926)		Diesel		15928	390	530	04.97-10.02	■
3353 AS (OM 542.926)		Diesel		15928	390	530	04.97-10.02	■
3353 AS (OM 542.943)		Diesel		15928	390	530	04.97-10.02	■
3353 AS (OM 542.943)		Diesel		15928	390	530	04.97-10.02	■
1857 L (OM 542.922)		Diesel		15928	420	571	04.97-10.02	■
1857 L (OM 542.922)		Diesel		15928	420	571	04.97-10.02	■
2557 L (OM 542.922)		Diesel		15928	420	571	09.96-10.02	■
2557 L (OM 542.922)		Diesel		15928	420	571	09.96-10.02	■
2657 L (OM 542.922)		Diesel		15928	420	571	04.97-10.02	■
2657 L (OM 542.922)		Diesel		15928	420	571	04.97-10.02	■
3357 (OM 542.922)		Diesel		15928	420	571	04.97-10.02	■
3357 (OM 542.922)		Diesel		15928	420	571	04.97-10.02	■
ACTROS 04.96-10.03					Truck Tractor			
1831 S, 1831 LS (OM 541.920)		Diesel		11946	230	313	04.96-10.02	■
1831 S, 1831 LS (OM 541.920)		Diesel		11946	230	313	04.96-10.02	■
1831 S, 1831 LS (OM 541.940)		Diesel		11946	230	313	04.96-10.02	■

LISTA DE APLICACIONES - BUYERS GUIDE

1831 S, 1831 LS (OM 541.940)	Diesel	11946	230	313	04.96-10.02	■
2031AS (OM 541.926)	Diesel	11946	230	313	04.96-10.02	■
2031AS (OM 541.926)	Diesel	11946	230	313	04.96-10.02	■
2031AS (OM 541.941)	Diesel	11946	230	313	04.96-10.02	■
2031AS (OM 541.941)	Diesel	11946	230	313	04.96-10.02	■
2031S (OM 541.920)	Diesel	11946	230	313	04.96-10.02	■
2031S (OM 541.920)	Diesel	11946	230	313	04.96-10.02	■
2031S (OM 541.940)	Diesel	11946	230	313	04.96-10.02	■
2031S (OM 541.940)	Diesel	11946	230	313	04.96-10.02	■
2531 LS (OM 541.920)	Diesel	11946	230	313	09.96-10.02	■
2531 LS (OM 541.920)	Diesel	11946	230	313	09.96-10.02	■
2531 LS (OM 541.940)	Diesel	11946	230	313	09.96-10.02	■
2531 LS (OM 541.940)	Diesel	11946	230	313	09.96-10.02	■
3331 AS (OM 541.926)	Diesel	11946	230	313	04.97-10.02	■
3331 AS (OM 541.926)	Diesel	11946	230	313	04.97-10.02	■
3331 AS (OM 541.941)	Diesel	11946	230	313	04.97-10.02	■
3331 AS (OM 541.941)	Diesel	11946	230	313	04.97-10.02	■
3331 S (OM 541.920)	Diesel	11946	230	313	04.97-10.02	■
3331 S (OM 541.920)	Diesel	11946	230	313	04.97-10.02	■
3331 S (OM 541.940)	Diesel	11946	230	313	04.97-10.02	■
3331 S (OM 541.940)	Diesel	11946	230	313	04.97-10.02	■
1835 S, 1835 LS (OM 541.922)	Diesel	11946	260	354	04.96-10.02	■
1835 S, 1835 LS (OM 541.922)	Diesel	11946	260	354	04.96-10.02	■
1835 S, 1835 LS (OM 541.942)	Diesel	11946	260	354	04.96-10.02	■
1835 S, 1835 LS (OM 541.942)	Diesel	11946	260	354	04.96-10.02	■
2535 LS (OM 541.922)	Diesel	11946	260	354	09.96-10.02	■
2535 LS (OM 541.922)	Diesel	11946	260	354	09.96-10.02	■
2535 LS (OM 541.942)	Diesel	11946	260	354	09.96-10.02	■
2535 LS (OM 541.942)	Diesel	11946	260	354	09.96-10.02	■
3335 S (OM 541.922)	Diesel	11946	260	354	04.97-10.02	■
3335 S (OM 541.922)	Diesel	11946	260	354	04.97-10.02	■
1840 S, 1840 LS (OM 541.923)	Diesel	11946	290	394	04.96-10.02	■
1840 S, 1840 LS (OM 541.923)	Diesel	11946	290	394	04.96-10.02	■
1840 S, 1840 LS (OM 541.944)	Diesel	11946	290	394	04.96-10.02	■
1840 S, 1840 LS (OM 541.944)	Diesel	11946	290	394	04.96-10.02	■
2040 AS (OM 541.924)	Diesel	11946	290	394	04.96-10.02	■
2040 AS (OM 541.924)	Diesel	11946	290	394	04.96-10.02	■
2040 AS (OM 541.945)	Diesel	11946	290	394	04.96-10.02	■
2040 AS (OM 541.945)	Diesel	11946	290	394	04.96-10.02	■
2040 S (OM 541.923)	Diesel	11946	290	394	04.96-10.02	■
2040 S (OM 541.923)	Diesel	11946	290	394	04.96-10.02	■
2040 S (OM 541.944)	Diesel	11946	290	394	04.96-10.02	■
2040 S (OM 541.944)	Diesel	11946	290	394	04.96-10.02	■
2540 LS (OM 541.923)	Diesel	11946	290	394	09.96-10.02	■
2540 LS (OM 541.923)	Diesel	11946	290	394	09.96-10.02	■
2540 LS (OM 541.944)	Diesel	11946	290	394	09.96-10.02	■
2540 LS (OM 541.944)	Diesel	11946	290	394	09.96-10.02	■
2640 S, 2640 LS (OM 541.923)	Diesel	11946	290	394	09.96-10.02	■
2640 S, 2640 LS (OM 541.923)	Diesel	11946	290	394	09.96-10.02	■
2640 S, 2640 LS (OM 541.944)	Diesel	11946	290	394	09.96-10.02	■
2640 S, 2640 LS (OM 541.944)	Diesel	11946	290	394	09.96-10.02	■

LISTA DE APLICACIONES - BUYERS GUIDE

3340 AS (OM 541.924)	Diesel	11946	290	394	04.97-10.02	■
3340 AS (OM 541.924)	Diesel	11946	290	394	04.97-10.02	■
3340 AS (OM 541.945)	Diesel	11946	290	394	04.97-10.02	■
3340 AS (OM 541.945)	Diesel	11946	290	394	04.97-10.02	■
3340 S (OM 541.923)	Diesel	11946	290	394	04.97-10.02	■
3340 S (OM 541.923)	Diesel	11946	290	394	04.97-10.02	■
1843 S, 1843 LS (OM 541.925)	Diesel	11946	315	428	04.96-10.02	■
1843 S, 1843 LS (OM 541.925)	Diesel	11946	315	428	04.96-10.02	■
1843 S, 1843 LS (OM 541.946)	Diesel	11946	315	428	04.96-10.02	■
1843 S, 1843 LS (OM 541.946)	Diesel	11946	315	428	04.96-10.02	■
2543 LS (OM 541.925)	Diesel	11946	315	428	09.96-10.02	■
2543 LS (OM 541.925)	Diesel	11946	315	428	09.96-10.02	■
2543 LS (OM 541.946)	Diesel	11946	315	428	09.96-10.02	■
2543 LS (OM 541.946)	Diesel	11946	315	428	09.96-10.02	■
2643 S, 2643 LS (OM 541.925)	Diesel	11946	315	428	04.97-10.02	■
2643 S, 2643 LS (OM 541.925)	Diesel	11946	315	428	04.97-10.02	■
2643 S, 2643 LS (OM 541.946)	Diesel	11946	315	428	04.97-10.02	■
2643 S, 2643 LS (OM 541.946)	Diesel	11946	315	428	04.97-10.02	■
3343 AS (OM 541.921)	Diesel	11946	315	428	04.97-10.02	■
3343 AS (OM 541.921)	Diesel	11946	315	428	04.97-10.02	■
3343 AS (OM 541.947)	Diesel	11946	315	428	04.97-10.02	■
3343 AS (OM 541.947)	Diesel	11946	315	428	04.97-10.02	■
3343 S (OM 541.925)	Diesel	11946	315	428	04.97-10.02	■
3343 S (OM 541.925)	Diesel	11946	315	428	04.97-10.02	■
3343 S (OM 541.946)	Diesel	11946	315	428	04.97-10.02	■
3343 S (OM 541.946)	Diesel	11946	315	428	04.97-10.02	■
1848 S, 1848 LS (OM 542.921)	Diesel	15928	350	476	04.96-10.02	■
1848 S, 1848 LS (OM 542.921)	Diesel	15928	350	476	04.96-10.02	■
1848 S, 1848 LS (OM 542.940)	Diesel	15928	350	476	04.96-10.02	■
1848 S, 1848 LS (OM 542.940)	Diesel	15928	350	476	04.96-10.02	■
2548 LS (OM 542.921)	Diesel	15928	350	476	09.96-10.02	■
2548 LS (OM 542.921)	Diesel	15928	350	476	09.96-10.02	■
2548 LS (OM 542.940)	Diesel	15928	350	476	09.96-10.02	■
2548 LS (OM 542.940)	Diesel	15928	350	476	09.96-10.02	■
2648 S, 2648 LS (OM 542.921)	Diesel	15928	350	476	09.96-10.02	■
2648 S, 2648 LS (OM 542.921)	Diesel	15928	350	476	09.96-10.02	■
2648 S, 2648 LS (OM 542.940)	Diesel	15928	350	476	09.96-10.02	■
2648 S, 2648 LS (OM 542.940)	Diesel	15928	350	476	09.96-10.02	■
3348 AS (OM 542.925)	Diesel	15928	350	476	04.97-10.02	■
3348 AS (OM 542.925)	Diesel	15928	350	476	04.97-10.02	■
3348 S (OM 542.921)	Diesel	15928	350	476	04.97-10.02	■
3348 S (OM 542.921)	Diesel	15928	350	476	04.97-10.02	■
1853 S, 1853 LS (OM 542.920)	Diesel	15928	390	530	04.96-10.02	■
1853 S, 1853 LS (OM 542.920)	Diesel	15928	390	530	04.96-10.02	■
1853 S, 1853 LS (OM 542.942)	Diesel	15928	390	530	04.96-10.02	■
1853 S, 1853 LS (OM 542.942)	Diesel	15928	390	530	04.96-10.02	■
2053 S (OM 542.920)	Diesel	15928	390	530	04.96-10.02	■
2053 S (OM 542.920)	Diesel	15928	390	530	04.96-10.02	■
2053 S (OM 542.942)	Diesel	15928	390	530	04.96-10.02	■
2053 S (OM 542.942)	Diesel	15928	390	530	04.96-10.02	■
2553 LS (OM 542.920)	Diesel	15928	390	530	09.96-10.02	■

LISTA DE APLICACIONES - BUYERS GUIDE

2553 LS (OM 542.920)	Diesel	15928	390	530	09.96-10.02	■
2553 LS (OM 542.942)	Diesel	15928	390	530	09.96-10.02	■
2553 LS (OM 542.942)	Diesel	15928	390	530	09.96-10.02	■
2653 S, 2653 LS (OM 542.920)	Diesel	15928	390	530	09.96-10.02	■
2653 S, 2653 LS (OM 542.920)	Diesel	15928	390	530	09.96-10.02	■
2653 S, 2653 LS (OM 542.942)	Diesel	15928	390	530	09.96-10.02	■
2653 S, 2653 LS (OM 542.942)	Diesel	15928	390	530	09.96-10.02	■
3353 S (OM 542.920)	Diesel	15928	390	530	04.97-10.02	■
3353 S (OM 542.920)	Diesel	15928	390	530	04.97-10.02	■
3353 S (OM 542.942)	Diesel	15928	390	530	04.97-10.02	■
3353 S (OM 542.942)	Diesel	15928	390	530	04.97-10.02	■
1857 LS (OM 542.922)	Diesel	15928	420	571	04.97-10.02	■
1857 LS (OM 542.922)	Diesel	15928	420	571	04.97-10.02	■
1857 LS (OM 542.944)	Diesel	15928	420	571	04.97-10.02	■
1857 LS (OM 542.944)	Diesel	15928	420	571	04.97-10.02	■
2657 S, 2657 LS (OM 542.922)	Diesel	15928	420	571	04.97-10.02	■
2657 S, 2657 LS (OM 542.922)	Diesel	15928	420	571	04.97-10.02	■
2657 S, 2657 LS (OM 542.944)	Diesel	15928	420	571	04.97-10.02	■
2657 S, 2657 LS (OM 542.944)	Diesel	15928	420	571	04.97-10.02	■
3357 S (OM 542.922)	Diesel	15928	420	571	04.97-10.02	■
3357 S (OM 542.922)	Diesel	15928	420	571	04.97-10.02	■
3357 S (OM 542.944)	Diesel	15928	420	571	04.97-10.02	■
3357 S (OM 542.944)	Diesel	15928	420	571	04.97-10.02	■
ACTROS MP2 / MP3 10.02-				Dump Truck		
1832 AK (OM 541.940)	Diesel	11946	235	320	04.03-	■
1832 AK (OM 541.940)	Diesel	11946	235	320	04.03-	■
1832 AK (OM 541.971)	Diesel	11946	235	320	04.03-	■
1832 AK (OM 541.971)	Diesel	11946	235	320	04.03-	■
1832 AK (OM 541.997)	Diesel	11946	235	320	04.03-	■
1832 AK (OM 541.997)	Diesel	11946	235	320	04.03-	■
1832 K (OM 541.940)	Diesel	11946	235	320	04.03-	■
1832 K (OM 541.940)	Diesel	11946	235	320	04.03-	■
1832 K (OM 541.970)	Diesel	11946	235	320	04.03-	■
1832 K (OM 541.970)	Diesel	11946	235	320	04.03-	■
1832 K (OM 541.996)	Diesel	11946	235	320	04.03-	■
1832 K (OM 541.996)	Diesel	11946	235	320	04.03-	■
2632 K, LK (OM 541.940)	Diesel	11946	235	320	04.03-	■
2632 K, LK (OM 541.940)	Diesel	11946	235	320	04.03-	■
2632 K, LK (OM 541.970)	Diesel	11946	235	320	04.03-	■
2632 K, LK (OM 541.970)	Diesel	11946	235	320	04.03-	■
2632 K, LK (OM 541.996)	Diesel	11946	235	320	04.03-	■
2632 K, LK (OM 541.996)	Diesel	11946	235	320	04.03-	■
1836 AK (OM 541.942)	Diesel	11946	265	360	04.03-	■
1836 AK (OM 541.942)	Diesel	11946	265	360	04.03-	■
1836 AK (OM 541.999)	Diesel	11946	265	360	04.03-	■
1836 AK (OM 541.999)	Diesel	11946	265	360	04.03-	■
1836 K (OM 541.942)	Diesel	11946	265	360	04.03-	■
1836 K (OM 541.942)	Diesel	11946	265	360	04.03-	■
1836 K (OM 541.972)	Diesel	11946	265	360	04.03-	■
1836 K (OM 541.972)	Diesel	11946	265	360	04.03-	■
1836 K (OM 541.998)	Diesel	11946	265	360	04.03-	■

LISTA DE APLICACIONES - BUYERS GUIDE

1836 K (OM 541.998)	Diesel	11946	265	360	04.03-	■
2636 K, LK (OM 541.942)	Diesel	11946	265	360	04.03-	■
2636 K, LK (OM 541.942)	Diesel	11946	265	360	04.03-	■
2636 K, LK (OM 541.972)	Diesel	11946	265	360	04.03-	■
2636 K, LK (OM 541.972)	Diesel	11946	265	360	04.03-	■
2636 K, LK (OM 541.998)	Diesel	11946	265	360	04.03-	■
2636 K, LK (OM 541.998)	Diesel	11946	265	360	04.03-	■
1841 K (OM 541.944)	Diesel	11946	300	408	04.03-	■
1841 K (OM 541.944)	Diesel	11946	300	408	04.03-	■
1841 K (OM 541.974)	Diesel	11946	300	408	04.03-	■
1841 K (OM 541.974)	Diesel	11946	300	408	04.03-	■
1841 K (OM 541.990)	Diesel	11946	300	408	04.03-	■
1841 K (OM 541.990)	Diesel	11946	300	408	04.03-	■
1841 L, LL (OM 541.944)	Diesel	11946	300	408	04.03-	■
1841 L, LL (OM 541.944)	Diesel	11946	300	408	04.03-	■
1841 L, LL (OM 541.974)	Diesel	11946	300	408	04.03-	■
1841 L, LL (OM 541.974)	Diesel	11946	300	408	04.03-	■
2641 K, LK (OM 541.944)	Diesel	11946	300	408	04.03-	■
2641 K, LK (OM 541.944)	Diesel	11946	300	408	04.03-	■
2641 K, LK (OM 541.974)	Diesel	11946	300	408	04.03-	■
2641 K, LK (OM 541.974)	Diesel	11946	300	408	04.03-	■
2641 K, LK (OM 541.990)	Diesel	11946	300	408	04.03-	■
2641 K, LK (OM 541.990)	Diesel	11946	300	408	04.03-	■
1844 AK (OM 541.921)	Diesel	11946	315	428	04.03-	■
1844 AK (OM 541.921)	Diesel	11946	315	428	04.03-	■
1844 AK (OM 541.946)	Diesel	11946	315	428	04.03-	■
1844 AK (OM 541.946)	Diesel	11946	315	428	04.03-	■
1844 AK (OM 541.947)	Diesel	11946	315	428	04.03-	■
1844 AK (OM 541.947)	Diesel	11946	315	428	04.03-	■
1844 AK (OM 541.993)	Diesel	11946	315	428	04.03-	■
1844 AK (OM 541.993)	Diesel	11946	315	428	04.03-	■
1844 K (OM 541.925)	Diesel	11946	315	428	04.03-	■
1844 K (OM 541.925)	Diesel	11946	315	428	04.03-	■
1844 K (OM 541.946)	Diesel	11946	315	428	04.03-	■
1844 K (OM 541.946)	Diesel	11946	315	428	04.03-	■
1844 K (OM 541.976)	Diesel	11946	315	428	04.03-	■
1844 K (OM 541.976)	Diesel	11946	315	428	04.03-	■
1844 K (OM 541.992)	Diesel	11946	315	428	04.03-	■
1844 K (OM 541.992)	Diesel	11946	315	428	04.03-	■
2644 K, LK (OM 541.946)	Diesel	11946	320	435	04.03-	■
2644 K, LK (OM 541.946)	Diesel	11946	320	435	04.03-	■
2644 K, LK (OM 541.976)	Diesel	11946	320	435	04.03-	■
2644 K, LK (OM 541.976)	Diesel	11946	320	435	04.03-	■
2644 K, LK (OM 541.992)	Diesel	11946	320	435	04.03-	■
2644 K, LK (OM 541.992)	Diesel	11946	320	435	04.03-	■
1846 AK (OM 541.948)	Diesel	11946	335	456	04.03-	■
1846 AK (OM 541.948)	Diesel	11946	335	456	04.03-	■
1846 AK (OM 541.949)	Diesel	11946	335	456	04.03-	■
1846 AK (OM 541.949)	Diesel	11946	335	456	04.03-	■
1846 AK (OM 541.981)	Diesel	11946	335	456	04.03-	■
1846 AK (OM 541.981)	Diesel	11946	335	456	04.03-	■

LISTA DE APLICACIONES - BUYERS GUIDE

1846 AK (OM 541.995)	Diesel	11946	335	456	04.03-	■
1846 AK (OM 541.995)	Diesel	11946	335	456	04.03-	■
1846 K (OM 541.948)	Diesel	11946	335	456	04.03-	■
1846 K (OM 541.948)	Diesel	11946	335	456	04.03-	■
1846 K (OM 541.980)	Diesel	11946	335	456	04.03-	■
1846 K (OM 541.980)	Diesel	11946	335	456	04.03-	■
1846 K (OM 541.994)	Diesel	11946	335	456	04.03-	■
1846 K (OM 541.994)	Diesel	11946	335	456	04.03-	■
2646 K, LK (OM 541.948)	Diesel	11946	335	456	04.03-	■
2646 K, LK (OM 541.948)	Diesel	11946	335	456	04.03-	■
2646 K, LK (OM 541.980)	Diesel	11946	335	456	04.03-	■
2646 K, LK (OM 541.980)	Diesel	11946	335	456	04.03-	■
2646 K, LK (OM 541.994)	Diesel	11946	335	456	04.03-	■
2646 K, LK (OM 541.994)	Diesel	11946	335	456	04.03-	■
1850, 1851 K (OM 542.940)	Diesel	15928	370	503	04.03-	■
1850, 1851 K (OM 542.940)	Diesel	15928	370	503	04.03-	■
1850, 1851 K (OM 542.960)	Diesel	15928	370	503	04.03-	■
1850, 1851 K (OM 542.960)	Diesel	15928	370	503	04.03-	■
1850 AK, 1851 AK (OM 542.940)	Diesel	15928	370	503	04.03-	■
1850 AK, 1851 AK (OM 542.940)	Diesel	15928	370	503	04.03-	■
1850 AK, 1851 AK (OM 542.941)	Diesel	15928	370	503	04.03-	■
1850 AK, 1851 AK (OM 542.941)	Diesel	15928	370	503	04.03-	■
1850 AK, 1851 AK (OM 542.960)	Diesel	15928	370	503	04.03-	■
1850 AK, 1851 AK (OM 542.960)	Diesel	15928	370	503	04.03-	■
1850 AK, 1851 AK (OM 542.961)	Diesel	15928	370	503	04.03-	■
1850 AK, 1851 AK (OM 542.961)	Diesel	15928	370	503	04.03-	■
2650 K, 2651 K, LK (OM 542.940)	Diesel	15928	370	503	04.03-	■
2650 K, 2651 K, LK (OM 542.940)	Diesel	15928	370	503	04.03-	■
2650 K, 2651 K, LK (OM 542.960)	Diesel	15928	370	503	04.03-	■
2650 K, 2651 K, LK (OM 542.960)	Diesel	15928	370	503	04.03-	■
2654 K, LK, 2655 K, LK (OM 542.942)	Diesel	15928	395	537	04.03-	■
2654 K, LK, 2655 K, LK (OM 542.942)	Diesel	15928	395	537	04.03-	■
2654 K, LK, 2655 K, LK (OM 542.962)	Diesel	15928	395	537	04.03-	■
2654 K, LK, 2655 K, LK (OM 542.962)	Diesel	15928	395	537	04.03-	■
2658 K, LK (OM 542.944)	Diesel	15928	425	578	04.03-	■
2658 K, LK (OM 542.944)	Diesel	15928	425	578	04.03-	■
ACTROS MP2 / MP3 10.02-				Platform/Chassis		
1832, L, LL (OM 541.940)	Diesel	11946	235	320	04.03-	■
1832, L, LL (OM 541.940)	Diesel	11946	235	320	04.03-	■
1832, L, LL (OM 541.970)	Diesel	11946	235	320	04.03-	■
1832, L, LL (OM 541.970)	Diesel	11946	235	320	04.03-	■
2632, L, LL (OM 541.940)	Diesel	11946	235	320	04.03-	■
2632, L, LL (OM 541.940)	Diesel	11946	235	320	04.03-	■
2632, L, LL (OM 541.970)	Diesel	11946	235	320	04.03-	■
2632, L, LL (OM 541.970)	Diesel	11946	235	320	04.03-	■
2632, L, LL (OM 541.996)	Diesel	11946	235	320	04.03-	■
2632, L, LL (OM 541.996)	Diesel	11946	235	320	04.03-	■
1836, L, LL (OM 541.942)	Diesel	11946	265	360	04.03-	■
1836, L, LL (OM 541.942)	Diesel	11946	265	360	04.03-	■
2636, L, LL (OM 541.942)	Diesel	11946	265	360	04.03-	■
2636, L, LL (OM 541.942)	Diesel	11946	265	360	04.03-	■

LISTA DE APLICACIONES - BUYERS GUIDE

2636, L, LL (OM 541.972)	Diesel	11946	265	360	04.03-	■
2636, L, LL (OM 541.972)	Diesel	11946	265	360	04.03-	■
2636, L, LL (OM 541.998)	Diesel	11946	265	360	04.03-	■
2636, L, LL (OM 541.998)	Diesel	11946	265	360	04.03-	■
1841, L, LL (OM 541.944)	Diesel	11946	300	408	04.03-	■
1841, L, LL (OM 541.944)	Diesel	11946	300	408	04.03-	■
1841, L, LL (OM 541.974)	Diesel	11946	300	408	04.03-	■
1841, L, LL (OM 541.974)	Diesel	11946	300	408	04.03-	■
2641, L, LL (OM 541.944)	Diesel	11946	300	408	04.03-	■
2641, L, LL (OM 541.944)	Diesel	11946	300	408	04.03-	■
2641, L, LL (OM 541.974)	Diesel	11946	300	408	04.03-	■
2641, L, LL (OM 541.974)	Diesel	11946	300	408	04.03-	■
2641, L, LL (OM 541.990)	Diesel	11946	300	408	04.03-	■
2641, L, LL (OM 541.990)	Diesel	11946	300	408	04.03-	■
1844, L, LL (OM 541.946)	Diesel	11946	320	435	04.03-	■
1844, L, LL (OM 541.946)	Diesel	11946	320	435	04.03-	■
1844, L, LL (OM 541.976)	Diesel	11946	320	435	04.03-	■
1844, L, LL (OM 541.976)	Diesel	11946	320	435	04.03-	■
2644, L, LL (OM 541.946)	Diesel	11946	320	435	04.03-	■
2644, L, LL (OM 541.946)	Diesel	11946	320	435	04.03-	■
2644, L, LL (OM 541.976)	Diesel	11946	320	435	04.03-	■
2644, L, LL (OM 541.976)	Diesel	11946	320	435	04.03-	■
2644, L, LL (OM 541.976)	Diesel	11946	320	435	04.03-	■
2644, L, LL (OM 541.992)	Diesel	11946	320	435	04.03-	■
2644, L, LL (OM 541.992)	Diesel	11946	320	435	04.03-	■
1846, L, LL (OM 541.948)	Diesel	11946	335	456	04.03-	■
1846, L, LL (OM 541.948)	Diesel	11946	335	456	04.03-	■
1846, L, LL (OM 541.980)	Diesel	11946	335	456	04.03-	■
1846, L, LL (OM 541.980)	Diesel	11946	335	456	04.03-	■
2646, L, LL (OM 541.948)	Diesel	11946	335	456	04.03-	■
2646, L, LL (OM 541.948)	Diesel	11946	335	456	04.03-	■
2646, L, LL (OM 541.980)	Diesel	11946	335	456	04.03-	■
2646, L, LL (OM 541.980)	Diesel	11946	335	456	04.03-	■
2646, L, LL (OM 541.980)	Diesel	11946	335	456	04.03-	■
2646, L, LL (OM 541.994)	Diesel	11946	335	456	04.03-	■
2646, L, LL (OM 541.994)	Diesel	11946	335	456	04.03-	■
1850, 1851, L, LL (OM 542.940)	Diesel	15928	370	503	04.03-	■
1850, 1851, L, LL (OM 542.940)	Diesel	15928	370	503	04.03-	■
1850, 1851, L, LL (OM 542.960)	Diesel	15928	370	503	04.03-	■
1850, 1851, L, LL (OM 542.960)	Diesel	15928	370	503	04.03-	■
2650, L, 2651, L, LL (OM 542.940)	Diesel	15928	370	503	04.03-	■
2650, L, 2651, L, LL (OM 542.940)	Diesel	15928	370	503	04.03-	■
1854, L (OM 542.942)	Diesel	15928	395	537	04.03-	■
1854, L (OM 542.942)	Diesel	15928	395	537	04.03-	■
1854, L (OM 542.962)	Diesel	15928	395	537	04.03-	■
1854, L (OM 542.962)	Diesel	15928	395	537	04.03-	■
2654, L, 2655, L, LL (OM 542.942)	Diesel	15928	395	537	04.03-	■
2654, L, 2655, L, LL (OM 542.942)	Diesel	15928	395	537	04.03-	■
2654, L, 2655, L, LL (OM 542.962)	Diesel	15928	395	537	04.03-	■
2654, L, 2655, L, LL (OM 542.962)	Diesel	15928	395	537	04.03-	■
1858, L (OM 542.944)	Diesel	15928	425	578	04.03-	■
1858, L (OM 542.944)	Diesel	15928	425	578	04.03-	■
2658 L (OM 542.944)	Diesel	15928	425	578	04.03-	■

LISTA DE APLICACIONES - BUYERS GUIDE

2658 L (OM 542.944)	Diesel	15928	425	578	04.03-	■
ACTROS MP2 / MP3 10.02-			Truck Tractor			
1832, LS, LLS (OM 541.940)	Diesel	11946	235	320	04.03-	■
1832, LS, LLS (OM 541.940)	Diesel	11946	235	320	04.03-	■
1832, LS, LLS (OM 541.970)	Diesel	11946	235	320	04.03-	■
1832, LS, LLS (OM 541.970)	Diesel	11946	235	320	04.03-	■
2632 LS (OM 541.940)	Diesel	11946	235	320	04.03-	■
2632 LS (OM 541.940)	Diesel	11946	235	320	04.03-	■
2632 LS (OM 541.970)	Diesel	11946	235	320	04.03-	■
2632 LS (OM 541.970)	Diesel	11946	235	320	04.03-	■
2632 LS (OM 541.996)	Diesel	11946	235	320	04.03-	■
2632 LS (OM 541.996)	Diesel	11946	235	320	04.03-	■
1836 LS, LLS (OM 541.942)	Diesel	11946	265	360	04.03-	■
1836 LS, LLS (OM 541.942)	Diesel	11946	265	360	04.03-	■
2636 LS (OM 541.942)	Diesel	11946	265	360	04.03-	■
2636 LS (OM 541.942)	Diesel	11946	265	360	04.03-	■
2636 LS (OM 541.972)	Diesel	11946	265	360	04.03-	■
2636 LS (OM 541.972)	Diesel	11946	265	360	04.03-	■
2636 LS (OM 541.998)	Diesel	11946	265	360	04.03-	■
2636 LS (OM 541.998)	Diesel	11946	265	360	04.03-	■
1841 LS, LLS (OM 541.944)	Diesel	11946	300	408	04.03-	■
1841 LS, LLS (OM 541.944)	Diesel	11946	300	408	04.03-	■
1841 LS, LLS (OM 541.974)	Diesel	11946	300	408	04.03-	■
1841 LS, LLS (OM 541.974)	Diesel	11946	300	408	04.03-	■
2641 S, LS (OM 541.944)	Diesel	11946	300	408	04.03-	■
2641 S, LS (OM 541.944)	Diesel	11946	300	408	04.03-	■
2641 S, LS (OM 541.974)	Diesel	11946	300	408	04.03-	■
2641 S, LS (OM 541.974)	Diesel	11946	300	408	04.03-	■
2641 S, LS (OM 541.990)	Diesel	11946	300	408	04.03-	■
2641 S, LS (OM 541.990)	Diesel	11946	300	408	04.03-	■
2644 S, LS (OM 541.925)	Diesel	11946	315	428	04.03-	■
2644 S, LS (OM 541.925)	Diesel	11946	315	428	04.03-	■
2644 S, LS (OM 541.946)	Diesel	11946	315	428	04.03-	■
2644 S, LS (OM 541.946)	Diesel	11946	315	428	04.03-	■
2644 S, LS (OM 541.976)	Diesel	11946	315	428	04.03-	■
2644 S, LS (OM 541.976)	Diesel	11946	315	428	04.03-	■
2644 S, LS (OM 541.992)	Diesel	11946	315	428	04.03-	■
2644 S, LS (OM 541.992)	Diesel	11946	315	428	04.03-	■
1844 LS, LLS (OM 541.946)	Diesel	11946	320	435	04.03-	■
1844 LS, LLS (OM 541.946)	Diesel	11946	320	435	04.03-	■
1844 LS, LLS (OM 541.976)	Diesel	11946	320	435	04.03-	■
1844 LS, LLS (OM 541.976)	Diesel	11946	320	435	04.03-	■
1846 LS, LLS (OM 541.948)	Diesel	11946	335	456	04.03-	■
1846 LS, LLS (OM 541.948)	Diesel	11946	335	456	04.03-	■
1846 LS, LLS (OM 541.980)	Diesel	11946	335	456	04.03-	■
1846 LS, LLS (OM 541.980)	Diesel	11946	335	456	04.03-	■
2646 S, LS (OM 541.948)	Diesel	11946	335	456	04.03-	■
2646 S, LS (OM 541.948)	Diesel	11946	335	456	04.03-	■
2646 S, LS (OM 541.980)	Diesel	11946	335	456	04.03-	■
2646 S, LS (OM 541.980)	Diesel	11946	335	456	04.03-	■
2646 S, LS (OM 541.994)	Diesel	11946	335	456	04.03-	■

LISTA DE APLICACIONES - BUYERS GUIDE

2646 S, LS (OM 541.994)		Diesel		11946	335	456	04.03-	■
1850, 1851 LS, LLS (OM 542.940)		Diesel		15928	370	503	04.03-	■
1850, 1851 LS, LLS (OM 542.940)		Diesel		15928	370	503	04.03-	■
1850, 1851 LS, LLS (OM 542.960)		Diesel		15928	370	503	04.03-	■
1850, 1851 LS, LLS (OM 542.960)		Diesel		15928	370	503	04.03-	■
2650 S, LS (OM 542.940)		Diesel		15928	370	503	04.03-	■
2650 S, LS (OM 542.940)		Diesel		15928	370	503	04.03-	■
2654 S, LS (OM 542.920)		Diesel		15928	390	530	04.03-	■
2654 S, LS (OM 542.920)		Diesel		15928	390	530	04.03-	■
2654 S, LS (OM 542.942)		Diesel		15928	390	530	04.03-	■
2654 S, LS (OM 542.942)		Diesel		15928	390	530	04.03-	■
1854 LS (OM 542.942)		Diesel		15928	395	537	04.03-	■
1854 LS (OM 542.942)		Diesel		15928	395	537	04.03-	■
1858 LS (OM 542.944)		Diesel		15928	425	578	10.02-	■
1858 LS (OM 542.944)		Diesel		15928	425	578	10.02-	■
2658 LS (OM 542.944)		Diesel		15928	425	578	04.03-	■
2658 LS (OM 542.944)		Diesel		15928	425	578	04.03-	■
ATEGO 01.98-10.04					Dump Truck			
1823 AK (OM 906.922)		Diesel		6374	170	231	04.98-10.04	■
1823 AK (OM 906.922)		Diesel		6374	170	231	04.98-10.04	■
1828 AK (OM 906.923)		Diesel		6374	205	279	04.98-10.04	■
1828 AK (OM 906.923)		Diesel		6374	205	279	04.98-10.04	■
ATEGO 01.98-10.04					Platform/Chassis			
1828 A (OM 906.923)		Diesel		6374	205	279	04.98-10.04	■
1828 A (OM 906.923)		Diesel		6374	205	279	04.98-10.04	■
MK 12.87-12.05					Platform/Chassis			
1717/L	01/93-	Diesel		5995	129	175	12.87-	■
1717/L	01/93-	Diesel		5995	129	175	12.87-	■
1717K	01/93-	Diesel		5995	129	175	12.87-	■
1717K	01/93-	Diesel		5995	129	175	12.87-	■
1720/L	01/93-	Diesel		5995	150	204	12.87-	■
1720/L	01/93-	Diesel		5995	150	204	12.87-	■
1722L	01/93-	Diesel		5995	150	204	12.87-	■
1722L	01/93-	Diesel		5995	150	204	12.87-	■
2420/L	01/93-	Diesel		5995	150	204	12.87-	■
2420/L	01/93-	Diesel		5995	150	204	12.87-	■
1720S	01/93-	Diesel		5995	155	211	12.87-	■
1720S	01/93-	Diesel		5995	155	211	12.87-	■
1820/L	01/93-	Diesel		5995	155	211	12.87-	■
1820/L	01/93-	Diesel		5995	155	211	12.87-	■
1820s	01/93-	Diesel		5995	155	211	12.87-	■
1820s	01/93-	Diesel		5995	155	211	12.87-	■
1824 (OM 401.975)	01/93-	Diesel		9570	180	245	08.92-09.96	■
1824 (OM 401.975)	01/93-	Diesel		9570	180	245	08.92-09.96	■
2431 (OM 401.972)	01/93-	Diesel		9570	230	313	12.87-09.96	■
2431 (OM 401.972)	01/93-	Diesel		9570	230	313	12.87-09.96	■
2431 (OM 401.979)	01/93-	Diesel		9570	230	313	12.87-09.96	■
2431 (OM 401.979)	01/93-	Diesel		9570	230	313	12.87-09.96	■
2431 (OM 401.993)	01/93-	Diesel		9570	230	313	12.87-09.96	■
2431 (OM 401.993)	01/93-	Diesel		9570	230	313	12.87-09.96	■

LISTA DE APLICACIONES - BUYERS GUIDE

2024	01/93-	Diesel		9595	180	245	12.87-		■
2024	01/93-	Diesel		9595	180	245	12.87-		■
2024AK	01/93-	Diesel		9595	180	245	12.87-		■
2024AK	01/93-	Diesel		9595	180	245	12.87-		■
2024K	01/93-	Diesel		9595	180	245	12.87-		■
2024K	01/93-	Diesel		9595	180	245	12.87-		■
2524	01/93-	Diesel		9595	180	245	12.87-	■	■
2524	01/93-	Diesel		9595	180	245	12.87-	■	■
2524/L	01/93-	Diesel		9595	180	245	12.87-	■	
2524/L	01/93-	Diesel		9595	180	245	12.87-	■	
2524/L	01/93-, Auxiliary Axle	Diesel		9595	180	245	12.87-		■
2524/L	01/93-, Auxiliary Axle	Diesel		9595	180	245	12.87-		■
2524K	01/93-	Diesel		9595	180	245	12.87-	■	■
2524K	01/93-	Diesel		9595	180	245	12.87-	■	■
1726/L	01/93-	Diesel		9595	200	272	12.87-	■	
1726/L	01/93-	Diesel		9595	200	272	12.87-	■	
1827/L	01/93-	Diesel		9595	200	272	12.87-	■	
1827/L	01/93-	Diesel		9595	200	272	12.87-	■	
1827S/LS	01/93-	Diesel		9595	200	272	12.87-	■	
1827S/LS	01/93-	Diesel		9595	200	272	12.87-	■	
2426/L	01/93-	Diesel		9595	200	272	12.87-	■	
2426/L	01/93-	Diesel		9595	200	272	12.87-	■	
2527	01/93-	Diesel		9595	200	272	12.87-	■	■
2527	01/93-	Diesel		9595	200	272	12.87-	■	■
2527/L	01/93-	Diesel		9595	200	272	12.87-	■	
2527/L	01/93-	Diesel		9595	200	272	12.87-	■	
2527/L	01/93-, Auxiliary Axle	Diesel		9595	200	272	12.87-		■
2527/L	01/93-, Auxiliary Axle	Diesel		9595	200	272	12.87-		■
2527B	01/93-	Diesel		9595	200	272	12.87-	■	■
2527B	01/93-	Diesel		9595	200	272	12.87-	■	■
2527K	01/93-	Diesel		9595	200	272	12.87-	■	■
2527K	01/93-	Diesel		9595	200	272	12.87-	■	■
1722K	01/93-	Diesel		9595	230	313	12.87-	■	
1722K	01/93-	Diesel		9595	230	313	12.87-	■	
1831/L	01/93-	Diesel		9595	230	313	12.87-	■	
1831/L	01/93-	Diesel		9595	230	313	12.87-	■	
1831S/LS	01/93-	Diesel		9595	230	313	12.87-	■	
1831S/LS	01/93-	Diesel		9595	230	313	12.87-	■	
2031	01/93-	Diesel		9595	230	313	12.87-		■
2031	01/93-	Diesel		9595	230	313	12.87-		■
2031A	01/93-	Diesel		9595	230	313	12.87-		■
2031A	01/93-	Diesel		9595	230	313	12.87-		■
2031AS	01/93-	Diesel		9595	230	313	12.87-		■
2031AS	01/93-	Diesel		9595	230	313	12.87-		■
2031S	01/93-	Diesel		9595	230	313	12.87-		■
2031S	01/93-	Diesel		9595	230	313	12.87-		■
2531/L	01/93-	Diesel		9595	230	313	12.87-	■	
2531/L	01/93-	Diesel		9595	230	313	12.87-	■	
2531/L	01/93-, Auxiliary Axle	Diesel		9595	230	313	12.87-		■
2531/L	01/93-, Auxiliary Axle	Diesel		9595	230	313	12.87-		■
2631	01/93-	Diesel		9595	230	313	12.87-	■	■

LISTA DE APLICACIONES - BUYERS GUIDE

2631	01/93-	Diesel		9595	230	313	12.87-	■	■
2631A	01/93-	Diesel		9595	230	313	12.87-		■
2631A	01/93-	Diesel		9595	230	313	12.87-		■
2631AK	01/93-	Diesel		9595	230	313	12.87-		■
2631AK	01/93-	Diesel		9595	230	313	12.87-		■
2631AS	01/93-	Diesel		9595	230	313	12.87-		■
2631AS	01/93-	Diesel		9595	230	313	12.87-		■
2631B	01/93-	Diesel		9595	230	313	12.87-	■	■
2631B	01/93-	Diesel		9595	230	313	12.87-	■	■
2631S	01/93-	Diesel		9595	230	313	12.87-	■	■
2631S	01/93-	Diesel		9595	230	313	12.87-	■	■
1824	01/94-	Diesel		10995	180	245	12.87-	■	
1824	01/94-	Diesel		10995	180	245	12.87-	■	
2024	01/94-	Diesel		10995	180	245	12.87-		■
2024	01/94-	Diesel		10995	180	245	12.87-		■
2024AK	01/94-	Diesel		10995	180	245	12.87-		■
2024AK	01/94-	Diesel		10995	180	245	12.87-		■
2024K	01/94-	Diesel		10995	180	245	12.87-		■
2024K	01/94-	Diesel		10995	180	245	12.87-		■
2524	01/94-	Diesel		10995	180	245	12.87-	■	■
2524	01/94-	Diesel		10995	180	245	12.87-	■	■
2524/L	01/94-	Diesel		10995	180	245	12.87-	■	
2524/L	01/94-	Diesel		10995	180	245	12.87-	■	
2524/L	01/94-, Auxiliary Axle	Diesel		10995	180	245	12.87-		■
2524/L	01/94-, Auxiliary Axle	Diesel		10995	180	245	12.87-		■
2524K	01/94-	Diesel		10995	180	245	12.87-	■	■
2524K	01/94-	Diesel		10995	180	245	12.87-	■	■
1827/L	01/94-	Diesel		10995	200	272	12.87-	■	
1827/L	01/94-	Diesel		10995	200	272	12.87-	■	
1827S	01/94-	Diesel		10995	200	272	12.87-	■	
1827S	01/94-	Diesel		10995	200	272	12.87-	■	
2527	01/94-	Diesel		10995	200	272	12.87-	■	■
2527	01/94-	Diesel		10995	200	272	12.87-	■	■
2527/L	01/94-	Diesel		10995	200	272	12.87-	■	
2527/L	01/94-	Diesel		10995	200	272	12.87-	■	
2527/L	01/94-, Auxiliary Axle	Diesel		10995	200	272	12.87-		■
2527/L	01/94-, Auxiliary Axle	Diesel		10995	200	272	12.87-		■
2527B	01/94-	Diesel		10995	200	272	12.87-	■	■
2527B	01/94-	Diesel		10995	200	272	12.87-	■	■
2527K	01/94-	Diesel		10995	200	272	12.87-	■	■
2527K	01/94-	Diesel		10995	200	272	12.87-	■	■
1831/L	01/94-	Diesel		10995	230	313	12.87-	■	
1831/L	01/94-	Diesel		10995	230	313	12.87-	■	
1831S/LS	01/94-	Diesel		10995	230	313	12.87-	■	
1831S/LS	01/94-	Diesel		10995	230	313	12.87-	■	
2031A	01/94-	Diesel		10995	230	313	12.87-		■
2031A	01/94-	Diesel		10995	230	313	12.87-		■
2531/L	01/94-	Diesel		10995	230	313	12.87-	■	
2531/L	01/94-	Diesel		10995	230	313	12.87-	■	
2531/L	01/94-, Auxiliary Axle	Diesel		10995	230	313	12.87-		■
2531/L	01/94-, Auxiliary Axle	Diesel		10995	230	313	12.87-		■

LISTA DE APLICACIONES - BUYERS GUIDE

2631	01/93-	Diesel		10995	230	313	12.87-	■	■
2631	01/93-	Diesel		10995	230	313	12.87-	■	■
2631A	01/94-	Diesel		10995	230	313	12.87-		■
2631A	01/94-	Diesel		10995	230	313	12.87-		■
2631AK	01/94-	Diesel		10995	230	313	12.87-		■
2631AK	01/94-	Diesel		10995	230	313	12.87-		■
2631S	01/93-	Diesel		10995	230	313	12.87-	■	■
2631S	01/93-	Diesel		10995	230	313	12.87-	■	■
1726/L	01/93-	Diesel		10995	250	340	12.87-	■	
1726/L	01/93-	Diesel		10995	250	340	12.87-	■	
1834/L	01/93-	Diesel		10995	250	340	12.87-	■	
1834/L	01/93-	Diesel		10995	250	340	12.87-	■	
1834S/LS	01/93-	Diesel		10995	250	340	12.87-	■	
1834S/LS	01/93-	Diesel		10995	250	340	12.87-	■	
2426/L	01/93-	Diesel		10995	250	340	12.87-	■	
2426/L	01/93-	Diesel		10995	250	340	12.87-	■	
2534/L	01/93-	Diesel		10995	250	340	12.87-	■	
2534/L	01/93-	Diesel		10995	250	340	12.87-	■	
2534K	01/93-	Diesel		10995	250	340	12.87-	■	■
2534K	01/93-	Diesel		10995	250	340	12.87-	■	■
2534S/LS	01/93-	Diesel		10995	250	340	12.87-	■	
2534S/LS	01/93-	Diesel		10995	250	340	12.87-	■	
2534S/LS	01/93-, Auxiliary Axle	Diesel		10995	250	340	12.87-		■
2534S/LS	01/93-, Auxiliary Axle	Diesel		10995	250	340	12.87-		■
3234B	01/93-	Diesel		10995	250	340	12.87-	■	■
3234B	01/93-	Diesel		10995	250	340	12.87-	■	■
3234K	01/93-	Diesel		10995	250	340	12.87-	■	■
3234K	01/93-	Diesel		10995	250	340	12.87-	■	■
3534K	01/93-	Diesel		10995	250	340	12.87-	■	■
3534K	01/93-	Diesel		10995	250	340	12.87-	■	■
1735S/LS	01/93-	Diesel		10995	260	354	12.87-	■	
1735S/LS	01/93-	Diesel		10995	260	354	12.87-	■	
1722/L	01/93-	Diesel		11295	151	205	12.87-	■	
1722/L	01/93-	Diesel		11295	151	205	12.87-	■	
1722K	01/93-	Diesel		11295	153	208	12.87-	■	
1722K	01/93-	Diesel		11295	153	208	12.87-	■	
1722S	01/93-	Diesel		11295	153	208	12.87-	■	
1722S	01/93-	Diesel		11295	153	208	12.87-	■	
2422/L	01/93-	Diesel		11295	153	208	12.87-	■	
2422/L	01/93-	Diesel		11295	153	208	12.87-	■	
1922	01/93-	Diesel		11295	160	218	12.87-	■	
1922	01/93-	Diesel		11295	160	218	12.87-	■	
1922K	01/93-	Diesel		11295	160	218	12.87-	■	
1922K	01/93-	Diesel		11295	160	218	12.87-	■	
1922S	01/93-	Diesel		11295	160	218	12.87-	■	
1922S	01/93-	Diesel		11295	160	218	12.87-	■	
1838/L	01/93-	Diesel		12795	280	381	12.87-	■	
1838/L	01/93-	Diesel		12795	280	381	12.87-	■	
1838S/LS	01/93-	Diesel		12795	280	381	12.87-	■	
1838S/LS	01/93-	Diesel		12795	280	381	12.87-	■	
2031A	01/93-	Diesel		12795	280	381	12.87-		■

LISTA DE APLICACIONES - BUYERS GUIDE

2031A	01/93-	Diesel		12795	280	381	12.87-		■
2038	01/93-	Diesel		12795	280	381	12.87-		■
2038	01/93-	Diesel		12795	280	381	12.87-		■
2038AS	01/93-	Diesel		12795	280	381	12.87-		■
2038AS	01/93-	Diesel		12795	280	381	12.87-		■
2038S	01/93-	Diesel		12795	280	381	12.87-		■
2038S	01/93-	Diesel		12795	280	381	12.87-		■
2538	01/93-	Diesel		12795	280	381	12.87-	■	
2538	01/93-	Diesel		12795	280	381	12.87-	■	
2538/L	01/93-	Diesel		12795	280	381	12.87-	■	
2538/L	01/93-	Diesel		12795	280	381	12.87-	■	
2538K	01/93-	Diesel		12795	280	381	12.87-	■	■
2538K	01/93-	Diesel		12795	280	381	12.87-	■	■
2538S/LS	01/93-	Diesel		12795	280	381	12.87-	■	
2538S/LS	01/93-	Diesel		12795	280	381	12.87-	■	
2538S/LS	01/93-, Auxiliary Axle	Diesel		12795	280	381	12.87-		■
2538S/LS	01/93-, Auxiliary Axle	Diesel		12795	280	381	12.87-		■
2638	01/93-	Diesel		12795	280	381	12.87-	■	■
2638	01/93-	Diesel		12795	280	381	12.87-	■	■
2638AK	01/93-	Diesel		12795	280	381	12.87-		■
2638AK	01/93-	Diesel		12795	280	381	12.87-		■
2638AS	01/93-	Diesel		12795	280	381	12.87-		■
2638AS	01/93-	Diesel		12795	280	381	12.87-		■
2638K	01/93-	Diesel		12795	280	381	12.87-	■	■
2638K	01/93-	Diesel		12795	280	381	12.87-	■	■
3238	01/93-	Diesel		12795	280	381	12.87-	■	■
3238	01/93-	Diesel		12795	280	381	12.87-	■	■
3538AK	01/93-	Diesel		12795	280	381	12.87-	■	■
3538AK	01/93-	Diesel		12795	280	381	12.87-	■	■
3538K	01/93-	Diesel		12795	280	381	12.87-	■	■
3538K	01/93-	Diesel		12795	280	381	12.87-	■	■
2031A	01/93-	Diesel		12795	320	435	12.87-		■
2031A	01/93-	Diesel		12795	320	435	12.87-		■
2435S/LS	01/93-	Diesel		14595	191	260	12.87-	■	
2435S/LS	01/93-	Diesel		14595	191	260	12.87-	■	
2435/L	01/93-	Diesel		14595	260	354	12.87-	■	
2435/L	01/93-	Diesel		14595	260	354	12.87-	■	
2635AS	01/93-	Diesel		14595	266	362	12.87-		■
2635AS	01/93-	Diesel		14595	266	362	12.87-		■
1935	01/93-	Diesel		14595	269	366	12.87-	■	
1935	01/93-	Diesel		14595	269	366	12.87-	■	
1935K	01/93-	Diesel		14595	269	366	12.87-	■	
1935K	01/93-	Diesel		14595	269	366	12.87-	■	
1935S	01/93-	Diesel		14595	269	366	12.87-	■	
1935S	01/93-	Diesel		14595	269	366	12.87-	■	
1838/L	01/95-	Diesel		14595	280	381	12.87-	■	
1838/L	01/95-	Diesel		14595	280	381	12.87-	■	
1838S/LS	01/95-	Diesel		14595	280	381	12.87-	■	
1838S/LS	01/95-	Diesel		14595	280	381	12.87-	■	
2031A	01/94-	Diesel		14595	280	381	12.87-		■
2031A	01/94-	Diesel		14595	280	381	12.87-		■

LISTA DE APLICACIONES - BUYERS GUIDE

2038AS	01/94-	Diesel		14595	280	381	12.87-		■
2038AS	01/94-	Diesel		14595	280	381	12.87-		■
2538	01/94-	Diesel		14595	280	381	12.87-	■	■
2538	01/94-	Diesel		14595	280	381	12.87-	■	■
2538/L	01/94-	Diesel		14595	280	381	12.87-	■	
2538/L	01/94-	Diesel		14595	280	381	12.87-	■	
2538K	01/94-	Diesel		14595	280	381	12.87-	■	■
2538K	01/94-	Diesel		14595	280	381	12.87-	■	■
2538S/LS	01/94-	Diesel		14595	280	381	12.87-	■	
2538S/LS	01/94-	Diesel		14595	280	381	12.87-	■	
2538S/LS	01/94-, Auxiliary Axle	Diesel		14595	280	381	12.87-		■
2538S/LS	01/94-, Auxiliary Axle	Diesel		14595	280	381	12.87-		■
2638	01/93-	Diesel		14595	280	381	12.87-	■	■
2638	01/93-	Diesel		14595	280	381	12.87-	■	■
2638AK	01/94-	Diesel		14595	280	381	12.87-		■
2638AK	01/94-	Diesel		14595	280	381	12.87-		■
2638AS	01/94-	Diesel		14595	280	381	12.87-		■
2638AS	01/94-	Diesel		14595	280	381	12.87-		■
2638K	01/93-	Diesel		14595	280	381	12.87-	■	■
2638K	01/93-	Diesel		14595	280	381	12.87-	■	■
3238	01/94-	Diesel		14595	280	381	12.87-	■	■
3238	01/94-	Diesel		14595	280	381	12.87-	■	■
3538AK	01/94-	Diesel		14595	280	381	12.87-	■	■
3538AK	01/94-	Diesel		14595	280	381	12.87-	■	■
3538K	01/94-	Diesel		14595	280	381	12.87-	■	■
3538K	01/94-	Diesel		14595	280	381	12.87-	■	■
1838/L	01/93-	Diesel		14595	320	435	12.87-	■	
1838/L	01/93-	Diesel		14595	320	435	12.87-	■	
1838S/LS	01/93-	Diesel		14595	320	435	12.87-	■	
1838S/LS	01/93-	Diesel		14595	320	435	12.87-	■	
1844/L	01/93-	Diesel		14595	320	435	12.87-	■	
1844/L	01/93-	Diesel		14595	320	435	12.87-	■	
1844S/LS	01/93-	Diesel		14595	320	435	12.87-	■	
1844S/LS	01/93-	Diesel		14595	320	435	12.87-	■	
20344S	01/93-	Diesel		14595	320	435	12.87-		■
20344S	01/93-	Diesel		14595	320	435	12.87-		■
2038AS	01/93-	Diesel		14595	320	435	12.87-		■
2038AS	01/93-	Diesel		14595	320	435	12.87-		■
2044	01/93-	Diesel		14595	320	435	12.87-		■
2044	01/93-	Diesel		14595	320	435	12.87-		■
2538	01/93-	Diesel		14595	320	435	12.87-	■	■
2538	01/93-	Diesel		14595	320	435	12.87-	■	■
2538/L	01/93-	Diesel		14595	320	435	12.87-	■	
2538/L	01/93-	Diesel		14595	320	435	12.87-	■	
2538K	01/93-	Diesel		14595	320	435	12.87-	■	■
2538K	01/93-	Diesel		14595	320	435	12.87-	■	■
2538S/LS	01/93-	Diesel		14595	320	435	12.87-	■	
2538S/LS	01/93-	Diesel		14595	320	435	12.87-	■	
2538S/LS	01/93-, Auxiliary Axle	Diesel		14595	320	435	12.87-		■
2538S/LS	01/93-, Auxiliary Axle	Diesel		14595	320	435	12.87-		■
2544/L	01/93-	Diesel		14595	320	435	12.87-	■	

LISTA DE APLICACIONES - BUYERS GUIDE

2544/L	01/93-	Diesel		14595	320	435	12.87-	■	
2544S	01/93-	Diesel		14595	320	435	12.87-	■	
2544S	01/93-	Diesel		14595	320	435	12.87-	■	
2638	01/93-	Diesel		14595	320	435	12.87-	■	■
2638	01/93-	Diesel		14595	320	435	12.87-	■	■
2638AK	01/93-	Diesel		14595	320	435	12.87-		■
2638AK	01/93-	Diesel		14595	320	435	12.87-		■
2638AS	01/93-	Diesel		14595	320	435	12.87-		■
2638AS	01/93-	Diesel		14595	320	435	12.87-		■
2638K	01/93-	Diesel		14595	320	435	12.87-	■	■
2638K	01/93-	Diesel		14595	320	435	12.87-	■	■
2638S	01/93-	Diesel		14595	320	435	12.87-	■	■
2638S	01/93-	Diesel		14595	320	435	12.87-	■	■
2644	01/93-	Diesel		14595	320	435	12.87-	■	■
2644	01/93-	Diesel		14595	320	435	12.87-	■	■
2644S	01/93-	Diesel		14595	320	435	12.87-	■	■
2644S	01/93-	Diesel		14595	320	435	12.87-	■	■
3238	01/93-	Diesel		14595	320	435	12.87-	■	■
3238	01/93-	Diesel		14595	320	435	12.87-	■	■
3538AK	01/93-	Diesel		14595	320	435	12.87-	■	■
3538AK	01/93-	Diesel		14595	320	435	12.87-	■	■
3538K	01/93-	Diesel		14595	320	435	12.87-	■	■
3538K	01/93-	Diesel		14595	320	435	12.87-	■	■
1850/L	01/93-	Diesel		14595	362	492	12.87-	■	
1850/L	01/93-	Diesel		14595	362	492	12.87-	■	
1850S/LS	01/93-	Diesel		14595	362	492	12.87-	■	
1850S/LS	01/93-	Diesel		14595	362	492	12.87-	■	
2050	01/93-	Diesel		14595	362	492	12.87-		■
2050	01/93-	Diesel		14595	362	492	12.87-		■
2050S	01/93-	Diesel		14595	362	492	12.87-		■
2050S	01/93-	Diesel		14595	362	492	12.87-		■
2538K	01/93-	Diesel		14595	362	492	12.87-	■	■
2538K	01/93-	Diesel		14595	362	492	12.87-	■	■
2638K	01/93-	Diesel		14595	362	492	12.87-	■	■
2638K	01/93-	Diesel		14595	362	492	12.87-	■	■
3238	01/93-	Diesel		14595	362	492	12.87-	■	■
3238	01/93-	Diesel		14595	362	492	12.87-	■	■
3538K	01/93-	Diesel		14595	362	492	12.87-	■	■
3538K	01/93-	Diesel		14595	362	492	12.87-	■	■
3550S	01/93-	Diesel		14595	362	492	12.87-	■	■
3550S	01/93-	Diesel		14595	362	492	12.87-	■	■
2538	01/93-	Diesel		14595	370	503	12.87-	■	
2538	01/93-	Diesel		14595	370	503	12.87-	■	
2538	01/93-	Diesel		14595	370	503	12.87-	■	■
2538	01/93-	Diesel		14595	370	503	12.87-	■	■
2538S	01/93-	Diesel		14595	370	503	12.87-	■	
2538S	01/93-	Diesel		14595	370	503	12.87-	■	
2538S	01/93-, Auxiliary Axle	Diesel		14595	370	503	12.87-		■
2538S	01/93-, Auxiliary Axle	Diesel		14595	370	503	12.87-		■
2550/L	01/93-	Diesel		14595	370	503	12.87-	■	
2550/L	01/93-	Diesel		14595	370	503	12.87-	■	

LISTA DE APLICACIONES - BUYERS GUIDE

2550S	01/93-	Diesel		14595	370	503	12.87-	■	■
2550S	01/93-	Diesel		14595	370	503	12.87-	■	■
2638	01/93-	Diesel		14595	370	503	12.87-	■	■
2638	01/93-	Diesel		14595	370	503	12.87-	■	■
2638AK	01/93-	Diesel		14595	370	503	12.87-		■
2638AK	01/93-	Diesel		14595	370	503	12.87-		■
2638AS	01/93-	Diesel		14595	370	503	12.87-		■
2638AS	01/93-	Diesel		14595	370	503	12.87-		■
2638K	01/93-	Diesel		14595	370	503	12.87-	■	■
2638K	01/93-	Diesel		14595	370	503	12.87-	■	■
2638S	01/93-	Diesel		14595	370	503	12.87-	■	■
2638S	01/93-	Diesel		14595	370	503	12.87-	■	■
2650	01/93-	Diesel		14595	370	503	12.87-	■	■
2650	01/93-	Diesel		14595	370	503	12.87-	■	■
2650S	01/93-	Diesel		14595	370	503	12.87-	■	■
2650S	01/93-	Diesel		14595	370	503	12.87-	■	■
3538AK	01/93-	Diesel		14595	370	503	12.87-	■	■
3538AK	01/93-	Diesel		14595	370	503	12.87-	■	■
1853/L	01/96-	Diesel		14595	390	530	12.87-	■	
1853/L	01/96-	Diesel		14595	390	530	12.87-	■	
1853S/LS	01/96-	Diesel		14595	390	530	12.87-	■	
1853S/LS	01/96-	Diesel		14595	390	530	12.87-	■	
2553/L	01/96-	Diesel		14595	390	530	12.87-	■	
2553/L	01/96-	Diesel		14595	390	530	12.87-	■	
2553S	01/96-	Diesel		14595	390	530	12.87-	■	■
2553S	01/96-	Diesel		14595	390	530	12.87-	■	■
3253	01/96-	Diesel		14595	390	530	12.87-	■	■
3253	01/96-	Diesel		14595	390	530	12.87-	■	■
1735L	01/93-	Diesel		14695	218	296	12.87-	■	
1735L	01/93-	Diesel		14695	218	296	12.87-	■	
1735K	01/93-	Diesel		14695	250	340	12.87-	■	
1735K	01/93-	Diesel		14695	250	340	12.87-	■	
1735/L	01/93-	Diesel		14695	260	354	12.87-	■	
1735/L	01/93-	Diesel		14695	260	354	12.87-	■	
1926 (OM 442.914)	01/93-	Diesel		15078	195	265	12.87-09.96	■	
1926 (OM 442.914)	01/93-	Diesel		15078	195	265	12.87-09.96	■	
1926 (OM 442.922)	01/93-	Diesel		15078	195	265	12.87-09.96	■	
1926 (OM 442.922)	01/93-	Diesel		15078	195	265	12.87-09.96	■	
1926 (OM 442.932)	01/93-	Diesel		15078	195	265	12.87-09.96	■	
1926 (OM 442.932)	01/93-	Diesel		15078	195	265	12.87-09.96	■	
1729 (OM 442.906)	01/93-	Diesel		15078	210	286	12.87-09.96	■	
1729 (OM 442.906)	01/93-	Diesel		15078	210	286	12.87-09.96	■	
1729 (OM 442.907)	01/93-	Diesel		15078	210	286	12.87-09.96	■	
1729 (OM 442.907)	01/93-	Diesel		15078	210	286	12.87-09.96	■	
1729 (OM 442.923)	01/93-	Diesel		15078	210	286	12.87-09.96	■	
1729 (OM 442.923)	01/93-	Diesel		15078	210	286	12.87-09.96	■	
2429 (OM 442.906)	01/93-	Diesel		15078	210	286	12.87-09.96	■	
2429 (OM 442.906)	01/93-	Diesel		15078	210	286	12.87-09.96	■	
2429 (OM 442.907)	01/93-	Diesel		15078	210	286	12.87-09.96	■	
2429 (OM 442.907)	01/93-	Diesel		15078	210	286	12.87-09.96	■	
2429 (OM 442.909)	01/93-	Diesel		15078	210	286	12.87-09.96	■	

LISTA DE APLICACIONES - BUYERS GUIDE

2429 (OM 442.909)	01/93-	Diesel		15078	210	286	12.87-09.96	■	
2429 (OM 442.923)	01/93-	Diesel		15078	210	286	12.87-09.96	■	
2429 (OM 442.923)	01/93-	Diesel		15078	210	286	12.87-09.96	■	
1726/L	01/93-	Diesel		15095	195	265	12.87-	■	
1726/L	01/93-	Diesel		15095	195	265	12.87-	■	
1726K	01/93-	Diesel		15095	195	265	12.87-	■	
1726K	01/93-	Diesel		15095	195	265	12.87-	■	
1726S/LS	01/93-	Diesel		15095	195	265	12.87-	■	
1726S/LS	01/93-	Diesel		15095	195	265	12.87-	■	
2426/L	01/93-	Diesel		15095	195	265	12.87-	■	
2426/L	01/93-	Diesel		15095	195	265	12.87-	■	
2527/L	01/93-	Diesel		15095	195	265	12.87-	■	
2527/L	01/93-	Diesel		15095	195	265	12.87-	■	
2527/L	01/93-, Auxiliary Axle	Diesel		15095	195	265	12.87-		■
2527/L	01/93-, Auxiliary Axle	Diesel		15095	195	265	12.87-		■
1729S/LS	01/93-	Diesel		15095	210	286	12.87-	■	
1729S/LS	01/93-	Diesel		15095	210	286	12.87-	■	
1929/L	01/93-	Diesel		15095	210	286	12.87-	■	
1929/L	01/93-	Diesel		15095	210	286	12.87-	■	
1929K	01/93-	Diesel		15095	210	286	12.87-	■	
1929K	01/93-	Diesel		15095	210	286	12.87-	■	
1929S	01/93-	Diesel		15095	210	286	12.87-	■	
1929S	01/93-	Diesel		15095	210	286	12.87-	■	
1729K	01/93-	Diesel		15095	213	290	12.87-	■	
1729K	01/93-	Diesel		15095	213	290	12.87-	■	
2426S/LS	01/93-	Diesel		15095	213	290	12.87-	■	
2426S/LS	01/93-	Diesel		15095	213	290	12.87-	■	
2429/L	01/93-	Diesel		15095	213	290	12.87-	■	
2429/L	01/93-	Diesel		15095	213	290	12.87-	■	
1722	01/93-	Diesel		15095	218	296	12.87-	■	
1722	01/93-	Diesel		15095	218	296	12.87-	■	
NG 08.73-03.98									
3850A	01/93-	Diesel		18295	357	486	08.73-	■	■
3850A	01/93-	Diesel		18295	357	486	08.73-	■	■
3250AF	01/93-	Diesel		18295	368	500	08.73-		■
3250AF	01/93-	Diesel		18295	368	500	08.73-		■
SK-Class 07.87-09.96					Platform/Chassis				
3248 (OM 442.984)	01/93-	Diesel		14618	353	480	07.87-09.96	■	■
3248 (OM 442.984)	01/93-	Diesel		14618	353	480	07.87-09.96	■	■
3248 (OM 442.985)	01/93-	Diesel		14618	353	480	07.87-09.96	■	■
3248 (OM 442.985)	01/93-	Diesel		14618	353	480	07.87-09.96	■	■
STEYR									
S 01.90-									
19 S	01/94-	Diesel					01.90-	■	
19 S	01/94-	Diesel					01.90-	■	
22 S	01/94-	Diesel					01.90-	■	
22 S	01/94-	Diesel					01.90-	■	
26 S	01/94-	Diesel					01.90-	■	
26 S	01/94-	Diesel					01.90-	■	
32 S	01/94-	Diesel					01.90-	■	

LISTA DE APLICACIONES - BUYERS GUIDE

32 S	01/94-	Diesel					01.90-	■
42 S	01/94-	Diesel					01.90-	■
42 S	01/94-	Diesel					01.90-	■