


# LISTA DE APLICACIONES - BUYERS GUIDE


## 21 9496 00




8 424073 090706

Qty: 850      Weight: 10.300

O.E.M.	MAKE
617 423 05 30	MERCEDES-BENZ



## 21 9496 00



223x17x178- Ø410

WVA
19488
19496

MAKE
MAN
MERCEDES-BENZ
STEYR



Trac.	CC	Kw	CV		 Front / Rear
-------	----	----	----	---	--

## MAN

### EL 01.93-02.01

							Bus	
EL 202,EL 222 (D 0826 LUH 03)		Diesel		6871	157	214	01.93-06.97	■
EL 202,EL 222 (D 0826 LUH 03)		Diesel		6871	157	214	01.93-06.97	■
EL 202,EL 222 (D 0826 LUH 05)		Diesel		6871	157	214	01.93-06.97	■
EL 202,EL 222 (D 0826 LUH 05)		Diesel		6871	157	214	01.93-06.97	■
EL 202,EL 222 (D 0826 LUH 12)		Diesel		6871	157	214	01.93-06.97	■
EL 202,EL 222 (D 0826 LUH 12)		Diesel		6871	157	214	01.93-06.97	■
EL 202,EL 262 (D 0826 LUH)		Diesel		6871	184	250	04.94-06.97	■
EL 202,EL 262 (D 0826 LUH)		Diesel		6871	184	250	04.94-06.97	■
EL 262 (D 2866 LUH 22)		Diesel		11967	191	260	07.98-02.01	■
EL 262 (D 2866 LUH 22)		Diesel		11967	191	260	07.98-02.01	■

### F2000 01.94-

48.343VF/VFA	01/94-	Diesel			250	340	01.94-	■
48.343VF/VFA	01/94-	Diesel			250	340	01.94-	■
48.403VF/VFA	01/94-	Diesel			294	400	01.94-	■
48.403VF/VFA	01/94-	Diesel			294	400	01.94-	■
48.463VF/VFA	01/94-	Diesel			338	460	01.94-	■
48.463VF/VFA	01/94-	Diesel			338	460	01.94-	■
19.273FA	01/94-	Diesel		10000	198	269	01.94-	■
19.273FA	01/94-	Diesel		10000	198	269	01.94-	■
19.273FAK	01/94-	Diesel		10000	198	269	01.94-	■
19.273FAK	01/94-	Diesel		10000	198	269	01.94-	■
19.273FK	01/94-	Diesel		10000	198	269	01.94-	■
19.273FK	01/94-	Diesel		10000	198	269	01.94-	■

# LISTA DE APLICACIONES - BUYERS GUIDE

19.293FAC	01/94-	Diesel		10000	213	290	01.94-
19.293FAC	01/94-	Diesel		10000	213	290	01.94-
19.293FAS	01/94-	Diesel		10000	213	290	01.94-
19.293FAS	01/94-	Diesel		10000	213	290	01.94-
19.293FK	01/94-	Diesel		10000	213	290	01.94-
19.293FK	01/94-	Diesel		10000	213	290	01.94-
19.293FK/FLK	01/94-	Diesel		10000	213	290	01.94-
19.293FK/FLK	01/94-	Diesel		10000	213	290	01.94-
19.323FAC	01/94-	Diesel		10000	235	320	01.94-
19.323FAC	01/94-	Diesel		10000	235	320	01.94-
19.323FAK	01/94-	Diesel		10000	235	320	01.94-
19.323FAK	01/94-	Diesel		10000	235	320	01.94-
19.323FAS	01/94-	Diesel		10000	235	320	01.94-
19.323FAS	01/94-	Diesel		10000	235	320	01.94-
19.343FAC	01/94-	Diesel		10000	250	340	01.94-
19.343FAC	01/94-	Diesel		10000	250	340	01.94-
19.343FAK	01/94-	Diesel		10000	250	340	01.94-
19.343FAK	01/94-	Diesel		10000	250	340	01.94-
19.343FAS	01/94-	Diesel		10000	250	340	01.94-
19.343FAS	01/94-	Diesel		10000	250	340	01.94-
35.343VFC	01/95-	Diesel		10000	250	340	01.94-
35.343VFC	01/95-	Diesel		10000	250	340	01.94-
35.343VFK	01/95-	Diesel		10000	250	340	01.94-
35.343VFK	01/95-	Diesel		10000	250	340	01.94-
41.343VFC	01/95-	Diesel		10000	250	340	01.94-
41.343VFC	01/95-	Diesel		10000	250	340	01.94-
41.343VFK	01/95-	Diesel		10000	250	340	01.94-
41.343VFK	01/95-	Diesel		10000	250	340	01.94-
19.373FAC	01/94-	Diesel		11995	200	272	01.94-
19.373FAC	01/94-	Diesel		11995	200	272	01.94-
19.314FAS	01/98-	Diesel		11995	228	310	01.94-
19.314FAS	01/98-	Diesel		11995	228	310	01.94-
19.314FK/FLK	01/98-	Diesel		11995	228	310	01.94-
19.314FK/FLK	01/98-	Diesel		11995	228	310	01.94-
19.323FK/FLK	01/94-	Diesel		11995	235	320	01.94-
19.323FK/FLK	01/94-	Diesel		11995	235	320	01.94-
19.343FK/FLK	01/94-	Diesel		11995	250	340	01.94-
19.343FK/FLK	01/94-	Diesel		11995	250	340	01.94-
19.364FAC	01/98-	Diesel		11995	265	360	01.94-
19.364FAC	01/98-	Diesel		11995	265	360	01.94-
19.364FAK	01/98-	Diesel		11995	265	360	01.94-
19.364FAK	01/98-	Diesel		11995	265	360	01.94-
19.364FAS	01/98-	Diesel		11995	265	360	01.94-
19.364FAS	01/98-	Diesel		11995	265	360	01.94-
19.364FK/FLK	01/98-	Diesel		11995	265	360	01.94-
19.364FK/FLK	01/98-	Diesel		11995	265	360	01.94-
19.373FAK	01/94-	Diesel		11995	272	370	01.94-
19.373FAK	01/94-	Diesel		11995	272	370	01.94-
19.373FAS	01/94-	Diesel		11995	272	370	01.94-
19.373FAS	01/94-	Diesel		11995	272	370	01.94-
19.373FK/FLK	01/94-	Diesel		11995	272	370	01.94-

# LISTA DE APLICACIONES - BUYERS GUIDE

19.373FK/FLK	01/94-	Diesel		11995	272	370	01.94-
19.403FAC	01/94-	Diesel		11995	294	400	01.94-
19.403FAC	01/94-	Diesel		11995	294	400	01.94-
19.403FAK	01/94-	Diesel		11995	294	400	01.94-
19.403FAK	01/94-	Diesel		11995	294	400	01.94-
19.403FAS	01/94-	Diesel		11995	294	400	01.94-
19.403FAS	01/94-	Diesel		11995	294	400	01.94-
19.403FK/FLK	01/94-	Diesel		11995	294	400	01.94-
19.403FK/FLK	01/94-	Diesel		11995	294	400	01.94-
35.403VFC	01/95-	Diesel		11995	294	400	01.94-
35.403VFC	01/95-	Diesel		11995	294	400	01.94-
35.403VFK	01/95-	Diesel		11995	294	400	01.94-
35.403VFK	01/95-	Diesel		11995	294	400	01.94-
41.403VFC	01/95-	Diesel		11995	294	400	01.94-
41.403VFC	01/95-	Diesel		11995	294	400	01.94-
41.403VFK	01/95-	Diesel		11995	294	400	01.94-
41.403VFK	01/95-	Diesel		11995	294	400	01.94-
19.414FAC	01/98-	Diesel		11995	301	409	01.94-
19.414FAC	01/98-	Diesel		11995	301	409	01.94-
19.414FAK	01/98-	Diesel		11995	301	409	01.94-
19.414FAK	01/98-	Diesel		11995	301	409	01.94-
19.414FAS	01/98-	Diesel		11995	301	409	01.94-
19.414FAS	01/98-	Diesel		11995	301	409	01.94-
19.414FK/FLK	01/98-	Diesel		11995	301	409	01.94-
19.414FK/FLK	01/98-	Diesel		11995	301	409	01.94-
19.423FAC	01/94-	Diesel		11995	309	420	01.94-
19.423FAC	01/94-	Diesel		11995	309	420	01.94-
19.423FAK	01/94-	Diesel		11995	309	420	01.94-
19.423FAK	01/94-	Diesel		11995	309	420	01.94-
19.423FAS	01/94-	Diesel		11995	309	420	01.94-
19.423FAS	01/94-	Diesel		11995	309	420	01.94-
19.423FK/FLK	01/94-	Diesel		11995	309	420	01.94-
19.423FK/FLK	01/94-	Diesel		11995	309	420	01.94-
19.463FAC	01/94-	Diesel		11995	338	460	01.94-
19.463FAC	01/94-	Diesel		11995	338	460	01.94-
19.463FAK	01/94-	Diesel		12795	338	460	01.94-
19.463FAK	01/94-	Diesel		12795	338	460	01.94-
19.463FAS	01/94-	Diesel		12795	338	460	01.94-
19.463FAS	01/94-	Diesel		12795	338	460	01.94-
19.463FK/FLK	01/94-	Diesel		12795	338	460	01.94-
19.463FK/FLK	01/94-	Diesel		12795	338	460	01.94-
19.464FAK	01/98-	Diesel		12795	338	460	01.94-
19.464FAK	01/98-	Diesel		12795	338	460	01.94-
19.464FAS	01/98-	Diesel		12795	338	460	01.94-
19.464FAS	01/98-	Diesel		12795	338	460	01.94-
19.464FK/FLK	01/98-	Diesel		12795	338	460	01.94-
19.464FK/FLK	01/98-	Diesel		12795	338	460	01.94-
35.463VFC	01/95-	Diesel		12795	338	460	01.94-
35.463VFC	01/95-	Diesel		12795	338	460	01.94-
35.463VFK	01/95-	Diesel		12795	338	460	01.94-
35.463VFK	01/95-	Diesel		12795	338	460	01.94-

# LISTA DE APLICACIONES - BUYERS GUIDE

41.463VFC	01/95-	Diesel		12795	338	460	01.94-	■
41.463VFC	01/95-	Diesel		12795	338	460	01.94-	■
41.463VFK	01/95-	Diesel		12795	338	460	01.94-	■
41.463VFK	01/95-	Diesel		12795	338	460	01.94-	■
<b>F2000 01.94-</b>					<b>Platform/Chassis</b>			
19.273 F, FL, FLL (D 2865 LF22)	-12/95	Diesel		9973	198	269	01.94-	■
19.273 F, FL, FLL (D 2865 LF22)	-12/95	Diesel		9973	198	269	01.94-	■
26.273 FNLC,26.273 FNLLC,26.273 FVLC (D 2865 LF22)		Diesel		9973	198	269	01.94-12.95	■
26.273 FNLC,26.273 FNLLC,26.273 FVLC (D 2865 LF22)		Diesel		9973	198	269	01.94-12.95	■
19.293 FC,19.293 FLC,19.293 FLLC (D 2865 LF20)		Diesel		9973	213	290	01.94-	■
19.293 FC,19.293 FLC,19.293 FLLC (D 2865 LF20)		Diesel		9973	213	290	01.94-	■
19.293 FC,19.293 FLC,19.293 FLLC (D 2865 LF24)		Diesel		9973	213	290	01.94-	■
19.293 FC,19.293 FLC,19.293 FLLC (D 2865 LF24)		Diesel		9973	213	290	01.94-	■
23.293 FNLLC (D 2865 LF20)		Diesel		9973	213	290	01.94-	■
23.293 FNLLC (D 2865 LF20)		Diesel		9973	213	290	01.94-	■
23.293 FNLLC (D 2865 LF24)		Diesel		9973	213	290	01.94-	■
23.293 FNLLC (D 2865 LF24)		Diesel		9973	213	290	01.94-	■
26.293 FNLC,26.293 FNLLC,26.293 FVLC (D 2865 LF20)		Diesel		9973	213	290	01.94-	■
26.293 FNLC,26.293 FNLLC,26.293 FVLC (D 2865 LF20)		Diesel		9973	213	290	01.94-	■
26.293 FNLC,26.293 FNLLC,26.293 FVLC (D 2865 LF24)		Diesel		9973	213	290	01.94-	■
26.293 FNLC,26.293 FNLLC,26.293 FVLC (D 2865 LF24)		Diesel		9973	213	290	01.94-	■
19.323 FC,19.323 FLC,19.323 FLLC (D 2865 LF23)		Diesel		9973	235	320	01.94-12.95	■
19.323 FC,19.323 FLC,19.323 FLLC (D 2865 LF23)		Diesel		9973	235	320	01.94-12.95	■
26.323 FNLC,26.323 FNLLC,26.323 FVLC (D 2865 LF23)		Diesel		9973	235	320	01.94-12.95	■
26.323 FNLC,26.323 FNLLC,26.323 FVLC (D 2865 LF23)		Diesel		9973	235	320	01.94-12.95	■
19.343 FC,19.343 FLC,19.343 FLLC (D 2865 LF21)		Diesel		9973	250	340	01.94-	■
19.343 FC,19.343 FLC,19.343 FLLC (D 2865 LF21)		Diesel		9973	250	340	01.94-	■
23.343 FNLLC (D 2865 LF21)		Diesel		9973	250	340	01.94-	■
23.343 FNLLC (D 2865 LF21)		Diesel		9973	250	340	01.94-	■
26.343 FNLC,26.343 FNLLC,26.343 FVLC (D 2865 LF21)		Diesel		9973	250	340	01.94-	■
26.343 FNLC,26.343 FNLLC,26.343 FVLC (D 2865 LF21)		Diesel		9973	250	340	01.94-	■
19.314 FC, FLC, FLLC, FLLW, FRC, FLRC, FLLRC, FLL, FLLR, F-N (D 2866 LF34)		Diesel		11967	228	310	06.98-	■
19.314 FC, FLC, FLLC, FLLW, FRC, FLRC, FLLRC, FLL, FLLR, F-N (D 2866 LF34)		Diesel		11967	228	310	06.98-	■
19.364 FC, FLC, FLLC, FLLW, FRC, FLRC, FLLRC, FLL, FLLR, F-N (D 2866 LF35)		Diesel		11967	265	360	06.98-	■
19.364 FC, FLC, FLLC, FLLW, FRC, FLRC, FLLRC, FLL, FLLR, F-N (D 2866 LF35)		Diesel		11967	265	360	06.98-	■
19.373 FC, FLC, FLLC, FRC, FLRC, F-NL (D 2866 LF21)	-12/95	Diesel		11967	272	370	01.94-	■
19.373 FC, FLC, FLLC, FRC, FLRC, F-NL (D 2866 LF21)	-12/95	Diesel		11967	272	370	01.94-	■
26.373 FNLC,26.373 FNLLC,26.373 FVLC (D 2866 LF21)		Diesel		11967	272	370	01.94-12.95	■
26.373 FNLC,26.373 FNLLC,26.373 FVLC (D 2866 LF21)		Diesel		11967	272	370	01.94-12.95	■

# LISTA DE APLICACIONES - BUYERS GUIDE

19.403 FC, FLC, FLLC, FRC, FLRC, F-NL (D 2866 LF20)	Diesel		11967	294	400	01.94-	■
19.403 FC, FLC, FLLC, FRC, FLRC, F-NL (D 2866 LF20)	Diesel		11967	294	400	01.94-	■
23.403 FNLLC (D 2866 LF20)	Diesel		11967	294	400	01.94-	■
23.403 FNLLC (D 2866 LF20)	Diesel		11967	294	400	01.94-	■
26.403 FNLC,26.403 FNLLC,26.403 FVLC (D 2866 LF20)	Diesel		11967	294	400	01.94-	■
26.403 FNLC,26.403 FNLLC,26.403 FVLC (D 2866 LF20)	Diesel		11967	294	400	01.94-	■
19.414 FC, FLC, FLLC, FRC, FLRC, FLLRC, FLL, FLLR, F-NL (D 2866 LF31)	Diesel		11967	301	409	06.98-	■
19.414 FC, FLC, FLLC, FRC, FLRC, FLLRC, FLL, FLLR, F-NL (D 2866 LF31)	Diesel		11967	301	409	06.98-	■
19.423 FC, FLC, FLLC, F-NL (D 2866 LF22)	-12/95 Diesel		11967	309	420	01.94-	■
19.423 FC, FLC, FLLC, F-NL (D 2866 LF22)	-12/95 Diesel		11967	309	420	01.94-	■
26.423 FNLC,26.423 FNLLC,26.423 FVLC (D 2866 LF22)	Diesel		11967	309	420	01.94-12.95	■
26.423 FNLC,26.423 FNLLC,26.423 FVLC (D 2866 LF22)	Diesel		11967	309	420	01.94-12.95	■
19.463 FC, FLC, FLLC, FRC, FLRC, F-NL (D 2876 LF 02)	Diesel		12816	338	460	01.94-	■
19.463 FC, FLC, FLLC, FRC, FLRC, F-NL (D 2876 LF 02)	Diesel		12816	338	460	01.94-	■
19.464 FC, FLC, FLLC, FLL, FRC, FLLR, FLLRC, FLLW, F-NL (D 2876 LF 06)	Diesel		12816	338	460	06.98-	■
19.464 FC, FLC, FLLC, FLL, FRC, FLLR, FLLRC, FLLW, F-NL (D 2876 LF 06)	Diesel		12816	338	460	06.98-	■
23.463 FNLLC (D 2876 LF 02)	Diesel		12816	338	460	01.94-	■
23.463 FNLLC (D 2876 LF 02)	Diesel		12816	338	460	01.94-	■
26.463 FNLC, FNLLC, FNLLRC, FNLLW, FNLRC, FNLLRC, FVLC (D 2876 LF 02)	Diesel		12816	338	460	01.94-	■
26.463 FNLC, FNLLC, FNLLRC, FNLLW, FNLRC, FNLLRC, FVLC (D 2876 LF 02)	Diesel		12816	338	460	01.94-	■
<b>F2000 01.94-</b>				<b>Platform/Chassis</b>			
19.233 FC CNG (E 2866 DF 01)	Gasolina		11967	170	231	03.00-	■
19.233 FC CNG (E 2866 DF 01)	Gasolina		11967	170	231	03.00-	■
26.233 FVLC CNG (E 2866 DF 01)	Gasolina		11967	170	231	09.96-	■
26.233 FVLC CNG (E 2866 DF 01)	Gasolina		11967	170	231	09.96-	■
<b>F2000 01.94-</b>				<b>Truck Tractor</b>			
19.273 FS,19.273 FLS (D 2865 LF22)	Diesel		9973	198	269	01.94-12.95	■
19.273 FS,19.273 FLS (D 2865 LF22)	Diesel		9973	198	269	01.94-12.95	■
26.273 FNLS,26.273 FVLS (D 2865 LF22)	Diesel		9973	198	269	01.94-12.95	■
26.273 FNLS,26.273 FVLS (D 2865 LF22)	Diesel		9973	198	269	01.94-12.95	■
19.293 FS,19.293 FLS,19.293 FLLS (D 2865 LF20)	Diesel		9973	213	290	01.94-	■
19.293 FS,19.293 FLS,19.293 FLLS (D 2865 LF20)	Diesel		9973	213	290	01.94-	■
19.293 FS,19.293 FLS,19.293 FLLS (D 2865 LF24)	Diesel		9973	213	290	01.94-	■
19.293 FS,19.293 FLS,19.293 FLLS (D 2865 LF24)	Diesel		9973	213	290	01.94-	■
26.293 FNLS,26.293 FVLS (D 2865 LF20)	Diesel		9973	213	290	01.94-	■
26.293 FNLS,26.293 FVLS (D 2865 LF20)	Diesel		9973	213	290	01.94-	■
26.293 FNLS,26.293 FVLS (D 2865 LF24)	Diesel		9973	213	290	01.94-	■
26.293 FNLS,26.293 FVLS (D 2865 LF24)	Diesel		9973	213	290	01.94-	■
19.323 FS,19.323 FLS,19.323 FLLS (D 2865 LF23)	Diesel		9973	235	320	01.94-12.95	■
19.323 FS,19.323 FLS,19.323 FLLS (D 2865 LF23)	Diesel		9973	235	320	01.94-12.95	■
26.323 FNLS,26.323 FVLS (D 2865 LF23)	Diesel		9973	235	320	01.94-12.95	■
26.323 FNLS,26.323 FVLS (D 2865 LF23)	Diesel		9973	235	320	01.94-12.95	■

# LISTA DE APLICACIONES - BUYERS GUIDE

19.343 FS,19.343 FLS,19.343 FLLS (D 2865 LF21)		Diesel		9973	250	340	01.94-	■
19.343 FS,19.343 FLS,19.343 FLLS (D 2865 LF21)		Diesel		9973	250	340	01.94-	■
26.343 FNLS,26.343 FVLS (D 2865 LF21)		Diesel		9973	250	340	01.94-	■
26.343 FNLS,26.343 FVLS (D 2865 LF21)		Diesel		9973	250	340	01.94-	■
19.314 FS, FLS, FLLS, FRS, FLRS, FLLRS (D 2866 LF34)		Diesel		11967	228	310	06.98-	■
19.314 FS, FLS, FLLS, FRS, FLRS, FLLRS (D 2866 LF34)		Diesel		11967	228	310	06.98-	■
19.364 FS, FLS, FLLS, FRS, FLRS, FLLRS (D 2866 LF35)		Diesel		11967	265	360	06.98-	■
19.364 FS, FLS, FLLS, FRS, FLRS, FLLRS (D 2866 LF35)		Diesel		11967	265	360	06.98-	■
19.373 FS, FLS, FLLS, FRS, FLRS, FLLRS (D 2866 LF21)	-12/95	Diesel		11967	272	370	01.94-	■
19.373 FS, FLS, FLLS, FRS, FLRS, FLLRS (D 2866 LF21)	-12/95	Diesel		11967	272	370	01.94-	■
26.373 FNLS,26.373 FVLS (D 2866 LF21)		Diesel		11967	272	370	01.94-12.95	■
26.373 FNLS,26.373 FVLS (D 2866 LF21)		Diesel		11967	272	370	01.94-12.95	■
19.403 FS, FLS, FLLS, FRS, FLRS, FLLRS (D 2866 LF20)		Diesel		11967	294	400	01.94-	■
19.403 FS, FLS, FLLS, FRS, FLRS, FLLRS (D 2866 LF20)		Diesel		11967	294	400	01.94-	■
26.403 FNLS,26.403 FVLS (D 2866 LF20)		Diesel		11967	294	400	01.94-	■
26.403 FNLS,26.403 FVLS (D 2866 LF20)		Diesel		11967	294	400	01.94-	■
19.414 FS, FLS, FLLS, FRS, FLRS, FLLRS (D 2866 LF31)		Diesel		11967	301	409	06.98-	■
19.414 FS, FLS, FLLS, FRS, FLRS, FLLRS (D 2866 LF31)		Diesel		11967	301	409	06.98-	■
19.423 FS, FLS, FLLS (D 2866 LF22)	-12/95	Diesel		11967	309	420	01.94-	■
19.423 FS, FLS, FLLS (D 2866 LF22)	-12/95	Diesel		11967	309	420	01.94-	■
26.423 FNLS,26.423 FVLS (D 2866 LF22)		Diesel		11967	309	420	01.94-12.95	■
26.423 FNLS,26.423 FVLS (D 2866 LF22)		Diesel		11967	309	420	01.94-12.95	■
19.463 FS, FLS, FLLS, FRS, FLRS, FLLRS (D 2876 LF 02)		Diesel		12816	338	460	01.94-	■
19.463 FS, FLS, FLLS, FRS, FLRS, FLLRS (D 2876 LF 02)		Diesel		12816	338	460	01.94-	■
19.464 FS, FLS, FLLS, FRS, FLRS, FLLRS (D 2876 LF 06)		Diesel		12816	338	460	06.98-	■
19.464 FS, FLS, FLLS, FRS, FLRS, FLLRS (D 2876 LF 06)		Diesel		12816	338	460	06.98-	■
26.463 FNLS, FVLS, FVLRs (D 2876 LF 02)		Diesel		12816	338	460	01.94-	■
26.463 FNLS, FVLS, FVLRs (D 2876 LF 02)		Diesel		12816	338	460	01.94-	■
19.603 FLS, 19604 FLS (D 2840 LF20)		Diesel		18273	441	600	04.96-	■
19.603 FLS, 19604 FLS (D 2840 LF20)		Diesel		18273	441	600	04.96-	■
<b>F90 06.86-12.97</b>								
27.272 DF/DFA	01/93-	Diesel			198	270	06.86-	■
27.272 DF/DFA	01/93-	Diesel			198	270	06.86-	■
27.272 DFK/DFAK	01/93-	Diesel			198	270	06.86-	■
27.272 DFK/DFAK	01/93-	Diesel			198	270	06.86-	■
27.272 DFS/DFAS	01/93-	Diesel			198	270	06.86-	■
27.272 DFS/DFAS	01/93-	Diesel			198	270	06.86-	■
27.422 DFK/DFAK	01/93-	Diesel			198	270	06.86-	■
27.422 DFK/DFAK	01/93-	Diesel			198	270	06.86-	■
27.422 DFS/DFAS	01/93-	Diesel			198	270	06.86-	■
27.422 DFS/DFAS	01/93-	Diesel			198	270	06.86-	■
27.472 DF/DFA	01/93-	Diesel			198	270	06.86-	■
27.472 DF/DFA	01/93-	Diesel			198	270	06.86-	■
27.322 DF/DFA	01/93-	Diesel			235	320	06.86-	■

# LISTA DE APLICACIONES - BUYERS GUIDE

27.322 DF/DFA	01/93-	Diesel			235	320	06.86-
27.322 DFK/DFAK	01/93-	Diesel			235	320	06.86-
27.322 DFK/DFAK	01/93-	Diesel			235	320	06.86-
27.322 DFS/DFAS	01/93-	Diesel			235	320	06.86-
27.322 DFS/DFAS	01/93-	Diesel			235	320	06.86-
27.372 DF/DFA	01/93-	Diesel			272	370	06.86-
27.372 DF/DFA	01/93-	Diesel			272	370	06.86-
27.372 DFK/DFAK	01/93-	Diesel			272	370	06.86-
27.372 DFK/DFAK	01/93-	Diesel			272	370	06.86-
27.372 DFS/DFAS	01/93-	Diesel			272	370	06.86-
27.372 DFS/DFAS	01/93-	Diesel			272	370	06.86-
27.502 DFA	01/93-	Diesel			368	500	06.86-
27.502 DFA	01/93-	Diesel			368	500	06.86-
27.502 DFAS	01/93-	Diesel			368	500	06.86-
27.502 DFAS	01/93-	Diesel			368	500	06.86-
41.262VFAK	01/93-	Diesel		10000	191	260	06.86-
41.262VFAK	01/93-	Diesel		10000	191	260	06.86-
19.272F/FL/FLL	01/93-	Diesel		10000	198	269	06.86-
19.272F/FL/FLL	01/93-	Diesel		10000	198	269	06.86-
19.272FA	01/93-	Diesel		10000	198	269	06.86-
19.272FA	01/93-	Diesel		10000	198	269	06.86-
19.272FAK	01/93-	Diesel		10000	198	269	06.86-
19.272FAK	01/93-	Diesel		10000	198	269	06.86-
19.272FAS	01/93-	Diesel		10000	198	269	06.86-
19.272FAS	01/93-	Diesel		10000	198	269	06.86-
19.272FK	01/93-	Diesel		10000	198	269	06.86-
19.272FK	01/93-	Diesel		10000	198	269	06.86-
19.272FS/FLS/FL	01/93-	Diesel		10000	198	269	06.86-
19.272FS/FLS/FL	01/93-	Diesel		10000	198	269	06.86-
24.272DFS/DFLS	01/93-	Diesel		10000	198	269	06.86-
24.272DFS/DFLS	01/93-	Diesel		10000	198	269	06.86-
24.272FNL/FNLL	01/93-	Diesel		10000	198	269	06.86-
24.272FNL/FNLL	01/93-	Diesel		10000	198	269	06.86-
24.272FNL/FNLL	01/93-	Diesel		10000	198	269	06.86-
24.272FNL/FNLL	01/93-	Diesel		10000	198	269	06.86-
25.272FNL/FNLL	01/93-	Diesel		10000	198	269	06.86-
25.272FNL/FNLL	01/93-	Diesel		10000	198	269	06.86-
26.272DF	01/93-	Diesel		10000	198	269	06.86-
26.272DF	01/93-	Diesel		10000	198	269	06.86-
26.272DFK	01/93-	Diesel		10000	198	269	06.86-
26.272DFK	01/93-	Diesel		10000	198	269	06.86-
26.272DFS/DFLS	01/93-	Diesel		10000	198	269	06.86-
26.272DFS/DFLS	01/93-	Diesel		10000	198	269	06.86-
26.272FNLS/FVLS	01/93-	Diesel		10000	198	269	06.86-
26.272FNLS/FVLS	01/93-	Diesel		10000	198	269	06.86-
32.272VF	01/93-	Diesel		10000	198	269	06.86-
32.272VF	01/93-	Diesel		10000	198	269	06.86-
32.272VFK	01/93-	Diesel		10000	198	269	06.86-
32.272VFK	01/93-	Diesel		10000	198	269	06.86-
33.272 DF	01/93-	Diesel		10000	198	269	06.86-
33.272 DF	01/93-	Diesel		10000	198	269	06.86-

# LISTA DE APLICACIONES - BUYERS GUIDE

33.272DFA	01/93-	Diesel		10000	198	269	06.86-
33.272DFA	01/93-	Diesel		10000	198	269	06.86-
19.322F/FL/FLL	01/93-	Diesel		10000	235	320	06.86-
19.322F/FL/FLL	01/93-	Diesel		10000	235	320	06.86-
19.322FA	01/93-	Diesel		10000	235	320	06.86-
19.322FA	01/93-	Diesel		10000	235	320	06.86-
19.322FAK	01/93-	Diesel		10000	235	320	06.86-
19.322FAK	01/93-	Diesel		10000	235	320	06.86-
19.322FAS	01/93-	Diesel		10000	235	320	06.86-
19.322FAS	01/93-	Diesel		10000	235	320	06.86-
19.322FK	01/93-	Diesel		10000	235	320	06.86-
19.322FK	01/93-	Diesel		10000	235	320	06.86-
19.322FS/FLS/FL	01/93-	Diesel		10000	235	320	06.86-
19.322FS/FLS/FL	01/93-	Diesel		10000	235	320	06.86-
19.322U/ULL	01/93-	Diesel		10000	235	320	06.86-
19.322U/ULL	01/93-	Diesel		10000	235	320	06.86-
24.322FNL/FNLL	01/93-	Diesel		10000	235	320	06.86-
24.322FNL/FNLL	01/93-	Diesel		10000	235	320	06.86-
24.322FNL/FNLL	01/93-	Diesel		10000	235	320	06.86-
24.322FNL/FNLL	01/93-	Diesel		10000	235	320	06.86-
26.322DF	01/93-	Diesel		10000	235	320	06.86-
26.322DF	01/93-	Diesel		10000	235	320	06.86-
26.322DFK	01/93-	Diesel		10000	235	320	06.86-
26.322DFK	01/93-	Diesel		10000	235	320	06.86-
26.322DFS/DFLS	01/93-	Diesel		10000	235	320	06.86-
26.322DFS/DFLS	01/93-	Diesel		10000	235	320	06.86-
26.322FNL/FNLL	01/93-	Diesel		10000	235	320	06.86-
26.322FNL/FNLL	01/93-	Diesel		10000	235	320	06.86-
26.322FNLS/FVLS	01/93-	Diesel		10000	235	320	06.86-
26.322FNLS/FVLS	01/93-	Diesel		10000	235	320	06.86-
26.322UNL/UNLL	01/93-	Diesel		10000	235	320	06.86-
26.322UNL/UNLL	01/93-	Diesel		10000	235	320	06.86-
32.322VF	01/93-	Diesel		10000	235	320	06.86-
32.322VF	01/93-	Diesel		10000	235	320	06.86-
32.322VFK	01/93-	Diesel		10000	235	320	06.86-
32.322VFK	01/93-	Diesel		10000	235	320	06.86-
33.322 DF	01/93-	Diesel		10000	235	320	06.86-
33.322 DF	01/93-	Diesel		10000	235	320	06.86-
33.322DFA	01/93-	Diesel		10000	235	320	06.86-
33.322DFA	01/93-	Diesel		10000	235	320	06.86-
35.322VF	01/93-	Diesel		10000	235	320	06.86-
35.322VF	01/93-	Diesel		10000	235	320	06.86-
35.322VF	01/93-	Diesel		10000	235	320	06.86-
35.322VF	01/93-	Diesel		10000	235	320	06.86-
35.322VFAK	01/93-	Diesel		10000	235	320	06.86-
35.322VFAK	01/93-	Diesel		10000	235	320	06.86-
35.322VFK	01/93-	Diesel		10000	235	320	06.86-
35.322VFK	01/93-	Diesel		10000	235	320	06.86-
35.322VFK	01/93-	Diesel		10000	235	320	06.86-
35.322VFK	01/93-	Diesel		10000	235	320	06.86-
35.322VFKK	01/93-	Diesel		10000	235	320	06.86-



# LISTA DE APLICACIONES - BUYERS GUIDE

35.322VFKK	01/93-	Diesel		10000	235	320	06.86-
35.322VFKK	01/93-	Diesel		10000	235	320	06.86-
35.322VFKK	01/93-	Diesel		10000	235	320	06.86-
41.322VF	01/93-	Diesel		10000	235	320	06.86-
41.322VF	01/93-	Diesel		10000	235	320	06.86-
41.322VF	01/93-	Diesel		10000	235	320	06.86-
41.322VF	01/93-	Diesel		10000	235	320	06.86-
19.372FS/FLS/FL	01/93-	Diesel		10000	249	339	06.86-
19.372FS/FLS/FL	01/93-	Diesel		10000	249	339	06.86-
19.342F/FL/FLL	01/94-	Diesel		10000	250	340	06.86-
19.342F/FL/FLL	01/94-	Diesel		10000	250	340	06.86-
19.342FA	01/94-	Diesel		10000	250	340	06.86-
19.342FA	01/94-	Diesel		10000	250	340	06.86-
19.342FAK	01/94-	Diesel		10000	250	340	06.86-
19.342FAK	01/94-	Diesel		10000	250	340	06.86-
19.342FAS	01/94-	Diesel		10000	250	340	06.86-
19.342FAS	01/94-	Diesel		10000	250	340	06.86-
19.342FK	01/94-	Diesel		10000	250	340	06.86-
19.342FK	01/94-	Diesel		10000	250	340	06.86-
19.342FS/FLS/FL	01/94-	Diesel		10000	250	340	06.86-
19.342FS/FLS/FL	01/94-	Diesel		10000	250	340	06.86-
24.342FNL/FNLL	01/94-	Diesel		10000	250	340	06.86-
24.342FNL/FNLL	01/94-	Diesel		10000	250	340	06.86-
26.342DF/DFL	01/94-	Diesel		10000	250	340	06.86-
26.342DF/DFL	01/94-	Diesel		10000	250	340	06.86-
26.342DFK/DFLK	01/94-	Diesel		10000	250	340	06.86-
26.342DFK/DFLK	01/94-	Diesel		10000	250	340	06.86-
26.342DFS	01/94-	Diesel		10000	250	340	06.86-
26.342DFS	01/94-	Diesel		10000	250	340	06.86-
32.342VFK	01/94-	Diesel		10000	250	340	06.86-
32.342VFK	01/94-	Diesel		10000	250	340	06.86-
33.342 DF	01/94-	Diesel		10000	250	340	06.86-
33.342 DF	01/94-	Diesel		10000	250	340	06.86-
33.342DFA	01/94-	Diesel		10000	250	340	06.86-
33.342DFA	01/94-	Diesel		10000	250	340	06.86-
35.342VF	01/94-	Diesel		10000	250	340	06.86-
35.342VF	01/94-	Diesel		10000	250	340	06.86-
35.342VF	01/94-	Diesel		10000	250	340	06.86-
35.342VF	01/94-	Diesel		10000	250	340	06.86-
35.342VFK	01/94-	Diesel		10000	250	340	06.86-
35.342VFK	01/94-	Diesel		10000	250	340	06.86-
35.342VFK	01/94-	Diesel		10000	250	340	06.86-
35.342VFK	01/94-	Diesel		10000	250	340	06.86-
41.342VF	01/94-	Diesel		10000	250	340	06.86-
41.342VF	01/94-	Diesel		10000	250	340	06.86-
41.342VF	01/94-	Diesel		10000	250	340	06.86-
41.342VF	01/94-	Diesel		10000	250	340	06.86-
19.372FS/FLS/FL	01/93-	Diesel		10000	272	370	06.86-
19.372FS/FLS/FL	01/93-	Diesel		10000	272	370	06.86-
19.402FS/FLS/FL	01/94-	Diesel		10000	294	400	06.86-
19.402FS/FLS/FL	01/94-	Diesel		10000	294	400	06.86-

# LISTA DE APLICACIONES - BUYERS GUIDE

19.422FS/FLS/FL	01/93-	Diesel		10000	309	420	06.86-
19.422FS/FLS/FL	01/93-	Diesel		10000	309	420	06.86-
35.292VF	01/93-	Diesel		11995	213	290	06.86-
35.292VF	01/93-	Diesel		11995	213	290	06.86-
35.292VF	01/93-	Diesel		11995	213	290	06.86-
35.292VF	01/93-	Diesel		11995	213	290	06.86-
35.292VFK	01/93-	Diesel		11995	213	290	06.86-
35.292VFK	01/93-	Diesel		11995	213	290	06.86-
35.292VFK	01/93-	Diesel		11995	213	290	06.86-
35.292VFK	01/93-	Diesel		11995	213	290	06.86-
41.292VFAK	01/93-	Diesel		11995	213	290	06.86-
41.292VFAK	01/93-	Diesel		11995	213	290	06.86-
24.302DFS/DFLS	01/93-	Diesel		11995	220	299	06.86-
24.302DFS/DFLS	01/93-	Diesel		11995	220	299	06.86-
41.322VFAK	01/93-	Diesel		11995	235	320	06.86-
41.322VFAK	01/93-	Diesel		11995	235	320	06.86-
35.332VF	01/93-	Diesel		11995	243	330	06.86-
35.332VF	01/93-	Diesel		11995	243	330	06.86-
35.332VF	01/93-	Diesel		11995	243	330	06.86-
35.332VF	01/93-	Diesel		11995	243	330	06.86-
35.332VFK	01/93-	Diesel		11995	243	330	06.86-
35.332VFK	01/93-	Diesel		11995	243	330	06.86-
35.332VFK	01/93-	Diesel		11995	243	330	06.86-
35.332VFK	01/93-	Diesel		11995	243	330	06.86-
41.332VFAK	01/93-	Diesel		11995	243	330	06.86-
41.332VFAK	01/93-	Diesel		11995	243	330	06.86-
19.372F/FL/FLL	01/93-	Diesel		11995	249	339	06.86-
19.372F/FL/FLL	01/93-	Diesel		11995	249	339	06.86-
19.372FK	01/93-	Diesel		11995	249	339	06.86-
19.372FK	01/93-	Diesel		11995	249	339	06.86-
25.372FVLS	01/93-	Diesel		11995	249	339	06.86-
25.372FVLS	01/93-	Diesel		11995	249	339	06.86-
32.372VF	01/93-	Diesel		11995	249	339	06.86-
32.372VF	01/93-	Diesel		11995	249	339	06.86-
32.372VFK	01/93-	Diesel		11995	249	339	06.86-
32.372VFK	01/93-	Diesel		11995	249	339	06.86-
35.372VF	01/93-	Diesel		11995	249	339	06.86-
35.372VF	01/93-	Diesel		11995	249	339	06.86-
35.372VF	01/93-	Diesel		11995	249	339	06.86-
35.372VF	01/93-	Diesel		11995	249	339	06.86-
35.372VFK	01/93-	Diesel		11995	249	339	06.86-
35.372VFK	01/93-	Diesel		11995	249	339	06.86-
35.372VFK	01/93-	Diesel		11995	249	339	06.86-
35.372VFK	01/93-	Diesel		11995	249	339	06.86-
41.362VFAK	01/93-	Diesel		11995	265	360	06.86-
41.362VFAK	01/93-	Diesel		11995	265	360	06.86-
19.372F/FL/FLL	01/93-	Diesel		11995	272	370	06.86-
19.372F/FL/FLL	01/93-	Diesel		11995	272	370	06.86-
19.372FA	01/93-	Diesel		11995	272	370	06.86-
19.372FA	01/93-	Diesel		11995	272	370	06.86-
19.372FAK	01/93-	Diesel		11995	272	370	06.86-

# LISTA DE APLICACIONES - BUYERS GUIDE

19.372FAK	01/93-	Diesel		11995	272	370	06.86-
19.372FAS	01/93-	Diesel		11995	272	370	06.86-
19.372FAS	01/93-	Diesel		11995	272	370	06.86-
19.372FK	01/93-	Diesel		11995	272	370	06.86-
19.372FK	01/93-	Diesel		11995	272	370	06.86-
19.372U/ULL	01/93-	Diesel		11995	272	370	06.86-
19.372U/ULL	01/93-	Diesel		11995	272	370	06.86-
24.372DFS/DFLS	01/93-	Diesel		11995	272	370	06.86-
24.372DFS/DFLS	01/93-	Diesel		11995	272	370	06.86-
24.372FNL/FNLL	01/93-	Diesel		11995	272	370	06.86-
24.372FNL/FNLL	01/93-	Diesel		11995	272	370	06.86-
24.372FNL/FNLL	01/93-	Diesel		11995	272	370	06.86-
24.372FNL/FNLL	01/93-	Diesel		11995	272	370	06.86-
25.372FNLS/FVLS	01/93-	Diesel		11995	272	370	06.86-
25.372FNLS/FVLS	01/93-	Diesel		11995	272	370	06.86-
26.372DF/DFL	01/93-	Diesel		11995	272	370	06.86-
26.372DF/DFL	01/93-	Diesel		11995	272	370	06.86-
26.372DFAK	01/93-	Diesel		11995	272	370	06.86-
26.372DFAK	01/93-	Diesel		11995	272	370	06.86-
26.372DFK	01/93-	Diesel		11995	272	370	06.86-
26.372DFK	01/93-	Diesel		11995	272	370	06.86-
26.372DFS	01/93-	Diesel		11995	272	370	06.86-
26.372DFS	01/93-	Diesel		11995	272	370	06.86-
26.372FNL/FNLL	01/93-	Diesel		11995	272	370	06.86-
26.372FNL/FNLL	01/93-	Diesel		11995	272	370	06.86-
26.372FNLS/FVLS	01/93-	Diesel		11995	272	370	06.86-
26.372FNLS/FVLS	01/93-	Diesel		11995	272	370	06.86-
32.372VF	01/93-	Diesel		11995	272	370	06.86-
32.372VF	01/93-	Diesel		11995	272	370	06.86-
32.372VFK	01/93-	Diesel		11995	272	370	06.86-
32.372VFK	01/93-	Diesel		11995	272	370	06.86-
33.372 DF	01/93-	Diesel		11995	272	370	06.86-
33.372 DF	01/93-	Diesel		11995	272	370	06.86-
33.372DFA	01/93-	Diesel		11995	272	370	06.86-
33.372DFA	01/93-	Diesel		11995	272	370	06.86-
33.372DFAK	01/93-	Diesel		11995	272	370	06.86-
33.372DFAK	01/93-	Diesel		11995	272	370	06.86-
33.372DFK	01/93-	Diesel		11995	272	370	06.86-
33.372DFK	01/93-	Diesel		11995	272	370	06.86-
33.372DFS	01/93-	Diesel		11995	272	370	06.86-
33.372DFS	01/93-	Diesel		11995	272	370	06.86-
35.372VF	01/93-	Diesel		11995	272	370	06.86-
35.372VF	01/93-	Diesel		11995	272	370	06.86-
35.372VF	01/93-	Diesel		11995	272	370	06.86-
35.372VF	01/93-	Diesel		11995	272	370	06.86-
35.372VF	01/93-	Diesel		11995	272	370	06.86-
35.372VF	01/93-	Diesel		11995	272	370	06.86-
35.372VF	01/93-	Diesel		11995	272	370	06.86-
35.372VF	01/93-	Diesel		11995	272	370	06.86-
35.372VFK	01/93-	Diesel		11995	272	370	06.86-
35.372VFK	01/93-	Diesel		11995	272	370	06.86-

# LISTA DE APLICACIONES - BUYERS GUIDE

35.372VFK	01/93-	Diesel		11995	272	370	06.86-
35.372VFK	01/93-	Diesel		11995	272	370	06.86-
35.372VFK	01/93-	Diesel		11995	272	370	06.86-
35.372VFK	01/93-	Diesel		11995	272	370	06.86-
35.372VFK	01/93-	Diesel		11995	272	370	06.86-
35.372VFK	01/93-	Diesel		11995	272	370	06.86-
40.372DF	01/93-	Diesel		11995	272	370	06.86-
40.372DF	01/93-	Diesel		11995	272	370	06.86-
40.372DFA	01/93-	Diesel		11995	272	370	06.86-
40.372DFA	01/93-	Diesel		11995	272	370	06.86-
41.372VF	01/93-	Diesel		11995	272	370	06.86-
41.372VF	01/93-	Diesel		11995	272	370	06.86-
41.372VF	01/93-	Diesel		11995	272	370	06.86-
41.372VF	01/93-	Diesel		11995	272	370	06.86-
41.372VFAK	01/93-	Diesel		11995	272	370	06.86-
41.372VFAK	01/93-	Diesel		11995	272	370	06.86-
19.4022FA	01/94-	Diesel		11995	294	400	06.86-
19.4022FA	01/94-	Diesel		11995	294	400	06.86-
19.402F/FL/FLL	01/94-	Diesel		11995	294	400	06.86-
19.402F/FL/FLL	01/94-	Diesel		11995	294	400	06.86-
19.402FAK	01/94-	Diesel		11995	294	400	06.86-
19.402FAK	01/94-	Diesel		11995	294	400	06.86-
19.402FAS	01/94-	Diesel		11995	294	400	06.86-
19.402FAS	01/94-	Diesel		11995	294	400	06.86-
19.402FK	01/94-	Diesel		11995	294	400	06.86-
19.402FK	01/94-	Diesel		11995	294	400	06.86-
24.402FNL/FNLL	01/94-	Diesel		11995	294	400	06.86-
24.402FNL/FNLL	01/94-	Diesel		11995	294	400	06.86-
26.402DF/DFL	01/94-	Diesel		11995	294	400	06.86-
26.402DF/DFL	01/94-	Diesel		11995	294	400	06.86-
26.402DFK/DFLK	01/94-	Diesel		11995	294	400	06.86-
26.402DFK/DFLK	01/94-	Diesel		11995	294	400	06.86-
26.402DFS	01/94-	Diesel		11995	294	400	06.86-
26.402DFS	01/94-	Diesel		11995	294	400	06.86-
26.402FNL/FNLL	01/94-	Diesel		11995	294	400	06.86-
26.402FNL/FNLL	01/94-	Diesel		11995	294	400	06.86-
26.402FNLS/FVLS	01/94-	Diesel		11995	294	400	06.86-
26.402FNLS/FVLS	01/94-	Diesel		11995	294	400	06.86-
32.402VFK	01/94-	Diesel		11995	294	400	06.86-
32.402VFK	01/94-	Diesel		11995	294	400	06.86-
33.402 DF	01/94-	Diesel		11995	294	400	06.86-
33.402 DF	01/94-	Diesel		11995	294	400	06.86-
33.402DFA	01/94-	Diesel		11995	294	400	06.86-
33.402DFA	01/94-	Diesel		11995	294	400	06.86-
33.402DFAK	01/94-	Diesel		11995	294	400	06.86-
33.402DFAK	01/94-	Diesel		11995	294	400	06.86-
33.402DFK	01/94-	Diesel		11995	294	400	06.86-
33.402DFK	01/94-	Diesel		11995	294	400	06.86-
33.402DFS	01/94-	Diesel		11995	294	400	06.86-
33.402DFS	01/94-	Diesel		11995	294	400	06.86-
35.402VF	01/94-	Diesel		11995	294	400	06.86-

# LISTA DE APLICACIONES - BUYERS GUIDE

35.402VF	01/94-	Diesel		11995	294	400	06.86-
35.402VF	01/94-	Diesel		11995	294	400	06.86-
35.402VF	01/94-	Diesel		11995	294	400	06.86-
35.402VF	01/94-	Diesel		11995	294	400	06.86-
35.402VF	01/94-	Diesel		11995	294	400	06.86-
35.402VF	01/94-	Diesel		11995	294	400	06.86-
35.402VF	01/94-	Diesel		11995	294	400	06.86-
35.402VFK	01/94-	Diesel		11995	294	400	06.86-
35.402VFK	01/94-	Diesel		11995	294	400	06.86-
35.402VFK	01/94-	Diesel		11995	294	400	06.86-
35.402VFK	01/94-	Diesel		11995	294	400	06.86-
35.402VFK	01/94-	Diesel		11995	294	400	06.86-
35.402VFK	01/94-	Diesel		11995	294	400	06.86-
35.402VFK	01/94-	Diesel		11995	294	400	06.86-
35.402VFK	01/94-	Diesel		11995	294	400	06.86-
40.402DF	01/95-	Diesel		11995	294	400	06.86-
40.402DF	01/95-	Diesel		11995	294	400	06.86-
40.402DFA	01/95-	Diesel		11995	294	400	06.86-
40.402DFA	01/95-	Diesel		11995	294	400	06.86-
41.4022VF	01/94-	Diesel		11995	294	400	06.86-
41.4022VF	01/94-	Diesel		11995	294	400	06.86-
41.4022VF	01/94-	Diesel		11995	294	400	06.86-
41.4022VF	01/94-	Diesel		11995	294	400	06.86-
19.422F/FL/FLL	01/93-	Diesel		11995	309	420	06.86-
19.422F/FL/FLL	01/93-	Diesel		11995	309	420	06.86-
19.422FA	01/93-	Diesel		11995	309	420	06.86-
19.422FA	01/93-	Diesel		11995	309	420	06.86-
19.422FAK	01/93-	Diesel		11995	309	420	06.86-
19.422FAK	01/93-	Diesel		11995	309	420	06.86-
19.422FAS	01/93-	Diesel		11995	309	420	06.86-
19.422FAS	01/93-	Diesel		11995	309	420	06.86-
19.422FK	01/93-	Diesel		11995	309	420	06.86-
19.422FK	01/93-	Diesel		11995	309	420	06.86-
19.422U/ULL	01/93-	Diesel		11995	309	420	06.86-
19.422U/ULL	01/93-	Diesel		11995	309	420	06.86-
24.422FNL/FNLL	01/93-	Diesel		11995	309	420	06.86-
24.422FNL/FNLL	01/93-	Diesel		11995	309	420	06.86-
26.402FNLS/FVLS	01/93-	Diesel		11995	309	420	06.86-
26.402FNLS/FVLS	01/93-	Diesel		11995	309	420	06.86-
26.422DF/DFL	01/93-	Diesel		11995	309	420	06.86-
26.422DF/DFL	01/93-	Diesel		11995	309	420	06.86-
26.422DFK	01/93-	Diesel		11995	309	420	06.86-
26.422DFK	01/93-	Diesel		11995	309	420	06.86-
26.422DFS	01/93-	Diesel		11995	309	420	06.86-
26.422DFS	01/93-	Diesel		11995	309	420	06.86-
26.422FNL/FNLL	01/93-	Diesel		11995	309	420	06.86-
26.422FNL/FNLL	01/93-	Diesel		11995	309	420	06.86-
32.422VF	01/93-	Diesel		11995	309	420	06.86-
32.422VF	01/93-	Diesel		11995	309	420	06.86-
32.422VFK	01/93-	Diesel		11995	309	420	06.86-
32.422VFK	01/93-	Diesel		11995	309	420	06.86-

# LISTA DE APLICACIONES - BUYERS GUIDE

33.422 DF	01/93-	Diesel		11995	309	420	06.86-
33.422 DF	01/93-	Diesel		11995	309	420	06.86-
33.422DFA	01/93-	Diesel		11995	309	420	06.86-
33.422DFA	01/93-	Diesel		11995	309	420	06.86-
33.422DFAK	01/94-	Diesel		11995	309	420	06.86-
33.422DFAK	01/94-	Diesel		11995	309	420	06.86-
33.422DFK	01/94-	Diesel		11995	309	420	06.86-
33.422DFK	01/94-	Diesel		11995	309	420	06.86-
33.422DFS	01/94-	Diesel		11995	309	420	06.86-
33.422DFS	01/94-	Diesel		11995	309	420	06.86-
35.422VF	01/93-	Diesel		11995	309	420	06.86-
35.422VF	01/93-	Diesel		11995	309	420	06.86-
35.422VF	01/93-	Diesel		11995	309	420	06.86-
35.422VF	01/93-	Diesel		11995	309	420	06.86-
35.422VF	01/93-	Diesel		11995	309	420	06.86-
35.422VF	01/93-	Diesel		11995	309	420	06.86-
35.422VF	01/93-	Diesel		11995	309	420	06.86-
35.422VF	01/93-	Diesel		11995	309	420	06.86-
35.422VF	01/93-	Diesel		11995	309	420	06.86-
35.422VF	01/93-	Diesel		11995	309	420	06.86-
35.422VF	01/93-	Diesel		11995	309	420	06.86-
35.422VFK	01/93-	Diesel		11995	309	420	06.86-
35.422VFK	01/93-	Diesel		11995	309	420	06.86-
35.422VFK	01/93-	Diesel		11995	309	420	06.86-
35.422VFK	01/93-	Diesel		11995	309	420	06.86-
40.422DF	01/93-	Diesel		11995	309	420	06.86-
40.422DF	01/93-	Diesel		11995	309	420	06.86-
40.422DFA	01/93-	Diesel		11995	309	420	06.86-
40.422DFA	01/93-	Diesel		11995	309	420	06.86-
41.422VF	01/93-	Diesel		11995	309	420	06.86-
41.422VF	01/93-	Diesel		11995	309	420	06.86-
41.422VF	01/93-	Diesel		11995	309	420	06.86-
41.422VF	01/93-	Diesel		11995	309	420	06.86-
41.422VFAK	01/93-	Diesel		11995	309	420	06.86-
41.422VFAK	01/93-	Diesel		11995	309	420	06.86-
48.502VFA	01/93-	Diesel		11995	368	500	06.86-
48.502VFA	01/93-	Diesel		11995	368	500	06.86-
48.502VFAK	01/93-	Diesel		11995	368	500	06.86-
48.502VFAK	01/93-	Diesel		11995	368	500	06.86-
27.502 DF/DFS	01/00-	Diesel		18195	368	500	06.86-
27.502 DF/DFS	01/00-	Diesel		18195	368	500	06.86-
27.502 DF/DFS	01/00-	Diesel		18195	368	500	06.86-
27.502 DF/DFS	01/00-	Diesel		18195	368	500	06.86-
27.502 DF/DFS	01/93-	Diesel		18195	368	500	06.86-
27.502 DF/DFS	01/93-	Diesel		18195	368	500	06.86-
27.502 DF/DFS	01/93-	Diesel		18195	368	500	06.86-
27.502 DF/DFS	01/93-	Diesel		18195	368	500	06.86-
48.502VF	01/00-	Diesel		18195	368	500	06.86-
48.502VF	01/00-	Diesel		18195	368	500	06.86-
48.502VF	01/93-	Diesel		18195	368	500	06.86-

# LISTA DE APLICACIONES - BUYERS GUIDE

48.502VF	01/93-	Diesel		18195	368	500	06.86-	■
48.502VF	01/93-	Diesel		18195	368	500	06.86-	■
48.502VF	01/93-	Diesel		18195	368	500	06.86-	■
48.502VF	01/93-	Diesel		18195	368	500	06.86-	■
48.502VF	01/93-	Diesel		18195	368	500	06.86-	■
33.502DFA	01/93-	Diesel		18295	368	500	06.86-	■
33.502DFA	01/93-	Diesel		18295	368	500	06.86-	■
40.502DFA	01/93-	Diesel		18295	368	500	06.86-	■
40.502DFA	01/93-	Diesel		18295	368	500	06.86-	■
<b>F90 06.86-12.97</b>					<b>Platform/Chassis</b>			
19.502 F,19.502 FL,19.502 FLL (D 2840 LF01)	01/93-	Diesel		18273	368	500	02.90-06.96	■
19.502 F,19.502 FL,19.502 FLL (D 2840 LF01)	01/93-	Diesel		18273	368	500	02.90-06.96	■
19.502 F,19.502 FL,19.502 FLL (D 2840 LF04)	01/93-	Diesel		18273	368	500	02.90-06.96	■
19.502 F,19.502 FL,19.502 FLL (D 2840 LF04)	01/93-	Diesel		18273	368	500	02.90-06.96	■
19.502 F,19.502 FL,19.502 FLL (D 2840 LF06)	01/93-	Diesel		18273	368	500	02.90-06.96	■
19.502 F,19.502 FL,19.502 FLL (D 2840 LF06)	01/93-	Diesel		18273	368	500	02.90-06.96	■
24.502 DF (D 2840 LF01)		Diesel		18273	368	500	02.90-12.90	■
24.502 DF (D 2840 LF01)		Diesel		18273	368	500	02.90-12.90	■
26.502 DF (D 2840 LF01)	01/93-	Diesel		18273	368	500	02.90-06.96	■
26.502 DF (D 2840 LF01)	01/93-	Diesel		18273	368	500	02.90-06.96	■
26.502 DF (D 2840 LF04)	01/93-	Diesel		18273	368	500	02.90-06.96	■
26.502 DF (D 2840 LF04)	01/93-	Diesel		18273	368	500	02.90-06.96	■
26.502 DF (D 2840 LF06)	01/93-	Diesel		18273	368	500	02.90-06.96	■
26.502 DF (D 2840 LF06)	01/93-	Diesel		18273	368	500	02.90-06.96	■
26.502 FNL,26.502 FNLL (D 2840 LF01)	01/93-	Diesel		18273	368	500	09.91-06.96	■
26.502 FNL,26.502 FNLL (D 2840 LF01)	01/93-	Diesel		18273	368	500	09.91-06.96	■
26.502 FNL,26.502 FNLL (D 2840 LF04)	01/93-	Diesel		18273	368	500	09.91-06.96	■
26.502 FNL,26.502 FNLL (D 2840 LF04)	01/93-	Diesel		18273	368	500	09.91-06.96	■
26.502 FNL,26.502 FNLL (D 2840 LF06)	01/93-	Diesel		18273	368	500	09.91-06.96	■
26.502 FNL,26.502 FNLL (D 2840 LF06)	01/93-	Diesel		18273	368	500	09.91-06.96	■
33.502 DF (D 2840 LF01)	01/93-	Diesel		18273	368	500	09.91-06.96	■
33.502 DF (D 2840 LF01)	01/93-	Diesel		18273	368	500	09.91-06.96	■
33.502 DF (D 2840 LF04)	01/93-	Diesel		18273	368	500	09.91-06.96	■
33.502 DF (D 2840 LF04)	01/93-	Diesel		18273	368	500	09.91-06.96	■
33.502 DF (D 2840 LF06)	01/93-	Diesel		18273	368	500	09.91-06.96	■
33.502 DF (D 2840 LF06)	01/93-	Diesel		18273	368	500	09.91-06.96	■
<b>F90 06.86-12.97</b>					<b>Truck Tractor</b>			
19.502 FS,19.502 FLS,19.502 FLLS (D 2840 LF01)	01/93-	Diesel		18273	368	500	02.90-06.96	■
19.502 FS,19.502 FLS,19.502 FLLS (D 2840 LF01)	01/93-	Diesel		18273	368	500	02.90-06.96	■
19.502 FS,19.502 FLS,19.502 FLLS (D 2840 LF04)	01/93-	Diesel		18273	368	500	02.90-06.96	■
19.502 FS,19.502 FLS,19.502 FLLS (D 2840 LF04)	01/93-	Diesel		18273	368	500	02.90-06.96	■
19.502 FS,19.502 FLS,19.502 FLLS (D 2840 LF06)	01/93-	Diesel		18273	368	500	02.90-06.96	■
19.502 FS,19.502 FLS,19.502 FLLS (D 2840 LF06)	01/93-	Diesel		18273	368	500	02.90-06.96	■
26.502 DFS,26.502 DFLS (D 2840 LF04)	01/93-	Diesel		18273	368	500	02.90-06.96	■
26.502 DFS,26.502 DFLS (D 2840 LF04)	01/93-	Diesel		18273	368	500	02.90-06.96	■
26.502 DFS,26.502 DFLS (D 2840 LF06)	01/93-	Diesel		18273	368	500	02.90-06.96	■
26.502 DFS,26.502 DFLS (D 2840 LF06)	01/93-	Diesel		18273	368	500	02.90-06.96	■

# LISTA DE APLICACIONES - BUYERS GUIDE

LOW Chassis 01.86-									
24.332U/UL	01/93-	Diesel					01.86-		■
24.332U/UL	01/93-	Diesel					01.86-		■
24.362U/UL	01/93-	Diesel					01.86-		■
24.362U/UL	01/93-	Diesel					01.86-		■
14.272U	01/93-	Diesel			198	269	01.86-		■
14.272U	01/93-	Diesel			198	269	01.86-		■
19.322U/UL	01/93-	Diesel			235	320	01.86-		■
19.322U/UL	01/93-	Diesel			235	320	01.86-		■
26.322U/UL	01/93-	Diesel			235	320	01.86-		■
26.322U/UL	01/93-	Diesel			235	320	01.86-		■
19.372U/UL	01/93-	Diesel			272	370	01.86-		■
19.372U/UL	01/93-	Diesel			272	370	01.86-		■
19.422U/UL	01/93-	Diesel			309	420	01.86-		■
19.422U/UL	01/93-	Diesel			309	420	01.86-		■
26.372U/UL	01/93-	Diesel		11995	272	370	01.86-		■
26.372U/UL	01/93-	Diesel		11995	272	370	01.86-		■
26.422U/UL	01/93-	Diesel		11995	309	420	01.86-		■
26.422U/UL	01/93-	Diesel		11995	309	420	01.86-		■
M 2000 L 04.95-					Platform/Chassis				
15.163 LC, LLC, LLLC, LLLRC, LLRC, LRC (D 0824 LFL 06)		Diesel		4580	114	155	08.95-		■
15.163 LC, LLC, LLLC, LLLRC, LLRC, LRC (D 0824 LFL 06)		Diesel		4580	114	155	08.95-		■
15.163 LC, LLC, LLLC, LLLRC, LLRC, LRC (D 0824 LFL 09)		Diesel		4580	114	155	08.95-		■
15.163 LC, LLC, LLLC, LLLRC, LLRC, LRC (D 0824 LFL 09)		Diesel		4580	114	155	08.95-		■
15.224 LC, LLC, LLLC, LRC, LLRC, LLLRC (D 0826 LFL03)		Diesel		6871	162	220	08.95-		■
15.224 LC, LLC, LLLC, LRC, LLRC, LLLRC (D 0826 LFL03)		Diesel		6871	162	220	08.95-		■
15.224 LC, LLC, LLLC, LRC, LLRC, LLLRC (D 0826 LFL10)		Diesel		6871	162	220	08.95-		■
15.224 LC, LLC, LLLC, LRC, LLRC, LLLRC (D 0826 LFL10)		Diesel		6871	162	220	08.95-		■
18.224, 18.225, LC, LLC, LLLC, LRC, LLRC, LLLRC (D 0826 LFL03)		Diesel		6871	162	220	08.95-		■
18.224, 18.225, LC, LLC, LLLC, LRC, LLRC, LLLRC (D 0826 LFL03)		Diesel		6871	162	220	08.95-		■
18.224, 18.225, LC, LLC, LLLC, LRC, LLRC, LLLRC (D 0826 LFL10)		Diesel		6871	162	220	08.95-		■
18.224, 18.225, LC, LLC, LLLC, LRC, LLRC, LLLRC (D 0826 LFL10)		Diesel		6871	162	220	08.95-		■
18.224, 18.225, LC, LLC, LLLC, LRC, LLRC, LLLRC (D 0836 LFL 02)		Diesel		6871	162	220	08.95-		■
18.224, 18.225, LC, LLC, LLLC, LRC, LLRC, LLLRC (D 0836 LFL 02)		Diesel		6871	162	220	08.95-		■
15.263, 15.264 LC, LLC, LLLC, LRC, LLRC, LLLRC (D 0826 LFL09)		Diesel		6871	191	260	08.95-		■
15.263, 15.264 LC, LLC, LLLC, LRC, LLRC, LLLRC (D 0826 LFL09)		Diesel		6871	191	260	08.95-		■
18.263, 18.264, LC, LLC, LLLC, LRC, LLRC, LLLRC (D 0826 LFL09)		Diesel		6871	191	260	08.95-		■
18.263, 18.264, LC, LLC, LLLC, LRC, LLRC, LLLRC (D 0826 LFL09)		Diesel		6871	191	260	08.95-		■
15.284 LC, LLC, LLLC, LRC, LLRC, LLLRC (D 0836 LF 01)		Diesel		6871	206	280	06.98-		■
15.284 LC, LLC, LLLC, LRC, LLRC, LLLRC (D 0836 LF 01)		Diesel		6871	206	280	06.98-		■
18.284 LC, LLC, LLLC, LRC, LLRC, LLLRC (D 0836 LF 01)		Diesel		6871	206	280	06.98-		■



# LISTA DE APLICACIONES - BUYERS GUIDE

18.284 LC, LLC, LLLC, LRC, LLRC, LLLRC (D 0836 LF 01)	Diesel		6871	206	280	06.98-	■	
M 2000 M 08.95-12.05				Platform/Chassis				
18.224 MC, MLC, MLLC, MRC, MLRC, MLLRC (D 0826 LF15)	Diesel		6871	162	220	08.95-12.05	■	
18.224 MC, MLC, MLLC, MRC, MLRC, MLLRC (D 0826 LF15)	Diesel		6871	162	220	08.95-12.05	■	
18.224 MC, MLC, MLLC, MRC, MLRC, MLLRC (D 0826 LF18)	Diesel		6871	162	220	08.95-12.05	■	
18.224 MC, MLC, MLLC, MRC, MLRC, MLLRC (D 0826 LF18)	Diesel		6871	162	220	08.95-12.05	■	
25.224 MNLC, MNLLC, MNLRC, MNLLRC, MVLC (D 0826 LF15)	Diesel		6871	162	220	08.95-12.05	■	
25.224 MNLC, MNLLC, MNLRC, MNLLRC, MVLC (D 0826 LF15)	Diesel		6871	162	220	08.95-12.05	■	
25.224 MNLC, MNLLC, MNLRC, MNLLRC, MVLC (D 0826 LF18)	Diesel		6871	162	220	08.95-12.05	■	
25.224 MNLC, MNLLC, MNLRC, MNLLRC, MVLC (D 0826 LF18)	Diesel		6871	162	220	08.95-12.05	■	
25.224 MNLC, MNLLC, MNLRC, MNLLRC, MVLC (D 0826 LFL10)	Diesel		6871	162	220	08.95-12.05	■	
25.224 MNLC, MNLLC, MNLRC, MNLLRC, MVLC (D 0826 LFL10)	Diesel		6871	162	220	08.95-12.05	■	
18.264 MC, MLC, MLLC, MRC, MLRC, MLLRC (D 0826 LF17)	Diesel		6871	191	260	08.95-12.05	■	
18.264 MC, MLC, MLLC, MRC, MLRC, MLLRC (D 0826 LF17)	Diesel		6871	191	260	08.95-12.05	■	
25.264 MNLC, MNLLC, MNLRC, MNLLRC, MVLC (D 0826 LF17)	Diesel		6871	191	260	08.95-12.05	■	
25.264 MNLC, MNLLC, MNLRC, MNLLRC, MVLC (D 0826 LF17)	Diesel		6871	191	260	08.95-12.05	■	
18.284 MC, MLC, MLLC, MLRC, MRC, MLLRC (D 0836 LF 01)	Diesel		6871	206	280	06.98-12.05	■	
18.284 MC, MLC, MLLC, MLRC, MRC, MLLRC (D 0836 LF 01)	Diesel		6871	206	280	06.98-12.05	■	
M 2000 M 08.95-12.05				Truck Tractor				
18.224 MLS, MLRS (D 0826 LF15)	Diesel		6871	162	220	08.95-12.05	■	
18.224 MLS, MLRS (D 0826 LF15)	Diesel		6871	162	220	08.95-12.05	■	
18.224 MLS, MLRS (D 0826 LF18)	Diesel		6871	162	220	08.95-12.05	■	
18.224 MLS, MLRS (D 0826 LF18)	Diesel		6871	162	220	08.95-12.05	■	
18.264 MLS, MLRS (D 0826 LF17)	Diesel		6871	191	260	08.95-12.05	■	
18.264 MLS, MLRS (D 0826 LF17)	Diesel		6871	191	260	08.95-12.05	■	
18.284 MLS, MLRS (D 0836 LF 01)	Diesel		6871	206	280	06.98-12.05	■	
18.284 MLS, MLRS (D 0836 LF 01)	Diesel		6871	206	280	06.98-12.05	■	
M90 08.88-12.98								
17.192F/FL	01/93-	Diesel		6895	140	190	08.88-	■
17.192F/FL	01/93-	Diesel		6895	140	190	08.88-	■
17.192FA	01/93-	Diesel		6895	140	190	08.88-	■
17.192FA	01/93-	Diesel		6895	140	190	08.88-	■
17.192FAK	01/93-	Diesel		6895	140	190	08.88-	■
17.192FAK	01/93-	Diesel		6895	140	190	08.88-	■
17.192FS/FLS	01/93-	Diesel		6895	140	190	08.88-	■
17.192FS/FLS	01/93-	Diesel		6895	140	190	08.88-	■
17.232F/FL	01/93-	Diesel		6895	160	218	08.88-	■
17.232F/FL	01/93-	Diesel		6895	160	218	08.88-	■
17.232FA	01/93-	Diesel		6895	160	218	08.88-	■
17.232FA	01/93-	Diesel		6895	160	218	08.88-	■
17.232FAK	01/93-	Diesel		6895	160	218	08.88-	■
17.232FAK	01/93-	Diesel		6895	160	218	08.88-	■
17.232FS/FLS	01/93-	Diesel		6895	160	218	08.88-	■

# LISTA DE APLICACIONES - BUYERS GUIDE

17.232FS/FLS	01/93-	Diesel		6895	160	218	08.88-		■
17.222FA	01/94-	Diesel		6895	162	220	08.88-		■
17.222FA	01/94-	Diesel		6895	162	220	08.88-		■
17.222FAK	01/94-	Diesel		6895	162	220	08.88-		■
17.222FAK	01/94-	Diesel		6895	162	220	08.88-		■
17.192FS/FLS	01/93-	Diesel		6895	169	230	08.88-		■
17.192FS/FLS	01/93-	Diesel		6895	169	230	08.88-		■
17.232F/FL	01/93-	Diesel		6895	169	230	08.88-		■
17.232F/FL	01/93-	Diesel		6895	169	230	08.88-		■
17.232FA	01/93-	Diesel		6895	169	230	08.88-		■
17.232FA	01/93-	Diesel		6895	169	230	08.88-		■
17.232FAK	01/93-	Diesel		6895	169	230	08.88-		■
17.232FAK	01/93-	Diesel		6895	169	230	08.88-		■
17.272FLS	01/93-	Diesel		6895	198	269	08.88-		■
17.272FLS	01/93-	Diesel		6895	198	269	08.88-		■
17.272FLS	01/93-	Diesel		10000	198	269	08.88-		■
17.272FLS	01/93-	Diesel		10000	198	269	08.88-		■
NM 08.87-					Bus				
NM 222, NM 223 (D 0826 LOH 15)		Diesel		6871	162	220	02.96-		■
NM 222, NM 223 (D 0826 LOH 15)		Diesel		6871	162	220	02.96-		■
NM 222, NM 223 (D 0826 LUH 12)		Diesel		6871	162	220	02.96-		■
NM 222, NM 223 (D 0826 LUH 12)		Diesel		6871	162	220	02.96-		■
MERCEDES-BENZ									
ACTROS 04.96-10.03					Concrete Mixer				
2631B (OM 541.920)		Diesel		11946	230	313	04.97-10.02		■
2631B (OM 541.920)		Diesel		11946	230	313	04.97-10.02		■
2631B (OM 541.940)		Diesel		11946	230	313	04.97-10.02		■
2631B (OM 541.940)		Diesel		11946	230	313	04.97-10.02		■
3331 B (OM 541.920)		Diesel		11946	230	313	04.97-10.02		■
3331 B (OM 541.920)		Diesel		11946	230	313	04.97-10.02		■
3331 B (OM 541.940)		Diesel		11946	230	313	04.97-10.02		■
3331 B (OM 541.940)		Diesel		11946	230	313	04.97-10.02		■
2635 B (OM 541.922)		Diesel		11946	260	354	04.97-10.02		■
2635 B (OM 541.922)		Diesel		11946	260	354	04.97-10.02		■
2635 B (OM 541.942)		Diesel		11946	260	354	04.97-10.02		■
2635 B (OM 541.942)		Diesel		11946	260	354	04.97-10.02		■
3335 B (OM 541.922)		Diesel		11946	260	354	04.97-10.02		■
3335 B (OM 541.922)		Diesel		11946	260	354	04.97-10.02		■
3335 B (OM 541.942)		Diesel		11946	260	354	04.97-10.02		■
3335 B (OM 541.942)		Diesel		11946	260	354	04.97-10.02		■
2640 B (OM 541.923)		Diesel		11946	290	394	04.97-10.02		■
2640 B (OM 541.923)		Diesel		11946	290	394	04.97-10.02		■
2640 B (OM 541.944)		Diesel		11946	290	394	04.97-10.02		■
2640 B (OM 541.944)		Diesel		11946	290	394	04.97-10.02		■
3340 B (OM 541.923)		Diesel		11946	290	394	04.97-10.02		■
3340 B (OM 541.923)		Diesel		11946	290	394	04.97-10.02		■
3340 B (OM 541.944)		Diesel		11946	290	394	04.97-10.02		■
3340 B (OM 541.944)		Diesel		11946	290	394	04.97-10.02		■
2643 B (OM 541.925)		Diesel		11946	315	428	04.97-10.02		■
2643 B (OM 541.925)		Diesel		11946	315	428	04.97-10.02		■
2643 B (OM 541.946)		Diesel		11946	315	428	04.97-10.02		■

# LISTA DE APLICACIONES - BUYERS GUIDE

2643 B (OM 541.946)	Diesel	11946	315	428	04.97-10.02	■
<b>ACTROS 04.96-10.03</b>			<b>Dump Truck</b>			
1831AK (OM 541.926)	Diesel	11946	230	313	04.97-10.02	■
1831AK (OM 541.926)	Diesel	11946	230	313	04.97-10.02	■
1831AK (OM 541.941)	Diesel	11946	230	313	04.97-10.02	■
1831AK (OM 541.941)	Diesel	11946	230	313	04.97-10.02	■
1831K (OM 541.920)	Diesel	11946	230	313	04.97-10.02	■
1831K (OM 541.920)	Diesel	11946	230	313	04.97-10.02	■
1831K (OM 541.940)	Diesel	11946	230	313	04.97-10.02	■
1831K (OM 541.940)	Diesel	11946	230	313	04.97-10.02	■
2031 AK (OM 541.926)	Diesel	11946	230	313	09.96-10.02	■
2031 AK (OM 541.926)	Diesel	11946	230	313	09.96-10.02	■
2031 AK (OM 541.941)	Diesel	11946	230	313	09.96-10.02	■
2031 AK (OM 541.941)	Diesel	11946	230	313	09.96-10.02	■
2031 K (OM 541.920)	Diesel	11946	230	313	04.97-10.02	■
2031 K (OM 541.920)	Diesel	11946	230	313	04.97-10.02	■
2031 K (OM 541.940)	Diesel	11946	230	313	04.97-10.02	■
2031 K (OM 541.940)	Diesel	11946	230	313	04.97-10.02	■
2631 K (OM 541.920)	Diesel	11946	230	313	04.97-10.02	■
2631 K (OM 541.920)	Diesel	11946	230	313	04.97-10.02	■
2631 K (OM 541.940)	Diesel	11946	230	313	04.97-10.02	■
2631 K (OM 541.940)	Diesel	11946	230	313	04.97-10.02	■
3331 AK (OM 541.926)	Diesel	11946	230	313	04.97-10.02	■
3331 AK (OM 541.926)	Diesel	11946	230	313	04.97-10.02	■
3331 AK (OM 541.941)	Diesel	11946	230	313	04.97-10.02	■
3331 AK (OM 541.941)	Diesel	11946	230	313	04.97-10.02	■
3331 K (OM 541.920)	Diesel	11946	230	313	04.97-10.02	■
3331 K (OM 541.920)	Diesel	11946	230	313	04.97-10.02	■
3331 K (OM 541.940)	Diesel	11946	230	313	04.97-10.02	■
3331 K (OM 541.940)	Diesel	11946	230	313	04.97-10.02	■
1835 AK (OM 541.927)	Diesel	11946	260	354	04.97-10.02	■
1835 AK (OM 541.927)	Diesel	11946	260	354	04.97-10.02	■
1835 AK (OM 541.943)	Diesel	11946	260	354	04.97-10.02	■
1835 AK (OM 541.943)	Diesel	11946	260	354	04.97-10.02	■
1835 K (OM 541.922)	Diesel	11946	260	354	04.97-10.02	■
1835 K (OM 541.922)	Diesel	11946	260	354	04.97-10.02	■
1835 K (OM 541.942)	Diesel	11946	260	354	04.97-10.02	■
1835 K (OM 541.942)	Diesel	11946	260	354	04.97-10.02	■
2635 K, 2635 LK (OM 541.922)	Diesel	11946	260	354	04.97-10.02	■
2635 K, 2635 LK (OM 541.922)	Diesel	11946	260	354	04.97-10.02	■
2635 K, 2635 LK (OM 541.942)	Diesel	11946	260	354	04.97-10.02	■
2635 K, 2635 LK (OM 541.942)	Diesel	11946	260	354	04.97-10.02	■
3335 K (OM 541.922)	Diesel	11946	260	354	04.97-10.02	■
3335 K (OM 541.922)	Diesel	11946	260	354	04.97-10.02	■
3335 K (OM 541.942)	Diesel	11946	260	354	04.97-10.02	■
3335 K (OM 541.942)	Diesel	11946	260	354	04.97-10.02	■
1840 AK (OM 541.924)	Diesel	11946	290	394	04.97-10.02	■
1840 AK (OM 541.924)	Diesel	11946	290	394	04.97-10.02	■
1840 AK (OM 541.945)	Diesel	11946	290	394	04.97-10.02	■
1840 AK (OM 541.945)	Diesel	11946	290	394	04.97-10.02	■
1840 K (OM 541.923)	Diesel	11946	290	394	04.97-10.02	■

# LISTA DE APLICACIONES - BUYERS GUIDE

1840 K (OM 541.923)	Diesel	11946	290	394	04.97-10.02
1840 K (OM 541.944)	Diesel	11946	290	394	04.97-10.02
1840 K (OM 541.944)	Diesel	11946	290	394	04.97-10.02
2040 AK (OM 541.924)	Diesel	11946	290	394	09.96-10.02
2040 AK (OM 541.924)	Diesel	11946	290	394	09.96-10.02
2040 AK (OM 541.945)	Diesel	11946	290	394	09.96-10.02
2040 AK (OM 541.945)	Diesel	11946	290	394	09.96-10.02
2640 K, 2640 LK (OM 541.923)	Diesel	11946	290	394	04.97-10.02
2640 K, 2640 LK (OM 541.923)	Diesel	11946	290	394	04.97-10.02
2640 K, 2640 LK (OM 541.944)	Diesel	11946	290	394	04.97-10.02
2640 K, 2640 LK (OM 541.944)	Diesel	11946	290	394	04.97-10.02
3340 AK (OM 541.924)	Diesel	11946	290	394	04.97-10.02
3340 AK (OM 541.924)	Diesel	11946	290	394	04.97-10.02
3340 AK (OM 541.945)	Diesel	11946	290	394	04.97-10.02
3340 AK (OM 541.945)	Diesel	11946	290	394	04.97-10.02
3340 K (OM 541.923)	Diesel	11946	290	394	04.97-10.02
3340 K (OM 541.923)	Diesel	11946	290	394	04.97-10.02
3340 K (OM 541.944)	Diesel	11946	290	394	04.97-10.02
3340 K (OM 541.944)	Diesel	11946	290	394	04.97-10.02
1843 AK (OM 541.921)	Diesel	11946	315	428	04.97-10.02
1843 AK (OM 541.921)	Diesel	11946	315	428	04.97-10.02
1843 AK (OM 541.947)	Diesel	11946	315	428	04.97-10.02
1843 AK (OM 541.947)	Diesel	11946	315	428	04.97-10.02
1843 K (OM 541.925)	Diesel	11946	315	428	04.97-10.02
1843 K (OM 541.925)	Diesel	11946	315	428	04.97-10.02
1843 K (OM 541.946)	Diesel	11946	315	428	04.97-10.02
1843 K (OM 541.946)	Diesel	11946	315	428	04.97-10.02
2643 K, 2643 LK (OM 541.925)	Diesel	11946	315	428	04.97-10.02
2643 K, 2643 LK (OM 541.925)	Diesel	11946	315	428	04.97-10.02
2643 K, 2643 LK (OM 541.946)	Diesel	11946	315	428	04.97-10.02
2643 K, 2643 LK (OM 541.946)	Diesel	11946	315	428	04.97-10.02
3343 AK (OM 541.921)	Diesel	11946	315	428	04.97-10.02
3343 AK (OM 541.921)	Diesel	11946	315	428	04.97-10.02
3343 AK (OM 541.947)	Diesel	11946	315	428	04.97-10.02
3343 AK (OM 541.947)	Diesel	11946	315	428	04.97-10.02
3343 K (OM 541.925)	Diesel	11946	315	428	04.97-10.02
3343 K (OM 541.925)	Diesel	11946	315	428	04.97-10.02
3343 K (OM 541.946)	Diesel	11946	315	428	04.97-10.02
3343 K (OM 541.946)	Diesel	11946	315	428	04.97-10.02
1848 AK (OM 542.925)	Diesel	15928	350	476	04.97-10.02
1848 AK (OM 542.925)	Diesel	15928	350	476	04.97-10.02
1848 K (OM 542.921)	Diesel	15928	350	476	04.97-10.02
1848 K (OM 542.921)	Diesel	15928	350	476	04.97-10.02
1848 K (OM 542.940)	Diesel	15928	350	476	04.97-10.02
1848 K (OM 542.940)	Diesel	15928	350	476	04.97-10.02
2648 K, 2648 LK (OM 542.921)	Diesel	15928	350	476	04.97-10.02
2648 K, 2648 LK (OM 542.921)	Diesel	15928	350	476	04.97-10.02
2648 K, 2648 LK (OM 542.940)	Diesel	15928	350	476	04.97-10.02
2648 K, 2648 LK (OM 542.940)	Diesel	15928	350	476	04.97-10.02
3348 AK (OM 542.925)	Diesel	15928	350	476	04.97-10.02
3348 AK (OM 542.925)	Diesel	15928	350	476	04.97-10.02

# LISTA DE APLICACIONES - BUYERS GUIDE

3348 K (OM 542.921)		Diesel		15928	350	476	04.97-10.02	■
3348 K (OM 542.921)		Diesel		15928	350	476	04.97-10.02	■
3348 K (OM 542.940)		Diesel		15928	350	476	04.97-10.02	■
3348 K (OM 542.940)		Diesel		15928	350	476	04.97-10.02	■
2653 K, 2653 LK (OM 542.920)		Diesel		15928	390	530	04.97-10.02	■
2653 K, 2653 LK (OM 542.920)		Diesel		15928	390	530	04.97-10.02	■
2653 K, 2653 LK (OM 542.942)		Diesel		15928	390	530	04.97-10.02	■
2653 K, 2653 LK (OM 542.942)		Diesel		15928	390	530	04.97-10.02	■
2657 K, 2657 LK (OM 542.922)		Diesel		15928	420	571	04.97-10.02	■
2657 K, 2657 LK (OM 542.922)		Diesel		15928	420	571	04.97-10.02	■
2657 K, 2657 LK (OM 542.944)		Diesel		15928	420	571	04.97-10.02	■
2657 K, 2657 LK (OM 542.944)		Diesel		15928	420	571	04.97-10.02	■
<b>ACTROS 04.96-10.03</b>					<b>Platform/Chassis</b>			
1831, 1831 L (OM 541.920)		Diesel		11946	230	313	04.96-10.02	■
1831, 1831 L (OM 541.920)		Diesel		11946	230	313	04.96-10.02	■
2031 (OM 541.920)		Diesel		11946	230	313	04.97-10.02	■
2031 (OM 541.920)		Diesel		11946	230	313	04.97-10.02	■
2031A (OM 541.926)		Diesel		11946	230	313	04.97-10.02	■
2031A (OM 541.926)		Diesel		11946	230	313	04.97-10.02	■
2531, 2531 L (OM 541.920)		Diesel		11946	230	313	09.96-10.02	■
2531, 2531 L (OM 541.920)		Diesel		11946	230	313	09.96-10.02	■
2531, 2531 L (OM 541.940)		Diesel		11946	230	313	09.96-10.02	■
2531, 2531 L (OM 541.940)		Diesel		11946	230	313	09.96-10.02	■
2631, 2631 L (OM 541.920)	01/97-	Diesel		11946	230	313	04.96-10.02	■
2631, 2631 L (OM 541.920)	01/97-	Diesel		11946	230	313	04.96-10.02	■
3331 (OM 541.920)		Diesel		11946	230	313	04.97-10.02	■
3331 (OM 541.920)		Diesel		11946	230	313	04.97-10.02	■
3331 A (OM 541.926)		Diesel		11946	230	313	04.97-10.02	■
3331 A (OM 541.926)		Diesel		11946	230	313	04.97-10.02	■
1835, 1835 L (OM 541.922)		Diesel		11946	260	354	04.96-10.02	■
1835, 1835 L (OM 541.922)		Diesel		11946	260	354	04.96-10.02	■
2035 A (OM 541.927)		Diesel		11946	260	354	04.97-10.02	■
2035 A (OM 541.927)		Diesel		11946	260	354	04.97-10.02	■
2035 A (OM 541.943)		Diesel		11946	260	354	04.97-10.02	■
2035 A (OM 541.943)		Diesel		11946	260	354	04.97-10.02	■
2535 L (OM 541.922)		Diesel		11946	260	354	09.96-10.02	■
2535 L (OM 541.922)		Diesel		11946	260	354	09.96-10.02	■
2535 L (OM 541.942)		Diesel		11946	260	354	09.96-10.02	■
2535 L (OM 541.942)		Diesel		11946	260	354	09.96-10.02	■
2635, 2635 L (OM 541.922)	01/97-	Diesel		11946	260	354	04.96-10.02	■
2635, 2635 L (OM 541.922)	01/97-	Diesel		11946	260	354	04.96-10.02	■
3335 (OM 541.922)		Diesel		11946	260	354	04.97-10.02	■
3335 (OM 541.922)		Diesel		11946	260	354	04.97-10.02	■
1840, 1840 L (OM 541.923)		Diesel		11946	290	394	04.96-10.02	■
1840, 1840 L (OM 541.923)		Diesel		11946	290	394	04.96-10.02	■
2040 (OM 541.923)		Diesel		11946	290	394	09.96-10.02	■
2040 (OM 541.923)		Diesel		11946	290	394	09.96-10.02	■
2540, 2540 L (OM 541.923)		Diesel		11946	290	394	09.96-10.02	■
2540, 2540 L (OM 541.923)		Diesel		11946	290	394	09.96-10.02	■
2540, 2540 L (OM 541.944)		Diesel		11946	290	394	09.96-10.02	■
2540, 2540 L (OM 541.944)		Diesel		11946	290	394	09.96-10.02	■

# LISTA DE APLICACIONES - BUYERS GUIDE

2640, 2640 L (OM 541.923)	01/97-	Diesel		11946	290	394	04.96-10.02	■
2640, 2640 L (OM 541.923)	01/97-	Diesel		11946	290	394	04.96-10.02	■
3340 (OM 541.923)		Diesel		11946	290	394	04.97-10.02	■
3340 (OM 541.923)		Diesel		11946	290	394	04.97-10.02	■
3340 A (OM 541.924)		Diesel		11946	290	394	04.97-10.02	■
3340 A (OM 541.924)		Diesel		11946	290	394	04.97-10.02	■
1843, 1843 L (OM 541.925)		Diesel		11946	315	428	04.96-10.02	■
1843, 1843 L (OM 541.925)		Diesel		11946	315	428	04.96-10.02	■
2543, 2543 L (OM 541.925)		Diesel		11946	315	428	09.96-10.02	■
2543, 2543 L (OM 541.925)		Diesel		11946	315	428	09.96-10.02	■
2543, 2543 L (OM 541.946)		Diesel		11946	315	428	09.96-10.02	■
2543, 2543 L (OM 541.946)		Diesel		11946	315	428	09.96-10.02	■
2643, 2643 L (OM 541.925)	01/97-	Diesel		11946	315	428	04.96-10.02	■
2643, 2643 L (OM 541.925)	01/97-	Diesel		11946	315	428	04.96-10.02	■
3343 (OM 541.925)		Diesel		11946	315	428	04.97-10.02	■
3343 (OM 541.925)		Diesel		11946	315	428	04.97-10.02	■
3346 (OM 541.948)		Diesel		11946	335	456	04.97-10.02	■
3346 (OM 541.948)		Diesel		11946	335	456	04.97-10.02	■
1848, 1848 L (OM 542.921)		Diesel		15928	350	476	04.96-10.02	■
1848, 1848 L (OM 542.921)		Diesel		15928	350	476	04.96-10.02	■
2548, 2548 L (OM 542.921)		Diesel		15928	350	476	09.96-10.02	■
2548, 2548 L (OM 542.921)		Diesel		15928	350	476	09.96-10.02	■
2648, 2648 L (OM 542.921)		Diesel		15928	350	476	04.96-10.02	■
2648, 2648 L (OM 542.921)		Diesel		15928	350	476	04.96-10.02	■
3348 (OM 542.921)		Diesel		15928	350	476	04.97-10.02	■
3348 (OM 542.921)		Diesel		15928	350	476	04.97-10.02	■
1853, 1853 L (OM 542.920)		Diesel		15928	390	530	04.96-10.02	■
1853, 1853 L (OM 542.920)		Diesel		15928	390	530	04.96-10.02	■
2553, 2553 L (OM 542.920)		Diesel		15928	390	530	09.96-10.02	■
2553, 2553 L (OM 542.920)		Diesel		15928	390	530	09.96-10.02	■
2653, 2653 L (OM 542.920)	01/97-	Diesel		15928	390	530	04.96-10.02	■
2653, 2653 L (OM 542.920)	01/97-	Diesel		15928	390	530	04.96-10.02	■
3353 (OM 542.920)		Diesel		15928	390	530	04.97-10.02	■
3353 (OM 542.920)		Diesel		15928	390	530	04.97-10.02	■
3353 AS (OM 542.920)		Diesel		15928	390	530	04.97-10.02	■
3353 AS (OM 542.920)		Diesel		15928	390	530	04.97-10.02	■
3353 AS (OM 542.926)		Diesel		15928	390	530	04.97-10.02	■
3353 AS (OM 542.926)		Diesel		15928	390	530	04.97-10.02	■
3353 AS (OM 542.943)		Diesel		15928	390	530	04.97-10.02	■
3353 AS (OM 542.943)		Diesel		15928	390	530	04.97-10.02	■
1857 L (OM 542.922)		Diesel		15928	420	571	04.97-10.02	■
1857 L (OM 542.922)		Diesel		15928	420	571	04.97-10.02	■
2557 L (OM 542.922)		Diesel		15928	420	571	09.96-10.02	■
2557 L (OM 542.922)		Diesel		15928	420	571	09.96-10.02	■
2657 L (OM 542.922)		Diesel		15928	420	571	04.97-10.02	■
2657 L (OM 542.922)		Diesel		15928	420	571	04.97-10.02	■
3357 (OM 542.922)		Diesel		15928	420	571	04.97-10.02	■
3357 (OM 542.922)		Diesel		15928	420	571	04.97-10.02	■
<b>ACTROS 04.96-10.03</b>					<b>Truck Tractor</b>			
1831 S, 1831 LS (OM 541.920)		Diesel		11946	230	313	04.96-10.02	■
1831 S, 1831 LS (OM 541.920)		Diesel		11946	230	313	04.96-10.02	■

# LISTA DE APLICACIONES - BUYERS GUIDE

1831 S, 1831 LS (OM 541.940)	Diesel	11946	230	313	04.96-10.02
1831 S, 1831 LS (OM 541.940)	Diesel	11946	230	313	04.96-10.02
2031AS (OM 541.926)	Diesel	11946	230	313	04.96-10.02
2031AS (OM 541.926)	Diesel	11946	230	313	04.96-10.02
2031AS (OM 541.941)	Diesel	11946	230	313	04.96-10.02
2031AS (OM 541.941)	Diesel	11946	230	313	04.96-10.02
2031S (OM 541.920)	Diesel	11946	230	313	04.96-10.02
2031S (OM 541.920)	Diesel	11946	230	313	04.96-10.02
2031S (OM 541.940)	Diesel	11946	230	313	04.96-10.02
2031S (OM 541.940)	Diesel	11946	230	313	04.96-10.02
2531 LS (OM 541.920)	Diesel	11946	230	313	09.96-10.02
2531 LS (OM 541.920)	Diesel	11946	230	313	09.96-10.02
2531 LS (OM 541.940)	Diesel	11946	230	313	09.96-10.02
2531 LS (OM 541.940)	Diesel	11946	230	313	09.96-10.02
3331 AS (OM 541.926)	Diesel	11946	230	313	04.97-10.02
3331 AS (OM 541.926)	Diesel	11946	230	313	04.97-10.02
3331 AS (OM 541.941)	Diesel	11946	230	313	04.97-10.02
3331 AS (OM 541.941)	Diesel	11946	230	313	04.97-10.02
3331 S (OM 541.920)	Diesel	11946	230	313	04.97-10.02
3331 S (OM 541.920)	Diesel	11946	230	313	04.97-10.02
3331 S (OM 541.940)	Diesel	11946	230	313	04.97-10.02
3331 S (OM 541.940)	Diesel	11946	230	313	04.97-10.02
1835 S, 1835 LS (OM 541.922)	Diesel	11946	260	354	04.96-10.02
1835 S, 1835 LS (OM 541.922)	Diesel	11946	260	354	04.96-10.02
1835 S, 1835 LS (OM 541.942)	Diesel	11946	260	354	04.96-10.02
1835 S, 1835 LS (OM 541.942)	Diesel	11946	260	354	04.96-10.02
2535 LS (OM 541.922)	Diesel	11946	260	354	09.96-10.02
2535 LS (OM 541.922)	Diesel	11946	260	354	09.96-10.02
2535 LS (OM 541.942)	Diesel	11946	260	354	09.96-10.02
2535 LS (OM 541.942)	Diesel	11946	260	354	09.96-10.02
3335 S (OM 541.922)	Diesel	11946	260	354	04.97-10.02
3335 S (OM 541.922)	Diesel	11946	260	354	04.97-10.02
1840 S, 1840 LS (OM 541.923)	Diesel	11946	290	394	04.96-10.02
1840 S, 1840 LS (OM 541.923)	Diesel	11946	290	394	04.96-10.02
1840 S, 1840 LS (OM 541.944)	Diesel	11946	290	394	04.96-10.02
1840 S, 1840 LS (OM 541.944)	Diesel	11946	290	394	04.96-10.02
2040 AS (OM 541.924)	Diesel	11946	290	394	04.96-10.02
2040 AS (OM 541.924)	Diesel	11946	290	394	04.96-10.02
2040 AS (OM 541.945)	Diesel	11946	290	394	04.96-10.02
2040 AS (OM 541.945)	Diesel	11946	290	394	04.96-10.02
2040 S (OM 541.923)	Diesel	11946	290	394	04.96-10.02
2040 S (OM 541.923)	Diesel	11946	290	394	04.96-10.02
2040 S (OM 541.944)	Diesel	11946	290	394	04.96-10.02
2040 S (OM 541.944)	Diesel	11946	290	394	04.96-10.02
2540 LS (OM 541.923)	Diesel	11946	290	394	09.96-10.02
2540 LS (OM 541.923)	Diesel	11946	290	394	09.96-10.02
2540 LS (OM 541.944)	Diesel	11946	290	394	09.96-10.02
2540 LS (OM 541.944)	Diesel	11946	290	394	09.96-10.02
2640 S, 2640 LS (OM 541.923)	Diesel	11946	290	394	09.96-10.02
2640 S, 2640 LS (OM 541.923)	Diesel	11946	290	394	09.96-10.02
2640 S, 2640 LS (OM 541.944)	Diesel	11946	290	394	09.96-10.02

# LISTA DE APLICACIONES - BUYERS GUIDE

2640 S, 2640 LS (OM 541.944)	Diesel	11946	290	394	09.96-10.02
3340 AS (OM 541.924)	Diesel	11946	290	394	04.97-10.02
3340 AS (OM 541.924)	Diesel	11946	290	394	04.97-10.02
3340 AS (OM 541.945)	Diesel	11946	290	394	04.97-10.02
3340 AS (OM 541.945)	Diesel	11946	290	394	04.97-10.02
3340 S (OM 541.923)	Diesel	11946	290	394	04.97-10.02
3340 S (OM 541.923)	Diesel	11946	290	394	04.97-10.02
1843 S, 1843 LS (OM 541.925)	Diesel	11946	315	428	04.96-10.02
1843 S, 1843 LS (OM 541.925)	Diesel	11946	315	428	04.96-10.02
1843 S, 1843 LS (OM 541.946)	Diesel	11946	315	428	04.96-10.02
1843 S, 1843 LS (OM 541.946)	Diesel	11946	315	428	04.96-10.02
2543 LS (OM 541.925)	Diesel	11946	315	428	09.96-10.02
2543 LS (OM 541.925)	Diesel	11946	315	428	09.96-10.02
2543 LS (OM 541.946)	Diesel	11946	315	428	09.96-10.02
2543 LS (OM 541.946)	Diesel	11946	315	428	09.96-10.02
2643 S, 2643 LS (OM 541.925)	Diesel	11946	315	428	04.97-10.02
2643 S, 2643 LS (OM 541.925)	Diesel	11946	315	428	04.97-10.02
2643 S, 2643 LS (OM 541.946)	Diesel	11946	315	428	04.97-10.02
2643 S, 2643 LS (OM 541.946)	Diesel	11946	315	428	04.97-10.02
3343 AS (OM 541.921)	Diesel	11946	315	428	04.97-10.02
3343 AS (OM 541.921)	Diesel	11946	315	428	04.97-10.02
3343 AS (OM 541.947)	Diesel	11946	315	428	04.97-10.02
3343 AS (OM 541.947)	Diesel	11946	315	428	04.97-10.02
3343 S (OM 541.925)	Diesel	11946	315	428	04.97-10.02
3343 S (OM 541.925)	Diesel	11946	315	428	04.97-10.02
3343 S (OM 541.946)	Diesel	11946	315	428	04.97-10.02
3343 S (OM 541.946)	Diesel	11946	315	428	04.97-10.02
1848 S, 1848 LS (OM 542.921)	Diesel	15928	350	476	04.96-10.02
1848 S, 1848 LS (OM 542.921)	Diesel	15928	350	476	04.96-10.02
1848 S, 1848 LS (OM 542.940)	Diesel	15928	350	476	04.96-10.02
1848 S, 1848 LS (OM 542.940)	Diesel	15928	350	476	04.96-10.02
2548 LS (OM 542.921)	Diesel	15928	350	476	09.96-10.02
2548 LS (OM 542.921)	Diesel	15928	350	476	09.96-10.02
2548 LS (OM 542.940)	Diesel	15928	350	476	09.96-10.02
2548 LS (OM 542.940)	Diesel	15928	350	476	09.96-10.02
2648 S, 2648 LS (OM 542.921)	Diesel	15928	350	476	09.96-10.02
2648 S, 2648 LS (OM 542.921)	Diesel	15928	350	476	09.96-10.02
2648 S, 2648 LS (OM 542.940)	Diesel	15928	350	476	09.96-10.02
2648 S, 2648 LS (OM 542.940)	Diesel	15928	350	476	09.96-10.02
3348 AS (OM 542.925)	Diesel	15928	350	476	04.97-10.02
3348 AS (OM 542.925)	Diesel	15928	350	476	04.97-10.02
3348 S (OM 542.921)	Diesel	15928	350	476	04.97-10.02
3348 S (OM 542.921)	Diesel	15928	350	476	04.97-10.02
1853 S, 1853 LS (OM 542.920)	Diesel	15928	390	530	04.96-10.02
1853 S, 1853 LS (OM 542.920)	Diesel	15928	390	530	04.96-10.02
1853 S, 1853 LS (OM 542.942)	Diesel	15928	390	530	04.96-10.02
1853 S, 1853 LS (OM 542.942)	Diesel	15928	390	530	04.96-10.02
2053 S (OM 542.920)	Diesel	15928	390	530	04.96-10.02
2053 S (OM 542.920)	Diesel	15928	390	530	04.96-10.02
2053 S (OM 542.942)	Diesel	15928	390	530	04.96-10.02
2053 S (OM 542.942)	Diesel	15928	390	530	04.96-10.02



# LISTA DE APLICACIONES - BUYERS GUIDE

2553 LS (OM 542.920)	Diesel	15928	390	530	09.96-10.02	■
2553 LS (OM 542.920)	Diesel	15928	390	530	09.96-10.02	■
2553 LS (OM 542.942)	Diesel	15928	390	530	09.96-10.02	■
2553 LS (OM 542.942)	Diesel	15928	390	530	09.96-10.02	■
2653 S, 2653 LS (OM 542.920)	Diesel	15928	390	530	09.96-10.02	■
2653 S, 2653 LS (OM 542.920)	Diesel	15928	390	530	09.96-10.02	■
2653 S, 2653 LS (OM 542.942)	Diesel	15928	390	530	09.96-10.02	■
2653 S, 2653 LS (OM 542.942)	Diesel	15928	390	530	09.96-10.02	■
3353 S (OM 542.920)	Diesel	15928	390	530	04.97-10.02	■
3353 S (OM 542.920)	Diesel	15928	390	530	04.97-10.02	■
3353 S (OM 542.942)	Diesel	15928	390	530	04.97-10.02	■
3353 S (OM 542.942)	Diesel	15928	390	530	04.97-10.02	■
1857 LS (OM 542.922)	Diesel	15928	420	571	04.97-10.02	■
1857 LS (OM 542.922)	Diesel	15928	420	571	04.97-10.02	■
1857 LS (OM 542.944)	Diesel	15928	420	571	04.97-10.02	■
1857 LS (OM 542.944)	Diesel	15928	420	571	04.97-10.02	■
2657 S, 2657 LS (OM 542.922)	Diesel	15928	420	571	04.97-10.02	■
2657 S, 2657 LS (OM 542.922)	Diesel	15928	420	571	04.97-10.02	■
2657 S, 2657 LS (OM 542.944)	Diesel	15928	420	571	04.97-10.02	■
2657 S, 2657 LS (OM 542.944)	Diesel	15928	420	571	04.97-10.02	■
3357 S (OM 542.922)	Diesel	15928	420	571	04.97-10.02	■
3357 S (OM 542.922)	Diesel	15928	420	571	04.97-10.02	■
3357 S (OM 542.944)	Diesel	15928	420	571	04.97-10.02	■
3357 S (OM 542.944)	Diesel	15928	420	571	04.97-10.02	■
<b>ACTROS MP2 / MP3 10.02-</b>				<b>Dump Truck</b>		
1832 AK (OM 541.940)	Diesel	11946	235	320	04.03-	■
1832 AK (OM 541.940)	Diesel	11946	235	320	04.03-	■
1832 AK (OM 541.971)	Diesel	11946	235	320	04.03-	■
1832 AK (OM 541.971)	Diesel	11946	235	320	04.03-	■
1832 AK (OM 541.997)	Diesel	11946	235	320	04.03-	■
1832 AK (OM 541.997)	Diesel	11946	235	320	04.03-	■
1832 K (OM 541.940)	Diesel	11946	235	320	04.03-	■
1832 K (OM 541.940)	Diesel	11946	235	320	04.03-	■
1832 K (OM 541.970)	Diesel	11946	235	320	04.03-	■
1832 K (OM 541.970)	Diesel	11946	235	320	04.03-	■
1832 K (OM 541.996)	Diesel	11946	235	320	04.03-	■
1832 K (OM 541.996)	Diesel	11946	235	320	04.03-	■
2632 K, LK (OM 541.940)	Diesel	11946	235	320	04.03-	■
2632 K, LK (OM 541.940)	Diesel	11946	235	320	04.03-	■
2632 K, LK (OM 541.970)	Diesel	11946	235	320	04.03-	■
2632 K, LK (OM 541.970)	Diesel	11946	235	320	04.03-	■
2632 K, LK (OM 541.996)	Diesel	11946	235	320	04.03-	■
2632 K, LK (OM 541.996)	Diesel	11946	235	320	04.03-	■
1836 AK (OM 541.942)	Diesel	11946	265	360	04.03-	■
1836 AK (OM 541.942)	Diesel	11946	265	360	04.03-	■
1836 AK (OM 541.999)	Diesel	11946	265	360	04.03-	■
1836 AK (OM 541.999)	Diesel	11946	265	360	04.03-	■
1836 K (OM 541.942)	Diesel	11946	265	360	04.03-	■
1836 K (OM 541.942)	Diesel	11946	265	360	04.03-	■
1836 K (OM 541.972)	Diesel	11946	265	360	04.03-	■
1836 K (OM 541.972)	Diesel	11946	265	360	04.03-	■

# LISTA DE APLICACIONES - BUYERS GUIDE

1836 K (OM 541.998)	Diesel	11946	265	360	04.03-
1836 K (OM 541.998)	Diesel	11946	265	360	04.03-
2636 K, LK (OM 541.942)	Diesel	11946	265	360	04.03-
2636 K, LK (OM 541.942)	Diesel	11946	265	360	04.03-
2636 K, LK (OM 541.972)	Diesel	11946	265	360	04.03-
2636 K, LK (OM 541.972)	Diesel	11946	265	360	04.03-
2636 K, LK (OM 541.998)	Diesel	11946	265	360	04.03-
2636 K, LK (OM 541.998)	Diesel	11946	265	360	04.03-
1841 K (OM 541.944)	Diesel	11946	300	408	04.03-
1841 K (OM 541.944)	Diesel	11946	300	408	04.03-
1841 K (OM 541.974)	Diesel	11946	300	408	04.03-
1841 K (OM 541.974)	Diesel	11946	300	408	04.03-
1841 K (OM 541.990)	Diesel	11946	300	408	04.03-
1841 K (OM 541.990)	Diesel	11946	300	408	04.03-
1841 L, LL (OM 541.944)	Diesel	11946	300	408	04.03-
1841 L, LL (OM 541.944)	Diesel	11946	300	408	04.03-
1841 L, LL (OM 541.974)	Diesel	11946	300	408	04.03-
1841 L, LL (OM 541.974)	Diesel	11946	300	408	04.03-
2641 K, LK (OM 541.944)	Diesel	11946	300	408	04.03-
2641 K, LK (OM 541.944)	Diesel	11946	300	408	04.03-
2641 K, LK (OM 541.974)	Diesel	11946	300	408	04.03-
2641 K, LK (OM 541.974)	Diesel	11946	300	408	04.03-
2641 K, LK (OM 541.990)	Diesel	11946	300	408	04.03-
2641 K, LK (OM 541.990)	Diesel	11946	300	408	04.03-
1844 AK (OM 541.921)	Diesel	11946	315	428	04.03-
1844 AK (OM 541.921)	Diesel	11946	315	428	04.03-
1844 AK (OM 541.946)	Diesel	11946	315	428	04.03-
1844 AK (OM 541.946)	Diesel	11946	315	428	04.03-
1844 AK (OM 541.947)	Diesel	11946	315	428	04.03-
1844 AK (OM 541.947)	Diesel	11946	315	428	04.03-
1844 AK (OM 541.993)	Diesel	11946	315	428	04.03-
1844 AK (OM 541.993)	Diesel	11946	315	428	04.03-
1844 K (OM 541.925)	Diesel	11946	315	428	04.03-
1844 K (OM 541.925)	Diesel	11946	315	428	04.03-
1844 K (OM 541.946)	Diesel	11946	315	428	04.03-
1844 K (OM 541.946)	Diesel	11946	315	428	04.03-
1844 K (OM 541.976)	Diesel	11946	315	428	04.03-
1844 K (OM 541.976)	Diesel	11946	315	428	04.03-
1844 K (OM 541.992)	Diesel	11946	315	428	04.03-
1844 K (OM 541.992)	Diesel	11946	315	428	04.03-
2644 K, LK (OM 541.946)	Diesel	11946	320	435	04.03-
2644 K, LK (OM 541.946)	Diesel	11946	320	435	04.03-
2644 K, LK (OM 541.976)	Diesel	11946	320	435	04.03-
2644 K, LK (OM 541.976)	Diesel	11946	320	435	04.03-
2644 K, LK (OM 541.992)	Diesel	11946	320	435	04.03-
2644 K, LK (OM 541.992)	Diesel	11946	320	435	04.03-
1846 AK (OM 541.948)	Diesel	11946	335	456	04.03-
1846 AK (OM 541.948)	Diesel	11946	335	456	04.03-
1846 AK (OM 541.949)	Diesel	11946	335	456	04.03-
1846 AK (OM 541.949)	Diesel	11946	335	456	04.03-
1846 AK (OM 541.981)	Diesel	11946	335	456	04.03-

# LISTA DE APLICACIONES - BUYERS GUIDE

1846 AK (OM 541.981)	Diesel	11946	335	456	04.03-	■
1846 AK (OM 541.995)	Diesel	11946	335	456	04.03-	■
1846 AK (OM 541.995)	Diesel	11946	335	456	04.03-	■
1846 K (OM 541.948)	Diesel	11946	335	456	04.03-	■
1846 K (OM 541.948)	Diesel	11946	335	456	04.03-	■
1846 K (OM 541.980)	Diesel	11946	335	456	04.03-	■
1846 K (OM 541.980)	Diesel	11946	335	456	04.03-	■
1846 K (OM 541.994)	Diesel	11946	335	456	04.03-	■
1846 K (OM 541.994)	Diesel	11946	335	456	04.03-	■
2646 K, LK (OM 541.948)	Diesel	11946	335	456	04.03-	■
2646 K, LK (OM 541.948)	Diesel	11946	335	456	04.03-	■
2646 K, LK (OM 541.980)	Diesel	11946	335	456	04.03-	■
2646 K, LK (OM 541.980)	Diesel	11946	335	456	04.03-	■
2646 K, LK (OM 541.994)	Diesel	11946	335	456	04.03-	■
2646 K, LK (OM 541.994)	Diesel	11946	335	456	04.03-	■
1850, 1851 K (OM 542.940)	Diesel	15928	370	503	04.03-	■
1850, 1851 K (OM 542.940)	Diesel	15928	370	503	04.03-	■
1850, 1851 K (OM 542.960)	Diesel	15928	370	503	04.03-	■
1850, 1851 K (OM 542.960)	Diesel	15928	370	503	04.03-	■
1850 AK, 1851 AK (OM 542.940)	Diesel	15928	370	503	04.03-	■
1850 AK, 1851 AK (OM 542.940)	Diesel	15928	370	503	04.03-	■
1850 AK, 1851 AK (OM 542.941)	Diesel	15928	370	503	04.03-	■
1850 AK, 1851 AK (OM 542.941)	Diesel	15928	370	503	04.03-	■
1850 AK, 1851 AK (OM 542.960)	Diesel	15928	370	503	04.03-	■
1850 AK, 1851 AK (OM 542.960)	Diesel	15928	370	503	04.03-	■
1850 AK, 1851 AK (OM 542.961)	Diesel	15928	370	503	04.03-	■
1850 AK, 1851 AK (OM 542.961)	Diesel	15928	370	503	04.03-	■
2650 K, 2651 K, LK (OM 542.940)	Diesel	15928	370	503	04.03-	■
2650 K, 2651 K, LK (OM 542.940)	Diesel	15928	370	503	04.03-	■
2650 K, 2651 K, LK (OM 542.960)	Diesel	15928	370	503	04.03-	■
2650 K, 2651 K, LK (OM 542.960)	Diesel	15928	370	503	04.03-	■
2654 K, LK, 2655 K, LK (OM 542.942)	Diesel	15928	395	537	04.03-	■
2654 K, LK, 2655 K, LK (OM 542.942)	Diesel	15928	395	537	04.03-	■
2654 K, LK, 2655 K, LK (OM 542.962)	Diesel	15928	395	537	04.03-	■
2654 K, LK, 2655 K, LK (OM 542.962)	Diesel	15928	395	537	04.03-	■
2658 K, LK (OM 542.944)	Diesel	15928	425	578	04.03-	■
2658 K, LK (OM 542.944)	Diesel	15928	425	578	04.03-	■
<b>ACTROS MP2 / MP3 10.02-</b>				<b>Platform/Chassis</b>		
1832, L, LL (OM 541.940)	Diesel	11946	235	320	04.03-	■
1832, L, LL (OM 541.940)	Diesel	11946	235	320	04.03-	■
1832, L, LL (OM 541.970)	Diesel	11946	235	320	04.03-	■
1832, L, LL (OM 541.970)	Diesel	11946	235	320	04.03-	■
2632, L, LL (OM 541.940)	Diesel	11946	235	320	04.03-	■
2632, L, LL (OM 541.940)	Diesel	11946	235	320	04.03-	■
2632, L, LL (OM 541.970)	Diesel	11946	235	320	04.03-	■
2632, L, LL (OM 541.970)	Diesel	11946	235	320	04.03-	■
2632, L, LL (OM 541.996)	Diesel	11946	235	320	04.03-	■
2632, L, LL (OM 541.996)	Diesel	11946	235	320	04.03-	■
1836, L, LL (OM 541.942)	Diesel	11946	265	360	04.03-	■
1836, L, LL (OM 541.942)	Diesel	11946	265	360	04.03-	■
2636, L, LL (OM 541.942)	Diesel	11946	265	360	04.03-	■

# LISTA DE APLICACIONES - BUYERS GUIDE

2636, L, LL (OM 541.942)	Diesel	11946	265	360	04.03-
2636, L, LL (OM 541.972)	Diesel	11946	265	360	04.03-
2636, L, LL (OM 541.972)	Diesel	11946	265	360	04.03-
2636, L, LL (OM 541.998)	Diesel	11946	265	360	04.03-
2636, L, LL (OM 541.998)	Diesel	11946	265	360	04.03-
1841, L, LL (OM 541.944)	Diesel	11946	300	408	04.03-
1841, L, LL (OM 541.944)	Diesel	11946	300	408	04.03-
1841, L, LL (OM 541.974)	Diesel	11946	300	408	04.03-
1841, L, LL (OM 541.974)	Diesel	11946	300	408	04.03-
2641, L, LL (OM 541.944)	Diesel	11946	300	408	04.03-
2641, L, LL (OM 541.944)	Diesel	11946	300	408	04.03-
2641, L, LL (OM 541.974)	Diesel	11946	300	408	04.03-
2641, L, LL (OM 541.974)	Diesel	11946	300	408	04.03-
2641, L, LL (OM 541.990)	Diesel	11946	300	408	04.03-
2641, L, LL (OM 541.990)	Diesel	11946	300	408	04.03-
1844, L, LL (OM 541.946)	Diesel	11946	320	435	04.03-
1844, L, LL (OM 541.946)	Diesel	11946	320	435	04.03-
1844, L, LL (OM 541.976)	Diesel	11946	320	435	04.03-
1844, L, LL (OM 541.976)	Diesel	11946	320	435	04.03-
2644, L, LL (OM 541.946)	Diesel	11946	320	435	04.03-
2644, L, LL (OM 541.946)	Diesel	11946	320	435	04.03-
2644, L, LL (OM 541.976)	Diesel	11946	320	435	04.03-
2644, L, LL (OM 541.976)	Diesel	11946	320	435	04.03-
2644, L, LL (OM 541.976)	Diesel	11946	320	435	04.03-
2644, L, LL (OM 541.992)	Diesel	11946	320	435	04.03-
2644, L, LL (OM 541.992)	Diesel	11946	320	435	04.03-
1846, L, LL (OM 541.948)	Diesel	11946	335	456	04.03-
1846, L, LL (OM 541.948)	Diesel	11946	335	456	04.03-
1846, L, LL (OM 541.980)	Diesel	11946	335	456	04.03-
1846, L, LL (OM 541.980)	Diesel	11946	335	456	04.03-
2646, L, LL (OM 541.948)	Diesel	11946	335	456	04.03-
2646, L, LL (OM 541.948)	Diesel	11946	335	456	04.03-
2646, L, LL (OM 541.980)	Diesel	11946	335	456	04.03-
2646, L, LL (OM 541.980)	Diesel	11946	335	456	04.03-
2646, L, LL (OM 541.994)	Diesel	11946	335	456	04.03-
2646, L, LL (OM 541.994)	Diesel	11946	335	456	04.03-
1850, 1851, L, LL (OM 542.940)	Diesel	15928	370	503	04.03-
1850, 1851, L, LL (OM 542.940)	Diesel	15928	370	503	04.03-
1850, 1851, L, LL (OM 542.960)	Diesel	15928	370	503	04.03-
1850, 1851, L, LL (OM 542.960)	Diesel	15928	370	503	04.03-
2650, L, 2651, L, LL (OM 542.940)	Diesel	15928	370	503	04.03-
2650, L, 2651, L, LL (OM 542.940)	Diesel	15928	370	503	04.03-
1854, L (OM 542.942)	Diesel	15928	395	537	04.03-
1854, L (OM 542.942)	Diesel	15928	395	537	04.03-
1854, L (OM 542.962)	Diesel	15928	395	537	04.03-
1854, L (OM 542.962)	Diesel	15928	395	537	04.03-
2654, L, 2655, L, LL (OM 542.942)	Diesel	15928	395	537	04.03-
2654, L, 2655, L, LL (OM 542.942)	Diesel	15928	395	537	04.03-
2654, L, 2655, L, LL (OM 542.962)	Diesel	15928	395	537	04.03-
2654, L, 2655, L, LL (OM 542.962)	Diesel	15928	395	537	04.03-
1858, L (OM 542.944)	Diesel	15928	425	578	04.03-
1858, L (OM 542.944)	Diesel	15928	425	578	04.03-

# LISTA DE APLICACIONES - BUYERS GUIDE

2658 L (OM 542.944)	Diesel	15928	425	578	04.03-	■
2658 L (OM 542.944)	Diesel	15928	425	578	04.03-	■
<b>ACTROS MP2 / MP3 10.02-</b>			<b>Truck Tractor</b>			
1832, LS, LLS (OM 541.940)	Diesel	11946	235	320	04.03-	■
1832, LS, LLS (OM 541.940)	Diesel	11946	235	320	04.03-	■
1832, LS, LLS (OM 541.970)	Diesel	11946	235	320	04.03-	■
1832, LS, LLS (OM 541.970)	Diesel	11946	235	320	04.03-	■
2632 LS (OM 541.940)	Diesel	11946	235	320	04.03-	■
2632 LS (OM 541.940)	Diesel	11946	235	320	04.03-	■
2632 LS (OM 541.970)	Diesel	11946	235	320	04.03-	■
2632 LS (OM 541.970)	Diesel	11946	235	320	04.03-	■
2632 LS (OM 541.996)	Diesel	11946	235	320	04.03-	■
2632 LS (OM 541.996)	Diesel	11946	235	320	04.03-	■
1836 LS, LLS (OM 541.942)	Diesel	11946	265	360	04.03-	■
1836 LS, LLS (OM 541.942)	Diesel	11946	265	360	04.03-	■
2636 LS (OM 541.942)	Diesel	11946	265	360	04.03-	■
2636 LS (OM 541.942)	Diesel	11946	265	360	04.03-	■
2636 LS (OM 541.972)	Diesel	11946	265	360	04.03-	■
2636 LS (OM 541.972)	Diesel	11946	265	360	04.03-	■
2636 LS (OM 541.998)	Diesel	11946	265	360	04.03-	■
2636 LS (OM 541.998)	Diesel	11946	265	360	04.03-	■
1841 LS, LLS (OM 541.944)	Diesel	11946	300	408	04.03-	■
1841 LS, LLS (OM 541.944)	Diesel	11946	300	408	04.03-	■
1841 LS, LLS (OM 541.974)	Diesel	11946	300	408	04.03-	■
1841 LS, LLS (OM 541.974)	Diesel	11946	300	408	04.03-	■
2641 S, LS (OM 541.944)	Diesel	11946	300	408	04.03-	■
2641 S, LS (OM 541.944)	Diesel	11946	300	408	04.03-	■
2641 S, LS (OM 541.974)	Diesel	11946	300	408	04.03-	■
2641 S, LS (OM 541.974)	Diesel	11946	300	408	04.03-	■
2641 S, LS (OM 541.990)	Diesel	11946	300	408	04.03-	■
2641 S, LS (OM 541.990)	Diesel	11946	300	408	04.03-	■
2644 S, LS (OM 541.925)	Diesel	11946	315	428	04.03-	■
2644 S, LS (OM 541.925)	Diesel	11946	315	428	04.03-	■
2644 S, LS (OM 541.946)	Diesel	11946	315	428	04.03-	■
2644 S, LS (OM 541.946)	Diesel	11946	315	428	04.03-	■
2644 S, LS (OM 541.976)	Diesel	11946	315	428	04.03-	■
2644 S, LS (OM 541.976)	Diesel	11946	315	428	04.03-	■
2644 S, LS (OM 541.992)	Diesel	11946	315	428	04.03-	■
2644 S, LS (OM 541.992)	Diesel	11946	315	428	04.03-	■
1844 LS, LLS (OM 541.946)	Diesel	11946	320	435	04.03-	■
1844 LS, LLS (OM 541.946)	Diesel	11946	320	435	04.03-	■
1844 LS, LLS (OM 541.976)	Diesel	11946	320	435	04.03-	■
1844 LS, LLS (OM 541.976)	Diesel	11946	320	435	04.03-	■
1846 LS, LLS (OM 541.948)	Diesel	11946	335	456	04.03-	■
1846 LS, LLS (OM 541.948)	Diesel	11946	335	456	04.03-	■
1846 LS, LLS (OM 541.980)	Diesel	11946	335	456	04.03-	■
1846 LS, LLS (OM 541.980)	Diesel	11946	335	456	04.03-	■
2646 S, LS (OM 541.948)	Diesel	11946	335	456	04.03-	■
2646 S, LS (OM 541.948)	Diesel	11946	335	456	04.03-	■
2646 S, LS (OM 541.980)	Diesel	11946	335	456	04.03-	■
2646 S, LS (OM 541.980)	Diesel	11946	335	456	04.03-	■

# LISTA DE APLICACIONES - BUYERS GUIDE

2646 S, LS (OM 541.994)	Diesel	11946	335	456	04.03-	■
2646 S, LS (OM 541.994)	Diesel	11946	335	456	04.03-	■
1850, 1851 LS, LLS (OM 542.940)	Diesel	15928	370	503	04.03-	■
1850, 1851 LS, LLS (OM 542.940)	Diesel	15928	370	503	04.03-	■
1850, 1851 LS, LLS (OM 542.960)	Diesel	15928	370	503	04.03-	■
1850, 1851 LS, LLS (OM 542.960)	Diesel	15928	370	503	04.03-	■
2650 S, LS (OM 542.940)	Diesel	15928	370	503	04.03-	■
2650 S, LS (OM 542.940)	Diesel	15928	370	503	04.03-	■
2654 S, LS (OM 542.920)	Diesel	15928	390	530	04.03-	■
2654 S, LS (OM 542.920)	Diesel	15928	390	530	04.03-	■
2654 S, LS (OM 542.942)	Diesel	15928	390	530	04.03-	■
2654 S, LS (OM 542.942)	Diesel	15928	390	530	04.03-	■
1854 LS (OM 542.942)	Diesel	15928	395	537	04.03-	■
1854 LS (OM 542.942)	Diesel	15928	395	537	04.03-	■
1858 LS (OM 542.944)	Diesel	15928	425	578	10.02-	■
1858 LS (OM 542.944)	Diesel	15928	425	578	10.02-	■
2658 LS (OM 542.944)	Diesel	15928	425	578	04.03-	■
2658 LS (OM 542.944)	Diesel	15928	425	578	04.03-	■
<b>ATEGO 01.98-10.04</b>				<b>Concrete Mixer</b>		
2628B (OM 906.921)	Diesel	6374	205	279	04.98-10.04	■
2628B (OM 906.921)	Diesel	6374	205	279	04.98-10.04	■
<b>ATEGO 01.98-10.04</b>				<b>Dump Truck</b>		
1823 AK (OM 906.922)	Diesel	6374	170	231	04.98-10.04	■
1823 AK (OM 906.922)	Diesel	6374	170	231	04.98-10.04	■
1823 K (OM 906.920)	Diesel	6374	170	231	04.98-10.04	■
1823 K (OM 906.920)	Diesel	6374	170	231	04.98-10.04	■
1828 AK (OM 906.923)	Diesel	6374	205	279	04.98-10.04	■
1828 AK (OM 906.923)	Diesel	6374	205	279	04.98-10.04	■
1828 K (OM 906.921)	Diesel	6374	205	279	04.98-10.04	■
1828 K (OM 906.921)	Diesel	6374	205	279	04.98-10.04	■
2628K (OM 906.921)	Diesel	6374	205	279	04.98-10.04	■
2628K (OM 906.921)	Diesel	6374	205	279	04.98-10.04	■
<b>ATEGO 01.98-10.04</b>				<b>Platform/Chassis</b>		
1823, 1823 L (OM 906.920)	Diesel	6374	170	231	01.98-10.04	■
1823, 1823 L (OM 906.920)	Diesel	6374	170	231	01.98-10.04	■
1823, 1823 L (OM 906.925)	Diesel	6374	170	231	01.98-10.04	■
1823, 1823 L (OM 906.925)	Diesel	6374	170	231	01.98-10.04	■
2523 L (OM 906.920)	Diesel	6374	170	231	04.98-10.04	■
2523 L (OM 906.920)	Diesel	6374	170	231	04.98-10.04	■
1828, 1828 L (OM 906.921)	Diesel	6374	205	279	04.98-10.04	■
1828, 1828 L (OM 906.921)	Diesel	6374	205	279	04.98-10.04	■
1828, 1828 L (OM 906.926)	Diesel	6374	205	279	04.98-10.04	■
1828, 1828 L (OM 906.926)	Diesel	6374	205	279	04.98-10.04	■
1828 A (OM 906.923)	Diesel	6374	205	279	04.98-10.04	■
1828 A (OM 906.923)	Diesel	6374	205	279	04.98-10.04	■
2528 L (OM 906.921)	Diesel	6374	205	279	04.98-10.04	■
2528 L (OM 906.921)	Diesel	6374	205	279	04.98-10.04	■
2528 L (OM 906.926)	Diesel	6374	205	279	04.98-10.04	■
2528 L (OM 906.926)	Diesel	6374	205	279	04.98-10.04	■
2628 (OM 906.921)	Diesel	6374	205	279	04.98-10.04	■

# LISTA DE APLICACIONES - BUYERS GUIDE

2628 (OM 906.921)		Diesel		6374	205	279	04.98-10.04	■
<b>ATEGO 01.98-10.04</b>					<b>Truck Tractor</b>			
1823 LS (OM 906.920)		Diesel		6374	170	231	04.98-10.04	■
1823 LS (OM 906.920)		Diesel		6374	170	231	04.98-10.04	■
1828 LS (OM 906.921)		Diesel		6374	205	279	04.98-10.04	■
1828 LS (OM 906.921)		Diesel		6374	205	279	04.98-10.04	■
<b>MK 12.87-12.05</b>					<b>Dump Truck</b>			
1827 K (OM 445.926)		Diesel		10964	200	272	01.94-09.96	■
1827 K (OM 445.926)		Diesel		10964	200	272	01.94-09.96	■
<b>MK 12.87-12.05</b>					<b>Municipal Vehicle</b>			
1231 AF (OM 401.986)	-12/92	Diesel		9570	230	313	01.92-09.96	■
1231 AF (OM 401.986)	-12/92	Diesel		9570	230	313	01.92-09.96	■
1227 AF, 1227 LAF (OM 445.933)		Diesel		10964	200	272	01.92-07.92	■
1227 AF, 1227 LAF (OM 445.933)		Diesel		10964	200	272	01.92-07.92	■
<b>MK 12.87-12.05</b>					<b>Platform/Chassis</b>			
1717/L	01/93-	Diesel		5995	129	175	12.87-	■
1717/L	01/93-	Diesel		5995	129	175	12.87-	■
1717AK	01/93-	Diesel		5995	129	175	12.87-	■
1717AK	01/93-	Diesel		5995	129	175	12.87-	■
1717K	01/93-	Diesel		5995	129	175	12.87-	■
1717K	01/93-	Diesel		5995	129	175	12.87-	■
1720/L	01/93-	Diesel		5995	150	204	12.87-	■
1720/L	01/93-	Diesel		5995	150	204	12.87-	■
1722L	01/93-	Diesel		5995	150	204	12.87-	■
1722L	01/93-	Diesel		5995	150	204	12.87-	■
2420/L	01/93-	Diesel		5995	150	204	12.87-	■
2420/L	01/93-	Diesel		5995	150	204	12.87-	■
1720S	01/93-	Diesel		5995	155	211	12.87-	■
1720S	01/93-	Diesel		5995	155	211	12.87-	■
1820/L	01/93-	Diesel		5995	155	211	12.87-	■
1820/L	01/93-	Diesel		5995	155	211	12.87-	■
1820AK	01/93-	Diesel		5995	155	211	12.87-	■
1820AK	01/93-	Diesel		5995	155	211	12.87-	■
1820K	01/93-	Diesel		5995	155	211	12.87-	■
1820K	01/93-	Diesel		5995	155	211	12.87-	■
1820s	01/93-	Diesel		5995	155	211	12.87-	■
1820s	01/93-	Diesel		5995	155	211	12.87-	■
1722AK	01/93-	Diesel		5995	177	241	12.87-	■
1722AK	01/93-	Diesel		5995	177	241	12.87-	■
1824 (OM 401.975)	01/93-	Diesel		9570	180	245	08.92-09.96	■
1824 (OM 401.975)	01/93-	Diesel		9570	180	245	08.92-09.96	■
2431 (OM 401.972)	01/93-	Diesel		9570	230	313	12.87-09.96	■
2431 (OM 401.972)	01/93-	Diesel		9570	230	313	12.87-09.96	■
2431 (OM 401.979)	01/93-	Diesel		9570	230	313	12.87-09.96	■
2431 (OM 401.979)	01/93-	Diesel		9570	230	313	12.87-09.96	■
2431 (OM 401.993)	01/93-	Diesel		9570	230	313	12.87-09.96	■
2431 (OM 401.993)	01/93-	Diesel		9570	230	313	12.87-09.96	■
1820AK	01/93-	Diesel		9595	180	245	12.87-	■
1820AK	01/93-	Diesel		9595	180	245	12.87-	■
1824K	01/93-	Diesel		9595	180	245	12.87-	■

# LISTA DE APLICACIONES - BUYERS GUIDE

1824K	01/93-	Diesel		9595	180	245	12.87-
2524/L	01/93-	Diesel		9595	180	245	12.87-
2524/L	01/93-	Diesel		9595	180	245	12.87-
1722AK	01/93-	Diesel		9595	200	272	12.87-
1722AK	01/93-	Diesel		9595	200	272	12.87-
1726/L	01/93-	Diesel		9595	200	272	12.87-
1726/L	01/93-	Diesel		9595	200	272	12.87-
1827/L	01/93-	Diesel		9595	200	272	12.87-
1827/L	01/93-	Diesel		9595	200	272	12.87-
1827S/LS	01/93-	Diesel		9595	200	272	12.87-
1827S/LS	01/93-	Diesel		9595	200	272	12.87-
2426/L	01/93-	Diesel		9595	200	272	12.87-
2426/L	01/93-	Diesel		9595	200	272	12.87-
2527/L	01/93-	Diesel		9595	200	272	12.87-
2527/L	01/93-	Diesel		9595	200	272	12.87-
1722K	01/93-	Diesel		9595	230	313	12.87-
1722K	01/93-	Diesel		9595	230	313	12.87-
1831/L	01/93-	Diesel		9595	230	313	12.87-
1831/L	01/93-	Diesel		9595	230	313	12.87-
1831AK	01/93-	Diesel		9595	230	313	12.87-
1831AK	01/93-	Diesel		9595	230	313	12.87-
1831K	01/93-	Diesel		9595	230	313	12.87-
1831K	01/93-	Diesel		9595	230	313	12.87-
1831S/LS	01/93-	Diesel		9595	230	313	12.87-
1831S/LS	01/93-	Diesel		9595	230	313	12.87-
2531/L	01/93-	Diesel		9595	230	313	12.87-
2531/L	01/93-	Diesel		9595	230	313	12.87-
1824	01/94-	Diesel		10995	180	245	12.87-
1824	01/94-	Diesel		10995	180	245	12.87-
1824AK	01/94-	Diesel		10995	180	245	12.87-
1824AK	01/94-	Diesel		10995	180	245	12.87-
1824K	01/94-	Diesel		10995	180	245	12.87-
1824K	01/94-	Diesel		10995	180	245	12.87-
2524/L	01/94-	Diesel		10995	180	245	12.87-
2524/L	01/94-	Diesel		10995	180	245	12.87-
1827/L	01/94-	Diesel		10995	200	272	12.87-
1827/L	01/94-	Diesel		10995	200	272	12.87-
1827S	01/94-	Diesel		10995	200	272	12.87-
1827S	01/94-	Diesel		10995	200	272	12.87-
2527/L	01/94-	Diesel		10995	200	272	12.87-
2527/L	01/94-	Diesel		10995	200	272	12.87-
1831/L	01/94-	Diesel		10995	230	313	12.87-
1831/L	01/94-	Diesel		10995	230	313	12.87-
1831AK	01/94-	Diesel		10995	230	313	12.87-
1831AK	01/94-	Diesel		10995	230	313	12.87-
1831K	01/93-	Diesel		10995	230	313	12.87-
1831K	01/93-	Diesel		10995	230	313	12.87-
1831S/LS	01/94-	Diesel		10995	230	313	12.87-
1831S/LS	01/94-	Diesel		10995	230	313	12.87-
2531/L	01/94-	Diesel		10995	230	313	12.87-
2531/L	01/94-	Diesel		10995	230	313	12.87-



# LISTA DE APLICACIONES - BUYERS GUIDE

1726/L	01/93-	Diesel		10995	250	340	12.87-
1726/L	01/93-	Diesel		10995	250	340	12.87-
1834/L	01/93-	Diesel		10995	250	340	12.87-
1834/L	01/93-	Diesel		10995	250	340	12.87-
1834S/LS	01/93-	Diesel		10995	250	340	12.87-
1834S/LS	01/93-	Diesel		10995	250	340	12.87-
2426/L	01/93-	Diesel		10995	250	340	12.87-
2426/L	01/93-	Diesel		10995	250	340	12.87-
2534/L	01/93-	Diesel		10995	250	340	12.87-
2534/L	01/93-	Diesel		10995	250	340	12.87-
2534S/LS	01/93-	Diesel		10995	250	340	12.87-
2534S/LS	01/93-	Diesel		10995	250	340	12.87-
1735S/LS	01/93-	Diesel		10995	260	354	12.87-
1735S/LS	01/93-	Diesel		10995	260	354	12.87-
1722/L	01/93-	Diesel		11295	151	205	12.87-
1722/L	01/93-	Diesel		11295	151	205	12.87-
1722AK	01/93-	Diesel		11295	151	205	12.87-
1722AK	01/93-	Diesel		11295	151	205	12.87-
1722K	01/93-	Diesel		11295	153	208	12.87-
1722K	01/93-	Diesel		11295	153	208	12.87-
1722S	01/93-	Diesel		11295	153	208	12.87-
1722S	01/93-	Diesel		11295	153	208	12.87-
2422/L	01/93-	Diesel		11295	153	208	12.87-
2422/L	01/93-	Diesel		11295	153	208	12.87-
1922	01/93-	Diesel		11295	160	218	12.87-
1922	01/93-	Diesel		11295	160	218	12.87-
1922AK	01/93-	Diesel		11295	160	218	12.87-
1922AK	01/93-	Diesel		11295	160	218	12.87-
1922K	01/93-	Diesel		11295	160	218	12.87-
1922K	01/93-	Diesel		11295	160	218	12.87-
1922S	01/93-	Diesel		11295	160	218	12.87-
1922S	01/93-	Diesel		11295	160	218	12.87-
1838/L	01/93-	Diesel		12795	280	381	12.87-
1838/L	01/93-	Diesel		12795	280	381	12.87-
1838AK	01/93-	Diesel		12795	280	381	12.87-
1838AK	01/93-	Diesel		12795	280	381	12.87-
1838K	01/93-	Diesel		12795	280	381	12.87-
1838K	01/93-	Diesel		12795	280	381	12.87-
1838S/LS	01/93-	Diesel		12795	280	381	12.87-
1838S/LS	01/93-	Diesel		12795	280	381	12.87-
2538	01/93-	Diesel		12795	280	381	12.87-
2538	01/93-	Diesel		12795	280	381	12.87-
2538/L	01/93-	Diesel		12795	280	381	12.87-
2538/L	01/93-	Diesel		12795	280	381	12.87-
2538S/LS	01/93-	Diesel		12795	280	381	12.87-
2538S/LS	01/93-	Diesel		12795	280	381	12.87-
2435S/LS	01/93-	Diesel		14595	191	260	12.87-
2435S/LS	01/93-	Diesel		14595	191	260	12.87-
1935AK	01/93-	Diesel		14595	250	340	12.87-
1935AK	01/93-	Diesel		14595	250	340	12.87-
1935AS	01/93-	Diesel		14595	250	340	12.87-

# LISTA DE APLICACIONES - BUYERS GUIDE

1935AS	01/93-	Diesel		14595	250	340	12.87-
1735AK	01/93-	Diesel		14595	260	354	12.87-
1735AK	01/93-	Diesel		14595	260	354	12.87-
2435/L	01/93-	Diesel		14595	260	354	12.87-
2435/L	01/93-	Diesel		14595	260	354	12.87-
1935	01/93-	Diesel		14595	269	366	12.87-
1935	01/93-	Diesel		14595	269	366	12.87-
1935K	01/93-	Diesel		14595	269	366	12.87-
1935K	01/93-	Diesel		14595	269	366	12.87-
1935S	01/93-	Diesel		14595	269	366	12.87-
1935S	01/93-	Diesel		14595	269	366	12.87-
1838/L	01/95-	Diesel		14595	280	381	12.87-
1838/L	01/95-	Diesel		14595	280	381	12.87-
1838AK	01/94-	Diesel		14595	280	381	12.87-
1838AK	01/94-	Diesel		14595	280	381	12.87-
1838S/LS	01/95-	Diesel		14595	280	381	12.87-
1838S/LS	01/95-	Diesel		14595	280	381	12.87-
2538/L	01/94-	Diesel		14595	280	381	12.87-
2538/L	01/94-	Diesel		14595	280	381	12.87-
2538S/LS	01/94-	Diesel		14595	280	381	12.87-
2538S/LS	01/94-	Diesel		14595	280	381	12.87-
1838/L	01/93-	Diesel		14595	320	435	12.87-
1838/L	01/93-	Diesel		14595	320	435	12.87-
1838AK	01/93-	Diesel		14595	320	435	12.87-
1838AK	01/93-	Diesel		14595	320	435	12.87-
1838K	01/95-	Diesel		14595	320	435	12.87-
1838K	01/95-	Diesel		14595	320	435	12.87-
1838S/LS	01/93-	Diesel		14595	320	435	12.87-
1838S/LS	01/93-	Diesel		14595	320	435	12.87-
1844/L	01/93-	Diesel		14595	320	435	12.87-
1844/L	01/93-	Diesel		14595	320	435	12.87-
1844S/LS	01/93-	Diesel		14595	320	435	12.87-
1844S/LS	01/93-	Diesel		14595	320	435	12.87-
2538/L	01/93-	Diesel		14595	320	435	12.87-
2538/L	01/93-	Diesel		14595	320	435	12.87-
2538S/LS	01/93-	Diesel		14595	320	435	12.87-
2538S/LS	01/93-	Diesel		14595	320	435	12.87-
2544/L	01/93-	Diesel		14595	320	435	12.87-
2544/L	01/93-	Diesel		14595	320	435	12.87-
2544S	01/93-	Diesel		14595	320	435	12.87-
2544S	01/93-	Diesel		14595	320	435	12.87-
1850/L	01/93-	Diesel		14595	362	492	12.87-
1850/L	01/93-	Diesel		14595	362	492	12.87-
1850S/LS	01/93-	Diesel		14595	362	492	12.87-
1850S/LS	01/93-	Diesel		14595	362	492	12.87-
1838AK	01/93-	Diesel		14595	370	503	12.87-
1838AK	01/93-	Diesel		14595	370	503	12.87-
2538	01/93-	Diesel		14595	370	503	12.87-
2538	01/93-	Diesel		14595	370	503	12.87-
2538S	01/93-	Diesel		14595	370	503	12.87-
2538S	01/93-	Diesel		14595	370	503	12.87-

# LISTA DE APLICACIONES - BUYERS GUIDE

2550/L	01/93-	Diesel		14595	370	503	12.87-
2550/L	01/93-	Diesel		14595	370	503	12.87-
1853/L	01/96-	Diesel		14595	390	530	12.87-
1853/L	01/96-	Diesel		14595	390	530	12.87-
1853AK	01/96-	Diesel		14595	390	530	12.87-
1853AK	01/96-	Diesel		14595	390	530	12.87-
1853S/LS	01/96-	Diesel		14595	390	530	12.87-
1853S/LS	01/96-	Diesel		14595	390	530	12.87-
2553/L	01/96-	Diesel		14595	390	530	12.87-
2553/L	01/96-	Diesel		14595	390	530	12.87-
1735L	01/93-	Diesel		14695	218	296	12.87-
1735L	01/93-	Diesel		14695	218	296	12.87-
1735K	01/93-	Diesel		14695	250	340	12.87-
1735K	01/93-	Diesel		14695	250	340	12.87-
1735/L	01/93-	Diesel		14695	260	354	12.87-
1735/L	01/93-	Diesel		14695	260	354	12.87-
1926 (OM 442.914)	01/93-	Diesel		15078	195	265	12.87-09.96
1926 (OM 442.914)	01/93-	Diesel		15078	195	265	12.87-09.96
1926 (OM 442.922)	01/93-	Diesel		15078	195	265	12.87-09.96
1926 (OM 442.922)	01/93-	Diesel		15078	195	265	12.87-09.96
1926 (OM 442.932)	01/93-	Diesel		15078	195	265	12.87-09.96
1926 (OM 442.932)	01/93-	Diesel		15078	195	265	12.87-09.96
1729 (OM 442.906)	01/93-	Diesel		15078	210	286	12.87-09.96
1729 (OM 442.906)	01/93-	Diesel		15078	210	286	12.87-09.96
1729 (OM 442.907)	01/93-	Diesel		15078	210	286	12.87-09.96
1729 (OM 442.907)	01/93-	Diesel		15078	210	286	12.87-09.96
1729 (OM 442.923)	01/93-	Diesel		15078	210	286	12.87-09.96
1729 (OM 442.923)	01/93-	Diesel		15078	210	286	12.87-09.96
2429 (OM 442.906)	01/93-	Diesel		15078	210	286	12.87-09.96
2429 (OM 442.906)	01/93-	Diesel		15078	210	286	12.87-09.96
2429 (OM 442.907)	01/93-	Diesel		15078	210	286	12.87-09.96
2429 (OM 442.907)	01/93-	Diesel		15078	210	286	12.87-09.96
2429 (OM 442.909)	01/93-	Diesel		15078	210	286	12.87-09.96
2429 (OM 442.909)	01/93-	Diesel		15078	210	286	12.87-09.96
2429 (OM 442.923)	01/93-	Diesel		15078	210	286	12.87-09.96
2429 (OM 442.923)	01/93-	Diesel		15078	210	286	12.87-09.96
1726/L	01/93-	Diesel		15095	195	265	12.87-
1726/L	01/93-	Diesel		15095	195	265	12.87-
1726AK	01/93-	Diesel		15095	195	265	12.87-
1726AK	01/93-	Diesel		15095	195	265	12.87-
1726K	01/93-	Diesel		15095	195	265	12.87-
1726K	01/93-	Diesel		15095	195	265	12.87-
1726S/LS	01/93-	Diesel		15095	195	265	12.87-
1726S/LS	01/93-	Diesel		15095	195	265	12.87-
2426/L	01/93-	Diesel		15095	195	265	12.87-
2426/L	01/93-	Diesel		15095	195	265	12.87-
2527/L	01/93-	Diesel		15095	195	265	12.87-
2527/L	01/93-	Diesel		15095	195	265	12.87-
1729S/LS	01/93-	Diesel		15095	210	286	12.87-
1729S/LS	01/93-	Diesel		15095	210	286	12.87-
1929/L	01/93-	Diesel		15095	210	286	12.87-

# LISTA DE APLICACIONES - BUYERS GUIDE

1929/L	01/93-	Diesel		15095	210	286	12.87-
1929A	01/93-	Diesel		15095	210	286	12.87-
1929A	01/93-	Diesel		15095	210	286	12.87-
1929AK	01/93-	Diesel		15095	210	286	12.87-
1929AK	01/93-	Diesel		15095	210	286	12.87-
1929K	01/93-	Diesel		15095	210	286	12.87-
1929K	01/93-	Diesel		15095	210	286	12.87-
1929S	01/93-	Diesel		15095	210	286	12.87-
1929S	01/93-	Diesel		15095	210	286	12.87-
1729AK	01/93-	Diesel		15095	213	290	12.87-
1729AK	01/93-	Diesel		15095	213	290	12.87-
1729K	01/93-	Diesel		15095	213	290	12.87-
1729K	01/93-	Diesel		15095	213	290	12.87-
1929AS	01/93-	Diesel		15095	213	290	12.87-
1929AS	01/93-	Diesel		15095	213	290	12.87-
2426S/LS	01/93-	Diesel		15095	213	290	12.87-
2426S/LS	01/93-	Diesel		15095	213	290	12.87-
2429/L	01/93-	Diesel		15095	213	290	12.87-
2429/L	01/93-	Diesel		15095	213	290	12.87-
1722	01/93-	Diesel		15095	218	296	12.87-
1722	01/93-	Diesel		15095	218	296	12.87-
1929A	01/93-	Diesel		15095	269	366	12.87-
1929A	01/93-	Diesel		15095	269	366	12.87-
1929A	01/93-	Diesel		18295	340	462	12.87-
1929A	01/93-	Diesel		18295	340	462	12.87-

## STEYR

### S 01.90-

19 S	01/94-	Diesel					01.90-
19 S	01/94-	Diesel					01.90-
22 S	01/94-	Diesel					01.90-
22 S	01/94-	Diesel					01.90-
26 S	01/94-	Diesel					01.90-
26 S	01/94-	Diesel					01.90-
32 S	01/94-	Diesel					01.90-
32 S	01/94-	Diesel					01.90-
42 S	01/94-	Diesel					01.90-
42 S	01/94-	Diesel					01.90-