



LISTA DE APLICACIONES - BUYERS GUIDE

21 9900 00



Qty: 850

Weight: 8.300



21 9900 00



150x18.9/19x179.2/175.6- Ø420

WVA

19900

19901

MAKE

DAF



Trac.

CC

Kw

CV



Front / Rear

DAF

95 09.87-01.98

Platform/Chassis

| | | | | | | | | |
|------------|--------|--------|--|-------|-----|-----|--------|---|
| FA 95.310 | 01/87- | Diesel | | 11595 | 225 | 306 | 09.87- | ■ |
| FA 95.310 | 01/87- | Diesel | | 11595 | 225 | 306 | 09.87- | ■ |
| FA 95.310 | 01/87- | Diesel | | 11595 | 225 | 306 | 09.87- | ■ |
| FA 95.310 | 01/87- | Diesel | | 11595 | 225 | 306 | 09.87- | ■ |
| FT 95.310 | 01/87- | Diesel | | 11595 | 225 | 306 | 09.87- | ■ |
| FT 95.310 | 01/87- | Diesel | | 11595 | 225 | 306 | 09.87- | ■ |
| FA 95.350 | 01/87- | Diesel | | 11595 | 259 | 352 | 09.87- | ■ |
| FA 95.350 | 01/87- | Diesel | | 11595 | 259 | 352 | 09.87- | ■ |
| FAD 95.350 | 01/87- | Diesel | | 11595 | 259 | 352 | 09.87- | ■ |
| FAD 95.350 | 01/87- | Diesel | | 11595 | 259 | 352 | 09.87- | ■ |
| FAG 95.350 | 01/87- | Diesel | | 11595 | 259 | 352 | 09.87- | ■ |
| FAG 95.350 | 01/87- | Diesel | | 11595 | 259 | 352 | 09.87- | ■ |
| FAR 95.350 | 01/87- | Diesel | | 11595 | 259 | 352 | 09.87- | ■ |
| FAR 95.350 | 01/87- | Diesel | | 11595 | 259 | 352 | 09.87- | ■ |
| FAS 95.350 | 01/87- | Diesel | | 11595 | 259 | 352 | 09.87- | ■ |
| FAS 95.350 | 01/87- | Diesel | | 11595 | 259 | 352 | 09.87- | ■ |
| FAT 95.350 | 01/87- | Diesel | | 11595 | 259 | 352 | 09.87- | ■ |
| FAT 95.350 | 01/87- | Diesel | | 11595 | 259 | 352 | 09.87- | ■ |
| FT 95.350 | 01/87- | Diesel | | 11595 | 259 | 352 | 09.87- | ■ |
| FT 95.350 | 01/87- | Diesel | | 11595 | 259 | 352 | 09.87- | ■ |
| FTG 95.350 | 01/87- | Diesel | | 11595 | 259 | 352 | 09.87- | ■ |
| FTG 95.350 | 01/87- | Diesel | | 11595 | 259 | 352 | 09.87- | ■ |
| FTS 95.350 | 01/87- | Diesel | | 11595 | 259 | 352 | 09.87- | ■ |

LISTA DE APLICACIONES - BUYERS GUIDE

| | | | | | | | | |
|---------------|--------|--------|--|-------|-------------------------|-----|--------|---|
| FTS 95.350 | 01/87- | Diesel | | 11595 | 259 | 352 | 09.87- | ■ |
| FTT 95.350 | 01/87- | Diesel | | 11595 | 259 | 352 | 09.87- | ■ |
| FTT 95.350 | 01/87- | Diesel | | 11595 | 259 | 352 | 09.87- | ■ |
| FA 95.380 | 01/87- | Diesel | | 11595 | 282 | 384 | 09.87- | ■ |
| FA 95.380 | 01/87- | Diesel | | 11595 | 282 | 384 | 09.87- | ■ |
| FAD 95.380 | 01/87- | Diesel | | 11595 | 282 | 384 | 09.87- | ■ |
| FAD 95.380 | 01/87- | Diesel | | 11595 | 282 | 384 | 09.87- | ■ |
| FAG 95.380 | 01/87- | Diesel | | 11595 | 282 | 384 | 09.87- | ■ |
| FAG 95.380 | 01/87- | Diesel | | 11595 | 282 | 384 | 09.87- | ■ |
| FAR 95.380 | 01/87- | Diesel | | 11595 | 282 | 384 | 09.87- | ■ |
| FAR 95.380 | 01/87- | Diesel | | 11595 | 282 | 384 | 09.87- | ■ |
| FAS 95.380 | 01/87- | Diesel | | 11595 | 282 | 384 | 09.87- | ■ |
| FAS 95.380 | 01/87- | Diesel | | 11595 | 282 | 384 | 09.87- | ■ |
| FAT 95.380 | 01/87- | Diesel | | 11595 | 282 | 384 | 09.87- | ■ |
| FAT 95.380 | 01/87- | Diesel | | 11595 | 282 | 384 | 09.87- | ■ |
| FT 95.380 | 01/87- | Diesel | | 11595 | 282 | 384 | 09.87- | ■ |
| FT 95.380 | 01/87- | Diesel | | 11595 | 282 | 384 | 09.87- | ■ |
| FTG 95.380 | 01/87- | Diesel | | 11595 | 282 | 384 | 09.87- | ■ |
| FTG 95.380 | 01/87- | Diesel | | 11595 | 282 | 384 | 09.87- | ■ |
| FTS 95.380 | 01/87- | Diesel | | 11595 | 282 | 384 | 09.87- | ■ |
| FTS 95.380 | 01/87- | Diesel | | 11595 | 282 | 384 | 09.87- | ■ |
| FTT 95.380 | 01/87- | Diesel | | 11595 | 282 | 384 | 09.87- | ■ |
| FTT 95.380 | 01/87- | Diesel | | 11595 | 282 | 384 | 09.87- | ■ |
| F 1900 | | | | | Platform/Chassis | | | |
| FA1900 DNT | 01/86- | Diesel | | 6195 | 133 | 181 | 01.53- | ■ |
| FA1900 DNT | 01/86- | Diesel | | 6195 | 133 | 181 | 01.53- | ■ |
| FA1900 DNT | 01/86- | Diesel | | 6195 | 133 | 181 | 01.53- | ■ |
| FA1900 DNT | 01/86- | Diesel | | 6195 | 133 | 181 | 01.53- | ■ |
| FA1900 DNT | 01/86- | Diesel | | 6195 | 133 | 181 | 01.53- | ■ |
| FA1900 DNT | 01/86- | Diesel | | 6195 | 133 | 181 | 01.53- | ■ |
| FA1900 NT | 01/86- | Diesel | | 6195 | 133 | 181 | 01.53- | ■ |
| FA1900 NT | 01/86- | Diesel | | 6195 | 133 | 181 | 01.53- | ■ |
| FA1900 NT | 01/86- | Diesel | | 6195 | 133 | 181 | 01.53- | ■ |
| FA1900 NT | 01/86- | Diesel | | 6195 | 133 | 181 | 01.53- | ■ |
| FAV1900 DNT | 01/86- | Diesel | | 6195 | 133 | 181 | 01.53- | ■ |
| FAV1900 DNT | 01/86- | Diesel | | 6195 | 133 | 181 | 01.53- | ■ |
| FAV1900 NT | 01/86- | Diesel | | 6195 | 133 | 181 | 01.53- | ■ |
| FAV1900 NT | 01/86- | Diesel | | 6195 | 133 | 181 | 01.53- | ■ |
| FD1900 DNT | 01/86- | Diesel | | 6195 | 133 | 181 | 01.53- | ■ |
| FD1900 DNT | 01/86- | Diesel | | 6195 | 133 | 181 | 01.53- | ■ |
| FA1900 DNS | 01/86- | Diesel | | 6195 | 156 | 212 | 01.53- | ■ |
| FA1900 DNS | 01/86- | Diesel | | 6195 | 156 | 212 | 01.53- | ■ |
| FA1900 DNS | 01/86- | Diesel | | 6195 | 156 | 212 | 01.53- | ■ |
| FA1900 DNS | 01/86- | Diesel | | 6195 | 156 | 212 | 01.53- | ■ |
| FA1900 NS | 01/86- | Diesel | | 6195 | 156 | 212 | 01.53- | ■ |
| FA1900 NS | 01/86- | Diesel | | 6195 | 156 | 212 | 01.53- | ■ |
| FT1900 DNS | 01/86- | Diesel | | 6195 | 156 | 212 | 01.53- | ■ |
| FT1900 DNS | 01/86- | Diesel | | 6195 | 156 | 212 | 01.53- | ■ |
| F 2100 | | | | | Platform/Chassis | | | |
| FA2100 | 01/87- | Diesel | | | | | 01.53- | ■ |
| FA2100 | 01/87- | Diesel | | | | | 01.53- | ■ |

LISTA DE APLICACIONES - BUYERS GUIDE

| | | | | | | | | |
|---------------------------|--------|--------|--|-------|-----|-------------------------|--------|---|
| FAR2100 | 01/87- | Diesel | | | | | 01.53- | ■ |
| FAR2100 | 01/87- | Diesel | | | | | 01.53- | ■ |
| FAS2100 | 01/87- | Diesel | | | | | 01.53- | ■ |
| FAS2100 | 01/87- | Diesel | | | | | 01.53- | ■ |
| FAT2100 | 01/87- | Diesel | | | | | 01.53- | ■ |
| FAT2100 | 01/87- | Diesel | | | | | 01.53- | ■ |
| FD2100 | 01/87- | Diesel | | | | | 01.53- | ■ |
| FD2100 | 01/87- | Diesel | | | | | 01.53- | ■ |
| F 2500 | | | | | | Platform/Chassis | | |
| FA2500 | 01/87- | Diesel | | | | | 01.53- | ■ |
| FA2500 | 01/87- | Diesel | | | | | 01.53- | ■ |
| FAD2500 | 01/87- | Diesel | | | | | 01.53- | ■ |
| FAD2500 | 01/87- | Diesel | | | | | 01.53- | ■ |
| FAR2500 | 01/87- | Diesel | | | | | 01.53- | ■ |
| FAR2500 | 01/87- | Diesel | | | | | 01.53- | ■ |
| FAS2500 | 01/87- | Diesel | | | | | 01.53- | ■ |
| FAS2500 | 01/87- | Diesel | | | | | 01.53- | ■ |
| FT2500 | 01/87- | Diesel | | | | | 01.53- | ■ |
| FT2500 | 01/87- | Diesel | | | | | 01.53- | ■ |
| F 2800 09.73-09.91 | | | | | | Platform/Chassis | | |
| FD2800 | 01/87- | Diesel | | | | | 09.73- | ■ |
| FD2800 | 01/87- | Diesel | | | | | 09.73- | ■ |
| F 3200 01.90-10.93 | | | | | | Platform/Chassis | | |
| FA3200 KS | 01/90- | Diesel | | 11595 | 238 | 324 | 01.90- | ■ |
| FA3200 KS | 01/90- | Diesel | | 11595 | 238 | 324 | 01.90- | ■ |
| FAB3200 KS | 01/90- | Diesel | | 11595 | 238 | 324 | 01.90- | ■ |
| FAB3200 KS | 01/90- | Diesel | | 11595 | 238 | 324 | 01.90- | ■ |
| FAD3200 KD | 01/90- | Diesel | | 11595 | 238 | 324 | 01.90- | ■ |
| FAD3200 KD | 01/90- | Diesel | | 11595 | 238 | 324 | 01.90- | ■ |
| FAR3200 KS | 01/90- | Diesel | | 11595 | 238 | 324 | 01.90- | ■ |
| FAR3200 KS | 01/90- | Diesel | | 11595 | 238 | 324 | 01.90- | ■ |
| FAS3200 KS | 01/90- | Diesel | | 11595 | 238 | 324 | 01.90- | ■ |
| FAS3200 KS | 01/90- | Diesel | | 11595 | 238 | 324 | 01.90- | ■ |
| FAT3200 KV | 01/90- | Diesel | | 11595 | 238 | 324 | 01.90- | ■ |
| FAT3200 KV | 01/90- | Diesel | | 11595 | 238 | 324 | 01.90- | ■ |
| FMD3200 KD | 01/90- | Diesel | | 11595 | 238 | 324 | 01.90- | ■ |
| FMD3200 KD | 01/90- | Diesel | | 11595 | 238 | 324 | 01.90- | ■ |
| FT3200 KS | 01/90- | Diesel | | 11595 | 238 | 324 | 01.90- | ■ |
| FT3200 KS | 01/90- | Diesel | | 11595 | 238 | 324 | 01.90- | ■ |
| SB 01.74- | | | | | | Bus | | |
| 220 LD, LC | 01/87- | Diesel | | | | | 01.74- | ■ |
| 220 LD, LC | 01/87- | Diesel | | | | | 01.74- | ■ |