


# LISTA DE APLICACIONES - BUYERS GUIDE

## 30697-5601



Weight: 7.030



## 30697-5601



Lucas - Girling

87x52.8x17.2

Ø232x9x39

**WVA**

20960

**MAKE**

AUDI

SEAT

SKODA

VW



Trac.	CC	Kw	CV
-------	----	----	----



Front / Rear

### AUDI

#### A3 (8L1) 09.96-09.06

#### Hatchback (Compact executive car-D Segment)

Model	Year	Engine	Drive	CC	Kw	CV	Period	Application
1.6 (AEH)	-12/00	Gasolina	FWD	1595	74	101	09.96-05.03	■
1.6 (AEH)	-12/00	Gasolina	FWD	1595	74	101	09.96-05.03	■
1.6 (AKL)	-12/00	Gasolina	FWD	1595	74	101	09.96-05.03	■
1.6 (AKL)	-12/00	Gasolina	FWD	1595	74	101	09.96-05.03	■
1.6 (APF)	-12/00	Gasolina	FWD	1595	74	101	09.96-05.03	■
1.6 (APF)	-12/00	Gasolina	FWD	1595	74	101	09.96-05.03	■
1.6 (AVU)		Gasolina	FWD	1595	75	102	08.00-05.03	■
1.6 (AVU)		Gasolina	FWD	1595	75	102	08.00-05.03	■
1.6 (BFQ)		Gasolina	FWD	1595	75	102	08.00-05.03	■
1.6 (BFQ)		Gasolina	FWD	1595	75	102	08.00-05.03	■
1.8 (AGN)		Gasolina	FWD	1781	92	125	09.96-05.03	■
1.8 (AGN)		Gasolina	FWD	1781	92	125	09.96-05.03	■
1.8 (APG)		Gasolina	FWD	1781	92	125	09.96-05.03	■
1.8 (APG)		Gasolina	FWD	1781	92	125	09.96-05.03	■
1.9 TDI (AGR)		Diesel	FWD	1896	66	90	09.96-07.01	■
1.9 TDI (AGR)		Diesel	FWD	1896	66	90	09.96-07.01	■
1.9 TDI (ALH)		Diesel	FWD	1896	66	90	09.96-07.01	■
1.9 TDI (ALH)		Diesel	FWD	1896	66	90	09.96-07.01	■
1.9 TDI (ATD)		Diesel	FWD	1896	74	100	10.00-05.03	■
1.9 TDI (ATD)		Diesel	FWD	1896	74	100	10.00-05.03	■
1.9 TDI (AXR)		Diesel	FWD	1896	74	100	10.00-05.03	■
1.9 TDI (AXR)		Diesel	FWD	1896	74	100	10.00-05.03	■
1.9 TDI (AHF)		Diesel	FWD	1896	81	110	08.97-07.01	■

# LISTA DE APLICACIONES - BUYERS GUIDE

1.9 TDI (AHF)		Diesel	FWD	1896	81	110	08.97-07.01	■
1.9 TDI (ASV)		Diesel	FWD	1896	81	110	08.97-07.01	■
1.9 TDI (ASV)		Diesel	FWD	1896	81	110	08.97-07.01	■
1.9 TDI (ASZ)		Diesel	FWD	1896	96	130	08.00-05.03	■
1.9 TDI (ASZ)		Diesel	FWD	1896	96	130	08.00-05.03	■
<b>TT (8N9) 10.99-02.07</b>				<b>Convertible (Sports car-S Segment)</b>				
1.8 T (AUM)		Gasolina	FWD	1781	110	150	01.01-06.06	■
1.8 T (AUM)		Gasolina	FWD	1781	110	150	01.01-06.06	■
1.8 T (BVP)		Gasolina	FWD	1781	120	163	09.05-06.06	■
1.8 T (BVP)		Gasolina	FWD	1781	120	163	09.05-06.06	■
1.8 T (AJQ)		Gasolina	FWD	1781	132	180	10.99-06.06	■
1.8 T (AJQ)		Gasolina	FWD	1781	132	180	10.99-06.06	■
1.8 T (APP)		Gasolina	FWD	1781	132	180	10.99-06.06	■
1.8 T (APP)		Gasolina	FWD	1781	132	180	10.99-06.06	■
1.8 T (ATC)		Gasolina	FWD	1781	132	180	10.99-06.06	■
1.8 T (ATC)		Gasolina	FWD	1781	132	180	10.99-06.06	■
1.8 T (AUQ)		Gasolina	FWD	1781	132	180	10.99-06.06	■
1.8 T (AUQ)		Gasolina	FWD	1781	132	180	10.99-06.06	■
1.8 T (AWP)		Gasolina	FWD	1781	132	180	10.99-06.06	■
1.8 T (AWP)		Gasolina	FWD	1781	132	180	10.99-06.06	■
<b>TT (8N3) 10.98-02.07</b>				<b>Coupe (Sports car-S Segment)</b>				
1.6 T		Gasolina	FWD	1598	134	182	09.02-06.06	■
1.6 T		Gasolina	FWD	1598	134	182	09.02-06.06	■
1.8 T (AUM)		Gasolina	FWD	1781	110	150	09.02-06.06	■
1.8 T (AUM)		Gasolina	FWD	1781	110	150	09.02-06.06	■
1.8 T (BVP)		Gasolina	FWD	1781	120	163	09.05-06.06	■
1.8 T (BVP)		Gasolina	FWD	1781	120	163	09.05-06.06	■
1.8 T (AJQ)		Gasolina	FWD	1781	132	180	10.98-06.06	■
1.8 T (AJQ)		Gasolina	FWD	1781	132	180	10.98-06.06	■
1.8 T (APP)		Gasolina	FWD	1781	132	180	10.98-06.06	■
1.8 T (APP)		Gasolina	FWD	1781	132	180	10.98-06.06	■
1.8 T (ATC)		Gasolina	FWD	1781	132	180	10.98-06.06	■
1.8 T (ATC)		Gasolina	FWD	1781	132	180	10.98-06.06	■
1.8 T (AUQ)		Gasolina	FWD	1781	132	180	10.98-06.06	■
1.8 T (AUQ)		Gasolina	FWD	1781	132	180	10.98-06.06	■
1.8 T (BVR)		Gasolina	FWD	1781	140	190	09.05-06.06	■
1.8 T (BVR)		Gasolina	FWD	1781	140	190	09.05-06.06	■
<b>SEAT</b>								
<b>CORDOBA III (6L2) 09.02-11.09</b>				<b>Saloon (Supermini car-B Segment)</b>				
1.4 16V (BBY)	-12/06	Gasolina	FWD	1390	55	75	09.02-12.07	■
1.4 16V (BBY)	-12/06	Gasolina	FWD	1390	55	75	09.02-12.07	■
1.4 16V (BKY)	-12/06	Gasolina	FWD	1390	55	75	09.02-12.07	■
1.4 16V (BKY)	-12/06	Gasolina	FWD	1390	55	75	09.02-12.07	■
1.4 16V (BXW)	-12/08	Gasolina	FWD	1390	63	86	05.06-11.09	■
1.4 16V (BXW)	-12/08	Gasolina	FWD	1390	63	86	05.06-11.09	■
1.4 16V (BBZ)	-12/08	Gasolina	FWD	1390	74	100	10.02-11.09	■
1.4 16V (BBZ)	-12/08	Gasolina	FWD	1390	74	100	10.02-11.09	■
1.6 (BAH)	-12/08	Gasolina	FWD	1598	74	101	04.03-11.09	■
1.6 (BAH)	-12/08	Gasolina	FWD	1598	74	101	04.03-11.09	■
1.6 16V (BTS)	-12/08	Gasolina	FWD	1598	77	105	11.06-11.09	■

# LISTA DE APLICACIONES - BUYERS GUIDE

1.6 16V (BTS)	-12/08	Gasolina	FWD	1598	77	105	11.06-11.09	■
2.0 (AZL)	-12/08	Gasolina	FWD	1984	85	115	09.02-11.09	■
2.0 (AZL)	-12/08	Gasolina	FWD	1984	85	115	09.02-11.09	■
2.0 (BBX)	-12/08	Gasolina	FWD	1984	85	115	09.02-11.09	■
2.0 (BBX)	-12/08	Gasolina	FWD	1984	85	115	09.02-11.09	■
1.4 TDI (BNM)	-12/08	Diesel	FWD	1422	51	70	05.05-11.09	■
1.4 TDI (BNM)	-12/08	Diesel	FWD	1422	51	70	05.05-11.09	■
1.4 TDI (AMF)		Diesel	FWD	1422	55	75	10.02-12.05	■
1.4 TDI (AMF)		Diesel	FWD	1422	55	75	10.02-12.05	■
1.4 TDI (BMS)	-12/08	Diesel	FWD	1422	59	80	06.05-11.09	■
1.4 TDI (BMS)	-12/08	Diesel	FWD	1422	59	80	06.05-11.09	■
1.4 TDI (BNV)	-12/08	Diesel	FWD	1422	59	80	06.05-11.09	■
1.4 TDI (BNV)	-12/08	Diesel	FWD	1422	59	80	06.05-11.09	■
1.9 TDI (ATD)	-12/08	Diesel	FWD	1896	74	100	09.02-11.09	■
1.9 TDI (ATD)	-12/08	Diesel	FWD	1896	74	100	09.02-11.09	■
1.9 TDI (AXR)	-12/08	Diesel	FWD	1896	74	100	09.02-11.09	■
1.9 TDI (AXR)	-12/08	Diesel	FWD	1896	74	100	09.02-11.09	■
1.9 TDI (BMT)	-12/08	Diesel	FWD	1896	74	100	09.02-11.09	■
1.9 TDI (BMT)	-12/08	Diesel	FWD	1896	74	100	09.02-11.09	■
1.9 TDI (ASZ)	-12/08	Diesel	FWD	1896	96	131	10.02-11.09	■
1.9 TDI (ASZ)	-12/08	Diesel	FWD	1896	96	131	10.02-11.09	■
1.9 TDI (BLT)	-12/08	Diesel	FWD	1896	96	131	10.02-11.09	■
1.9 TDI (BLT)	-12/08	Diesel	FWD	1896	96	131	10.02-11.09	■
<b>IBIZA III (6L1) 02.02-11.09</b>							<b>Hatchback (Supermini car-B Segment)</b>	
1.4 16V (BXW)	-12/08	Gasolina	FWD	1390	63	86	05.06-11.09	■
1.4 16V (BXW)	-12/08	Gasolina	FWD	1390	63	86	05.06-11.09	■
1.4 16V (AUB)	-12/08	Gasolina	FWD	1390	74	100	02.02-11.09	■
1.4 16V (AUB)	-12/08	Gasolina	FWD	1390	74	100	02.02-11.09	■
1.4 16V (BBZ)	-12/08	Gasolina	FWD	1390	74	100	02.02-11.09	■
1.4 16V (BBZ)	-12/08	Gasolina	FWD	1390	74	100	02.02-11.09	■
1.6 (BAH)	-12/08	Gasolina	FWD	1598	74	101	02.03-11.09	■
1.6 (BAH)	-12/08	Gasolina	FWD	1598	74	101	02.03-11.09	■
1.6 16V (BTS)	-12/08	Gasolina	FWD	1598	77	105	11.06-11.09	■
1.6 16V (BTS)	-12/08	Gasolina	FWD	1598	77	105	11.06-11.09	■
1.8 T Cupra R (BBU)		Gasolina	FWD	1781	132	180	01.04-02.08	■
1.8 T Cupra R (BBU)		Gasolina	FWD	1781	132	180	01.04-02.08	■
1.8 T Cupra R (BLZ)		Gasolina	FWD	1781	132	180	01.04-02.08	■
1.8 T Cupra R (BLZ)		Gasolina	FWD	1781	132	180	01.04-02.08	■
1.4 TDI (BNM)	-12/08	Diesel	FWD	1422	51	70	05.05-11.09	■
1.4 TDI (BNM)	-12/08	Diesel	FWD	1422	51	70	05.05-11.09	■
1.4 TDI (AMF)		Diesel	FWD	1422	55	75	05.02-12.05	■
1.4 TDI (AMF)		Diesel	FWD	1422	55	75	05.02-12.05	■
1.4 TDI (BMS)	-12/08	Diesel	FWD	1422	59	80	06.05-11.09	■
1.4 TDI (BMS)	-12/08	Diesel	FWD	1422	59	80	06.05-11.09	■
1.4 TDI (BNV)	-12/08	Diesel	FWD	1422	59	80	06.05-11.09	■
1.4 TDI (BNV)	-12/08	Diesel	FWD	1422	59	80	06.05-11.09	■
1.9 TDI (ATD)	-12/08	Diesel	FWD	1896	74	100	02.02-11.09	■
1.9 TDI (ATD)	-12/08	Diesel	FWD	1896	74	100	02.02-11.09	■
1.9 TDI (AXR)	-12/08	Diesel	FWD	1896	74	100	02.02-11.09	■
1.9 TDI (AXR)	-12/08	Diesel	FWD	1896	74	100	02.02-11.09	■
1.9 TDI (BMT)	-12/08	Diesel	FWD	1896	74	100	02.02-11.09	■

# LISTA DE APLICACIONES - BUYERS GUIDE

1.9 TDI (BMT)	-12/08	Diesel	FWD	1896	74	100	02.02-11.09	■	
1.9 TDI (ASZ)	-12/08	Diesel	FWD	1896	96	131	02.02-11.09	■	
1.9 TDI (ASZ)	-12/08	Diesel	FWD	1896	96	131	02.02-11.09	■	
1.9 TDI (BLT)	-12/08	Diesel	FWD	1896	96	131	02.02-11.09	■	
1.9 TDI (BLT)	-12/08	Diesel	FWD	1896	96	131	02.02-11.09	■	
1.9 TDI Cupra R (BPX)		Diesel	FWD	1896	118	160	03.04-02.08	■	
1.9 TDI Cupra R (BPX)		Diesel	FWD	1896	118	160	03.04-02.08	■	
1.9 TDI Cupra R (BUK)		Diesel	FWD	1896	118	160	03.04-02.08	■	
1.9 TDI Cupra R (BUK)		Diesel	FWD	1896	118	160	03.04-02.08	■	
<b>IBIZA IV (6J1) 04.08-</b>							<b>Hatchback Van (Supermini car-B Segment)</b>		
1.2 (CGPA)		Gasolina	FWD	1198	51	69	04.08-05.15	■	
1.2 (CGPA)		Gasolina	FWD	1198	51	69	04.08-05.15	■	
<b>IBIZA IV (6J5, 6P1) 03.08-</b>							<b>Hatchback (Supermini car-B Segment)</b>		
1.2 (BZG)		Gasolina	FWD	1198	51	70	03.08-05.15	■	
1.2 (BZG)		Gasolina	FWD	1198	51	70	03.08-05.15	■	
1.2 (CGPA)		Gasolina	FWD	1198	51	70	03.08-05.15	■	
1.2 (CGPA)		Gasolina	FWD	1198	51	70	03.08-05.15	■	
1.2 (CJLB)		Gasolina	FWD	1198	51	70	03.08-05.15	■	
1.2 (CJLB)		Gasolina	FWD	1198	51	70	03.08-05.15	■	
1.4 (BXW)		Gasolina	FWD	1390	63	85	03.08-05.15	■	
1.4 (BXW)		Gasolina	FWD	1390	63	85	03.08-05.15	■	
1.4 (CGGB)		Gasolina	FWD	1390	63	85	03.08-05.15	■	
1.4 (CGGB)		Gasolina	FWD	1390	63	85	03.08-05.15	■	
1.6 (BTS)		Gasolina	FWD	1598	77	105	05.08-03.12	■	
1.6 (BTS)		Gasolina	FWD	1598	77	105	05.08-03.12	■	
1.4 TDI (BMS)		Diesel	FWD	1422	59	80	07.08-06.10	■	
1.4 TDI (BMS)		Diesel	FWD	1422	59	80	07.08-06.10	■	
1.9 TDI (BXJ)		Diesel	FWD	1896	66	90	07.08-06.10	■	
1.9 TDI (BXJ)		Diesel	FWD	1896	66	90	07.08-06.10	■	
1.9 TDI (BLS)		Diesel	FWD	1896	77	105	03.08-06.10	■	
1.9 TDI (BLS)		Diesel	FWD	1896	77	105	03.08-06.10	■	
<b>IBIZA IV SC (6J1, 6P5) 06.08-12.18</b>							<b>Hatchback (Supermini car-B Segment)</b>		
1.2 (BZG)		Gasolina	FWD	1198	51	70	07.08-05.15	■	
1.2 (BZG)		Gasolina	FWD	1198	51	70	07.08-05.15	■	
1.2 (CGPA)		Gasolina	FWD	1198	51	70	07.08-05.15	■	
1.2 (CGPA)		Gasolina	FWD	1198	51	70	07.08-05.15	■	
1.4 (BXW)		Gasolina	FWD	1390	63	85	07.08-05.15	■	
1.4 (BXW)		Gasolina	FWD	1390	63	85	07.08-05.15	■	
1.4 (CGGB)		Gasolina	FWD	1390	63	85	07.08-05.15	■	
1.4 (CGGB)		Gasolina	FWD	1390	63	85	07.08-05.15	■	
1.4 LPG		Gasol./Gas (LPG)	FWD	1390	63	85	07.08-05.11	■	
1.4 LPG		Gasol./Gas (LPG)	FWD	1390	63	85	07.08-05.11	■	
<b>LEON (1M1) 11.99-06.06</b>							<b>Hatchback (Compact car-C Segment)</b>		
1.4 16V (AHW)	-12/05	Gasolina	FWD	1390	55	75	11.99-06.06	■	
1.4 16V (AHW)	-12/05	Gasolina	FWD	1390	55	75	11.99-06.06	■	
1.4 16V (APE)	-12/05	Gasolina	FWD	1390	55	75	11.99-06.06	■	
1.4 16V (APE)	-12/05	Gasolina	FWD	1390	55	75	11.99-06.06	■	
1.4 16V (AXP)	-12/05	Gasolina	FWD	1390	55	75	11.99-06.06	■	

## LISTA DE APLICACIONES - BUYERS GUIDE

1.4 16V (AXP)	-12/05	Gasolina	FWD	1390	55	75	11.99-06.06	■
1.4 16V (BCA)	-12/05	Gasolina	FWD	1390	55	75	11.99-06.06	■
1.4 16V (BCA)	-12/05	Gasolina	FWD	1390	55	75	11.99-06.06	■
1.6 (AEH)	-12/05	Gasolina	FWD	1595	74	100	11.99-06.06	■
1.6 (AEH)	-12/05	Gasolina	FWD	1595	74	100	11.99-06.06	■
1.6 (AKL)	-12/05	Gasolina	FWD	1595	74	100	11.99-06.06	■
1.6 (AKL)	-12/05	Gasolina	FWD	1595	74	100	11.99-06.06	■
1.6 16V (AUS)	-12/05	Gasolina	FWD	1598	77	105	09.00-06.06	■
1.6 16V (AUS)	-12/05	Gasolina	FWD	1598	77	105	09.00-06.06	■
1.6 16V (AZD)	-12/05	Gasolina	FWD	1598	77	105	09.00-06.06	■
1.6 16V (AZD)	-12/05	Gasolina	FWD	1598	77	105	09.00-06.06	■
1.6 16V (BCB)	-12/05	Gasolina	FWD	1598	77	105	09.00-06.06	■
1.6 16V (BCB)	-12/05	Gasolina	FWD	1598	77	105	09.00-06.06	■
1.8 20V (AGN)	-12/05	Gasolina	FWD	1781	92	125	11.99-06.06	■
1.8 20V (AGN)	-12/05	Gasolina	FWD	1781	92	125	11.99-06.06	■
1.8 20V (APG)	-12/05	Gasolina	FWD	1781	92	125	11.99-06.06	■
1.8 20V (APG)	-12/05	Gasolina	FWD	1781	92	125	11.99-06.06	■
1.8 20VT (APP)	-12/05	Gasolina	FWD	1781	132	180	11.99-06.06	■
1.8 20VT (APP)	-12/05	Gasolina	FWD	1781	132	180	11.99-06.06	■
1.8 20VT (AUQ)	-12/05	Gasolina	FWD	1781	132	180	11.99-06.06	■
1.8 20VT (AUQ)	-12/05	Gasolina	FWD	1781	132	180	11.99-06.06	■
1.8 20V T 4 (AJQ)	-12/05	Gasolina	4WD	1781	132	180	11.99-06.06	■
1.8 20V T 4 (AJQ)	-12/05	Gasolina	4WD	1781	132	180	11.99-06.06	■
1.8 20V T 4 (ARY)	-12/05	Gasolina	4WD	1781	132	180	11.99-06.06	■
1.8 20V T 4 (ARY)	-12/05	Gasolina	4WD	1781	132	180	11.99-06.06	■
1.9 SDI (AQM)	01/00-	Diesel	FWD	1896	50	68	11.99-06.06	■
1.9 SDI (AQM)	01/00-	Diesel	FWD	1896	50	68	11.99-06.06	■
1.9 TDI (AGR)	-12/05	Diesel	FWD	1896	66	90	11.99-06.06	■
1.9 TDI (AGR)	-12/05	Diesel	FWD	1896	66	90	11.99-06.06	■
1.9 TDI (ALH)	-12/05	Diesel	FWD	1896	66	90	11.99-06.06	■
1.9 TDI (ALH)	-12/05	Diesel	FWD	1896	66	90	11.99-06.06	■
1.9 TDI (AXR)		Diesel	FWD	1896	74	100	10.05-06.06	■
1.9 TDI (AXR)		Diesel	FWD	1896	74	100	10.05-06.06	■
1.9 TDI (AHF)	-12/05	Diesel	FWD	1896	81	110	11.99-06.06	■
1.9 TDI (AHF)	-12/05	Diesel	FWD	1896	81	110	11.99-06.06	■
1.9 TDI (ASV)	-12/05	Diesel	FWD	1896	81	110	11.99-06.06	■
1.9 TDI (ASV)	-12/05	Diesel	FWD	1896	81	110	11.99-06.06	■
1.9 TDI (ASZ)	-12/05	Diesel	FWD	1896	96	130	05.03-06.06	■
1.9 TDI (ASZ)	-12/05	Diesel	FWD	1896	96	130	05.03-06.06	■
1.9 TDI (ARL)	-12/05	Diesel	FWD	1896	110	150	09.00-06.06	■
1.9 TDI (ARL)	-12/05	Diesel	FWD	1896	110	150	09.00-06.06	■
1.9 TDI Syncro (ARL)	-12/02	Diesel	4WD	1896	110	150	05.02-06.06	■
1.9 TDI Syncro (ARL)	-12/02	Diesel	4WD	1896	110	150	05.02-06.06	■
<b>TOLEDO II (1M2) 10.98-05.06</b>				<b>Saloon (Compact car-C Segment)</b>				
1.4 16V (AHW)		Gasolina	FWD	1390	55	75	01.00-05.02	■
1.4 16V (AHW)		Gasolina	FWD	1390	55	75	01.00-05.02	■
1.4 16V (APE)		Gasolina	FWD	1390	55	75	01.00-05.02	■
1.4 16V (APE)		Gasolina	FWD	1390	55	75	01.00-05.02	■
1.4 16V (AXP)		Gasolina	FWD	1390	55	75	01.00-05.02	■
1.4 16V (AXP)		Gasolina	FWD	1390	55	75	01.00-05.02	■
1.4 16V (BCA)		Gasolina	FWD	1390	55	75	01.00-05.02	■

# LISTA DE APLICACIONES - BUYERS GUIDE

1.4 16V (BCA)		Gasolina	FWD	1390	55	75	01.00-05.02	■	
1.6 (AEH)		Gasolina	FWD	1595	74	100	10.98-07.04	■	
1.6 (AEH)		Gasolina	FWD	1595	74	100	10.98-07.04	■	
1.6 (AKL)		Gasolina	FWD	1595	74	100	10.98-07.04	■	
1.6 (AKL)		Gasolina	FWD	1595	74	100	10.98-07.04	■	
1.6		Gasolina	FWD	1595	75	102	08.05-05.06	■	
1.6		Gasolina	FWD	1595	75	102	08.05-05.06	■	
1.6 16V (AUS)	-12/04	Gasolina	FWD	1598	77	105	06.00-05.06	■	
1.6 16V (AUS)	-12/04	Gasolina	FWD	1598	77	105	06.00-05.06	■	
1.6 16V (AZD)	-12/04	Gasolina	FWD	1598	77	105	06.00-05.06	■	
1.6 16V (AZD)	-12/04	Gasolina	FWD	1598	77	105	06.00-05.06	■	
1.6 16V (BCB)	-12/04	Gasolina	FWD	1598	77	105	06.00-05.06	■	
1.6 16V (BCB)	-12/04	Gasolina	FWD	1598	77	105	06.00-05.06	■	
1.8 20V (AGN)	-12/02	Gasolina	FWD	1781	92	125	10.98-07.04	■	
1.8 20V (AGN)	-12/02	Gasolina	FWD	1781	92	125	10.98-07.04	■	
1.8 20V (APG)	-12/02	Gasolina	FWD	1781	92	125	10.98-07.04	■	
1.8 20V (APG)	-12/02	Gasolina	FWD	1781	92	125	10.98-07.04	■	
1.8		Gasolina	FWD	1781	132	179	05.01-04.04	■	
1.8		Gasolina	FWD	1781	132	179	05.01-04.04	■	
1.8 20VT (APP)	-12/02	Gasolina	FWD	1781	132	180	09.00-07.04	■	
1.8 20VT (APP)	-12/02	Gasolina	FWD	1781	132	180	09.00-07.04	■	
1.8 20VT (ARY)	-12/02	Gasolina	FWD	1781	132	180	09.00-07.04	■	
1.8 20VT (ARY)	-12/02	Gasolina	FWD	1781	132	180	09.00-07.04	■	
1.8 20VT (AUQ)	-12/02	Gasolina	FWD	1781	132	180	09.00-07.04	■	
1.8 20VT (AUQ)	-12/02	Gasolina	FWD	1781	132	180	09.00-07.04	■	
1.8		Gasolina	FWD	1781	154	209	05.02-05.03	■	
1.8		Gasolina	FWD	1781	154	209	05.02-05.03	■	
2.3 V5 (AGZ)		Gasolina	FWD	2324	110	150	10.98-11.00	■	
2.3 V5 (AGZ)		Gasolina	FWD	2324	110	150	10.98-11.00	■	
2.3 V5 20V (AQN)	-12/02	Gasolina	FWD	2324	125	170	09.00-11.03	■	
2.3 V5 20V (AQN)	-12/02	Gasolina	FWD	2324	125	170	09.00-11.03	■	
1.9 TDI (AGR)		Diesel	FWD	1896	66	90	03.99-07.04	■	
1.9 TDI (AGR)		Diesel	FWD	1896	66	90	03.99-07.04	■	
1.9 TDI (ALH)		Diesel	FWD	1896	66	90	03.99-07.04	■	
1.9 TDI (ALH)		Diesel	FWD	1896	66	90	03.99-07.04	■	
1.9 TDI (AXR)		Diesel	FWD	1896	74	101	08.05-05.06	■	
1.9 TDI (AXR)		Diesel	FWD	1896	74	101	08.05-05.06	■	
1.9 TDI (AHF)		Diesel	FWD	1896	81	110	10.98-07.04	■	
1.9 TDI (AHF)		Diesel	FWD	1896	81	110	10.98-07.04	■	
1.9 TDI (ASV)		Diesel	FWD	1896	81	110	10.98-07.04	■	
1.9 TDI (ASV)		Diesel	FWD	1896	81	110	10.98-07.04	■	
1.9 TDI (ASZ)	-12/04	Diesel	FWD	1896	96	130	05.03-05.06	■	
1.9 TDI (ASZ)	-12/04	Diesel	FWD	1896	96	130	05.03-05.06	■	
1.9 TDI (ARL)		Diesel	FWD	1896	110	150	10.00-07.04	■	
1.9 TDI (ARL)		Diesel	FWD	1896	110	150	10.00-07.04	■	
<b>SKODA</b>									
<b>FABIA (6Y2) 08.99-03.08</b>							<b>Hatchback (Compact car-C Segment)</b>		
1.4 16V (AUB)	-12/00	Gasolina	FWD	1390	74	100	12.99-03.08	■	
1.4 16V (AUB)	-12/00	Gasolina	FWD	1390	74	100	12.99-03.08	■	
1.4 16V (BBZ)	-12/00	Gasolina	FWD	1390	74	100	12.99-03.08	■	
1.4 16V (BBZ)	-12/00	Gasolina	FWD	1390	74	100	12.99-03.08	■	

# LISTA DE APLICACIONES - BUYERS GUIDE

2.0 (AZL)	-12/01	Gasolina	FWD	1984	85	116	12.99-03.08	■	
2.0 (AZL)	-12/01	Gasolina	FWD	1984	85	116	12.99-03.08	■	
1.9 TDI (ATD)	-12/00	Diesel	FWD	1896	74	100	01.00-03.08	■	
1.9 TDI (ATD)	-12/00	Diesel	FWD	1896	74	100	01.00-03.08	■	
1.9 TDI (AXR)	-12/00	Diesel	FWD	1896	74	100	01.00-03.08	■	
1.9 TDI (AXR)	-12/00	Diesel	FWD	1896	74	100	01.00-03.08	■	
<b>FABIA (6Y3) 10.99-12.07</b>							<b>Saloon (Compact car-C Segment)</b>		
1.4 16V (AUB)	-12/00	Gasolina	FWD	1390	74	100	12.99-12.07	■	
1.4 16V (AUB)	-12/00	Gasolina	FWD	1390	74	100	12.99-12.07	■	
1.4 16V (BBZ)	-12/00	Gasolina	FWD	1390	74	100	12.99-12.07	■	
1.4 16V (BBZ)	-12/00	Gasolina	FWD	1390	74	100	12.99-12.07	■	
2.0 (AZL)	-12/01	Gasolina	FWD	1984	85	116	12.99-12.07	■	
2.0 (AZL)	-12/01	Gasolina	FWD	1984	85	116	12.99-12.07	■	
1.9 TDI (ATD)	-12/00	Diesel	FWD	1896	74	100	01.00-12.07	■	
1.9 TDI (ATD)	-12/00	Diesel	FWD	1896	74	100	01.00-12.07	■	
1.9 TDI (AXR)	-12/00	Diesel	FWD	1896	74	100	01.00-12.07	■	
1.9 TDI (AXR)	-12/00	Diesel	FWD	1896	74	100	01.00-12.07	■	
<b>FABIA II (542) 12.06-12.14</b>							<b>Hatchback (Compact car-C Segment)</b>		
1.4 (BXW)		Gasolina	FWD	1390	63	86	01.07-12.14	■	
1.4 (BXW)		Gasolina	FWD	1390	63	86	01.07-12.14	■	
1.4 (CGGB)		Gasolina	FWD	1390	63	86	01.07-12.14	■	
1.4 (CGGB)		Gasolina	FWD	1390	63	86	01.07-12.14	■	
1.6 (BTS)		Gasolina	FWD	1598	77	105	04.07-12.14	■	
1.6 (BTS)		Gasolina	FWD	1598	77	105	04.07-12.14	■	
1.6 (CFNA)		Gasolina	FWD	1598	77	105	04.07-12.14	■	
1.6 (CFNA)		Gasolina	FWD	1598	77	105	04.07-12.14	■	
1.6 (CLSA)		Gasolina	FWD	1598	77	105	04.07-12.14	■	
1.6 (CLSA)		Gasolina	FWD	1598	77	105	04.07-12.14	■	
1.4 TDI (BMS)		Diesel	FWD	1422	59	80	01.07-03.10	■	
1.4 TDI (BMS)		Diesel	FWD	1422	59	80	01.07-03.10	■	
1.4 TDI (BNV)		Diesel	FWD	1422	59	80	01.07-03.10	■	
1.4 TDI (BNV)		Diesel	FWD	1422	59	80	01.07-03.10	■	
1.9 TDI (BLS)		Diesel	FWD	1896	77	105	04.07-03.10	■	
1.9 TDI (BLS)		Diesel	FWD	1896	77	105	04.07-03.10	■	
1.9 TDI (BSW)		Diesel	FWD	1896	77	105	04.07-03.10	■	
1.9 TDI (BSW)		Diesel	FWD	1896	77	105	04.07-03.10	■	
<b>FABIA II Combi (545) 10.07-12.14</b>							<b>Estate (Compact car-C Segment)</b>		
1.4 (BXW)		Gasolina	FWD	1390	63	86	10.07-12.14	■	
1.4 (BXW)		Gasolina	FWD	1390	63	86	10.07-12.14	■	
1.4 (CGGB)		Gasolina	FWD	1390	63	86	10.07-12.14	■	
1.4 (CGGB)		Gasolina	FWD	1390	63	86	10.07-12.14	■	
1.6 (BTS)		Gasolina	FWD	1598	77	105	10.07-12.14	■	
1.6 (BTS)		Gasolina	FWD	1598	77	105	10.07-12.14	■	
1.6 (CFNA)		Gasolina	FWD	1598	77	105	10.07-12.14	■	
1.6 (CFNA)		Gasolina	FWD	1598	77	105	10.07-12.14	■	
1.4 TDI (BMS)		Diesel	FWD	1422	59	80	10.07-03.10	■	
1.4 TDI (BMS)		Diesel	FWD	1422	59	80	10.07-03.10	■	
1.4 TDI (BNV)		Diesel	FWD	1422	59	80	10.07-03.10	■	
1.4 TDI (BNV)		Diesel	FWD	1422	59	80	10.07-03.10	■	
1.9 TDI (BLS)		Diesel	FWD	1896	77	105	10.07-03.10	■	

# LISTA DE APLICACIONES - BUYERS GUIDE

1.9 TDI (BLS)		Diesel	FWD	1896	77	105	10.07-03.10	■	
1.9 TDI (BSW)		Diesel	FWD	1896	77	105	10.07-03.10	■	
1.9 TDI (BSW)		Diesel	FWD	1896	77	105	10.07-03.10	■	
<b>FABIA Combi (6Y5) 04.00-12.07</b>					<b>Estate (Compact car-C Segment)</b>				
1.4 16V (AUB)	-12/00	Gasolina	FWD	1390	74	100	04.00-12.07	■	
1.4 16V (AUB)	-12/00	Gasolina	FWD	1390	74	100	04.00-12.07	■	
1.4 16V (BBZ)	-12/00	Gasolina	FWD	1390	74	100	04.00-12.07	■	
1.4 16V (BBZ)	-12/00	Gasolina	FWD	1390	74	100	04.00-12.07	■	
2.0 (AZL)	-12/01	Gasolina	FWD	1984	85	116	04.00-12.07	■	
2.0 (AZL)	-12/01	Gasolina	FWD	1984	85	116	04.00-12.07	■	
1.9 TDI (ATD)	-12/00	Diesel	FWD	1896	74	100	04.00-12.07	■	
1.9 TDI (ATD)	-12/00	Diesel	FWD	1896	74	100	04.00-12.07	■	
1.9 TDI (AXR)	-12/00	Diesel	FWD	1896	74	100	04.00-12.07	■	
1.9 TDI (AXR)	-12/00	Diesel	FWD	1896	74	100	04.00-12.07	■	
<b>OCTAVIA (1U5) 08.00-03.10</b>					<b>Estate Van (Compact car-C Segment)</b>				
1.9 TDI (ALH)	-12/04	Diesel	FWD	1896	66	90	08.00-03.10	■	
1.9 TDI (ALH)	-12/04	Diesel	FWD	1896	66	90	08.00-03.10	■	
<b>OCTAVIA (1U2) 09.96-12.10</b>					<b>Hatchback (Compact car-C Segment)</b>				
1.8 (AGN)		Gasolina	FWD	1781	92	125	09.96-07.00	■	
1.8 (AGN)		Gasolina	FWD	1781	92	125	09.96-07.00	■	
1.8 T (AGU)	01/99-	Gasolina	FWD	1781	110	150	08.97-12.10	■	
1.8 T (AGU)	01/99-	Gasolina	FWD	1781	110	150	08.97-12.10	■	
1.8 T (ARX)	01/99-	Gasolina	FWD	1781	110	150	08.97-12.10	■	
1.8 T (ARX)	01/99-	Gasolina	FWD	1781	110	150	08.97-12.10	■	
1.8 T (ARZ)	01/99-	Gasolina	FWD	1781	110	150	08.97-12.10	■	
1.8 T (ARZ)	01/99-	Gasolina	FWD	1781	110	150	08.97-12.10	■	
1.8 T (AUM)	01/99-	Gasolina	FWD	1781	110	150	08.97-12.10	■	
1.8 T (AUM)	01/99-	Gasolina	FWD	1781	110	150	08.97-12.10	■	
1.8 T 4x4 (ARX)	-12/04	Gasolina	4WD	1781	110	150	05.01-05.06	■	
1.8 T 4x4 (ARX)	-12/04	Gasolina	4WD	1781	110	150	05.01-05.06	■	
2.0 (AEG)	-12/04	Gasolina	FWD	1984	85	116	04.99-05.07	■	
2.0 (AEG)	-12/04	Gasolina	FWD	1984	85	116	04.99-05.07	■	
2.0 (APK)	-12/04	Gasolina	FWD	1984	85	116	04.99-05.07	■	
2.0 (APK)	-12/04	Gasolina	FWD	1984	85	116	04.99-05.07	■	
2.0 (AQY)	-12/04	Gasolina	FWD	1984	85	116	04.99-05.07	■	
2.0 (AQY)	-12/04	Gasolina	FWD	1984	85	116	04.99-05.07	■	
2.0 (AZH)	-12/04	Gasolina	FWD	1984	85	116	04.99-05.07	■	
2.0 (AZH)	-12/04	Gasolina	FWD	1984	85	116	04.99-05.07	■	
2.0 (AZJ)	-12/04	Gasolina	FWD	1984	85	116	04.99-05.07	■	
2.0 (AZJ)	-12/04	Gasolina	FWD	1984	85	116	04.99-05.07	■	
1.9 TDI (AGR)	-12/04	Diesel	FWD	1896	66	90	09.96-03.10	■	
1.9 TDI (AGR)	-12/04	Diesel	FWD	1896	66	90	09.96-03.10	■	
1.9 TDI (ALH)	-12/04	Diesel	FWD	1896	66	90	09.96-03.10	■	
1.9 TDI (ALH)	-12/04	Diesel	FWD	1896	66	90	09.96-03.10	■	
1.9 TDI (AXR)		Diesel	FWD	1896	74	100	10.05-12.10	■	
1.9 TDI (AXR)		Diesel	FWD	1896	74	100	10.05-12.10	■	
1.9 TDI (AHF)	-12/04	Diesel	FWD	1896	81	110	08.97-01.06	■	
1.9 TDI (AHF)	-12/04	Diesel	FWD	1896	81	110	08.97-01.06	■	
1.9 TDI (ASV)	-12/04	Diesel	FWD	1896	81	110	08.97-01.06	■	
1.9 TDI (ASV)	-12/04	Diesel	FWD	1896	81	110	08.97-01.06	■	

# LISTA DE APLICACIONES - BUYERS GUIDE

1.9 TDI (ASZ)		Diesel	FWD	1896	96	130	09.02-09.04	■	
1.9 TDI (ASZ)		Diesel	FWD	1896	96	130	09.02-09.04	■	
<b>OCTAVIA Combi (1U5) 07.98-12.10</b>					<b>Estate (Compact car-C Segment)</b>				
1.8 20V (AGN)		Gasolina	FWD	1781	92	125	07.98-07.00	■	
1.8 20V (AGN)		Gasolina	FWD	1781	92	125	07.98-07.00	■	
1.8 T (AGU)	01/99-	Gasolina	FWD	1781	110	150	07.98-12.10	■	
1.8 T (AGU)	01/99-	Gasolina	FWD	1781	110	150	07.98-12.10	■	
1.8 T (ARX)	01/99-	Gasolina	FWD	1781	110	150	07.98-12.10	■	
1.8 T (ARX)	01/99-	Gasolina	FWD	1781	110	150	07.98-12.10	■	
1.8 T (ARZ)	01/99-	Gasolina	FWD	1781	110	150	07.98-12.10	■	
1.8 T (ARZ)	01/99-	Gasolina	FWD	1781	110	150	07.98-12.10	■	
1.8 T (AUM)	01/99-	Gasolina	FWD	1781	110	150	07.98-12.10	■	
1.8 T (AUM)	01/99-	Gasolina	FWD	1781	110	150	07.98-12.10	■	
1.8 T 4x4 (ARX)	-12/04	Gasolina	4WD	1781	110	150	05.01-05.06	■	
1.8 T 4x4 (ARX)	-12/04	Gasolina	4WD	1781	110	150	05.01-05.06	■	
2.0 (AEG)	-12/04	Gasolina	FWD	1984	85	116	04.99-05.07	■	
2.0 (AEG)	-12/04	Gasolina	FWD	1984	85	116	04.99-05.07	■	
2.0 (APK)	-12/04	Gasolina	FWD	1984	85	116	04.99-05.07	■	
2.0 (APK)	-12/04	Gasolina	FWD	1984	85	116	04.99-05.07	■	
2.0 (AQY)	-12/04	Gasolina	FWD	1984	85	116	04.99-05.07	■	
2.0 (AQY)	-12/04	Gasolina	FWD	1984	85	116	04.99-05.07	■	
2.0 (AZH)	-12/04	Gasolina	FWD	1984	85	116	04.99-05.07	■	
2.0 (AZH)	-12/04	Gasolina	FWD	1984	85	116	04.99-05.07	■	
2.0 (AZJ)	-12/04	Gasolina	FWD	1984	85	116	04.99-05.07	■	
2.0 (AZJ)	-12/04	Gasolina	FWD	1984	85	116	04.99-05.07	■	
2.0 4x4 (AZH)		Gasolina	4WD	1984	85	116	08.00-09.04	■	
2.0 4x4 (AZH)		Gasolina	4WD	1984	85	116	08.00-09.04	■	
2.0 4x4 (AZJ)		Gasolina	4WD	1984	85	116	08.00-09.04	■	
2.0 4x4 (AZJ)		Gasolina	4WD	1984	85	116	08.00-09.04	■	
2.0 4x4 (ATF)	-12/04	Gasolina	4WD	1984	88	120	01.00-12.10	■	
2.0 4x4 (ATF)	-12/04	Gasolina	4WD	1984	88	120	01.00-12.10	■	
1.9 TDI (AXR)	-12/04	Diesel	FWD	1896	74	100	08.00-12.10	■	
1.9 TDI (AXR)	-12/04	Diesel	FWD	1896	74	100	08.00-12.10	■	
1.9 TDI 4x4 (ATD)	-12/04	Diesel	4WD	1896	74	100	09.00-01.06	■	
1.9 TDI 4x4 (ATD)	-12/04	Diesel	4WD	1896	74	100	09.00-01.06	■	
1.9 TDI (AHF)	-12/04	Diesel	FWD	1896	81	110	07.98-01.06	■	
1.9 TDI (AHF)	-12/04	Diesel	FWD	1896	81	110	07.98-01.06	■	
1.9 TDI (ASV)	-12/04	Diesel	FWD	1896	81	110	07.98-01.06	■	
1.9 TDI (ASV)	-12/04	Diesel	FWD	1896	81	110	07.98-01.06	■	
1.9 TDI (ASZ)		Diesel	FWD	1896	96	130	09.02-09.04	■	
1.9 TDI (ASZ)		Diesel	FWD	1896	96	130	09.02-09.04	■	
<b>OCTAVIA II / LAURA (1Z3) 02.04-06.13</b>					<b>Hatchback (Compact car-C Segment)</b>				
2.0 TDI (BMM)		Diesel	FWD	1968	103	140	11.05-05.10	■	
2.0 TDI (BMM)		Diesel	FWD	1968	103	140	11.05-05.10	■	
2.0 TDI 16V (BKD)		Diesel	FWD	1968	103	140	02.04-04.13	■	
2.0 TDI 16V (BKD)		Diesel	FWD	1968	103	140	02.04-04.13	■	
2.0 TDI 16V (CFHC)		Diesel	FWD	1968	103	140	02.04-04.13	■	
2.0 TDI 16V (CFHC)		Diesel	FWD	1968	103	140	02.04-04.13	■	
2.0 TDI 16V (CLCB)		Diesel	FWD	1968	103	140	02.04-04.13	■	
2.0 TDI 16V (CLCB)		Diesel	FWD	1968	103	140	02.04-04.13	■	

# LISTA DE APLICACIONES - BUYERS GUIDE

<b>ROOMSTER / PRAKTIK (5J) 03.07-05.15</b>					<b>Estate Van (Large MPV-M1 Segment)</b>			
1.4 (BXW)		Gasolina	FWD	1390	63	86	03.07-05.15	■
1.4 (BXW)		Gasolina	FWD	1390	63	86	03.07-05.15	■
1.4 (CGGB)		Gasolina	FWD	1390	63	86	03.07-05.15	■
1.4 (CGGB)		Gasolina	FWD	1390	63	86	03.07-05.15	■
1.4 TDI (BMS)		Diesel	FWD	1422	59	80	03.07-03.10	■
1.4 TDI (BMS)		Diesel	FWD	1422	59	80	03.07-03.10	■
1.4 TDI (BNV)		Diesel	FWD	1422	59	80	03.07-03.10	■
1.4 TDI (BNV)		Diesel	FWD	1422	59	80	03.07-03.10	■
<b>ROOMSTER / PRAKTIK (5J7) 03.06-05.15</b>					<b>MPV (Large MPV-M1 Segment)</b>			
1.2 (BME)		Gasolina	FWD	1198	47	64	05.06-01.07	■
1.2 (BME)		Gasolina	FWD	1198	47	64	05.06-01.07	■
1.2 (BZG)		Gasolina	FWD	1198	51	70	01.07-05.15	■
1.2 (BZG)		Gasolina	FWD	1198	51	70	01.07-05.15	■
1.2 (CGPA)		Gasolina	FWD	1198	51	70	01.07-05.15	■
1.2 (CGPA)		Gasolina	FWD	1198	51	70	01.07-05.15	■
1.4 TDI (BNM)		Diesel	FWD	1422	51	70	07.06-03.10	■
1.4 TDI (BNM)		Diesel	FWD	1422	51	70	07.06-03.10	■
1.9 TDI (BLS)		Diesel	FWD	1896	77	105	09.06-03.10	■
1.9 TDI (BLS)		Diesel	FWD	1896	77	105	09.06-03.10	■
1.9 TDI (BSW)		Diesel	FWD	1896	77	105	09.06-03.10	■
1.9 TDI (BSW)		Diesel	FWD	1896	77	105	09.06-03.10	■
<b>VW</b>								
<b>BORA / JETTA IV (1J2) 10.98-12.13</b>					<b>Saloon (Compact car-C Segment)</b>			
1.4 16V (AHW)	-12/01	Gasolina	FWD	1390	55	75	03.00-05.05	■
1.4 16V (AHW)	-12/01	Gasolina	FWD	1390	55	75	03.00-05.05	■
1.4 16V (AKQ)	-12/01	Gasolina	FWD	1390	55	75	03.00-05.05	■
1.4 16V (AKQ)	-12/01	Gasolina	FWD	1390	55	75	03.00-05.05	■
1.4 16V (APE)	-12/01	Gasolina	FWD	1390	55	75	03.00-05.05	■
1.4 16V (APE)	-12/01	Gasolina	FWD	1390	55	75	03.00-05.05	■
1.4 16V (AXP)	-12/01	Gasolina	FWD	1390	55	75	03.00-05.05	■
1.4 16V (AXP)	-12/01	Gasolina	FWD	1390	55	75	03.00-05.05	■
1.4 16V (BCA)	-12/01	Gasolina	FWD	1390	55	75	03.00-05.05	■
1.4 16V (BCA)	-12/01	Gasolina	FWD	1390	55	75	03.00-05.05	■
1.6 (AEH)	-12/01	Gasolina	FWD	1595	74	101	10.98-05.05	■
1.6 (AEH)	-12/01	Gasolina	FWD	1595	74	101	10.98-05.05	■
1.6 (AKL)	-12/01	Gasolina	FWD	1595	74	101	10.98-05.05	■
1.6 (AKL)	-12/01	Gasolina	FWD	1595	74	101	10.98-05.05	■
1.6 (APF)	-12/01	Gasolina	FWD	1595	74	101	10.98-05.05	■
1.6 (APF)	-12/01	Gasolina	FWD	1595	74	101	10.98-05.05	■
1.6 (AVU)		Gasolina	FWD	1595	75	102	08.00-05.05	■
1.6 (AVU)		Gasolina	FWD	1595	75	102	08.00-05.05	■
1.6 (BFQ)		Gasolina	FWD	1595	75	102	08.00-05.05	■
1.6 (BFQ)		Gasolina	FWD	1595	75	102	08.00-05.05	■
1.6		Gasolina	FWD	1595	78	107	06.02-10.04	■
1.6		Gasolina	FWD	1595	78	107	06.02-10.04	■
1.6 16V (ATN)		Gasolina	FWD	1598	77	105	05.00-05.05	■
1.6 16V (ATN)		Gasolina	FWD	1598	77	105	05.00-05.05	■
1.6 16V (AUS)		Gasolina	FWD	1598	77	105	05.00-05.05	■
1.6 16V (AUS)		Gasolina	FWD	1598	77	105	05.00-05.05	■

# LISTA DE APLICACIONES - BUYERS GUIDE

1.6 16V (AZD)		Gasolina	FWD	1598	77	105	05.00-05.05	■
1.6 16V (AZD)		Gasolina	FWD	1598	77	105	05.00-05.05	■
1.6 16V (BCB)		Gasolina	FWD	1598	77	105	05.00-05.05	■
1.6 16V (BCB)		Gasolina	FWD	1598	77	105	05.00-05.05	■
1.6 FSI (BAD)		Gasolina	FWD	1598	81	110	01.02-05.05	■
1.6 FSI (BAD)		Gasolina	FWD	1598	81	110	01.02-05.05	■
1.8 (AGN)	-12/00	Gasolina	FWD	1781	92	125	10.98-05.05	■
1.8 (AGN)	-12/00	Gasolina	FWD	1781	92	125	10.98-05.05	■
1.8 (BAF)	-12/00	Gasolina	FWD	1781	92	125	10.98-05.05	■
1.8 (BAF)	-12/00	Gasolina	FWD	1781	92	125	10.98-05.05	■
1.8		Gasolina	FWD	1781	110	150	10.00-05.01	■
1.8		Gasolina	FWD	1781	110	150	10.00-05.01	■
1.8 T (AGU)		Gasolina	FWD	1781	110	150	05.00-05.05	■
1.8 T (AGU)		Gasolina	FWD	1781	110	150	05.00-05.05	■
1.8 T (ARX)		Gasolina	FWD	1781	110	150	05.00-05.05	■
1.8 T (ARX)		Gasolina	FWD	1781	110	150	05.00-05.05	■
1.8 T (AUM)		Gasolina	FWD	1781	110	150	05.00-05.05	■
1.8 T (AUM)		Gasolina	FWD	1781	110	150	05.00-05.05	■
1.8 T (AWD)		Gasolina	FWD	1781	110	150	05.00-05.05	■
1.8 T (AWD)		Gasolina	FWD	1781	110	150	05.00-05.05	■
1.8 T (AWW)		Gasolina	FWD	1781	110	150	05.00-05.05	■
1.8 T (AWW)		Gasolina	FWD	1781	110	150	05.00-05.05	■
1.8 T (AUQ)		Gasolina	FWD	1781	132	180	03.02-05.05	■
1.8 T (AUQ)		Gasolina	FWD	1781	132	180	03.02-05.05	■
1.8 T (AWP)		Gasolina	FWD	1781	132	180	03.02-05.05	■
1.8 T (AWP)		Gasolina	FWD	1781	132	180	03.02-05.05	■
2.0 (AEG)	01/00-	Gasolina	FWD	1984	85	115	10.98-12.13	■
2.0 (AEG)	01/00-	Gasolina	FWD	1984	85	115	10.98-12.13	■
2.0 (APK)	01/00-	Gasolina	FWD	1984	85	115	10.98-12.13	■
2.0 (APK)	01/00-	Gasolina	FWD	1984	85	115	10.98-12.13	■
2.0 (AQY)	01/00-	Gasolina	FWD	1984	85	115	10.98-12.13	■
2.0 (AQY)	01/00-	Gasolina	FWD	1984	85	115	10.98-12.13	■
2.0 (AVH)	01/00-	Gasolina	FWD	1984	85	115	10.98-12.13	■
2.0 (AVH)	01/00-	Gasolina	FWD	1984	85	115	10.98-12.13	■
2.0 (AZG)	01/00-	Gasolina	FWD	1984	85	115	10.98-12.13	■
2.0 (AZG)	01/00-	Gasolina	FWD	1984	85	115	10.98-12.13	■
2.0 (AZH)	01/00-	Gasolina	FWD	1984	85	115	10.98-12.13	■
2.0 (AZH)	01/00-	Gasolina	FWD	1984	85	115	10.98-12.13	■
2.0 (AZJ)	01/00-	Gasolina	FWD	1984	85	115	10.98-12.13	■
2.0 (AZJ)	01/00-	Gasolina	FWD	1984	85	115	10.98-12.13	■
2.0 (BBW)	01/00-	Gasolina	FWD	1984	85	115	10.98-12.13	■
2.0 (BBW)	01/00-	Gasolina	FWD	1984	85	115	10.98-12.13	■
2.0 (BER)	01/00-	Gasolina	FWD	1984	85	115	10.98-12.13	■
2.0 (BER)	01/00-	Gasolina	FWD	1984	85	115	10.98-12.13	■
2.0 (BEV)	01/00-	Gasolina	FWD	1984	85	115	10.98-12.13	■
2.0 (BEV)	01/00-	Gasolina	FWD	1984	85	115	10.98-12.13	■
2.0 (BHP)	01/00-	Gasolina	FWD	1984	85	115	10.98-12.13	■
2.0 (BHP)	01/00-	Gasolina	FWD	1984	85	115	10.98-12.13	■
2.0 (CBPA)	01/00-	Gasolina	FWD	1984	85	115	10.98-12.13	■
2.0 (CBPA)	01/00-	Gasolina	FWD	1984	85	115	10.98-12.13	■
2.0 (CFEA)	01/00-	Gasolina	FWD	1984	85	115	10.98-12.13	■

# LISTA DE APLICACIONES - BUYERS GUIDE

2.0 (CFEA)	01/00-	Gasolina	FWD	1984	85	115	10.98-12.13	■	
2.3 V5 (AGZ)		Gasolina	FWD	2324	110	150	10.98-10.00	■	
2.3 V5 (AGZ)		Gasolina	FWD	2324	110	150	10.98-10.00	■	
2.3 V5 4motion (AGZ)		Gasolina	4WD	2324	110	150	12.98-10.00	■	
2.3 V5 4motion (AGZ)		Gasolina	4WD	2324	110	150	12.98-10.00	■	
2.3 V5 (AQN)		Gasolina	FWD	2324	125	170	10.00-05.05	■	
2.3 V5 (AQN)		Gasolina	FWD	2324	125	170	10.00-05.05	■	
1.9 SDI (AGP)	-12/99	Diesel	FWD	1896	50	68	10.98-05.05	■	
1.9 SDI (AGP)	-12/99	Diesel	FWD	1896	50	68	10.98-05.05	■	
1.9 SDI (AQM)	-12/99	Diesel	FWD	1896	50	68	10.98-05.05	■	
1.9 SDI (AQM)	-12/99	Diesel	FWD	1896	50	68	10.98-05.05	■	
1.9 TDI (AGR)		Diesel	FWD	1896	66	90	10.98-05.05	■	
1.9 TDI (AGR)		Diesel	FWD	1896	66	90	10.98-05.05	■	
1.9 TDI (ALH)		Diesel	FWD	1896	66	90	10.98-05.05	■	
1.9 TDI (ALH)		Diesel	FWD	1896	66	90	10.98-05.05	■	
1.9 TDI (ATD)		Diesel	FWD	1896	74	101	09.00-05.05	■	
1.9 TDI (ATD)		Diesel	FWD	1896	74	101	09.00-05.05	■	
1.9 TDI (AXR)		Diesel	FWD	1896	74	101	09.00-05.05	■	
1.9 TDI (AXR)		Diesel	FWD	1896	74	101	09.00-05.05	■	
1.9 TDI (BEW)		Diesel	FWD	1896	74	101	09.00-05.05	■	
1.9 TDI (BEW)		Diesel	FWD	1896	74	101	09.00-05.05	■	
1.9 TDI (AHF)		Diesel	FWD	1896	81	110	10.98-06.01	■	
1.9 TDI (AHF)		Diesel	FWD	1896	81	110	10.98-06.01	■	
1.9 TDI (ASV)		Diesel	FWD	1896	81	110	10.98-06.01	■	
1.9 TDI (ASV)		Diesel	FWD	1896	81	110	10.98-06.01	■	
1.9 TDI (AJM)		Diesel	FWD	1896	85	115	12.98-01.02	■	
1.9 TDI (AJM)		Diesel	FWD	1896	85	115	12.98-01.02	■	
1.9 TDI (AUY)		Diesel	FWD	1896	85	115	12.98-01.02	■	
1.9 TDI (AUY)		Diesel	FWD	1896	85	115	12.98-01.02	■	
<b>BORA Variant / JETTA IV (1J6) 05.99-05.05</b>							<b>Estate (Compact car-C Segment)</b>		
1.4 16V (AHW)	-12/01	Gasolina	FWD	1390	55	75	09.01-05.05	■	
1.4 16V (AHW)	-12/01	Gasolina	FWD	1390	55	75	09.01-05.05	■	
1.4 16V (AXP)	-12/01	Gasolina	FWD	1390	55	75	09.01-05.05	■	
1.4 16V (AXP)	-12/01	Gasolina	FWD	1390	55	75	09.01-05.05	■	
1.4 16V (BCA)	-12/01	Gasolina	FWD	1390	55	75	09.01-05.05	■	
1.4 16V (BCA)	-12/01	Gasolina	FWD	1390	55	75	09.01-05.05	■	
1.6 (AEH)	-12/01	Gasolina	FWD	1595	74	100	05.99-05.05	■	
1.6 (AEH)	-12/01	Gasolina	FWD	1595	74	100	05.99-05.05	■	
1.6 (AKL)	-12/01	Gasolina	FWD	1595	74	100	05.99-05.05	■	
1.6 (AKL)	-12/01	Gasolina	FWD	1595	74	100	05.99-05.05	■	
1.6 (APF)	-12/01	Gasolina	FWD	1595	74	100	05.99-05.05	■	
1.6 (APF)	-12/01	Gasolina	FWD	1595	74	100	05.99-05.05	■	
1.6 (AVU)		Gasolina	FWD	1595	75	102	08.00-05.05	■	
1.6 (AVU)		Gasolina	FWD	1595	75	102	08.00-05.05	■	
1.6 (BFQ)		Gasolina	FWD	1595	75	102	08.00-05.05	■	
1.6 (BFQ)		Gasolina	FWD	1595	75	102	08.00-05.05	■	
1.6 16V (ATN)		Gasolina	FWD	1598	77	105	02.00-05.05	■	
1.6 16V (ATN)		Gasolina	FWD	1598	77	105	02.00-05.05	■	
1.6 16V (AUS)		Gasolina	FWD	1598	77	105	02.00-05.05	■	
1.6 16V (AUS)		Gasolina	FWD	1598	77	105	02.00-05.05	■	
1.6 16V (AZD)		Gasolina	FWD	1598	77	105	02.00-05.05	■	

# LISTA DE APLICACIONES - BUYERS GUIDE

1.6 16V (AZD)		Gasolina	FWD	1598	77	105	02.00-05.05	■
1.6 16V (BCB)		Gasolina	FWD	1598	77	105	02.00-05.05	■
1.6 16V (BCB)		Gasolina	FWD	1598	77	105	02.00-05.05	■
1.6 FSI (BAD)		Gasolina	FWD	1598	81	110	01.02-05.05	■
1.6 FSI (BAD)		Gasolina	FWD	1598	81	110	01.02-05.05	■
1.8 T (AGU)		Gasolina	FWD	1781	110	150	05.00-05.05	■
1.8 T (AGU)		Gasolina	FWD	1781	110	150	05.00-05.05	■
1.8 T (ARX)		Gasolina	FWD	1781	110	150	05.00-05.05	■
1.8 T (ARX)		Gasolina	FWD	1781	110	150	05.00-05.05	■
1.8 T (AUM)		Gasolina	FWD	1781	110	150	05.00-05.05	■
1.8 T (AUM)		Gasolina	FWD	1781	110	150	05.00-05.05	■
1.8 T (AWD)		Gasolina	FWD	1781	110	150	05.00-05.05	■
1.8 T (AWD)		Gasolina	FWD	1781	110	150	05.00-05.05	■
1.8 T (AWW)		Gasolina	FWD	1781	110	150	05.00-05.05	■
1.8 T (AWW)		Gasolina	FWD	1781	110	150	05.00-05.05	■
1.8 T (AUQ)		Gasolina	FWD	1781	132	180	05.02-05.05	■
1.8 T (AUQ)		Gasolina	FWD	1781	132	180	05.02-05.05	■
1.8 T (AWP)		Gasolina	FWD	1781	132	180	05.02-05.05	■
1.8 T (AWP)		Gasolina	FWD	1781	132	180	05.02-05.05	■
2.0 (APK)	01/00-	Gasolina	FWD	1984	85	115	05.99-05.05	■
2.0 (APK)	01/00-	Gasolina	FWD	1984	85	115	05.99-05.05	■
2.0 (AQY)	01/00-	Gasolina	FWD	1984	85	115	05.99-05.05	■
2.0 (AQY)	01/00-	Gasolina	FWD	1984	85	115	05.99-05.05	■
2.0 (AVH)	01/00-	Gasolina	FWD	1984	85	115	05.99-05.05	■
2.0 (AVH)	01/00-	Gasolina	FWD	1984	85	115	05.99-05.05	■
2.0 (AZG)	01/00-	Gasolina	FWD	1984	85	115	05.99-05.05	■
2.0 (AZG)	01/00-	Gasolina	FWD	1984	85	115	05.99-05.05	■
2.0 (AZH)	01/00-	Gasolina	FWD	1984	85	115	05.99-05.05	■
2.0 (AZH)	01/00-	Gasolina	FWD	1984	85	115	05.99-05.05	■
2.0 (AZJ)	01/00-	Gasolina	FWD	1984	85	115	05.99-05.05	■
2.0 (AZJ)	01/00-	Gasolina	FWD	1984	85	115	05.99-05.05	■
2.0 (BEV)	01/00-	Gasolina	FWD	1984	85	115	05.99-05.05	■
2.0 (BEV)	01/00-	Gasolina	FWD	1984	85	115	05.99-05.05	■
2.3 V5 (AGZ)		Gasolina	FWD	2324	110	150	05.99-10.00	■
2.3 V5 (AGZ)		Gasolina	FWD	2324	110	150	05.99-10.00	■
2.3 V5 (AQN)		Gasolina	FWD	2324	125	170	10.00-05.05	■
2.3 V5 (AQN)		Gasolina	FWD	2324	125	170	10.00-05.05	■
1.9 TDI (AGR)		Diesel	FWD	1896	66	90	07.04-05.05	■
1.9 TDI (AGR)		Diesel	FWD	1896	66	90	07.04-05.05	■
1.9 TDI (ALH)		Diesel	FWD	1896	66	90	07.04-05.05	■
1.9 TDI (ALH)		Diesel	FWD	1896	66	90	07.04-05.05	■
1.9 TDI (ATD)		Diesel	FWD	1896	74	101	09.00-05.05	■
1.9 TDI (ATD)		Diesel	FWD	1896	74	101	09.00-05.05	■
1.9 TDI (AXR)		Diesel	FWD	1896	74	101	09.00-05.05	■
1.9 TDI (AXR)		Diesel	FWD	1896	74	101	09.00-05.05	■
1.9 TDI (BEW)		Diesel	FWD	1896	74	101	09.00-05.05	■
1.9 TDI (BEW)		Diesel	FWD	1896	74	101	09.00-05.05	■
1.9 TDI (AHF)		Diesel	FWD	1896	81	110	05.99-06.01	■
1.9 TDI (AHF)		Diesel	FWD	1896	81	110	05.99-06.01	■
1.9 TDI (ASV)		Diesel	FWD	1896	81	110	05.99-06.01	■
1.9 TDI (ASV)		Diesel	FWD	1896	81	110	05.99-06.01	■

# LISTA DE APLICACIONES - BUYERS GUIDE

1.9 TDI (AJM)		Diesel	FWD	1896	85	115	05.99-06.01	■	
1.9 TDI (AJM)		Diesel	FWD	1896	85	115	05.99-06.01	■	
1.9 TDI (AUJ)		Diesel	FWD	1896	85	115	05.99-06.01	■	
1.9 TDI (AUJ)		Diesel	FWD	1896	85	115	05.99-06.01	■	
<b>GOLF IV (1J1) 08.97-04.08</b>							<b>Hatchback (Compact car-C Segment)</b>		
1.0		Gasolina	FWD	998	51	69	08.97-05.02	■	
1.0		Gasolina	FWD	998	51	69	08.97-05.02	■	
1.0 Turbo		Gasolina	FWD	998	82	111	08.97-05.02	■	
1.0 Turbo		Gasolina	FWD	998	82	111	08.97-05.02	■	
1.4 16V (AHW)	01/03-	Gasolina	FWD	1390	55	75	10.97-05.04	■	
1.4 16V (AHW)	01/03-	Gasolina	FWD	1390	55	75	10.97-05.04	■	
1.4 16V (AKQ)	01/03-	Gasolina	FWD	1390	55	75	10.97-05.04	■	
1.4 16V (AKQ)	01/03-	Gasolina	FWD	1390	55	75	10.97-05.04	■	
1.4 16V (APE)	01/03-	Gasolina	FWD	1390	55	75	10.97-05.04	■	
1.4 16V (APE)	01/03-	Gasolina	FWD	1390	55	75	10.97-05.04	■	
1.4 16V (AXP)	01/03-	Gasolina	FWD	1390	55	75	10.97-05.04	■	
1.4 16V (AXP)	01/03-	Gasolina	FWD	1390	55	75	10.97-05.04	■	
1.4 16V (BCA)	01/03-	Gasolina	FWD	1390	55	75	10.97-05.04	■	
1.4 16V (BCA)	01/03-	Gasolina	FWD	1390	55	75	10.97-05.04	■	
1.6		Gasolina	FWD	1595	68	92	12.98-05.02	■	
1.6		Gasolina	FWD	1595	68	92	12.98-05.02	■	
1.6 (AEH)	01/03-	Gasolina	FWD	1595	74	100	08.97-05.04	■	
1.6 (AEH)	01/03-	Gasolina	FWD	1595	74	100	08.97-05.04	■	
1.6 (AKL)	01/03-	Gasolina	FWD	1595	74	100	08.97-05.04	■	
1.6 (AKL)	01/03-	Gasolina	FWD	1595	74	100	08.97-05.04	■	
1.6 (APF)	01/03-	Gasolina	FWD	1595	74	100	08.97-05.04	■	
1.6 (APF)	01/03-	Gasolina	FWD	1595	74	100	08.97-05.04	■	
1.6 (AVU)	-12/01	Gasolina	FWD	1595	75	102	08.00-06.05	■	
1.6 (AVU)	-12/01	Gasolina	FWD	1595	75	102	08.00-06.05	■	
1.6 (BFQ)	-12/01	Gasolina	FWD	1595	75	102	08.00-06.05	■	
1.6 (BFQ)	-12/01	Gasolina	FWD	1595	75	102	08.00-06.05	■	
1.6		Gasolina	FWD	1595	78	107	08.03-06.05	■	
1.6		Gasolina	FWD	1595	78	107	08.03-06.05	■	
1.6 (BAH)		Gasolina	FWD	1598	74	101	02.01-03.07	■	
1.6 (BAH)		Gasolina	FWD	1598	74	101	02.01-03.07	■	
1.6 16V (ATN)	01/03-	Gasolina	FWD	1598	77	105	02.00-06.05	■	
1.6 16V (ATN)	01/03-	Gasolina	FWD	1598	77	105	02.00-06.05	■	
1.6 16V (AUS)	01/03-	Gasolina	FWD	1598	77	105	02.00-06.05	■	
1.6 16V (AUS)	01/03-	Gasolina	FWD	1598	77	105	02.00-06.05	■	
1.6 16V (AZD)	01/03-	Gasolina	FWD	1598	77	105	02.00-06.05	■	
1.6 16V (AZD)	01/03-	Gasolina	FWD	1598	77	105	02.00-06.05	■	
1.6 16V (BCB)	01/03-	Gasolina	FWD	1598	77	105	02.00-06.05	■	
1.6 16V (BCB)	01/03-	Gasolina	FWD	1598	77	105	02.00-06.05	■	
1.6 FSI (BAD)	-12/03	Gasolina	FWD	1598	81	110	01.02-06.05	■	
1.6 FSI (BAD)	-12/03	Gasolina	FWD	1598	81	110	01.02-06.05	■	
1.8		Gasolina	FWD	1781	66	90	10.97-09.99	■	
1.8		Gasolina	FWD	1781	66	90	10.97-09.99	■	
1.8		Gasolina	FWD	1781	77	105	04.98-05.02	■	
1.8		Gasolina	FWD	1781	77	105	04.98-05.02	■	
1.8 (AGN)	01/98-	Gasolina	FWD	1781	92	125	08.97-06.05	■	
1.8 (AGN)	01/98-	Gasolina	FWD	1781	92	125	08.97-06.05	■	

# LISTA DE APLICACIONES - BUYERS GUIDE

2.0 (AEG)	01/03-	Gasolina	FWD	1984	85	115	07.98-05.04	■
2.0 (AEG)	01/03-	Gasolina	FWD	1984	85	115	07.98-05.04	■
2.0 (APK)	01/03-	Gasolina	FWD	1984	85	115	07.98-05.04	■
2.0 (APK)	01/03-	Gasolina	FWD	1984	85	115	07.98-05.04	■
2.0 (AQY)	01/03-	Gasolina	FWD	1984	85	115	07.98-05.04	■
2.0 (AQY)	01/03-	Gasolina	FWD	1984	85	115	07.98-05.04	■
2.0 (AVH)	01/03-	Gasolina	FWD	1984	85	115	07.98-05.04	■
2.0 (AVH)	01/03-	Gasolina	FWD	1984	85	115	07.98-05.04	■
2.0 (AZG)	01/03-	Gasolina	FWD	1984	85	115	07.98-05.04	■
2.0 (AZG)	01/03-	Gasolina	FWD	1984	85	115	07.98-05.04	■
2.0 (AZJ)	01/03-	Gasolina	FWD	1984	85	115	07.98-05.04	■
2.0 (AZJ)	01/03-	Gasolina	FWD	1984	85	115	07.98-05.04	■
2.0 (BER)	01/03-	Gasolina	FWD	1984	85	115	07.98-05.04	■
2.0 (BER)	01/03-	Gasolina	FWD	1984	85	115	07.98-05.04	■
2.0 (BEV)	01/03-	Gasolina	FWD	1984	85	115	07.98-05.04	■
2.0 (BEV)	01/03-	Gasolina	FWD	1984	85	115	07.98-05.04	■
1.0		Gasol./el éc.	FWD	998	43	58	08.98-05.02	■
1.0		Gasol./el éc.	FWD	998	43	58	08.98-05.02	■
1.9 SDI (AGP)	01/03-	Diesel	FWD	1896	50	68	08.97-06.05	■
1.9 SDI (AGP)	01/03-	Diesel	FWD	1896	50	68	08.97-06.05	■
1.9 SDI (AQM)	01/03-	Diesel	FWD	1896	50	68	08.97-06.05	■
1.9 SDI (AQM)	01/03-	Diesel	FWD	1896	50	68	08.97-06.05	■
1.9 TD		Diesel	FWD	1896	55	75	10.97-09.99	■
1.9 TD		Diesel	FWD	1896	55	75	10.97-09.99	■
1.9 TDI (AGR)		Diesel	FWD	1896	66	90	10.97-05.04	■
1.9 TDI (AGR)		Diesel	FWD	1896	66	90	10.97-05.04	■
1.9 TDI (ALH)		Diesel	FWD	1896	66	90	10.97-05.04	■
1.9 TDI (ALH)		Diesel	FWD	1896	66	90	10.97-05.04	■
1.9 TDI (ATD)	01/03-	Diesel	FWD	1896	74	101	09.00-06.05	■
1.9 TDI (ATD)	01/03-	Diesel	FWD	1896	74	101	09.00-06.05	■
1.9 TDI (AXR)	01/03-	Diesel	FWD	1896	74	101	09.00-06.05	■
1.9 TDI (AXR)	01/03-	Diesel	FWD	1896	74	101	09.00-06.05	■
1.9 TDI (BEW)	01/03-	Diesel	FWD	1896	74	101	09.00-06.05	■
1.9 TDI (BEW)	01/03-	Diesel	FWD	1896	74	101	09.00-06.05	■
1.9 TDI (AHF)		Diesel	FWD	1896	81	110	08.97-05.04	■
1.9 TDI (AHF)		Diesel	FWD	1896	81	110	08.97-05.04	■
1.9 TDI (ASV)		Diesel	FWD	1896	81	110	08.97-05.04	■
1.9 TDI (ASV)		Diesel	FWD	1896	81	110	08.97-05.04	■
1.9 TDI (AJM)		Diesel	FWD	1896	85	115	12.98-06.01	■
1.9 TDI (AJM)		Diesel	FWD	1896	85	115	12.98-06.01	■
1.9 TDI (AUY)		Diesel	FWD	1896	85	115	12.98-06.01	■
1.9 TDI (AUY)		Diesel	FWD	1896	85	115	12.98-06.01	■
1.9 TDI (ASZ)	01/01-	Diesel	FWD	1896	96	130	11.00-06.05	■
1.9 TDI (ASZ)	01/01-	Diesel	FWD	1896	96	130	11.00-06.05	■
1.9 TDI (ARL)	-12/03	Diesel	FWD	1896	110	150	05.00-06.05	■
1.9 TDI (ARL)	-12/03	Diesel	FWD	1896	110	150	05.00-06.05	■
<b>GOLF IV VAN Variant / JETTA IV (1J5) 05.99-06.06</b>							<b>Estate Van (Compact car-C Segment)</b>	
1.4 (AXP)	-12/03	Gasolina	FWD	1390	55	75	05.00-06.06	■
1.4 (AXP)	-12/03	Gasolina	FWD	1390	55	75	05.00-06.06	■
1.4 (BCA)	-12/03	Gasolina	FWD	1390	55	75	05.00-06.06	■

## LISTA DE APLICACIONES - BUYERS GUIDE

1.4 (BCA)	-12/03	Gasolina	FWD	1390	55	75	05.00-06.06	■	
1.6 (AUS)	-12/03	Gasolina	FWD	1598	77	105	05.00-06.06	■	
1.6 (AUS)	-12/03	Gasolina	FWD	1598	77	105	05.00-06.06	■	
1.6 (AZD)	-12/03	Gasolina	FWD	1598	77	105	05.00-06.06	■	
1.6 (AZD)	-12/03	Gasolina	FWD	1598	77	105	05.00-06.06	■	
1.6 (BCB)	-12/03	Gasolina	FWD	1598	77	105	05.00-06.06	■	
1.6 (BCB)	-12/03	Gasolina	FWD	1598	77	105	05.00-06.06	■	
1.9 SDI (AQM)	01/03-	Diesel	FWD	1896	50	68	05.99-05.06	■	
1.9 SDI (AQM)	01/03-	Diesel	FWD	1896	50	68	05.99-05.06	■	
1.9 TDI (AGR)	-12/03	Diesel	FWD	1896	66	90	05.99-05.06	■	
1.9 TDI (AGR)	-12/03	Diesel	FWD	1896	66	90	05.99-05.06	■	
1.9 TDI (ALH)	-12/03	Diesel	FWD	1896	66	90	05.99-05.06	■	
1.9 TDI (ALH)	-12/03	Diesel	FWD	1896	66	90	05.99-05.06	■	
1.9 TDI (ATD)	-12/03	Diesel	FWD	1896	74	101	02.00-06.06	■	
1.9 TDI (ATD)	-12/03	Diesel	FWD	1896	74	101	02.00-06.06	■	
1.9 TDI (AXR)	-12/03	Diesel	FWD	1896	74	101	02.00-06.06	■	
1.9 TDI (AXR)	-12/03	Diesel	FWD	1896	74	101	02.00-06.06	■	
1.9 TDI (AHF)	-12/03	Diesel	FWD	1896	81	110	05.99-05.06	■	
1.9 TDI (AHF)	-12/03	Diesel	FWD	1896	81	110	05.99-05.06	■	
1.9 TDI (ASV)	-12/03	Diesel	FWD	1896	81	110	05.99-05.06	■	
1.9 TDI (ASV)	-12/03	Diesel	FWD	1896	81	110	05.99-05.06	■	
1.9 TDI		Diesel	FWD	1896	96	131	04.01-05.06	■	
1.9 TDI		Diesel	FWD	1896	96	131	04.01-05.06	■	
<b>GOLF IV Variant / JETTA IV (1J5) 05.99-06.06</b>							<b>Estate (Compact car-C Segment)</b>		
1.4 16V (AHW)	-12/03	Gasolina	FWD	1390	55	75	05.99-06.06	■	
1.4 16V (AHW)	-12/03	Gasolina	FWD	1390	55	75	05.99-06.06	■	
1.4 16V (AKQ)	-12/03	Gasolina	FWD	1390	55	75	05.99-06.06	■	
1.4 16V (AKQ)	-12/03	Gasolina	FWD	1390	55	75	05.99-06.06	■	
1.4 16V (APE)	-12/03	Gasolina	FWD	1390	55	75	05.99-06.06	■	
1.4 16V (APE)	-12/03	Gasolina	FWD	1390	55	75	05.99-06.06	■	
1.4 16V (AXP)	-12/03	Gasolina	FWD	1390	55	75	05.99-06.06	■	
1.4 16V (AXP)	-12/03	Gasolina	FWD	1390	55	75	05.99-06.06	■	
1.4 16V (BCA)	-12/03	Gasolina	FWD	1390	55	75	05.99-06.06	■	
1.4 16V (BCA)	-12/03	Gasolina	FWD	1390	55	75	05.99-06.06	■	
1.6 (AEH)		Gasolina	FWD	1595	74	101	05.99-04.02	■	
1.6 (AEH)		Gasolina	FWD	1595	74	101	05.99-04.02	■	
1.6 (AKL)		Gasolina	FWD	1595	74	101	05.99-04.02	■	
1.6 (AKL)		Gasolina	FWD	1595	74	101	05.99-04.02	■	
1.6 (APF)		Gasolina	FWD	1595	74	101	05.99-04.02	■	
1.6 (APF)		Gasolina	FWD	1595	74	101	05.99-04.02	■	
1.6 (AVU)	-12/01	Gasolina	FWD	1595	75	102	08.00-06.06	■	
1.6 (AVU)	-12/01	Gasolina	FWD	1595	75	102	08.00-06.06	■	
1.6 (BFQ)	-12/01	Gasolina	FWD	1595	75	102	08.00-06.06	■	
1.6 (BFQ)	-12/01	Gasolina	FWD	1595	75	102	08.00-06.06	■	
1.6 16V (ATN)	-12/03	Gasolina	FWD	1598	77	105	02.00-06.06	■	
1.6 16V (ATN)	-12/03	Gasolina	FWD	1598	77	105	02.00-06.06	■	
1.6 16V (AUS)	-12/03	Gasolina	FWD	1598	77	105	02.00-06.06	■	
1.6 16V (AUS)	-12/03	Gasolina	FWD	1598	77	105	02.00-06.06	■	
1.6 16V (AZD)	-12/03	Gasolina	FWD	1598	77	105	02.00-06.06	■	
1.6 16V (AZD)	-12/03	Gasolina	FWD	1598	77	105	02.00-06.06	■	
1.6 16V (BCB)	-12/03	Gasolina	FWD	1598	77	105	02.00-06.06	■	

# LISTA DE APLICACIONES - BUYERS GUIDE

1.6 16V (BCB)	-12/03	Gasolina	FWD	1598	77	105	02.00-06.06	■
1.6 FSI (BAD)	-12/03	Gasolina	FWD	1598	81	110	01.02-06.06	■
1.6 FSI (BAD)	-12/03	Gasolina	FWD	1598	81	110	01.02-06.06	■
1.8 T (AGU)	-12/03	Gasolina	FWD	1781	110	150	05.00-06.06	■
1.8 T (AGU)	-12/03	Gasolina	FWD	1781	110	150	05.00-06.06	■
1.8 T (ARZ)	-12/03	Gasolina	FWD	1781	110	150	05.00-06.06	■
1.8 T (ARZ)	-12/03	Gasolina	FWD	1781	110	150	05.00-06.06	■
1.8 T (AUM)	-12/03	Gasolina	FWD	1781	110	150	05.00-06.06	■
1.8 T (AUM)	-12/03	Gasolina	FWD	1781	110	150	05.00-06.06	■
2.0 (APK)	01/03-	Gasolina	FWD	1984	85	115	05.99-06.06	■
2.0 (APK)	01/03-	Gasolina	FWD	1984	85	115	05.99-06.06	■
2.0 (AQY)	01/03-	Gasolina	FWD	1984	85	115	05.99-06.06	■
2.0 (AQY)	01/03-	Gasolina	FWD	1984	85	115	05.99-06.06	■
2.0 (AZJ)	01/03-	Gasolina	FWD	1984	85	115	05.99-06.06	■
2.0 (AZJ)	01/03-	Gasolina	FWD	1984	85	115	05.99-06.06	■
2.0 4motion (ATF)		Gasolina	4WD	1984	88	120	12.99-06.06	■
2.0 4motion (ATF)		Gasolina	4WD	1984	88	120	12.99-06.06	■
2.3 V5 (AGZ)	-12/00	Gasolina	FWD	2324	110	150	05.99-06.06	■
2.3 V5 (AGZ)	-12/00	Gasolina	FWD	2324	110	150	05.99-06.06	■
2.3 V5 (AQN)	-12/03	Gasolina	FWD	2324	125	170	10.00-06.06	■
2.3 V5 (AQN)	-12/03	Gasolina	FWD	2324	125	170	10.00-06.06	■
2.0 Bi-Fuel (BEH)	-12/03	Gasol./Gas (CNG)	FWD	1984	85	116	02.02-06.06	■
2.0 Bi-Fuel (BEH)	-12/03	Gasol./Gas (CNG)	FWD	1984	85	116	02.02-06.06	■
1.9 SDI (AGP)	01/03-	Diesel	FWD	1896	50	68	05.99-06.06	■
1.9 SDI (AGP)	01/03-	Diesel	FWD	1896	50	68	05.99-06.06	■
1.9 SDI (AQM)	01/03-	Diesel	FWD	1896	50	68	05.99-06.06	■
1.9 SDI (AQM)	01/03-	Diesel	FWD	1896	50	68	05.99-06.06	■
1.9 TDI (AGR)	-12/03	Diesel	FWD	1896	66	90	05.99-05.06	■
1.9 TDI (AGR)	-12/03	Diesel	FWD	1896	66	90	05.99-05.06	■
1.9 TDI (ALH)	-12/03	Diesel	FWD	1896	66	90	05.99-05.06	■
1.9 TDI (ALH)	-12/03	Diesel	FWD	1896	66	90	05.99-05.06	■
1.9 TDI (ATD)	-12/03	Diesel	FWD	1896	74	101	09.00-06.06	■
1.9 TDI (ATD)	-12/03	Diesel	FWD	1896	74	101	09.00-06.06	■
1.9 TDI (AXR)	-12/03	Diesel	FWD	1896	74	101	09.00-06.06	■
1.9 TDI (AXR)	-12/03	Diesel	FWD	1896	74	101	09.00-06.06	■
1.9 TDI (AHF)		Diesel	FWD	1896	81	110	05.99-06.01	■
1.9 TDI (AHF)		Diesel	FWD	1896	81	110	05.99-06.01	■
1.9 TDI (ASV)		Diesel	FWD	1896	81	110	05.99-06.01	■
1.9 TDI (ASV)		Diesel	FWD	1896	81	110	05.99-06.01	■
1.9 TDI (AJM)		Diesel	FWD	1896	85	115	08.99-06.01	■
1.9 TDI (AJM)		Diesel	FWD	1896	85	115	08.99-06.01	■
1.9 TDI (AUY)		Diesel	FWD	1896	85	115	08.99-06.01	■
1.9 TDI (AUY)		Diesel	FWD	1896	85	115	08.99-06.01	■
1.9 TDI (ASZ)	01/01-	Diesel	FWD	1896	96	130	11.00-06.06	■
1.9 TDI (ASZ)	01/01-	Diesel	FWD	1896	96	130	11.00-06.06	■
<b>NEW BEETLE / BETTLE (1Y7) 09.02-07.12</b>							<b>Convertible (Compact car-C Segment)</b>	
1.4 (BCA)		Gasolina	FWD	1390	55	75	01.03-09.10	■
1.4 (BCA)		Gasolina	FWD	1390	55	75	01.03-09.10	■
1.6 (BFS)		Gasolina	FWD	1595	75	102	01.03-09.10	■

# LISTA DE APLICACIONES - BUYERS GUIDE

1.6 (BFS)		Gasolina	FWD	1595	75	102	01.03-09.10	■
1.8 T (AWU)		Gasolina	FWD	1781	110	150	01.03-09.10	■
1.8 T (AWU)		Gasolina	FWD	1781	110	150	01.03-09.10	■
1.8 T (AWV)		Gasolina	FWD	1781	110	150	01.03-09.10	■
1.8 T (AWV)		Gasolina	FWD	1781	110	150	01.03-09.10	■
1.8 T (BKF)		Gasolina	FWD	1781	110	150	01.03-09.10	■
1.8 T (BKF)		Gasolina	FWD	1781	110	150	01.03-09.10	■
2.0 (AZJ)		Gasolina	FWD	1984	85	115	09.02-10.10	■
2.0 (AZJ)		Gasolina	FWD	1984	85	115	09.02-10.10	■
2.0 (BDC)		Gasolina	FWD	1984	85	115	09.02-10.10	■
2.0 (BDC)		Gasolina	FWD	1984	85	115	09.02-10.10	■
2.0 (BEV)		Gasolina	FWD	1984	85	115	09.02-10.10	■
2.0 (BEV)		Gasolina	FWD	1984	85	115	09.02-10.10	■
2.0 (BGD)		Gasolina	FWD	1984	85	115	09.02-10.10	■
2.0 (BGD)		Gasolina	FWD	1984	85	115	09.02-10.10	■
1.9 TDI (BSW)		Diesel	FWD	1896	77	105	07.05-09.10	■
1.9 TDI (BSW)		Diesel	FWD	1896	77	105	07.05-09.10	■
<b>NEW BEETLE / BETTLE / NOVO FUSCA (9C1, 1C1) 01.98-12.13</b>							<b>Hatchback (Compact car-C Segment)</b>	
1.4 (BCA)		Gasolina	FWD	1390	55	75	11.01-09.10	■
1.4 (BCA)		Gasolina	FWD	1390	55	75	11.01-09.10	■
1.6 (AWH)		Gasolina	FWD	1595	74	100	10.99-09.00	■
1.6 (AWH)		Gasolina	FWD	1595	74	100	10.99-09.00	■
1.6 (AYD)		Gasolina	FWD	1595	75	102	06.00-09.10	■
1.6 (AYD)		Gasolina	FWD	1595	75	102	06.00-09.10	■
1.6 (BFS)		Gasolina	FWD	1595	75	102	06.00-09.10	■
1.6 (BFS)		Gasolina	FWD	1595	75	102	06.00-09.10	■
1.8 T (AGU)		Gasolina	FWD	1781	110	150	10.99-09.10	■
1.8 T (AGU)		Gasolina	FWD	1781	110	150	10.99-09.10	■
1.8 T (APH)		Gasolina	FWD	1781	110	150	10.99-09.10	■
1.8 T (APH)		Gasolina	FWD	1781	110	150	10.99-09.10	■
1.8 T (AVC)		Gasolina	FWD	1781	110	150	10.99-09.10	■
1.8 T (AVC)		Gasolina	FWD	1781	110	150	10.99-09.10	■
1.8 T (AWU)		Gasolina	FWD	1781	110	150	10.99-09.10	■
1.8 T (AWU)		Gasolina	FWD	1781	110	150	10.99-09.10	■
1.8 T (AWV)		Gasolina	FWD	1781	110	150	10.99-09.10	■
1.8 T (AWV)		Gasolina	FWD	1781	110	150	10.99-09.10	■
1.8 T (BKF)		Gasolina	FWD	1781	110	150	10.99-09.10	■
1.8 T (BKF)		Gasolina	FWD	1781	110	150	10.99-09.10	■
2.0 (AEG)	01/99-	Gasolina	FWD	1984	85	115	01.98-09.10	■
2.0 (AEG)	01/99-	Gasolina	FWD	1984	85	115	01.98-09.10	■
2.0 (APK)	01/99-	Gasolina	FWD	1984	85	115	01.98-09.10	■
2.0 (APK)	01/99-	Gasolina	FWD	1984	85	115	01.98-09.10	■
2.0 (AQY)	01/99-	Gasolina	FWD	1984	85	115	01.98-09.10	■
2.0 (AQY)	01/99-	Gasolina	FWD	1984	85	115	01.98-09.10	■
2.0 (AVH)	01/99-	Gasolina	FWD	1984	85	115	01.98-09.10	■
2.0 (AVH)	01/99-	Gasolina	FWD	1984	85	115	01.98-09.10	■
2.0 (AZG)	01/99-	Gasolina	FWD	1984	85	115	01.98-09.10	■
2.0 (AZG)	01/99-	Gasolina	FWD	1984	85	115	01.98-09.10	■
2.0 (AZJ)	01/99-	Gasolina	FWD	1984	85	115	01.98-09.10	■
2.0 (AZJ)	01/99-	Gasolina	FWD	1984	85	115	01.98-09.10	■
2.0 (BER)	01/99-	Gasolina	FWD	1984	85	115	01.98-09.10	■

## LISTA DE APLICACIONES - BUYERS GUIDE

2.0 (BER)	01/99-	Gasolina	FWD	1984	85	115	01.98-09.10	■
2.0 (BEV)	01/99-	Gasolina	FWD	1984	85	115	01.98-09.10	■
2.0 (BEV)	01/99-	Gasolina	FWD	1984	85	115	01.98-09.10	■
2.3 V5 (AQN)		Gasolina	FWD	2324	125	170	10.00-09.10	■
2.3 V5 (AQN)		Gasolina	FWD	2324	125	170	10.00-09.10	■
1.9 TDI (ALH)	01/99-	Diesel	FWD	1896	66	90	01.98-06.04	■
1.9 TDI (ALH)	01/99-	Diesel	FWD	1896	66	90	01.98-06.04	■
1.9 TDI (ATD)		Diesel	FWD	1896	74	101	02.01-09.10	■
1.9 TDI (ATD)		Diesel	FWD	1896	74	101	02.01-09.10	■
1.9 TDI (AXR)		Diesel	FWD	1896	74	101	02.01-09.10	■
1.9 TDI (AXR)		Diesel	FWD	1896	74	101	02.01-09.10	■
1.9 TDI (BEW)		Diesel	FWD	1896	74	101	02.01-09.10	■
1.9 TDI (BEW)		Diesel	FWD	1896	74	101	02.01-09.10	■
1.9 TDI (BSW)		Diesel	FWD	1896	77	105	07.05-09.10	■
1.9 TDI (BSW)		Diesel	FWD	1896	77	105	07.05-09.10	■
<b>POLO IV (9N_, 9A_) 10.01-10.14</b>						<b>Hatchback (Supermini car-B Segment)</b>		
1.4 TDI (BNM)		Diesel	FWD	1422	51	70	04.05-11.09	■
1.4 TDI (BNM)		Diesel	FWD	1422	51	70	04.05-11.09	■
1.4 TDI (BWB)		Diesel	FWD	1422	51	70	04.05-11.09	■
1.4 TDI (BWB)		Diesel	FWD	1422	51	70	04.05-11.09	■