



# LISTA DE APLICACIONES - BUYERS GUIDE

106 II (1A_, 1C_) 04.96-05.05					Hatchback (Supermini car-B Segment)			
1.0 i (CDY (TU9M))		Gasolina	FWD	954	33	45	05.96-10.99	■
1.0 i (CDY (TU9M))		Gasolina	FWD	954	33	45	05.96-10.99	■
1.0 i (CDZ (TU9M))		Gasolina	FWD	954	37	50	04.96-03.01	■
1.0 i (CDZ (TU9M))		Gasolina	FWD	954	37	50	04.96-03.01	■
1.1 i (HDY (TU1M+))		Gasolina	FWD	1124	40	54	01.97-03.01	■
1.1 i (HDY (TU1M+))		Gasolina	FWD	1124	40	54	01.97-03.01	■
1.1		Gasolina	FWD	1124	42	57	09.00-10.02	■
1.1		Gasolina	FWD	1124	42	57	09.00-10.02	■
1.1 i (HDZ (TU1M+))	-12/03	Gasolina	FWD	1124	44	60	05.96-07.04	■
1.1 i (HDZ (TU1M+))	-12/03	Gasolina	FWD	1124	44	60	05.96-07.04	■
1.1 i (HFX (TU1JP))	-12/03	Gasolina	FWD	1124	44	60	05.96-07.04	■
1.1 i (HFX (TU1JP))	-12/03	Gasolina	FWD	1124	44	60	05.96-07.04	■
1.5 D (VJY (TUD5))		Diesel	FWD	1527	40	55	05.96-03.01	■
1.5 D (VJY (TUD5))		Diesel	FWD	1527	40	55	05.96-03.01	■
1.5 D (VJX (TUD5))	-12/03	Diesel	FWD	1527	42	57	04.98-07.04	■
1.5 D (VJX (TUD5))	-12/03	Diesel	FWD	1527	42	57	04.98-07.04	■
1.5 D (VJY (TUD5))	-12/03	Diesel	FWD	1527	42	57	04.98-07.04	■
1.5 D (VJY (TUD5))	-12/03	Diesel	FWD	1527	42	57	04.98-07.04	■
1.5 D (VJZ (TUD5))	-12/03	Diesel	FWD	1527	42	57	04.98-07.04	■
1.5 D (VJZ (TUD5))	-12/03	Diesel	FWD	1527	42	57	04.98-07.04	■