


# LISTA DE APLICACIONES - BUYERS GUIDE

## 31121-4694



8 424073 103581

Weight: 10.511



## 31121-4694



Ate - Teves

140.25x47.4x17.3

Ø247x20.4x34.2

**WVA**

21827

**MAKE**

CITROËN

PEUGEOT



Trac.

CC

Kw

CV



Front / Rear

### CITROËN

#### SAXO / CHANSON (S0, S1) 02.96-04.04

#### Hatchback (Supermini car-B Segment)

1.6 VTL, VTR (NFZ (TU5JP))	Gasolina	FWD	1587	65	88	05.96-06.03	■
1.6 VTL, VTR (NFZ (TU5JP))	Gasolina	FWD	1587	65	88	05.96-06.03	■
1.6 (NFZ (TU5JP))	Gasolina	FWD	1587	66	90	02.96-06.03	■
1.6 (NFZ (TU5JP))	Gasolina	FWD	1587	66	90	02.96-06.03	■
1.6 VTS (NFT (TU5JP))	Gasolina	FWD	1587	72	98	09.00-09.03	■
1.6 VTS (NFT (TU5JP))	Gasolina	FWD	1587	72	98	09.00-09.03	■
1.6 (NFT (TU5JP))	Gasolina	FWD	1587	74	101	02.01-04.04	■
1.6 (NFT (TU5JP))	Gasolina	FWD	1587	74	101	02.01-04.04	■
1.6 VTR	Gasolina	FWD	1587	80	109	05.96-07.99	■
1.6 VTR	Gasolina	FWD	1587	80	109	05.96-07.99	■
1.6 VTS (NFX (TU5JP4))	Gasolina	FWD	1587	87	118	06.96-09.03	■
1.6 VTS (NFX (TU5JP4))	Gasolina	FWD	1587	87	118	06.96-09.03	■
1.6 (NFX (TU5JP4))	Gasolina	FWD	1587	88	120	02.96-04.04	■
1.6 (NFX (TU5JP4))	Gasolina	FWD	1587	88	120	02.96-04.04	■

#### XSARA (N0) 01.98-04.05

#### Coupe (Compact car-C Segment)

1.6 i (NFZ (TU5JP))	Gasolina	FWD	1587	65	88	02.98-09.00	■
1.6 i (NFZ (TU5JP))	Gasolina	FWD	1587	65	88	02.98-09.00	■
1.8 i (LFZ (XU7JP))	Gasolina	FWD	1761	74	101	02.98-09.00	■
1.8 i (LFZ (XU7JP))	Gasolina	FWD	1761	74	101	02.98-09.00	■
1.9 TD (DHY (XUD9TE/Y))	Diesel	FWD	1905	66	90	02.98-09.00	■
1.9 TD (DHY (XUD9TE/Y))	Diesel	FWD	1905	66	90	02.98-09.00	■

# LISTA DE APLICACIONES - BUYERS GUIDE

XSARA (N2) 10.97-03.10					Estate (Compact car-C Segment)			
1.4 i (KFW (TU3JP))	-12/00	Gasolina	FWD	1360	55	75	10.97-08.05	■
1.4 i (KFW (TU3JP))	-12/00	Gasolina	FWD	1360	55	75	10.97-08.05	■
1.4 i (KFX (TU3JP))	-12/00	Gasolina	FWD	1360	55	75	10.97-08.05	■
1.4 i (KFX (TU3JP))	-12/00	Gasolina	FWD	1360	55	75	10.97-08.05	■
1.6 i (NFZ (TU5JP))		Gasolina	FWD	1587	65	88	10.97-09.00	■
1.6 i (NFZ (TU5JP))		Gasolina	FWD	1587	65	88	10.97-09.00	■
1.8 D (A9A (XUD7))		Diesel	FWD	1769	43	58	10.97-09.00	■
1.8 D (A9A (XUD7))		Diesel	FWD	1769	43	58	10.97-09.00	■
1.9 D (WJY (DW8B))	-12/00	Diesel	FWD	1868	51	70	07.98-08.05	■
1.9 D (WJY (DW8B))	-12/00	Diesel	FWD	1868	51	70	07.98-08.05	■
1.9 D (WJZ (DW8))	-12/00	Diesel	FWD	1868	51	70	07.98-08.05	■
1.9 D (WJZ (DW8))	-12/00	Diesel	FWD	1868	51	70	07.98-08.05	■
1.9 D (DJY (XUD9A))		Diesel	FWD	1905	50	68	10.97-09.00	■
1.9 D (DJY (XUD9A))		Diesel	FWD	1905	50	68	10.97-09.00	■
1.9 D (DHV (XUD9BSD))		Diesel	FWD	1905	55	75	01.98-09.00	■
1.9 D (DHV (XUD9BSD))		Diesel	FWD	1905	55	75	01.98-09.00	■
XSARA (N1) 04.97-12.05					Hatchback (Compact car-C Segment)			
1.4 i (KFW (TU3JP))	-12/00	Gasolina	FWD	1360	55	75	04.97-03.05	■
1.4 i (KFW (TU3JP))	-12/00	Gasolina	FWD	1360	55	75	04.97-03.05	■
1.4 i (KFX (TU3JP))	-12/00	Gasolina	FWD	1360	55	75	04.97-03.05	■
1.4 i (KFX (TU3JP))	-12/00	Gasolina	FWD	1360	55	75	04.97-03.05	■
1.6 i (NFZ (TU5JP))		Gasolina	FWD	1587	65	88	04.97-09.00	■
1.6 i (NFZ (TU5JP))		Gasolina	FWD	1587	65	88	04.97-09.00	■
1.8 i (LFX (XU7JB))		Gasolina	FWD	1761	66	90	04.97-09.00	■
1.8 i (LFX (XU7JB))		Gasolina	FWD	1761	66	90	04.97-09.00	■
1.8 i Aut. (LFZ (XU7JP))		Gasolina	FWD	1761	74	101	04.97-09.00	■
1.8 i Aut. (LFZ (XU7JP))		Gasolina	FWD	1761	74	101	04.97-09.00	■
1.8 TD		Diesel	RWD	1761	66	90	10.97-09.00	■
1.8 TD		Diesel	RWD	1761	66	90	10.97-09.00	■
1.8 D (161A (XUD7))		Diesel	FWD	1769	43	58	04.97-09.00	■
1.8 D (161A (XUD7))		Diesel	FWD	1769	43	58	04.97-09.00	■
1.8 D (A9A (XUD7))		Diesel	FWD	1769	43	58	04.97-09.00	■
1.8 D (A9A (XUD7))		Diesel	FWD	1769	43	58	04.97-09.00	■
1.9 D (WJY (DW8B))	-12/00	Diesel	FWD	1868	51	70	07.98-03.05	■
1.9 D (WJY (DW8B))	-12/00	Diesel	FWD	1868	51	70	07.98-03.05	■
1.9 D (WJZ (DW8))	-12/00	Diesel	FWD	1868	51	70	07.98-03.05	■
1.9 D (WJZ (DW8))	-12/00	Diesel	FWD	1868	51	70	07.98-03.05	■
1.9 D (DJY (XUD9A))		Diesel	FWD	1905	50	68	04.97-09.00	■
1.9 D (DJY (XUD9A))		Diesel	FWD	1905	50	68	04.97-09.00	■
1.9 SD (DHV (XUD9BSD))		Diesel	FWD	1905	55	75	01.98-09.00	■
1.9 SD (DHV (XUD9BSD))		Diesel	FWD	1905	55	75	01.98-09.00	■
1.9 TD (DHY (XUD9TE/Y))		Diesel	FWD	1905	66	90	04.97-09.00	■
1.9 TD (DHY (XUD9TE/Y))		Diesel	FWD	1905	66	90	04.97-09.00	■
PEUGEOT								
106 (1A, 1C) 08.91-04.96					Hatchback (Supermini car-B Segment)			
1.3 (TU2J2)	01/95-	Gasolina	FWD	1294	72	98	10.93-04.96	■
1.3 (TU2J2)	01/95-	Gasolina	FWD	1294	72	98	10.93-04.96	■
1.4 (K5A (TU3))	01/95-	Gasolina	FWD	1360	51	69	08.91-03.96	■
1.4 (K5A (TU3))	01/95-	Gasolina	FWD	1360	51	69	08.91-03.96	■

# LISTA DE APLICACIONES - BUYERS GUIDE

1.4 D (K9Y (TUD3Y))	01/95-	Diesel	FWD	1361	37	50	09.92-04.96	■
1.4 D (K9Y (TUD3Y))	01/95-	Diesel	FWD	1361	37	50	09.92-04.96	■
1.5 D (VJY (TUD5))	01/95-	Diesel	FWD	1527	40	54	06.94-04.96	■
1.5 D (VJY (TUD5))	01/95-	Diesel	FWD	1527	40	54	06.94-04.96	■
1.5 D (VJY (TUD5))	01/95-	Diesel	FWD	1527	43	58	06.94-04.96	■
1.5 D (VJY (TUD5))	01/95-	Diesel	FWD	1527	43	58	06.94-04.96	■
1.5 D (VJZ (TUD5))	01/95-	Diesel	FWD	1527	43	58	06.94-04.96	■
1.5 D (VJZ (TUD5))	01/95-	Diesel	FWD	1527	43	58	06.94-04.96	■
<b>106 II (1S_) 04.96-03.01</b>					<b>Hatchback Van (LCVs-N1 Segment)</b>			
1.5 D (VJY (TUD5))		Diesel	FWD	1527	40	55	05.96-03.01	■
1.5 D (VJY (TUD5))		Diesel	FWD	1527	40	55	05.96-03.01	■
1.5 D (VJX (TUD5))		Diesel	FWD	1527	42	57	06.96-03.01	■
1.5 D (VJX (TUD5))		Diesel	FWD	1527	42	57	06.96-03.01	■
<b>106 II (1A_, 1C_) 04.96-05.05</b>					<b>Hatchback (Supermini car-B Segment)</b>			
1.6 i (NFZ (TU5JP))		Gasolina	FWD	1587	65	89	05.96-10.99	■
1.6 i (NFZ (TU5JP))		Gasolina	FWD	1587	65	89	05.96-10.99	■
1.6 i (NFW (TU5J2))	-12/99	Gasolina	FWD	1587	74	101	05.96-01.01	■
1.6 i (NFW (TU5J2))	-12/99	Gasolina	FWD	1587	74	101	05.96-01.01	■
1.6 i (NFY (TU5J2))	-12/99	Gasolina	FWD	1587	74	101	05.96-01.01	■
1.6 i (NFY (TU5J2))	-12/99	Gasolina	FWD	1587	74	101	05.96-01.01	■
1.6 S16 (NFX (TU5J4))	-12/99	Gasolina	FWD	1587	87	118	05.96-07.04	■
1.6 S16 (NFX (TU5J4))	-12/99	Gasolina	FWD	1587	87	118	05.96-07.04	■
<b>306 (7D, N3, N5) 01.94-04.02</b>					<b>Convertible (Compact car-C Segment)</b>			
1.6 (NFT (TU5JP))	-12/01	Gasolina	FWD	1587	72	98	10.00-04.02	■
1.6 (NFT (TU5JP))	-12/01	Gasolina	FWD	1587	72	98	10.00-04.02	■
1.8 (L6A (XU7JP))	01/97-	Gasolina	FWD	1761	74	101	03.94-04.02	■
1.8 (L6A (XU7JP))	01/97-	Gasolina	FWD	1761	74	101	03.94-04.02	■
1.8 (LFZ (XU7JP))	01/97-	Gasolina	FWD	1761	74	101	03.94-04.02	■
1.8 (LFZ (XU7JP))	01/97-	Gasolina	FWD	1761	74	101	03.94-04.02	■
<b>306 (7E, N3, N5) 06.94-12.02</b>					<b>Estate (Compact car-C Segment)</b>			
1.4 (KFW (TU3JP))	-12/00	Gasolina	FWD	1360	55	75	03.97-04.02	■
1.4 (KFW (TU3JP))	-12/00	Gasolina	FWD	1360	55	75	03.97-04.02	■
1.4 (KFX (TU3JP))	-12/00	Gasolina	FWD	1360	55	75	03.97-04.02	■
1.4 (KFX (TU3JP))	-12/00	Gasolina	FWD	1360	55	75	03.97-04.02	■
1.6 (NFZ (TU5JP))		Gasolina	FWD	1587	65	89	03.97-10.00	■
1.6 (NFZ (TU5JP))		Gasolina	FWD	1587	65	89	03.97-10.00	■
1.6 (NFT (TU5JP))	-12/01	Gasolina	FWD	1587	72	98	10.00-04.02	■
1.6 (NFT (TU5JP))	-12/01	Gasolina	FWD	1587	72	98	10.00-04.02	■
1.9 D (DJY (XUD9A))	-12/01	Diesel	FWD	1905	50	68	03.97-04.02	■
1.9 D (DJY (XUD9A))	-12/01	Diesel	FWD	1905	50	68	03.97-04.02	■
1.9 D (DJY (XUD9A))		Diesel	FWD	1905	51	69	05.97-05.99	■
1.9 D (DJY (XUD9A))		Diesel	FWD	1905	51	69	05.97-05.99	■
1.9 D (DHV (XUD9BSD))		Diesel	FWD	1905	55	75	03.98-04.02	■
1.9 D (DHV (XUD9BSD))		Diesel	FWD	1905	55	75	03.98-04.02	■
<b>306 (7A, 7C, N3, N5) 01.93-10.03</b>					<b>Hatchback (Compact car-C Segment)</b>			
1.4 (KDX (TU3MC))	01/97-	Gasolina	FWD	1360	55	75	04.93-07.01	■
1.4 (KDX (TU3MC))	01/97-	Gasolina	FWD	1360	55	75	04.93-07.01	■
1.4 (KFW (TU3JP))	01/97-	Gasolina	FWD	1360	55	75	04.93-07.01	■
1.4 (KFW (TU3JP))	01/97-	Gasolina	FWD	1360	55	75	04.93-07.01	■

# LISTA DE APLICACIONES - BUYERS GUIDE

1.4 (KFX (TU3JP))	01/97-	Gasolina	FWD	1360	55	75	04.93-07.01	■
1.4 (KFX (TU3JP))	01/97-	Gasolina	FWD	1360	55	75	04.93-07.01	■
1.6 (NFZ (TU5JP))	01/97-	Gasolina	FWD	1587	65	89	05.93-10.00	■
1.6 (NFZ (TU5JP))	01/97-	Gasolina	FWD	1587	65	89	05.93-10.00	■
1.6 (NFZ (TU5JP))		Gasolina	FWD	1587	66	90	07.00-05.01	■
1.6 (NFZ (TU5JP))		Gasolina	FWD	1587	66	90	07.00-05.01	■
1.6 (NFT (TU5JP))		Gasolina	FWD	1587	72	98	10.00-05.01	■
1.6 (NFT (TU5JP))		Gasolina	FWD	1587	72	98	10.00-05.01	■
1.8 (LFZ (XU7JP))	01/97-	Gasolina	FWD	1761	74	101	05.93-05.01	■
1.8 (LFZ (XU7JP))	01/97-	Gasolina	FWD	1761	74	101	05.93-05.01	■
1.8 D (A9A (XUD7))	01/97-	Diesel	FWD	1769	43	58	05.93-05.01	■
1.8 D (A9A (XUD7))	01/97-	Diesel	FWD	1769	43	58	05.93-05.01	■
1.9 D (DJZ (XUD9A))	01/97-	Diesel	FWD	1905	47	64	05.93-05.01	■
1.9 D (DJZ (XUD9A))	01/97-	Diesel	FWD	1905	47	64	05.93-05.01	■
1.9 D (DJY (XUD9A))	01/97-	Diesel	FWD	1905	50	68	06.94-05.01	■
1.9 D (DJY (XUD9A))	01/97-	Diesel	FWD	1905	50	68	06.94-05.01	■
1.9 D (DHV (XUD9BSD))		Diesel	FWD	1905	55	75	03.98-05.01	■
1.9 D (DHV (XUD9BSD))		Diesel	FWD	1905	55	75	03.98-05.01	■
<b>306 (7B, N3, N5) 04.93-10.03</b>					<b>Saloon (Compact car-C Segment)</b>			
1.4 SL (KDX (TU3MC))	01/97-	Gasolina	FWD	1360	55	75	06.94-05.01	■
1.4 SL (KDX (TU3MC))	01/97-	Gasolina	FWD	1360	55	75	06.94-05.01	■
1.4 SL (KFW (TU3JP))	01/97-	Gasolina	FWD	1360	55	75	06.94-05.01	■
1.4 SL (KFW (TU3JP))	01/97-	Gasolina	FWD	1360	55	75	06.94-05.01	■
1.4 SL (KFX (TU3JP))	01/97-	Gasolina	FWD	1360	55	75	06.94-05.01	■
1.4 SL (KFX (TU3JP))	01/97-	Gasolina	FWD	1360	55	75	06.94-05.01	■
1.6 SR (NFZ (TU5JP))	01/97-	Gasolina	FWD	1587	65	89	06.94-10.00	■
1.6 SR (NFZ (TU5JP))	01/97-	Gasolina	FWD	1587	65	89	06.94-10.00	■
1.6 (NFZ (TU5JP))		Gasolina	FWD	1587	66	90	07.00-05.01	■
1.6 (NFZ (TU5JP))		Gasolina	FWD	1587	66	90	07.00-05.01	■
1.6 (NFT (TU5JP))		Gasolina	FWD	1587	72	98	10.00-05.01	■
1.6 (NFT (TU5JP))		Gasolina	FWD	1587	72	98	10.00-05.01	■
1.8 ST (LFZ (XU7JP))	01/97-	Gasolina	FWD	1761	74	101	06.94-05.01	■
1.8 ST (LFZ (XU7JP))	01/97-	Gasolina	FWD	1761	74	101	06.94-05.01	■
1.8 D (A9A (XUD7))		Diesel	FWD	1769	44	60	05.97-06.00	■
1.8 D (A9A (XUD7))		Diesel	FWD	1769	44	60	05.97-06.00	■
1.9 D (WJY (DW8B))	-12/00	Diesel	FWD	1868	51	69	09.98-05.01	■
1.9 D (WJY (DW8B))	-12/00	Diesel	FWD	1868	51	69	09.98-05.01	■
1.9 D (WJZ (DW8))	-12/00	Diesel	FWD	1868	51	69	09.98-05.01	■
1.9 D (WJZ (DW8))	-12/00	Diesel	FWD	1868	51	69	09.98-05.01	■
1.9 SLD (DJZ (XUD9A))	01/97-	Diesel	FWD	1905	47	64	06.94-05.01	■
1.9 SLD (DJZ (XUD9A))	01/97-	Diesel	FWD	1905	47	64	06.94-05.01	■
1.9 SLD (DJY (XUD9A))	01/97-	Diesel	FWD	1905	50	68	06.94-05.01	■
1.9 SLD (DJY (XUD9A))	01/97-	Diesel	FWD	1905	50	68	06.94-05.01	■
1.9 D (DHV (XUD9BSD))		Diesel	FWD	1905	55	75	03.98-05.01	■
1.9 D (DHV (XUD9BSD))		Diesel	FWD	1905	55	75	03.98-05.01	■