


LISTA DE APLICACIONES - BUYERS GUIDE

31136-4697



8 424073 103635

Weight: 12.210



31136-4697



Lucas - Girling

129.8x56x19

Ø266x20.5x27.5

WVA

23124

MAKE

CITROËN

PEUGEOT



Trac.	CC	Kw	CV
-------	----	----	----



Front / Rear

CITROËN

BERLINGO / BERLINGO FIRST (M_) 07.96-12.11

Box Body/MPV (LCVs-N1 Segment)

1.1 i (MAHDZ, MBHDZ, MBHFX) (HDZ (TU1M))	-12/01	Gasolina	FWD	1124	44	60	07.96-03.08	■
1.1 i (MAHDZ, MBHDZ, MBHFX) (HDZ (TU1M))	-12/01	Gasolina	FWD	1124	44	60	07.96-03.08	■
1.1 i (MAHDZ, MBHDZ, MBHFX) (HFX (TU1JP))	-12/01	Gasolina	FWD	1124	44	60	07.96-03.08	■
1.1 i (MAHDZ, MBHDZ, MBHFX) (HFX (TU1JP))	-12/01	Gasolina	FWD	1124	44	60	07.96-03.08	■
1.4 i (MBKFX, MBKFW) (KFW (TU3A))	-12/01	Gasolina	FWD	1360	55	75	07.96-12.11	■
1.4 i (MBKFX, MBKFW) (KFW (TU3A))	-12/01	Gasolina	FWD	1360	55	75	07.96-12.11	■
1.4 i (MBKFX, MBKFW) (KFW (TU3JP))	-12/01	Gasolina	FWD	1360	55	75	07.96-12.11	■
1.4 i (MBKFX, MBKFW) (KFW (TU3JP))	-12/01	Gasolina	FWD	1360	55	75	07.96-12.11	■
1.4 i (MBKFX, MBKFW) (KFX (TU3JP))	-12/01	Gasolina	FWD	1360	55	75	07.96-12.11	■
1.4 i (MBKFX, MBKFW) (KFX (TU3JP))	-12/01	Gasolina	FWD	1360	55	75	07.96-12.11	■
1.6 16V (MBNFU) (NFU (TU5JP4))	-12/02	Gasolina	FWD	1587	80	109	10.00-03.08	■
1.6 16V (MBNFU) (NFU (TU5JP4))	-12/02	Gasolina	FWD	1587	80	109	10.00-03.08	■
1.8 i (LFX (XU7JB))		Gasolina	FWD	1761	66	90	05.98-10.02	■
1.8 i (LFX (XU7JB))		Gasolina	FWD	1761	66	90	05.98-10.02	■
1.8 D (MBA9A, MCA9A) (A9A (XUD7))		Diesel	FWD	1769	43	59	07.96-10.02	■
1.8 D (MBA9A, MCA9A) (A9A (XUD7))		Diesel	FWD	1769	43	59	07.96-10.02	■
1.9 D 70 (MBWJZ, MCWJZ) (WJY (DW8B))	-12/01	Diesel	FWD	1868	51	69	04.99-12.11	■
1.9 D 70 (MBWJZ, MCWJZ) (WJY (DW8B))	-12/01	Diesel	FWD	1868	51	69	04.99-12.11	■
1.9 D 70 (MBWJZ, MCWJZ) (WJZ (DW8))	-12/01	Diesel	FWD	1868	51	69	04.99-12.11	■
1.9 D 70 (MBWJZ, MCWJZ) (WJZ (DW8))	-12/01	Diesel	FWD	1868	51	69	04.99-12.11	■
1.9 D 70 4WD (MBWJZ, MCWJZ) (WJY (DW8B))	-12/01	Diesel	4WD	1868	51	69	07.98-03.06	■

LISTA DE APLICACIONES - BUYERS GUIDE

1.9 D 70 4WD (MBWJZ, MCWJZ) (WJY (DW8B))	-12/01	Diesel	4WD	1868	51	69	07.98-03.06	■
1.9 D 70 4WD (MBWJZ, MCWJZ) (WJZ (DW8))	-12/01	Diesel	4WD	1868	51	69	07.98-03.06	■
1.9 D 70 4WD (MBWJZ, MCWJZ) (WJZ (DW8))	-12/01	Diesel	4WD	1868	51	69	07.98-03.06	■
1.9 D (MBDJY) (DJY (XUD9A))	-12/01	Diesel	FWD	1905	51	70	07.96-12.03	■
1.9 D (MBDJY) (DJY (XUD9A))	-12/01	Diesel	FWD	1905	51	70	07.96-12.03	■
2.0 HDI 90 (MBRHY, MCRHY) (RHY (DW10TD))	-12/00	Diesel	FWD	1997	66	90	12.99-12.11	■
2.0 HDI 90 (MBRHY, MCRHY) (RHY (DW10TD))	-12/00	Diesel	FWD	1997	66	90	12.99-12.11	■
BERLINGO / BERLINGO FIRST (MF_, GJK_, GFK_) 07.96-12.11					MPV (Large MPV-M1 Segment)			
1.1 i (MFHDZ, MFHFX) (HDZ (TU1M))	-12/01	Gasolina	FWD	1124	44	60	07.96-05.08	■
1.1 i (MFHDZ, MFHFX) (HDZ (TU1M))	-12/01	Gasolina	FWD	1124	44	60	07.96-05.08	■
1.1 i (MFHDZ, MFHFX) (HFX (TU1JP))	-12/01	Gasolina	FWD	1124	44	60	07.96-05.08	■
1.1 i (MFHDZ, MFHFX) (HFX (TU1JP))	-12/01	Gasolina	FWD	1124	44	60	07.96-05.08	■
1.4 i (MFKFX, MFKFW, GJKFWB, GJKFWC, GFKFWC) (KFW (TU3JP))	-12/01	Gasolina	FWD	1360	55	75	07.96-12.11	■
1.4 i (MFKFX, MFKFW, GJKFWB, GJKFWC, GFKFWC) (KFW (TU3JP))	-12/01	Gasolina	FWD	1360	55	75	07.96-12.11	■
1.4 i (MFKFX, MFKFW, GJKFWB, GJKFWC, GFKFWC) (KFX (TU3JP))	-12/01	Gasolina	FWD	1360	55	75	07.96-12.11	■
1.4 i (MFKFX, MFKFW, GJKFWB, GJKFWC, GFKFWC) (KFX (TU3JP))	-12/01	Gasolina	FWD	1360	55	75	07.96-12.11	■
1.6 16V (MFNFU) (NFU (TU5JP4))	-12/02	Gasolina	FWD	1587	80	109	10.00-12.11	■
1.6 16V (MFNFU) (NFU (TU5JP4))	-12/02	Gasolina	FWD	1587	80	109	10.00-12.11	■
1.8 i (MFLFX) (LFX (XU7JB))		Gasolina	FWD	1761	66	90	05.97-10.02	■
1.8 i (MFLFX) (LFX (XU7JB))		Gasolina	FWD	1761	66	90	05.97-10.02	■
1.8 i 4WD (MFLFX) (LFX (XU7JB))		Gasolina	4WD	1761	66	90	04.97-10.01	■
1.8 i 4WD (MFLFX) (LFX (XU7JB))		Gasolina	4WD	1761	66	90	04.97-10.01	■
electrique		Eléctrico	FWD		16	22	01.00-10.02	■
electrique		Eléctrico	FWD		16	22	01.00-10.02	■
1.8 D (MFA9A) (A9A (XUD7))	-12/99	Diesel	FWD	1769	43	58	07.98-10.02	■
1.8 D (MFA9A) (A9A (XUD7))	-12/99	Diesel	FWD	1769	43	58	07.98-10.02	■
1.8 D		Diesel	RWD	1769	44	60	11.96-10.99	■
1.8 D		Diesel	RWD	1769	44	60	11.96-10.99	■
1.9 D (MFWJZ) (WJY (DW8B))	-12/01	Diesel	FWD	1868	51	70	07.98-10.05	■
1.9 D (MFWJZ) (WJY (DW8B))	-12/01	Diesel	FWD	1868	51	70	07.98-10.05	■
1.9 D (MFWJZ) (WJZ (DW8))	-12/01	Diesel	FWD	1868	51	70	07.98-10.05	■
1.9 D (MFWJZ) (WJZ (DW8))	-12/01	Diesel	FWD	1868	51	70	07.98-10.05	■
1.9 D 4WD (MFWJZ) (WJY (DW8B))	-12/02	Diesel	4WD	1868	51	69	07.98-10.05	■
1.9 D 4WD (MFWJZ) (WJY (DW8B))	-12/02	Diesel	4WD	1868	51	69	07.98-10.05	■
1.9 D 4WD (MFWJZ) (WJZ (DW8))	-12/02	Diesel	4WD	1868	51	69	07.98-10.05	■
1.9 D 4WD (MFWJZ) (WJZ (DW8))	-12/02	Diesel	4WD	1868	51	69	07.98-10.05	■
1.9 D (MFDJY) (D9B (XUD9A/L))	-12/01	Diesel	FWD	1905	50	68	07.96-12.03	■
1.9 D (MFDJY) (D9B (XUD9A/L))	-12/01	Diesel	FWD	1905	50	68	07.96-12.03	■
1.9 D (MFDJY) (DJY (XUD9A))	-12/01	Diesel	FWD	1905	50	68	07.96-12.03	■
1.9 D (MFDJY) (DJY (XUD9A))	-12/01	Diesel	FWD	1905	50	68	07.96-12.03	■
1.9 D		Diesel	RWD	1905	51	69	07.96-10.99	■
1.9 D		Diesel	RWD	1905	51	69	07.96-10.99	■
2.0 HDI 90 (MFRHY) (RHY (DW10TD))	-12/02	Diesel	FWD	1997	66	90	12.99-10.05	■
2.0 HDI 90 (MFRHY) (RHY (DW10TD))	-12/02	Diesel	FWD	1997	66	90	12.99-10.05	■
XSARA (N0) 01.98-04.05					Coupe (Compact car-C Segment)			
1.8 i 16V (LFY (XU7JP4))		Gasolina	FWD	1761	81	110	02.98-09.00	■
1.8 i 16V (LFY (XU7JP4))		Gasolina	FWD	1761	81	110	02.98-09.00	■
2.0 HDI 90 (RHY (DW10TD))	-12/00	Diesel	FWD	1997	66	90	02.99-03.05	■

LISTA DE APLICACIONES - BUYERS GUIDE

2.0 HDI 90 (RHY (DW10TD))	-12/00	Diesel	FWD	1997	66	90	02.99-03.05	■
XSARA 05.98-08.05					Estate Van (Compact car-C Segment)			
2.0 HDi (RHY (DW10TD))	-12/00	Diesel	FWD	1997	66	90	09.00-03.05	■
2.0 HDi (RHY (DW10TD))	-12/00	Diesel	FWD	1997	66	90	09.00-03.05	■
XSARA (N2) 10.97-03.10					Estate (Compact car-C Segment)			
1.4 i (KFW (TU3JP))	-12/00	Gasolina	FWD	1360	55	75	10.97-08.05	■
1.4 i (KFW (TU3JP))	-12/00	Gasolina	FWD	1360	55	75	10.97-08.05	■
1.4 i (KFX (TU3JP))	-12/00	Gasolina	FWD	1360	55	75	10.97-08.05	■
1.4 i (KFX (TU3JP))	-12/00	Gasolina	FWD	1360	55	75	10.97-08.05	■
1.6 i (NFZ (TU5JP))		Gasolina	FWD	1587	65	88	10.97-09.00	■
1.6 i (NFZ (TU5JP))		Gasolina	FWD	1587	65	88	10.97-09.00	■
1.8 i (LFX (XU7JB))		Gasolina	FWD	1761	66	90	10.97-09.00	■
1.8 i (LFX (XU7JB))		Gasolina	FWD	1761	66	90	10.97-09.00	■
1.8 i Aut. (LFZ (XU7JP))		Gasolina	FWD	1761	74	101	10.97-09.00	■
1.8 i Aut. (LFZ (XU7JP))		Gasolina	FWD	1761	74	101	10.97-09.00	■
1.8 i 16V (LFY (XU7JP4))		Gasolina	FWD	1761	81	110	10.97-09.00	■
1.8 i 16V (LFY (XU7JP4))		Gasolina	FWD	1761	81	110	10.97-09.00	■
2.0 16V (RFV (XU10J4R))		Gasolina	FWD	1998	97	132	07.98-09.00	■
2.0 16V (RFV (XU10J4R))		Gasolina	FWD	1998	97	132	07.98-09.00	■
1.8 D (A9A (XUD7))		Diesel	FWD	1769	43	58	10.97-09.00	■
1.8 D (A9A (XUD7))		Diesel	FWD	1769	43	58	10.97-09.00	■
1.9 D (WJY (DW8B))	-12/00	Diesel	FWD	1868	51	70	07.98-08.05	■
1.9 D (WJY (DW8B))	-12/00	Diesel	FWD	1868	51	70	07.98-08.05	■
1.9 D (WJZ (DW8))	-12/00	Diesel	FWD	1868	51	70	07.98-08.05	■
1.9 D (WJZ (DW8))	-12/00	Diesel	FWD	1868	51	70	07.98-08.05	■
XSARA (N1) 04.97-12.05					Hatchback (Compact car-C Segment)			
1.8 i 16V (LFY (XU7JP4))		Gasolina	FWD	1761	81	110	04.97-09.00	■
1.8 i 16V (LFY (XU7JP4))		Gasolina	FWD	1761	81	110	04.97-09.00	■
2.0 16V (RFV (XU10J4R))		Gasolina	FWD	1998	97	132	07.98-09.00	■
2.0 16V (RFV (XU10J4R))		Gasolina	FWD	1998	97	132	07.98-09.00	■
2.0 HDI 90 (RHY (DW10TD))	-12/00	Diesel	FWD	1997	66	90	02.99-03.05	■
2.0 HDI 90 (RHY (DW10TD))	-12/00	Diesel	FWD	1997	66	90	02.99-03.05	■
PEUGEOT								
306 (7D, N3, N5) 01.94-04.02					Convertible (Compact car-C Segment)			
1.6 (NFT (TU5JP))		Gasolina	FWD	1587	72	98	10.00-04.02	■
1.6 (NFT (TU5JP))		Gasolina	FWD	1587	72	98	10.00-04.02	■
1.8 (L6A (XU7JP))	01/98-	Gasolina	FWD	1761	74	101	03.94-04.02	■
1.8 (L6A (XU7JP))	01/98-	Gasolina	FWD	1761	74	101	03.94-04.02	■
1.8 (LFZ (XU7JP))	01/98-	Gasolina	FWD	1761	74	101	03.94-04.02	■
1.8 (LFZ (XU7JP))	01/98-	Gasolina	FWD	1761	74	101	03.94-04.02	■
1.8 16V (LFY (XU7JP4))		Gasolina	FWD	1761	81	110	05.97-04.02	■
1.8 16V (LFY (XU7JP4))		Gasolina	FWD	1761	81	110	05.97-04.02	■
2.0 16V (RFV (XU10J4R))		Gasolina	FWD	1998	97	132	03.97-04.02	■
2.0 16V (RFV (XU10J4R))		Gasolina	FWD	1998	97	132	03.97-04.02	■
306 (7E, N3, N5) 06.94-12.02					Estate (Compact car-C Segment)			
1.6 (NFZ (TU5JP))		Gasolina	FWD	1587	65	89	03.97-10.00	■
1.6 (NFZ (TU5JP))		Gasolina	FWD	1587	65	89	03.97-10.00	■
1.6 (NFT (TU5JP))		Gasolina	FWD	1587	72	98	10.00-04.02	■
1.6 (NFT (TU5JP))		Gasolina	FWD	1587	72	98	10.00-04.02	■

LISTA DE APLICACIONES - BUYERS GUIDE

1.8 (LFZ (XU7JP))	-12/99	Gasolina	FWD	1761	74	101	03.97-04.02	■
1.8 (LFZ (XU7JP))	-12/99	Gasolina	FWD	1761	74	101	03.97-04.02	■
1.8 16V (LFY (XU7JP4))		Gasolina	FWD	1761	81	110	03.97-04.02	■
1.8 16V (LFY (XU7JP4))		Gasolina	FWD	1761	81	110	03.97-04.02	■
2.0 (RFV (XU10J4R))	-12/01	Gasolina	FWD	1998	97	132	03.97-04.02	■
2.0 (RFV (XU10J4R))	-12/01	Gasolina	FWD	1998	97	132	03.97-04.02	■
1.8 D		Diesel	RWD	1769	44	60	05.97-06.00	■
1.8 D		Diesel	RWD	1769	44	60	05.97-06.00	■
1.9 D (WJY (DW8B))		Diesel	FWD	1868	51	69	09.98-04.02	■
1.9 D (WJY (DW8B))		Diesel	FWD	1868	51	69	09.98-04.02	■
1.9 D (WJZ (DW8))		Diesel	FWD	1868	51	69	09.98-04.02	■
1.9 D (WJZ (DW8))		Diesel	FWD	1868	51	69	09.98-04.02	■
1.9 D (DJY (XUD9A))		Diesel	FWD	1905	50	68	03.97-04.02	■
1.9 D (DJY (XUD9A))		Diesel	FWD	1905	50	68	03.97-04.02	■
1.9 D (DJY (XUD9A))		Diesel	FWD	1905	51	69	05.97-05.99	■
1.9 D (DJY (XUD9A))		Diesel	FWD	1905	51	69	05.97-05.99	■
1.9 D (DHV (XUD9BSD))		Diesel	FWD	1905	55	75	03.98-04.02	■
1.9 D (DHV (XUD9BSD))		Diesel	FWD	1905	55	75	03.98-04.02	■
1.9 TD (D8A (XUD9TE))		Diesel	FWD	1905	66	90	02.97-04.02	■
1.9 TD (D8A (XUD9TE))		Diesel	FWD	1905	66	90	02.97-04.02	■
1.9 TD (DHY (XUD9TE))		Diesel	FWD	1905	66	90	02.97-04.02	■
1.9 TD (DHY (XUD9TE))		Diesel	FWD	1905	66	90	02.97-04.02	■
2.0 HDI 90 (RHY (DW10TD))		Diesel	FWD	1997	66	90	06.99-04.02	■
2.0 HDI 90 (RHY (DW10TD))		Diesel	FWD	1997	66	90	06.99-04.02	■
306 (7A, 7C, N3, N5) 01.93-10.03					Hatchback (Compact car-C Segment)			
1.6 (NFZ (TU5JP))	01/98-	Gasolina	FWD	1587	65	89	05.93-10.00	■
1.6 (NFZ (TU5JP))	01/98-	Gasolina	FWD	1587	65	89	05.93-10.00	■
1.6 (NFZ (TU5JP))		Gasolina	FWD	1587	66	90	07.00-05.01	■
1.6 (NFZ (TU5JP))		Gasolina	FWD	1587	66	90	07.00-05.01	■
1.6 (NFT (TU5JP))		Gasolina	FWD	1587	72	98	10.00-05.01	■
1.6 (NFT (TU5JP))		Gasolina	FWD	1587	72	98	10.00-05.01	■
1.8 (LFZ (XU7JP))	01/98-	Gasolina	FWD	1761	74	101	05.93-05.01	■
1.8 (LFZ (XU7JP))	01/98-	Gasolina	FWD	1761	74	101	05.93-05.01	■
1.8 (LFZ (XU7JP))		Gasolina	FWD	1761	74	101	05.93-05.01	■
1.8 (LFZ (XU7JP))		Gasolina	FWD	1761	74	101	05.93-05.01	■
1.8 16V (LFY (XU7JP4))		Gasolina	FWD	1761	81	110	03.97-05.01	■
1.8 16V (LFY (XU7JP4))		Gasolina	FWD	1761	81	110	03.97-05.01	■
1.8 16V		Gasolina	FWD	1761	86	117	10.99-10.03	■
1.8 16V		Gasolina	FWD	1761	86	117	10.99-10.03	■
2.0 16V (RFV (XU10J4R))		Gasolina	FWD	1998	97	132	03.97-05.01	■
2.0 16V (RFV (XU10J4R))		Gasolina	FWD	1998	97	132	03.97-05.01	■
2.0 16V (RFV (XU10J4R))		Gasolina	FWD	1998	99	135	03.97-06.00	■
2.0 16V (RFV (XU10J4R))		Gasolina	FWD	1998	99	135	03.97-06.00	■
2.0		Gasolina	FWD	1998	123	167	01.98-05.00	■
2.0		Gasolina	FWD	1998	123	167	01.98-05.00	■
1.9 D (WJY (DW8B))		Diesel	FWD	1868	51	69	09.98-05.01	■
1.9 D (WJY (DW8B))		Diesel	FWD	1868	51	69	09.98-05.01	■
1.9 D (WJZ (DW8))		Diesel	FWD	1868	51	69	09.98-05.01	■
1.9 D (WJZ (DW8))		Diesel	FWD	1868	51	69	09.98-05.01	■
1.9 D (DJY (XUD9A))	01/98-	Diesel	FWD	1905	50	68	06.94-05.01	■
1.9 D (DJY (XUD9A))	01/98-	Diesel	FWD	1905	50	68	06.94-05.01	■

LISTA DE APLICACIONES - BUYERS GUIDE

1.9 D (DHV (XUD9BSD))		Diesel	FWD	1905	55	75	03.98-05.01	■
1.9 D (DHV (XUD9BSD))		Diesel	FWD	1905	55	75	03.98-05.01	■
1.9 DT (DHY (XUD9TE))	01/97-	Diesel	FWD	1905	66	90	05.93-05.01	■
1.9 DT (DHY (XUD9TE))	01/97-	Diesel	FWD	1905	66	90	05.93-05.01	■
2.0 HDI 90 (RHY (DW10TD))		Diesel	FWD	1997	66	90	06.99-12.02	■
2.0 HDI 90 (RHY (DW10TD))		Diesel	FWD	1997	66	90	06.99-12.02	■
306 (7B, N3, N5) 04.93-10.03					Saloon (Compact car-C Segment)			
1.6 SR (NFZ (TU5JP))	01/98-	Gasolina	FWD	1587	65	89	06.94-10.00	■
1.6 SR (NFZ (TU5JP))	01/98-	Gasolina	FWD	1587	65	89	06.94-10.00	■
1.6 (NFZ (TU5JP))		Gasolina	FWD	1587	66	90	07.00-05.01	■
1.6 (NFZ (TU5JP))		Gasolina	FWD	1587	66	90	07.00-05.01	■
1.6 (NFT (TU5JP))		Gasolina	FWD	1587	72	98	10.00-05.01	■
1.6 (NFT (TU5JP))		Gasolina	FWD	1587	72	98	10.00-05.01	■
1.8 ST (LFZ (XU7JP))	01/98-	Gasolina	FWD	1761	74	101	06.94-05.01	■
1.8 ST (LFZ (XU7JP))	01/98-	Gasolina	FWD	1761	74	101	06.94-05.01	■
1.8 16V (LFY (XU7JP4))		Gasolina	FWD	1761	81	110	03.97-05.01	■
1.8 16V (LFY (XU7JP4))		Gasolina	FWD	1761	81	110	03.97-05.01	■
2.0 (RFV (XU10J4R))		Gasolina	FWD	1998	97	132	03.97-05.01	■
2.0 (RFV (XU10J4R))		Gasolina	FWD	1998	97	132	03.97-05.01	■
1.9 D (WJY (DW8B))		Diesel	FWD	1868	51	69	09.98-05.01	■
1.9 D (WJY (DW8B))		Diesel	FWD	1868	51	69	09.98-05.01	■
1.9 D (WJZ (DW8))		Diesel	FWD	1868	51	69	09.98-05.01	■
1.9 D (WJZ (DW8))		Diesel	FWD	1868	51	69	09.98-05.01	■
2.0 HDI 90 (RHY (DW10TD))		Diesel	FWD	1997	66	90	06.99-12.01	■
2.0 HDI 90 (RHY (DW10TD))		Diesel	FWD	1997	66	90	06.99-12.01	■
PARTNER / GRAND RAID / RANCH (5_, G_) 05.96-12.15					MPV (Compact MPV-M1 Segment)			
1.1 (HDZ (TU1M))		Gasolina	FWD	1124	44	60	06.96-10.02	■
1.1 (HDZ (TU1M))		Gasolina	FWD	1124	44	60	06.96-10.02	■
1.1 (HFX (TU1JP))		Gasolina	FWD	1124	44	60	06.96-10.02	■
1.1 (HFX (TU1JP))		Gasolina	FWD	1124	44	60	06.96-10.02	■
1.4 (KFW (TU3A))	-12/08	Gasolina	FWD	1360	55	75	06.96-12.15	■
1.4 (KFW (TU3A))	-12/08	Gasolina	FWD	1360	55	75	06.96-12.15	■
1.4 (KFW (TU3JP))	-12/08	Gasolina	FWD	1360	55	75	06.96-12.15	■
1.4 (KFW (TU3JP))	-12/08	Gasolina	FWD	1360	55	75	06.96-12.15	■
1.4 (KFX (TU3JP))	-12/08	Gasolina	FWD	1360	55	75	06.96-12.15	■
1.4 (KFX (TU3JP))	-12/08	Gasolina	FWD	1360	55	75	06.96-12.15	■
1.8 (LFX (XU7JB))		Gasolina	FWD	1761	66	90	05.97-12.02	■
1.8 (LFX (XU7JB))		Gasolina	FWD	1761	66	90	05.97-12.02	■
1.9 D (WJY (DW8B))		Diesel	FWD	1868	51	69	01.99-07.08	■
1.9 D (WJY (DW8B))		Diesel	FWD	1868	51	69	01.99-07.08	■
1.9 D (WJZ (DW8))		Diesel	FWD	1868	51	69	01.99-07.08	■
1.9 D (WJZ (DW8))		Diesel	FWD	1868	51	69	01.99-07.08	■
1.9 D (DJY (XUD9A))		Diesel	FWD	1905	50	68	06.96-12.02	■
1.9 D (DJY (XUD9A))		Diesel	FWD	1905	50	68	06.96-12.02	■
1.9 D (XUD9)		Diesel	FWD	1905	51	69	05.96-12.98	■
1.9 D (XUD9)		Diesel	FWD	1905	51	69	05.96-12.98	■
2.0 HDi (RHY (DW10TD))		Diesel	FWD	1997	66	90	02.00-07.08	■
2.0 HDi (RHY (DW10TD))		Diesel	FWD	1997	66	90	02.00-07.08	■
PARTNER / RANCH (5_, G_) 06.96-12.15					Box Body/MPV (LCVs-N1 Segment)			
1.1 (HDZ (TU1M))		Gasolina	FWD	1124	44	60	06.96-09.05	■

LISTA DE APLICACIONES - BUYERS GUIDE

1.1 (HDZ (TU1M))		Gasolina	FWD	1124	44	60	06.96-09.05	■
1.4 (KFW (TU3A))	-12/08	Gasolina	FWD	1360	55	75	06.96-12.15	■
1.4 (KFW (TU3A))	-12/08	Gasolina	FWD	1360	55	75	06.96-12.15	■
1.4 (KFX (TU3JP))	-12/08	Gasolina	FWD	1360	55	75	06.96-12.15	■
1.4 (KFX (TU3JP))	-12/08	Gasolina	FWD	1360	55	75	06.96-12.15	■
1.4 (TU32)	-12/08	Gasolina	FWD	1360	55	75	06.96-12.15	■
1.4 (TU32)	-12/08	Gasolina	FWD	1360	55	75	06.96-12.15	■
1.6 (NFU (TU5JP4))		Gasolina	FWD	1587	80	109	09.00-10.02	■
1.6 (NFU (TU5JP4))		Gasolina	FWD	1587	80	109	09.00-10.02	■
1.8 (LFX (XU7JB))		Gasolina	FWD	1761	66	90	03.97-08.00	■
1.8 (LFX (XU7JB))		Gasolina	FWD	1761	66	90	03.97-08.00	■
1.8 D (A9A (XUD7))		Diesel	FWD	1769	43	58	06.96-12.02	■
1.8 D (A9A (XUD7))		Diesel	FWD	1769	43	58	06.96-12.02	■
1.8 D (A9A (XUD7))		Diesel	FWD	1769	44	60	11.96-02.98	■
1.8 D (A9A (XUD7))		Diesel	FWD	1769	44	60	11.96-02.98	■
1.9 D (WJY (DW8B))	-12/08	Diesel	FWD	1868	51	69	06.96-12.15	■
1.9 D (WJY (DW8B))	-12/08	Diesel	FWD	1868	51	69	06.96-12.15	■
1.9 D (WJZ (DW8))	-12/08	Diesel	FWD	1868	51	69	06.96-12.15	■
1.9 D (WJZ (DW8))	-12/08	Diesel	FWD	1868	51	69	06.96-12.15	■
1.9 D (DJY (XUD9A))		Diesel	FWD	1905	50	68	06.96-12.98	■
1.9 D (DJY (XUD9A))		Diesel	FWD	1905	50	68	06.96-12.98	■
1.9 D (DJY (XUD9A))		Diesel	FWD	1905	51	69	06.96-12.02	■
1.9 D (DJY (XUD9A))		Diesel	FWD	1905	51	69	06.96-12.02	■
2.0 HDi (RHY (DW10TD))		Diesel	FWD	1997	66	90	04.00-07.08	■
2.0 HDi (RHY (DW10TD))		Diesel	FWD	1997	66	90	04.00-07.08	■