


# LISTA DE APLICACIONES - BUYERS GUIDE

## 31248-9060



8 424073 103857

Weight: 16.486



## 31248-9060



Ate - Teves

155.2x71.7x19.6

Ø280x25x42

**WVA**

23057

**MAKE**

OPEL

VAUXHALL



Trac.

CC

Kw

CV



Front / Rear

### OPEL

#### ASTRA G (T98) 03.01-10.05

#### Convertible (Compact car-C Segment)

1.6 16V (F67) (Z 16 XE)	-12/04	Gasolina	FWD	1598	74	101	03.01-10.05	■
1.6 16V (F67) (Z 16 XE)	-12/04	Gasolina	FWD	1598	74	101	03.01-10.05	■
1.6 (F67) (Z 16 XEP)	-12/04	Gasolina	FWD	1598	76	103	01.03-10.05	■
1.6 (F67) (Z 16 XEP)	-12/04	Gasolina	FWD	1598	76	103	01.03-10.05	■
1.8 16V (F67) (Z 18 XE)	-12/04	Gasolina	FWD	1796	92	125	03.01-10.05	■
1.8 16V (F67) (Z 18 XE)	-12/04	Gasolina	FWD	1796	92	125	03.01-10.05	■
2.2 16V (F67) (Z 22 SE)	-12/04	Gasolina	FWD	2198	108	147	03.01-10.05	■
2.2 16V (F67) (Z 22 SE)	-12/04	Gasolina	FWD	2198	108	147	03.01-10.05	■
2.2 DTI (F67) (Y 22 DTR)	-12/04	Diesel	FWD	2172	92	125	09.02-10.05	■
2.2 DTI (F67) (Y 22 DTR)	-12/04	Diesel	FWD	2172	92	125	09.02-10.05	■

#### ASTRA G (T98) 03.00-06.06

#### Coupe (Compact car-C Segment)

1.6 16V (F07) (Z 16 XEP)	01/03-	Gasolina	FWD	1598	76	103	03.00-05.05	■
1.6 16V (F07) (Z 16 XEP)	01/03-	Gasolina	FWD	1598	76	103	03.00-05.05	■
1.8 16V (F07) (X 18 XE1)		Gasolina	FWD	1796	85	116	03.00-10.00	■
1.8 16V (F07) (X 18 XE1)		Gasolina	FWD	1796	85	116	03.00-10.00	■
1.8 16V (F07) (Z 18 XE)	-12/04	Gasolina	FWD	1796	92	125	09.00-05.05	■
1.8 16V (F07) (Z 18 XE)	-12/04	Gasolina	FWD	1796	92	125	09.00-05.05	■
2.2 16V (F07) (Z 22 SE)	-12/04	Gasolina	FWD	2198	108	147	09.00-05.05	■
2.2 16V (F07) (Z 22 SE)	-12/04	Gasolina	FWD	2198	108	147	09.00-05.05	■
2.2 DTI (F07) (Y 22 DTR)	-12/04	Diesel	FWD	2172	92	125	09.02-05.05	■
2.2 DTI (F07) (Y 22 DTR)	-12/04	Diesel	FWD	2172	92	125	09.02-05.05	■

# LISTA DE APLICACIONES - BUYERS GUIDE

ASTRA G (F70) 09.98-04.05					Estate Van (Compact car-C Segment)			
2.0 DI (F70) (X 20 DTL)	01/01-	Diesel	FWD	1995	60	82	01.99-04.05	■
2.0 DI (F70) (X 20 DTL)	01/01-	Diesel	FWD	1995	60	82	01.99-04.05	■
2.0 DI (F70) (Y 20 DTL)	01/01-	Diesel	FWD	1995	60	82	01.99-04.05	■
2.0 DI (F70) (Y 20 DTL)	01/01-	Diesel	FWD	1995	60	82	01.99-04.05	■
ASTRA G (T98) 02.98-07.05					Estate (Compact car-C Segment)			
1.6 16V (F35) (X 16 XEL)	01/00-	Gasolina	FWD	1598	74	101	02.98-07.04	■
1.6 16V (F35) (X 16 XEL)	01/00-	Gasolina	FWD	1598	74	101	02.98-07.04	■
1.6 16V (F35) (Z 16 XE)	01/00-	Gasolina	FWD	1598	74	101	02.98-07.04	■
1.6 16V (F35) (Z 16 XE)	01/00-	Gasolina	FWD	1598	74	101	02.98-07.04	■
1.8		Gasolina	FWD	1796	81	110	02.03-07.04	■
1.8		Gasolina	FWD	1796	81	110	02.03-07.04	■
1.8 16V (F35) (X 18 XE1)		Gasolina	FWD	1796	85	116	02.98-09.00	■
1.8 16V (F35) (X 18 XE1)		Gasolina	FWD	1796	85	116	02.98-09.00	■
1.8 16V (F35) (Z 18 XE)		Gasolina	FWD	1796	92	125	09.00-07.04	■
1.8 16V (F35) (Z 18 XE)		Gasolina	FWD	1796	92	125	09.00-07.04	■
2.0 16V (F35) (X 20 XEV)	-12/00	Gasolina	FWD	1998	100	136	02.98-07.04	■
2.0 16V (F35) (X 20 XEV)	-12/00	Gasolina	FWD	1998	100	136	02.98-07.04	■
2.2 16V (F35) (Z 22 SE)		Gasolina	FWD	2198	108	147	03.01-07.04	■
2.2 16V (F35) (Z 22 SE)		Gasolina	FWD	2198	108	147	03.01-07.04	■
1.6 CNG (F35) (Z 16 YNG)		Gasol./Gas (CNG)	FWD	1598	71	97	03.03-07.04	■
1.6 CNG (F35) (Z 16 YNG)		Gasol./Gas (CNG)	FWD	1598	71	97	03.03-07.04	■
2.0 DI (F35) (X 20 DTL)		Diesel	FWD	1995	60	82	02.98-07.04	■
2.0 DI (F35) (X 20 DTL)		Diesel	FWD	1995	60	82	02.98-07.04	■
2.0 DI (F35) (Y 20 DTL)		Diesel	FWD	1995	60	82	02.98-07.04	■
2.0 DI (F35) (Y 20 DTL)		Diesel	FWD	1995	60	82	02.98-07.04	■
2.0 DTI 16V (F35) (Y 20 DTH)		Diesel	FWD	1995	74	101	08.99-07.04	■
2.0 DTI 16V (F35) (Y 20 DTH)		Diesel	FWD	1995	74	101	08.99-07.04	■
2.2 DTI (F35) (Y 22 DTR)		Diesel	FWD	2172	92	125	09.02-07.04	■
2.2 DTI (F35) (Y 22 DTR)		Diesel	FWD	2172	92	125	09.02-07.04	■
ASTRA G (T98) 02.98-12.09					Hatchback (Compact car-C Segment)			
1.6 16V (F08, F48) (C 16 SEL)	01/00-	Gasolina	FWD	1598	74	101	02.98-01.05	■
1.6 16V (F08, F48) (C 16 SEL)	01/00-	Gasolina	FWD	1598	74	101	02.98-01.05	■
1.6 16V (F08, F48) (X 16 XEL)	01/00-	Gasolina	FWD	1598	74	101	02.98-01.05	■
1.6 16V (F08, F48) (X 16 XEL)	01/00-	Gasolina	FWD	1598	74	101	02.98-01.05	■
1.6 16V (F08, F48) (Z 16 XE)	01/00-	Gasolina	FWD	1598	74	101	02.98-01.05	■
1.6 16V (F08, F48) (Z 16 XE)	01/00-	Gasolina	FWD	1598	74	101	02.98-01.05	■
1.8 (F08, F48)		Gasolina	FWD	1796	81	110	02.03-01.04	■
1.8 (F08, F48)		Gasolina	FWD	1796	81	110	02.03-01.04	■
1.8 16V (F08, F48) (X 18 XE1)		Gasolina	FWD	1796	85	116	02.98-09.00	■
1.8 16V (F08, F48) (X 18 XE1)		Gasolina	FWD	1796	85	116	02.98-09.00	■
1.8 16V (F08, F48) (Z 18 XE)	-12/04	Gasolina	FWD	1796	92	125	09.00-01.05	■
1.8 16V (F08, F48) (Z 18 XE)	-12/04	Gasolina	FWD	1796	92	125	09.00-01.05	■
2.0 16V (F08, F48) (X 20 XEV)	-12/00	Gasolina	FWD	1998	100	136	02.98-01.05	■
2.0 16V (F08, F48) (X 20 XEV)	-12/00	Gasolina	FWD	1998	100	136	02.98-01.05	■
2.2 16V (F08, F48) (Z 22 SE)	-12/04	Gasolina	FWD	2198	108	147	06.00-01.05	■
2.2 16V (F08, F48) (Z 22 SE)	-12/04	Gasolina	FWD	2198	108	147	06.00-01.05	■
2.0 DI (F08, F48) (X 20 DTL)	-12/04	Diesel	FWD	1995	60	82	02.98-01.05	■

# LISTA DE APLICACIONES - BUYERS GUIDE

2.0 DI (F08, F48) (X 20 DTL)	-12/04	Diesel	FWD	1995	60	82	02.98-01.05	■
2.0 DI (F08, F48) (Y 20 DTL)	-12/04	Diesel	FWD	1995	60	82	02.98-01.05	■
2.0 DI (F08, F48) (Y 20 DTL)	-12/04	Diesel	FWD	1995	60	82	02.98-01.05	■
2.0 DTI 16V (F08, F48) (Y 20 DTH)	-12/04	Diesel	FWD	1995	74	101	08.99-01.05	■
2.0 DTI 16V (F08, F48) (Y 20 DTH)	-12/04	Diesel	FWD	1995	74	101	08.99-01.05	■
2.2 DTI (F08, F48) (Y 22 DTR)	-12/04	Diesel	FWD	2172	92	125	09.02-01.05	■
2.2 DTI (F08, F48) (Y 22 DTR)	-12/04	Diesel	FWD	2172	92	125	09.02-01.05	■
<b>ASTRA G (T98) 03.98-12.09</b>					<b>Saloon (Compact car-C Segment)</b>			
1.6 16V (F69) (X 16 XEL)	01/00-	Gasolina	FWD	1598	74	101	09.98-01.05	■
1.6 16V (F69) (X 16 XEL)	01/00-	Gasolina	FWD	1598	74	101	09.98-01.05	■
1.6 16V (F69) (Z 16 XE)	01/00-	Gasolina	FWD	1598	74	101	09.98-01.05	■
1.6 16V (F69) (Z 16 XE)	01/00-	Gasolina	FWD	1598	74	101	09.98-01.05	■
1.8		Gasolina	FWD	1796	81	110	02.03-01.05	■
1.8		Gasolina	FWD	1796	81	110	02.03-01.05	■
1.8 16V (F69) (X 18 XE1)		Gasolina	FWD	1796	85	116	09.98-09.00	■
1.8 16V (F69) (X 18 XE1)		Gasolina	FWD	1796	85	116	09.98-09.00	■
1.8 16V (F69) (Z 18 XE)	-12/04	Gasolina	FWD	1796	92	125	06.00-01.05	■
1.8 16V (F69) (Z 18 XE)	-12/04	Gasolina	FWD	1796	92	125	06.00-01.05	■
2.0 16V (F69) (X 20 XEV)	-12/00	Gasolina	FWD	1998	100	136	09.98-01.05	■
2.0 16V (F69) (X 20 XEV)	-12/00	Gasolina	FWD	1998	100	136	09.98-01.05	■
2.2 16V (F69) (Z 22 SE)	-12/04	Gasolina	FWD	2198	108	147	03.01-01.05	■
2.2 16V (F69) (Z 22 SE)	-12/04	Gasolina	FWD	2198	108	147	03.01-01.05	■
2.0 DI (F69) (X 20 DTL)	-12/04	Diesel	FWD	1995	60	82	09.98-01.05	■
2.0 DI (F69) (X 20 DTL)	-12/04	Diesel	FWD	1995	60	82	09.98-01.05	■
2.0 DI (F69) (Y 20 DTL)	-12/04	Diesel	FWD	1995	60	82	09.98-01.05	■
2.0 DI (F69) (Y 20 DTL)	-12/04	Diesel	FWD	1995	60	82	09.98-01.05	■
2.0 DTI 16V (F69) (Y 20 DTH)	-12/04	Diesel	FWD	1995	74	101	08.99-01.05	■
2.0 DTI 16V (F69) (Y 20 DTH)	-12/04	Diesel	FWD	1995	74	101	08.99-01.05	■
2.2 DTI (F69) (Y 22 DTR)	-12/04	Diesel	FWD	2172	92	125	09.02-01.05	■
2.2 DTI (F69) (Y 22 DTR)	-12/04	Diesel	FWD	2172	92	125	09.02-01.05	■
<b>ZAFIRA A (T98) 04.99-06.06</b>					<b>MPV (Compact MPV-M1 Segment)</b>			
1.6		Gasolina	FWD	1598	70	95	09.02-06.05	■
1.6		Gasolina	FWD	1598	70	95	09.02-06.05	■
1.6 16V (F75) (X 16 XEL)		Gasolina	FWD	1598	74	101	04.99-06.05	■
1.6 16V (F75) (X 16 XEL)		Gasolina	FWD	1598	74	101	04.99-06.05	■
1.6 16V (F75) (Z 16 XE)		Gasolina	FWD	1598	74	101	04.99-06.05	■
1.6 16V (F75) (Z 16 XE)		Gasolina	FWD	1598	74	101	04.99-06.05	■
1.8		Gasolina	FWD	1796	81	110	02.03-06.05	■
1.8		Gasolina	FWD	1796	81	110	02.03-06.05	■
1.8 16V (F75) (X 18 XE1)		Gasolina	FWD	1796	85	116	04.99-09.00	■
1.8 16V (F75) (X 18 XE1)		Gasolina	FWD	1796	85	116	04.99-09.00	■
1.8 16V (F75) (Z 18 XE)	01/01-	Gasolina	FWD	1796	92	125	09.00-06.05	■
1.8 16V (F75) (Z 18 XE)	01/01-	Gasolina	FWD	1796	92	125	09.00-06.05	■
2.2 16V (F75) (Z 22 SE)		Gasolina	FWD	2198	108	147	09.00-06.05	■
2.2 16V (F75) (Z 22 SE)		Gasolina	FWD	2198	108	147	09.00-06.05	■
1.6 CNG (F75) (Z 16 YNG)		Gasol./Gas (CNG)	FWD	1598	71	97	09.01-06.05	■
1.6 CNG (F75) (Z 16 YNG)		Gasol./Gas (CNG)	FWD	1598	71	97	09.01-06.05	■
2.0 DI 16V (F75) (X 20 DTL)	-12/01	Diesel	FWD	1995	60	82	07.99-06.05	■
2.0 DI 16V (F75) (X 20 DTL)	-12/01	Diesel	FWD	1995	60	82	07.99-06.05	■

# LISTA DE APLICACIONES - BUYERS GUIDE

2.0 DI 16V (F75) (Y 20 DTL)	-12/01	Diesel	FWD	1995	60	82	07.99-06.05	■
2.0 DI 16V (F75) (Y 20 DTL)	-12/01	Diesel	FWD	1995	60	82	07.99-06.05	■
2.0 DI (F75)		Diesel	FWD	1995	63	86	07.99-06.00	■
2.0 DI (F75)		Diesel	FWD	1995	63	86	07.99-06.00	■
2.0 DTI 16V (F75) (Y 20 DTH)	01/01-	Diesel	FWD	1995	74	101	09.00-06.05	■
2.0 DTI 16V (F75) (Y 20 DTH)	01/01-	Diesel	FWD	1995	74	101	09.00-06.05	■
2.2 DTI 16V (F75) (Y 22 DTR)		Diesel	FWD	2172	92	125	01.02-06.05	■
2.2 DTI 16V (F75) (Y 22 DTR)		Diesel	FWD	2172	92	125	01.02-06.05	■
VAUXHALL								
ASTRA Mk IV (G) (T98) 03.01-10.05					Convertible (Compact car-C Segment)			
1.8 16V (Z 18 XE)		Gasolina	FWD	1796	92	125	03.01-10.05	■
1.8 16V (Z 18 XE)		Gasolina	FWD	1796	92	125	03.01-10.05	■
2.2 16V (Z 22 SE)		Gasolina	FWD	2198	108	147	03.01-10.05	■
2.2 16V (Z 22 SE)		Gasolina	FWD	2198	108	147	03.01-10.05	■
ASTRA Mk IV (G) (T98) 03.00-08.05					Coupe (Compact car-C Segment)			
1.8 16V (X 18 XE1)	-12/00	Gasolina	FWD	1796	85	115	03.00-08.05	■
1.8 16V (X 18 XE1)	-12/00	Gasolina	FWD	1796	85	115	03.00-08.05	■
1.8 16V (Z 18 XE)		Gasolina	FWD	1796	92	125	09.00-08.05	■
1.8 16V (Z 18 XE)		Gasolina	FWD	1796	92	125	09.00-08.05	■
2.0 16V Turbo (Z 20 LET)	-12/01	Gasolina	FWD	1998	140	190	09.00-08.05	■
2.0 16V Turbo (Z 20 LET)	-12/01	Gasolina	FWD	1998	140	190	09.00-08.05	■
2.2 16V (Z 22 SE)		Gasolina	FWD	2198	108	147	03.00-08.05	■
2.2 16V (Z 22 SE)		Gasolina	FWD	2198	108	147	03.00-08.05	■
1.8 16V Dualfuel (Z 18 XE)		Gasol./Gas (LPG)	FWD	1796	87	118	09.02-08.05	■
1.8 16V Dualfuel (Z 18 XE)		Gasol./Gas (LPG)	FWD	1796	87	118	09.02-08.05	■
ASTRA Mk IV (G) (T98) 02.98-05.05					Estate (Compact car-C Segment)			
1.8 16V (Z 18 XE)		Gasolina	FWD	1796	92	125	09.00-05.05	■
1.8 16V (Z 18 XE)		Gasolina	FWD	1796	92	125	09.00-05.05	■
2.0 16V		Gasolina	FWD	1998	100	136	02.98-05.05	■
2.0 16V		Gasolina	FWD	1998	100	136	02.98-05.05	■
2.2 16V (Z 22 SE)		Gasolina	FWD	2198	108	147	03.01-05.05	■
2.2 16V (Z 22 SE)		Gasolina	FWD	2198	108	147	03.01-05.05	■
1.8 16V Dualfuel (Z 18 XE)		Gasol./Gas (LPG)	FWD	1796	87	118	09.02-05.05	■
1.8 16V Dualfuel (Z 18 XE)		Gasol./Gas (LPG)	FWD	1796	87	118	09.02-05.05	■
2.0 DI (X 20 DTL)		Diesel	FWD	1995	60	82	03.98-04.04	■
2.0 DI (X 20 DTL)		Diesel	FWD	1995	60	82	03.98-04.04	■
2.0 DI (Y 20 DTL)		Diesel	FWD	1995	60	82	03.98-04.04	■
2.0 DI (Y 20 DTL)		Diesel	FWD	1995	60	82	03.98-04.04	■
2.0 DTI 16V (Y 20 DTH)		Diesel	FWD	1995	74	101	03.98-04.04	■
2.0 DTI 16V (Y 20 DTH)		Diesel	FWD	1995	74	101	03.98-04.04	■
ASTRA Mk IV (G) (T98) 02.98-05.05					Hatchback (Compact car-C Segment)			
1.8 16V (F08, F48) (Z 18 XE)		Gasolina	FWD	1796	92	125	09.00-05.05	■
1.8 16V (F08, F48) (Z 18 XE)		Gasolina	FWD	1796	92	125	09.00-05.05	■
2.0 16V (F08) (X 20 XEV)		Gasolina	FWD	1998	100	136	02.98-05.05	■
2.0 16V (F08) (X 20 XEV)		Gasolina	FWD	1998	100	136	02.98-05.05	■
2.2 16V (F08, F48) (Z 22 SE)		Gasolina	FWD	2198	108	147	03.01-05.05	■
2.2 16V (F08, F48) (Z 22 SE)		Gasolina	FWD	2198	108	147	03.01-05.05	■

# LISTA DE APLICACIONES - BUYERS GUIDE

1.8 16V Dualfuel (F08, F48) (Z 18 XE)		Gasol./Gas (LPG)	FWD	1796	87	118	09.02-05.05	■
1.8 16V Dualfuel (F08, F48) (Z 18 XE)		Gasol./Gas (LPG)	FWD	1796	87	118	09.02-05.05	■
2.0 DI (F48) (X 20 DTL)		Diesel	FWD	1995	60	82	02.98-05.05	■
2.0 DI (F48) (X 20 DTL)		Diesel	FWD	1995	60	82	02.98-05.05	■
2.0 DI (F48) (Y 20 DTL)		Diesel	FWD	1995	60	82	02.98-05.05	■
2.0 DI (F48) (Y 20 DTL)		Diesel	FWD	1995	60	82	02.98-05.05	■
2.0 DTI 16V (F48) (Y 20 DTH)	01/01-	Diesel	FWD	1995	74	101	08.99-05.05	■
2.0 DTI 16V (F48) (Y 20 DTH)	01/01-	Diesel	FWD	1995	74	101	08.99-05.05	■
<b>ASTRA Mk IV (G) (T98) 02.98-05.05</b>					<b>Saloon (Compact car-C Segment)</b>			
1.8 16V (Z 18 XE)	01/00-	Gasolina	FWD	1796	92	125	02.98-07.04	■
1.8 16V (Z 18 XE)	01/00-	Gasolina	FWD	1796	92	125	02.98-07.04	■
2.0 16V (X 20 XEV)		Gasolina	FWD	1998	100	136	09.98-05.05	■
2.0 16V (X 20 XEV)		Gasolina	FWD	1998	100	136	09.98-05.05	■
2.2 16V		Gasolina	RWD	2198	108	147	03.01-05.05	■
2.2 16V		Gasolina	RWD	2198	108	147	03.01-05.05	■
1.8 16V Dualfuel (Z 18 XE)	01/02-	Gasol./Gas (LPG)	FWD	1796	87	118	02.98-07.04	■
1.8 16V Dualfuel (Z 18 XE)	01/02-	Gasol./Gas (LPG)	FWD	1796	87	118	02.98-07.04	■
2.0 DI (X 20 DTL)		Diesel	FWD	1995	60	82	02.98-07.04	■
2.0 DI (X 20 DTL)		Diesel	FWD	1995	60	82	02.98-07.04	■
2.0 DI (Y 20 DTL)		Diesel	FWD	1995	60	82	02.98-07.04	■
2.0 DI (Y 20 DTL)		Diesel	FWD	1995	60	82	02.98-07.04	■
2.0 DTI 16V (Y 20 DTH)		Diesel	FWD	1995	74	101	02.98-07.04	■
2.0 DTI 16V (Y 20 DTH)		Diesel	FWD	1995	74	101	02.98-07.04	■
<b>ASTRAVAN Mk IV (G) (T98) 01.93-08.06</b>					<b>Estate Van (Compact car-C Segment)</b>			
1.7 CDTi (Z 17 DTL)		Diesel	FWD	1686	59	80	07.03-08.06	■
1.7 CDTi (Z 17 DTL)		Diesel	FWD	1686	59	80	07.03-08.06	■
2.0 DI (X 20 DTL)		Diesel	FWD	1995	60	82	08.98-08.06	■
2.0 DI (X 20 DTL)		Diesel	FWD	1995	60	82	08.98-08.06	■
2.0 DI (Y 20 DTL)		Diesel	FWD	1995	60	82	08.98-08.06	■
2.0 DI (Y 20 DTL)		Diesel	FWD	1995	60	82	08.98-08.06	■
2.0 DTI (Y 20 DTH)		Diesel	FWD	1995	74	100	04.04-08.06	■
2.0 DTI (Y 20 DTH)		Diesel	FWD	1995	74	100	04.04-08.06	■
<b>ZAFIRA Mk I (A) (T98) 11.98-08.05</b>					<b>MPV (Compact MPV-M1 Segment)</b>			
1.6 16V (X 16 XEL)		Gasolina	FWD	1598	74	101	04.99-08.05	■
1.6 16V (X 16 XEL)		Gasolina	FWD	1598	74	101	04.99-08.05	■
1.6 16V (Z 16 XE)		Gasolina	FWD	1598	74	101	04.99-08.05	■
1.6 16V (Z 16 XE)		Gasolina	FWD	1598	74	101	04.99-08.05	■
1.8 16V (X 18 XE1)		Gasolina	FWD	1796	85	116	05.99-08.00	■
1.8 16V (X 18 XE1)		Gasolina	FWD	1796	85	116	05.99-08.00	■
1.8 16V (Z 18 XE)		Gasolina	FWD	1796	92	125	09.00-08.05	■
1.8 16V (Z 18 XE)		Gasolina	FWD	1796	92	125	09.00-08.05	■
2.2 16V (Z 22 SE)	01/00-	Gasolina	FWD	2198	108	147	11.98-08.04	■
2.2 16V (Z 22 SE)	01/00-	Gasolina	FWD	2198	108	147	11.98-08.04	■
1.6 CNG (Z 16 YNG)		Gasol./Gas (CNG)	FWD	1598	71	97	09.01-06.05	■
1.6 CNG (Z 16 YNG)		Gasol./Gas (CNG)	FWD	1598	71	97	09.01-06.05	■
2.0 DI 16V (X 20 DTL)	-12/01	Diesel	FWD	1995	60	82	10.99-08.05	■

## LISTA DE APLICACIONES - BUYERS GUIDE

2.0 DI 16V (X 20 DTL)	-12/01	Diesel	FWD	1995	60	82	10.99-08.05	■
2.0 DTI 16V (Y 20 DTH)	01/01-	Diesel	FWD	1995	74	101	04.99-08.05	■
2.0 DTI 16V (Y 20 DTH)	01/01-	Diesel	FWD	1995	74	101	04.99-08.05	■