

1

LISTA DE APLICACIONES - BUYERS GUIDE

1.8 DI (RTN)		Diesel	FWD	1753	55	75	04.00-01.02	■
1.8 DI (RTP)		Diesel	FWD	1753	55	75	04.00-01.02	■
1.8 DI (RTP)		Diesel	FWD	1753	55	75	04.00-01.02	■
1.8 DI (RTQ)		Diesel	FWD	1753	55	75	04.00-01.02	■
1.8 DI (RTQ)		Diesel	FWD	1753	55	75	04.00-01.02	■
FIESTA IV / COURIER (J5_, J3_) 02.96-					Box Body/MPV (LCVs-N1 Segment)			
1.3 (J4C)	01/00-	Gasolina	FWD	1299	44	60	02.96-08.03	■
1.3 (J4C)	01/00-	Gasolina	FWD	1299	44	60	02.96-08.03	■
1.3 (J4J)	01/00-	Gasolina	FWD	1299	44	60	02.96-08.03	■
1.3 (J4J)	01/00-	Gasolina	FWD	1299	44	60	02.96-08.03	■
1.3 (J4L)	01/00-	Gasolina	FWD	1299	44	60	02.96-08.03	■
1.3 (J4L)	01/00-	Gasolina	FWD	1299	44	60	02.96-08.03	■
1.3 (J4Q)	01/00-	Gasolina	FWD	1299	44	60	02.96-08.03	■
1.3 (J4Q)	01/00-	Gasolina	FWD	1299	44	60	02.96-08.03	■
1.3 (J4R)	01/00-	Gasolina	FWD	1299	44	60	02.96-08.03	■
1.3 (J4R)	01/00-	Gasolina	FWD	1299	44	60	02.96-08.03	■
1.3 (J4T)	01/00-	Gasolina	FWD	1299	44	60	02.96-08.03	■
1.3 (J4T)	01/00-	Gasolina	FWD	1299	44	60	02.96-08.03	■
1.4 i (FHA)		Gasolina	FWD	1388	66	90	04.96-10.99	■
1.4 i (FHA)		Gasolina	FWD	1388	66	90	04.96-10.99	■
1.8 DI (RTN)	-12/01	Diesel	FWD	1753	55	75	09.00-08.03	■
1.8 DI (RTN)	-12/01	Diesel	FWD	1753	55	75	09.00-08.03	■
1.8 DI (RTP)	-12/01	Diesel	FWD	1753	55	75	09.00-08.03	■
1.8 DI (RTP)	-12/01	Diesel	FWD	1753	55	75	09.00-08.03	■
KA (RB_) 09.96-11.08					Hatchback (City car-A Segment)			
1.0 i	01/00-	Gasolina	FWD	999	48	65	09.99-11.08	■
1.0 i	01/00-	Gasolina	FWD	999	48	65	09.99-11.08	■
1.3 i (JJD)	01/00-	Gasolina	FWD	1299	36	49	06.98-11.08	■
1.3 i (JJD)	01/00-	Gasolina	FWD	1299	36	49	06.98-11.08	■
1.3 i (JJF)	01/00-	Gasolina	FWD	1299	36	49	06.98-11.08	■
1.3 i (JJF)	01/00-	Gasolina	FWD	1299	36	49	06.98-11.08	■
1.3 i (JJG)	01/00-	Gasolina	FWD	1299	36	49	06.98-11.08	■
1.3 i (JJG)	01/00-	Gasolina	FWD	1299	36	49	06.98-11.08	■
1.3 i (JJH)	01/00-	Gasolina	FWD	1299	36	49	06.98-11.08	■
1.3 i (JJH)	01/00-	Gasolina	FWD	1299	36	49	06.98-11.08	■
1.3 i (JLJ)	01/00-	Gasolina	FWD	1299	36	49	06.98-11.08	■
1.3 i (JLJ)	01/00-	Gasolina	FWD	1299	36	49	06.98-11.08	■
1.3 i (JJB)		Gasolina	FWD	1299	37	50	09.96-10.02	■
1.3 i (JJB)		Gasolina	FWD	1299	37	50	09.96-10.02	■
1.3 i (BAA)	01/00-	Gasolina	FWD	1299	44	60	09.96-11.08	■
1.3 i (BAA)	01/00-	Gasolina	FWD	1299	44	60	09.96-11.08	■
1.3 i (J4D)	01/00-	Gasolina	FWD	1299	44	60	09.96-11.08	■
1.3 i (J4D)	01/00-	Gasolina	FWD	1299	44	60	09.96-11.08	■
1.3 i (J4K)	01/00-	Gasolina	FWD	1299	44	60	09.96-11.08	■
1.3 i (J4K)	01/00-	Gasolina	FWD	1299	44	60	09.96-11.08	■
1.3 i (J4M)	01/00-	Gasolina	FWD	1299	44	60	09.96-11.08	■
1.3 i (J4M)	01/00-	Gasolina	FWD	1299	44	60	09.96-11.08	■
1.3 i (J4N)	01/00-	Gasolina	FWD	1299	44	60	09.96-11.08	■
1.3 i (J4N)	01/00-	Gasolina	FWD	1299	44	60	09.96-11.08	■
1.3 i (J4P)	01/00-	Gasolina	FWD	1299	44	60	09.96-11.08	■
1.3 i (J4P)	01/00-	Gasolina	FWD	1299	44	60	09.96-11.08	■

LISTA DE APLICACIONES - BUYERS GUIDE

1.3 i (J4S)	01/00-	Gasolina	FWD	1299	44	60	09.96-11.08	■
1.3 i (J4S)	01/00-	Gasolina	FWD	1299	44	60	09.96-11.08	■
1.3 i ROCAM (A9A)		Gasolina	FWD	1299	51	70	08.02-11.08	■
1.3 i ROCAM (A9A)		Gasolina	FWD	1299	51	70	08.02-11.08	■
1.3 i ROCAM (A9B)		Gasolina	FWD	1299	51	70	08.02-11.08	■
1.3 i ROCAM (A9B)		Gasolina	FWD	1299	51	70	08.02-11.08	■