


# LISTA DE APLICACIONES - BUYERS GUIDE

## 31344-1064



Weight: 9.839



## 31344-1064



Ate - Teves

150.2x54.21x18.8  
Ø239.5x20x43

**WVA**  
23200

**MAKE**  
FORD



Trac.	CC	Kw	CV
-------	----	----	----



Front / Rear

### FORD

FIESTA IV (JA_, JB_) 08.95-06.06							Hatchback (Supermini car-B Segment)		
1.25 i 16V (DHA)	01/00-	Gasolina	FWD	1242	55	75	08.95-01.02	■	
1.25 i 16V (DHA)	01/00-	Gasolina	FWD	1242	55	75	08.95-01.02	■	
1.25 i 16V (DHB)	01/00-	Gasolina	FWD	1242	55	75	08.95-01.02	■	
1.25 i 16V (DHB)	01/00-	Gasolina	FWD	1242	55	75	08.95-01.02	■	
1.25 i 16V (DHC)	01/00-	Gasolina	FWD	1242	55	75	08.95-01.02	■	
1.25 i 16V (DHC)	01/00-	Gasolina	FWD	1242	55	75	08.95-01.02	■	
1.25 i 16V (DHD)	01/00-	Gasolina	FWD	1242	55	75	08.95-01.02	■	
1.25 i 16V (DHD)	01/00-	Gasolina	FWD	1242	55	75	08.95-01.02	■	
1.25 i 16V (DHE)	01/00-	Gasolina	FWD	1242	55	75	08.95-01.02	■	
1.25 i 16V (DHE)	01/00-	Gasolina	FWD	1242	55	75	08.95-01.02	■	
1.25 i 16V (DHF)	01/00-	Gasolina	FWD	1242	55	75	08.95-01.02	■	
1.25 i 16V (DHF)	01/00-	Gasolina	FWD	1242	55	75	08.95-01.02	■	
1.25 i 16V (DHG)	01/00-	Gasolina	FWD	1242	55	75	08.95-01.02	■	
1.25 i 16V (DHG)	01/00-	Gasolina	FWD	1242	55	75	08.95-01.02	■	
1.4 i 16V (FHA)	01/00-	Gasolina	FWD	1388	66	90	04.96-01.02	■	
1.4 i 16V (FHA)	01/00-	Gasolina	FWD	1388	66	90	04.96-01.02	■	
1.4 i 16V (FHE)	01/00-	Gasolina	FWD	1388	66	90	04.96-01.02	■	
1.4 i 16V (FHE)	01/00-	Gasolina	FWD	1388	66	90	04.96-01.02	■	
1.8 D (RTJ)	01/00-	Diesel	FWD	1753	44	60	08.95-04.00	■	
1.8 D (RTJ)	01/00-	Diesel	FWD	1753	44	60	08.95-04.00	■	
1.8 D (RTK)	01/00-	Diesel	FWD	1753	44	60	08.95-04.00	■	
1.8 D (RTK)	01/00-	Diesel	FWD	1753	44	60	08.95-04.00	■	
1.8 DI (RTN)		Diesel	FWD	1753	55	75	04.00-01.02	■	

# LISTA DE APLICACIONES - BUYERS GUIDE

1.8 DI (RTN)		Diesel	FWD	1753	55	75	04.00-01.02	■	
1.8 DI (RTP)		Diesel	FWD	1753	55	75	04.00-01.02	■	
1.8 DI (RTP)		Diesel	FWD	1753	55	75	04.00-01.02	■	
1.8 DI (RTQ)		Diesel	FWD	1753	55	75	04.00-01.02	■	
1.8 DI (RTQ)		Diesel	FWD	1753	55	75	04.00-01.02	■	
<b>FIESTA IV / COURIER (J5_, J3_) 02.96-</b>					<b>Box Body/MPV (LCVs-N1 Segment)</b>				
1.3 (J4C)	01/00-	Gasolina	FWD	1299	44	60	02.96-08.03	■	
1.3 (J4C)	01/00-	Gasolina	FWD	1299	44	60	02.96-08.03	■	
1.3 (J4J)	01/00-	Gasolina	FWD	1299	44	60	02.96-08.03	■	
1.3 (J4J)	01/00-	Gasolina	FWD	1299	44	60	02.96-08.03	■	
1.3 (J4L)	01/00-	Gasolina	FWD	1299	44	60	02.96-08.03	■	
1.3 (J4L)	01/00-	Gasolina	FWD	1299	44	60	02.96-08.03	■	
1.3 (J4Q)	01/00-	Gasolina	FWD	1299	44	60	02.96-08.03	■	
1.3 (J4Q)	01/00-	Gasolina	FWD	1299	44	60	02.96-08.03	■	
1.3 (J4R)	01/00-	Gasolina	FWD	1299	44	60	02.96-08.03	■	
1.3 (J4R)	01/00-	Gasolina	FWD	1299	44	60	02.96-08.03	■	
1.3 (J4T)	01/00-	Gasolina	FWD	1299	44	60	02.96-08.03	■	
1.3 (J4T)	01/00-	Gasolina	FWD	1299	44	60	02.96-08.03	■	
1.4 i (FHA)		Gasolina	FWD	1388	66	90	04.96-10.99	■	
1.4 i (FHA)		Gasolina	FWD	1388	66	90	04.96-10.99	■	
1.8 DI (RTN)	-12/01	Diesel	FWD	1753	55	75	09.00-08.03	■	
1.8 DI (RTN)	-12/01	Diesel	FWD	1753	55	75	09.00-08.03	■	
1.8 DI (RTP)	-12/01	Diesel	FWD	1753	55	75	09.00-08.03	■	
1.8 DI (RTP)	-12/01	Diesel	FWD	1753	55	75	09.00-08.03	■	
<b>KA (RB_) 09.96-11.08</b>					<b>Hatchback (City car-A Segment)</b>				
1.0 i	01/00-	Gasolina	FWD	999	48	65	09.99-11.08	■	
1.0 i	01/00-	Gasolina	FWD	999	48	65	09.99-11.08	■	
1.3 i (JJD)	01/00-	Gasolina	FWD	1299	36	49	06.98-11.08	■	
1.3 i (JJD)	01/00-	Gasolina	FWD	1299	36	49	06.98-11.08	■	
1.3 i (JJF)	01/00-	Gasolina	FWD	1299	36	49	06.98-11.08	■	
1.3 i (JJF)	01/00-	Gasolina	FWD	1299	36	49	06.98-11.08	■	
1.3 i (JJG)	01/00-	Gasolina	FWD	1299	36	49	06.98-11.08	■	
1.3 i (JJG)	01/00-	Gasolina	FWD	1299	36	49	06.98-11.08	■	
1.3 i (JJH)	01/00-	Gasolina	FWD	1299	36	49	06.98-11.08	■	
1.3 i (JJH)	01/00-	Gasolina	FWD	1299	36	49	06.98-11.08	■	
1.3 i (JJL)	01/00-	Gasolina	FWD	1299	36	49	06.98-11.08	■	
1.3 i (JJL)	01/00-	Gasolina	FWD	1299	36	49	06.98-11.08	■	
1.3 i (JJB)		Gasolina	FWD	1299	37	50	09.96-10.02	■	
1.3 i (JJB)		Gasolina	FWD	1299	37	50	09.96-10.02	■	
1.3 i (BAA)	01/00-	Gasolina	FWD	1299	44	60	09.96-11.08	■	
1.3 i (BAA)	01/00-	Gasolina	FWD	1299	44	60	09.96-11.08	■	
1.3 i (J4D)	01/00-	Gasolina	FWD	1299	44	60	09.96-11.08	■	
1.3 i (J4D)	01/00-	Gasolina	FWD	1299	44	60	09.96-11.08	■	
1.3 i (J4K)	01/00-	Gasolina	FWD	1299	44	60	09.96-11.08	■	
1.3 i (J4K)	01/00-	Gasolina	FWD	1299	44	60	09.96-11.08	■	
1.3 i (J4M)	01/00-	Gasolina	FWD	1299	44	60	09.96-11.08	■	
1.3 i (J4M)	01/00-	Gasolina	FWD	1299	44	60	09.96-11.08	■	
1.3 i (J4N)	01/00-	Gasolina	FWD	1299	44	60	09.96-11.08	■	
1.3 i (J4N)	01/00-	Gasolina	FWD	1299	44	60	09.96-11.08	■	
1.3 i (J4P)	01/00-	Gasolina	FWD	1299	44	60	09.96-11.08	■	
1.3 i (J4P)	01/00-	Gasolina	FWD	1299	44	60	09.96-11.08	■	

## LISTA DE APLICACIONES - BUYERS GUIDE

1.3 i (J4S)	01/00-	Gasolina	FWD	1299	44	60	09.96-11.08	■
1.3 i (J4S)	01/00-	Gasolina	FWD	1299	44	60	09.96-11.08	■
1.3 i ROCAM (A9A)		Gasolina	FWD	1299	51	70	08.02-11.08	■
1.3 i ROCAM (A9A)		Gasolina	FWD	1299	51	70	08.02-11.08	■
1.3 i ROCAM (A9B)		Gasolina	FWD	1299	51	70	08.02-11.08	■
1.3 i ROCAM (A9B)		Gasolina	FWD	1299	51	70	08.02-11.08	■