


# LISTA DE APLICACIONES - BUYERS GUIDE

## 31349-5603



Weight: 14.010



## 31349-5603



Ate - Teves

146x54.7x19.6  
Ø280x22x36.5

**WVA**

23131

**MAKE**

AUDI

SEAT

SKODA

VW



Trac.	CC	Kw	CV
-------	----	----	----



Front / Rear

### AUDI

							Hatchback (Compact executive car-D Segment)	
<b>A3 (8L1) 09.96-09.06</b>								
1.6 (AVU)		Gasolina	FWD	1595	75	102	08.00-05.03	■
1.6 (AVU)		Gasolina	FWD	1595	75	102	08.00-05.03	■
1.6 (BFQ)		Gasolina	FWD	1595	75	102	08.00-05.03	■
1.6 (BFQ)		Gasolina	FWD	1595	75	102	08.00-05.03	■
1.8 (AGN)	01/99-	Gasolina	FWD	1781	92	125	09.96-05.03	■
1.8 (AGN)	01/99-	Gasolina	FWD	1781	92	125	09.96-05.03	■
1.8 (APG)	01/99-	Gasolina	FWD	1781	92	125	09.96-05.03	■
1.8 (APG)	01/99-	Gasolina	FWD	1781	92	125	09.96-05.03	■
1.9 TDI (AGR)	01/99-	Diesel	FWD	1896	66	90	09.96-07.01	■
1.9 TDI (AGR)	01/99-	Diesel	FWD	1896	66	90	09.96-07.01	■
1.9 TDI (ALH)	01/99-	Diesel	FWD	1896	66	90	09.96-07.01	■
1.9 TDI (ALH)	01/99-	Diesel	FWD	1896	66	90	09.96-07.01	■
1.9 TDI (AHF)	01/99-	Diesel	FWD	1896	81	110	08.97-07.01	■
1.9 TDI (AHF)	01/99-	Diesel	FWD	1896	81	110	08.97-07.01	■
1.9 TDI (ASV)	01/99-	Diesel	FWD	1896	81	110	08.97-07.01	■
1.9 TDI (ASV)	01/99-	Diesel	FWD	1896	81	110	08.97-07.01	■

### SEAT

							Hatchback (Compact car-C Segment)	
<b>LEON (1M1) 11.99-06.06</b>								
1.6 (AEH)	01/00-	Gasolina	FWD	1595	74	100	11.99-06.06	■
1.6 (AEH)	01/00-	Gasolina	FWD	1595	74	100	11.99-06.06	■
1.6 (AKL)	01/00-	Gasolina	FWD	1595	74	100	11.99-06.06	■
1.6 (AKL)	01/00-	Gasolina	FWD	1595	74	100	11.99-06.06	■

# LISTA DE APLICACIONES - BUYERS GUIDE

1.8 20V (AGN)	01/00-	Gasolina	FWD	1781	92	125	11.99-06.06	■
1.8 20V (AGN)	01/00-	Gasolina	FWD	1781	92	125	11.99-06.06	■
1.8 20V (APG)	01/00-	Gasolina	FWD	1781	92	125	11.99-06.06	■
1.8 20V (APG)	01/00-	Gasolina	FWD	1781	92	125	11.99-06.06	■
1.9 SDI (AQM)	01/00-	Diesel	FWD	1896	50	68	11.99-06.06	■
1.9 SDI (AQM)	01/00-	Diesel	FWD	1896	50	68	11.99-06.06	■
1.9 TDI (AGR)	01/00-	Diesel	FWD	1896	66	90	11.99-06.06	■
1.9 TDI (AGR)	01/00-	Diesel	FWD	1896	66	90	11.99-06.06	■
1.9 TDI (ALH)	01/00-	Diesel	FWD	1896	66	90	11.99-06.06	■
1.9 TDI (ALH)	01/00-	Diesel	FWD	1896	66	90	11.99-06.06	■
1.9 TDI (AXR)		Diesel	FWD	1896	74	100	10.05-06.06	■
1.9 TDI (AXR)		Diesel	FWD	1896	74	100	10.05-06.06	■
1.9 TDI (AHF)	01/00-	Diesel	FWD	1896	81	110	11.99-06.06	■
1.9 TDI (AHF)	01/00-	Diesel	FWD	1896	81	110	11.99-06.06	■
1.9 TDI (ASV)	01/00-	Diesel	FWD	1896	81	110	11.99-06.06	■
1.9 TDI (ASV)	01/00-	Diesel	FWD	1896	81	110	11.99-06.06	■
<b>TOLEDO II (1M2) 10.98-05.06</b>					<b>Saloon (Compact car-C Segment)</b>			
1.8 20V (AGN)	01/00-	Gasolina	FWD	1781	92	125	10.98-07.04	■
1.8 20V (AGN)	01/00-	Gasolina	FWD	1781	92	125	10.98-07.04	■
1.8 20V (APG)	01/00-	Gasolina	FWD	1781	92	125	10.98-07.04	■
1.8 20V (APG)	01/00-	Gasolina	FWD	1781	92	125	10.98-07.04	■
1.9 TDI (AGR)	01/00-	Diesel	FWD	1896	66	90	03.99-07.04	■
1.9 TDI (AGR)	01/00-	Diesel	FWD	1896	66	90	03.99-07.04	■
1.9 TDI (ALH)	01/00-	Diesel	FWD	1896	66	90	03.99-07.04	■
1.9 TDI (ALH)	01/00-	Diesel	FWD	1896	66	90	03.99-07.04	■
1.9 TDI (AXR)		Diesel	FWD	1896	74	101	08.05-05.06	■
1.9 TDI (AXR)		Diesel	FWD	1896	74	101	08.05-05.06	■
1.9 TDI (AHF)	01/00-	Diesel	FWD	1896	81	110	10.98-07.04	■
1.9 TDI (AHF)	01/00-	Diesel	FWD	1896	81	110	10.98-07.04	■
1.9 TDI (ASV)	01/00-	Diesel	FWD	1896	81	110	10.98-07.04	■
1.9 TDI (ASV)	01/00-	Diesel	FWD	1896	81	110	10.98-07.04	■
<b>SKODA</b>								
<b>OCTAVIA (1U5) 08.00-03.10</b>					<b>Estate Van (Compact car-C Segment)</b>			
1.9 D (AQM)		Diesel	FWD	1896	50	68	08.00-12.03	■
1.9 D (AQM)		Diesel	FWD	1896	50	68	08.00-12.03	■
1.9 TDI (ALH)		Diesel	FWD	1896	66	90	08.00-03.10	■
1.9 TDI (ALH)		Diesel	FWD	1896	66	90	08.00-03.10	■
<b>OCTAVIA (1U2) 09.96-12.10</b>					<b>Hatchback (Compact car-C Segment)</b>			
1.4 16V (AXP)	-12/04	Gasolina	FWD	1390	55	75	09.00-12.10	■
1.4 16V (AXP)	-12/04	Gasolina	FWD	1390	55	75	09.00-12.10	■
1.4 16V (BCA)	-12/04	Gasolina	FWD	1390	55	75	09.00-12.10	■
1.4 16V (BCA)	-12/04	Gasolina	FWD	1390	55	75	09.00-12.10	■
1.4 (AMD)	01/00-	Gasolina	FWD	1397	44	60	04.99-03.01	■
1.4 (AMD)	01/00-	Gasolina	FWD	1397	44	60	04.99-03.01	■
1.6 (AEH)	01/00-	Gasolina	FWD	1595	74	101	02.97-12.07	■
1.6 (AEH)	01/00-	Gasolina	FWD	1595	74	101	02.97-12.07	■
1.6 (AKL)	01/00-	Gasolina	FWD	1595	74	101	02.97-12.07	■
1.6 (AKL)	01/00-	Gasolina	FWD	1595	74	101	02.97-12.07	■
1.6 (AVU)	-12/04	Gasolina	FWD	1595	75	102	11.00-12.10	■
1.6 (AVU)	-12/04	Gasolina	FWD	1595	75	102	11.00-12.10	■

# LISTA DE APLICACIONES - BUYERS GUIDE

1.6 (BFQ)	-12/04	Gasolina	FWD	1595	75	102	11.00-12.10	■
1.6 (BFQ)	-12/04	Gasolina	FWD	1595	75	102	11.00-12.10	■
2.0 (AEG)	01/00-	Gasolina	FWD	1984	85	116	04.99-05.07	■
2.0 (AEG)	01/00-	Gasolina	FWD	1984	85	116	04.99-05.07	■
2.0 (APK)	01/00-	Gasolina	FWD	1984	85	116	04.99-05.07	■
2.0 (APK)	01/00-	Gasolina	FWD	1984	85	116	04.99-05.07	■
2.0 (AQY)	01/00-	Gasolina	FWD	1984	85	116	04.99-05.07	■
2.0 (AQY)	01/00-	Gasolina	FWD	1984	85	116	04.99-05.07	■
2.0 (AZH)	01/00-	Gasolina	FWD	1984	85	116	04.99-05.07	■
2.0 (AZH)	01/00-	Gasolina	FWD	1984	85	116	04.99-05.07	■
2.0 (AZJ)	01/00-	Gasolina	FWD	1984	85	116	04.99-05.07	■
2.0 (AZJ)	01/00-	Gasolina	FWD	1984	85	116	04.99-05.07	■
1.9 SDI (AGP)	01/00-	Diesel	FWD	1896	50	68	06.97-12.03	■
1.9 SDI (AGP)	01/00-	Diesel	FWD	1896	50	68	06.97-12.03	■
1.9 SDI (AQM)	01/00-	Diesel	FWD	1896	50	68	06.97-12.03	■
1.9 SDI (AQM)	01/00-	Diesel	FWD	1896	50	68	06.97-12.03	■
1.9 TDI (AGR)	01/00-	Diesel	FWD	1896	66	90	09.96-03.10	■
1.9 TDI (AGR)	01/00-	Diesel	FWD	1896	66	90	09.96-03.10	■
1.9 TDI (ALH)	01/00-	Diesel	FWD	1896	66	90	09.96-03.10	■
1.9 TDI (ALH)	01/00-	Diesel	FWD	1896	66	90	09.96-03.10	■
1.9 TDI (AXR)		Diesel	FWD	1896	74	100	10.05-12.10	■
1.9 TDI (AXR)		Diesel	FWD	1896	74	100	10.05-12.10	■
1.9 TDI (AHF)	01/00-	Diesel	FWD	1896	81	110	08.97-01.06	■
1.9 TDI (AHF)	01/00-	Diesel	FWD	1896	81	110	08.97-01.06	■
1.9 TDI (ASV)	01/00-	Diesel	FWD	1896	81	110	08.97-01.06	■
1.9 TDI (ASV)	01/00-	Diesel	FWD	1896	81	110	08.97-01.06	■
1.9 TDI (ASZ)		Diesel	FWD	1896	96	130	09.02-09.04	■
1.9 TDI (ASZ)		Diesel	FWD	1896	96	130	09.02-09.04	■
<b>OCTAVIA Combi (1U5) 07.98-12.10</b>				<b>Estate (Compact car-C Segment)</b>				
1.4 16V (AXP)	-12/04	Gasolina	FWD	1390	55	75	08.00-12.10	■
1.4 16V (AXP)	-12/04	Gasolina	FWD	1390	55	75	08.00-12.10	■
1.4 16V (BCA)	-12/04	Gasolina	FWD	1390	55	75	08.00-12.10	■
1.4 16V (BCA)	-12/04	Gasolina	FWD	1390	55	75	08.00-12.10	■
1.6 (AEH)	01/00-	Gasolina	FWD	1595	74	101	07.98-12.07	■
1.6 (AEH)	01/00-	Gasolina	FWD	1595	74	101	07.98-12.07	■
1.6 (AKL)	01/00-	Gasolina	FWD	1595	74	101	07.98-12.07	■
1.6 (AKL)	01/00-	Gasolina	FWD	1595	74	101	07.98-12.07	■
1.6 (AVU)	-12/04	Gasolina	FWD	1595	75	102	09.00-12.10	■
1.6 (AVU)	-12/04	Gasolina	FWD	1595	75	102	09.00-12.10	■
1.6 (BFQ)	-12/04	Gasolina	FWD	1595	75	102	09.00-12.10	■
1.6 (BFQ)	-12/04	Gasolina	FWD	1595	75	102	09.00-12.10	■
2.0 (AEG)	01/00-	Gasolina	FWD	1984	85	116	04.99-05.07	■
2.0 (AEG)	01/00-	Gasolina	FWD	1984	85	116	04.99-05.07	■
2.0 (APK)	01/00-	Gasolina	FWD	1984	85	116	04.99-05.07	■
2.0 (APK)	01/00-	Gasolina	FWD	1984	85	116	04.99-05.07	■
2.0 (AQY)	01/00-	Gasolina	FWD	1984	85	116	04.99-05.07	■
2.0 (AQY)	01/00-	Gasolina	FWD	1984	85	116	04.99-05.07	■
2.0 (AZH)	01/00-	Gasolina	FWD	1984	85	116	04.99-05.07	■
2.0 (AZH)	01/00-	Gasolina	FWD	1984	85	116	04.99-05.07	■
2.0 (AZJ)	01/00-	Gasolina	FWD	1984	85	116	04.99-05.07	■
2.0 (AZJ)	01/00-	Gasolina	FWD	1984	85	116	04.99-05.07	■

# LISTA DE APLICACIONES - BUYERS GUIDE

2.0 4x4 (AZH)		Gasolina	4WD	1984	85	116	08.00-09.04	■	
2.0 4x4 (AZH)		Gasolina	4WD	1984	85	116	08.00-09.04	■	
2.0 4x4 (AZJ)		Gasolina	4WD	1984	85	116	08.00-09.04	■	
2.0 4x4 (AZJ)		Gasolina	4WD	1984	85	116	08.00-09.04	■	
2.0 4x4 (ATF)	-12/04	Gasolina	4WD	1984	88	120	01.00-12.10	■	
2.0 4x4 (ATF)	-12/04	Gasolina	4WD	1984	88	120	01.00-12.10	■	
1.9 SDI (AGP)	01/00-	Diesel	FWD	1896	50	68	07.98-12.03	■	
1.9 SDI (AGP)	01/00-	Diesel	FWD	1896	50	68	07.98-12.03	■	
1.9 SDI (AQM)	01/00-	Diesel	FWD	1896	50	68	07.98-12.03	■	
1.9 SDI (AQM)	01/00-	Diesel	FWD	1896	50	68	07.98-12.03	■	
1.9 TDI (AGR)	01/00-	Diesel	FWD	1896	66	90	07.98-03.10	■	
1.9 TDI (AGR)	01/00-	Diesel	FWD	1896	66	90	07.98-03.10	■	
1.9 TDI (ALH)	01/00-	Diesel	FWD	1896	66	90	07.98-03.10	■	
1.9 TDI (ALH)	01/00-	Diesel	FWD	1896	66	90	07.98-03.10	■	
1.9 TDI (AXR)	-12/04	Diesel	FWD	1896	74	100	08.00-12.10	■	
1.9 TDI (AXR)	-12/04	Diesel	FWD	1896	74	100	08.00-12.10	■	
1.9 TDI 4x4 (ATD)	-12/04	Diesel	4WD	1896	74	100	09.00-01.06	■	
1.9 TDI 4x4 (ATD)	-12/04	Diesel	4WD	1896	74	100	09.00-01.06	■	
1.9 TDI (AHF)	01/00-	Diesel	FWD	1896	81	110	07.98-01.06	■	
1.9 TDI (AHF)	01/00-	Diesel	FWD	1896	81	110	07.98-01.06	■	
1.9 TDI (ASV)	01/00-	Diesel	FWD	1896	81	110	07.98-01.06	■	
1.9 TDI (ASV)	01/00-	Diesel	FWD	1896	81	110	07.98-01.06	■	
1.9 TDI (ASZ)		Diesel	FWD	1896	96	130	09.02-09.04	■	
1.9 TDI (ASZ)		Diesel	FWD	1896	96	130	09.02-09.04	■	
<b>VW</b>									
<b>BORA / JETTA IV (1J2) 10.98-12.13</b>						<b>Saloon (Compact car-C Segment)</b>			
1.4 16V (AHW)	-12/01	Gasolina	FWD	1390	55	75	03.00-05.05	■	
1.4 16V (AHW)	-12/01	Gasolina	FWD	1390	55	75	03.00-05.05	■	
1.4 16V (AKQ)	-12/01	Gasolina	FWD	1390	55	75	03.00-05.05	■	
1.4 16V (AKQ)	-12/01	Gasolina	FWD	1390	55	75	03.00-05.05	■	
1.4 16V (APE)	-12/01	Gasolina	FWD	1390	55	75	03.00-05.05	■	
1.4 16V (APE)	-12/01	Gasolina	FWD	1390	55	75	03.00-05.05	■	
1.4 16V (AXP)	-12/01	Gasolina	FWD	1390	55	75	03.00-05.05	■	
1.4 16V (AXP)	-12/01	Gasolina	FWD	1390	55	75	03.00-05.05	■	
1.4 16V (BCA)	-12/01	Gasolina	FWD	1390	55	75	03.00-05.05	■	
1.4 16V (BCA)	-12/01	Gasolina	FWD	1390	55	75	03.00-05.05	■	
1.6 (AEH)	01/00-	Gasolina	FWD	1595	74	101	10.98-05.05	■	
1.6 (AEH)	01/00-	Gasolina	FWD	1595	74	101	10.98-05.05	■	
1.6 (AKL)	01/00-	Gasolina	FWD	1595	74	101	10.98-05.05	■	
1.6 (AKL)	01/00-	Gasolina	FWD	1595	74	101	10.98-05.05	■	
1.6 (APF)	01/00-	Gasolina	FWD	1595	74	101	10.98-05.05	■	
1.6 (APF)	01/00-	Gasolina	FWD	1595	74	101	10.98-05.05	■	
1.6 (AVU)		Gasolina	FWD	1595	75	102	08.00-05.05	■	
1.6 (AVU)		Gasolina	FWD	1595	75	102	08.00-05.05	■	
1.6 (BFQ)		Gasolina	FWD	1595	75	102	08.00-05.05	■	
1.6 (BFQ)		Gasolina	FWD	1595	75	102	08.00-05.05	■	
1.6		Gasolina	FWD	1595	78	107	06.02-10.04	■	
1.6		Gasolina	FWD	1595	78	107	06.02-10.04	■	
1.6 16V (ATN)		Gasolina	FWD	1598	77	105	05.00-05.05	■	
1.6 16V (ATN)		Gasolina	FWD	1598	77	105	05.00-05.05	■	
1.6 16V (AUS)		Gasolina	FWD	1598	77	105	05.00-05.05	■	

# LISTA DE APLICACIONES - BUYERS GUIDE

1.6 16V (AUS)		Gasolina	FWD	1598	77	105	05.00-05.05	■
1.6 16V (AZD)		Gasolina	FWD	1598	77	105	05.00-05.05	■
1.6 16V (AZD)		Gasolina	FWD	1598	77	105	05.00-05.05	■
1.6 16V (BCB)		Gasolina	FWD	1598	77	105	05.00-05.05	■
1.6 16V (BCB)		Gasolina	FWD	1598	77	105	05.00-05.05	■
1.6 FSI (BAD)		Gasolina	FWD	1598	81	110	01.02-05.05	■
1.6 FSI (BAD)		Gasolina	FWD	1598	81	110	01.02-05.05	■
1.8 (AGN)	01/99-	Gasolina	FWD	1781	92	125	10.98-05.05	■
1.8 (AGN)	01/99-	Gasolina	FWD	1781	92	125	10.98-05.05	■
1.8 (BAF)	01/99-	Gasolina	FWD	1781	92	125	10.98-05.05	■
1.8 (BAF)	01/99-	Gasolina	FWD	1781	92	125	10.98-05.05	■
1.8 4motion (AGN)	-12/00	Gasolina	4WD	1781	92	125	02.99-05.05	■
1.8 4motion (AGN)	-12/00	Gasolina	4WD	1781	92	125	02.99-05.05	■
2.0 (AEG)	01/99-	Gasolina	FWD	1984	85	115	10.98-12.13	■
2.0 (AEG)	01/99-	Gasolina	FWD	1984	85	115	10.98-12.13	■
2.0 (APK)	01/99-	Gasolina	FWD	1984	85	115	10.98-12.13	■
2.0 (APK)	01/99-	Gasolina	FWD	1984	85	115	10.98-12.13	■
2.0 (AQY)	01/99-	Gasolina	FWD	1984	85	115	10.98-12.13	■
2.0 (AQY)	01/99-	Gasolina	FWD	1984	85	115	10.98-12.13	■
2.0 (AVH)	01/99-	Gasolina	FWD	1984	85	115	10.98-12.13	■
2.0 (AVH)	01/99-	Gasolina	FWD	1984	85	115	10.98-12.13	■
2.0 (AZG)	01/99-	Gasolina	FWD	1984	85	115	10.98-12.13	■
2.0 (AZG)	01/99-	Gasolina	FWD	1984	85	115	10.98-12.13	■
2.0 (AZH)	01/99-	Gasolina	FWD	1984	85	115	10.98-12.13	■
2.0 (AZH)	01/99-	Gasolina	FWD	1984	85	115	10.98-12.13	■
2.0 (AZJ)	01/99-	Gasolina	FWD	1984	85	115	10.98-12.13	■
2.0 (AZJ)	01/99-	Gasolina	FWD	1984	85	115	10.98-12.13	■
2.0 (BBW)	01/99-	Gasolina	FWD	1984	85	115	10.98-12.13	■
2.0 (BBW)	01/99-	Gasolina	FWD	1984	85	115	10.98-12.13	■
2.0 (BER)	01/99-	Gasolina	FWD	1984	85	115	10.98-12.13	■
2.0 (BER)	01/99-	Gasolina	FWD	1984	85	115	10.98-12.13	■
2.0 (BEV)	01/99-	Gasolina	FWD	1984	85	115	10.98-12.13	■
2.0 (BEV)	01/99-	Gasolina	FWD	1984	85	115	10.98-12.13	■
2.0 (BHP)	01/99-	Gasolina	FWD	1984	85	115	10.98-12.13	■
2.0 (BHP)	01/99-	Gasolina	FWD	1984	85	115	10.98-12.13	■
2.0 (CBPA)	01/99-	Gasolina	FWD	1984	85	115	10.98-12.13	■
2.0 (CBPA)	01/99-	Gasolina	FWD	1984	85	115	10.98-12.13	■
2.0 (CFEA)	01/99-	Gasolina	FWD	1984	85	115	10.98-12.13	■
2.0 (CFEA)	01/99-	Gasolina	FWD	1984	85	115	10.98-12.13	■
2.0 4motion (AZH)		Gasolina	4WD	1984	85	115	04.00-05.05	■
2.0 4motion (AZH)		Gasolina	4WD	1984	85	115	04.00-05.05	■
2.0 4motion (AZJ)		Gasolina	4WD	1984	85	115	04.00-05.05	■
2.0 4motion (AZJ)		Gasolina	4WD	1984	85	115	04.00-05.05	■
1.9 SDI (AGP)	01/99-	Diesel	FWD	1896	50	68	10.98-05.05	■
1.9 SDI (AGP)	01/99-	Diesel	FWD	1896	50	68	10.98-05.05	■
1.9 SDI (AQM)	01/99-	Diesel	FWD	1896	50	68	10.98-05.05	■
1.9 SDI (AQM)	01/99-	Diesel	FWD	1896	50	68	10.98-05.05	■
1.9 TDI (AGR)	01/99-	Diesel	FWD	1896	66	90	10.98-05.05	■
1.9 TDI (AGR)	01/99-	Diesel	FWD	1896	66	90	10.98-05.05	■
1.9 TDI (ALH)	01/99-	Diesel	FWD	1896	66	90	10.98-05.05	■
1.9 TDI (ALH)	01/99-	Diesel	FWD	1896	66	90	10.98-05.05	■

# LISTA DE APLICACIONES - BUYERS GUIDE

1.9 TDI 4motion (AGR)		Diesel	4WD	1896	66	90	11.98-04.02	■
1.9 TDI 4motion (AGR)		Diesel	4WD	1896	66	90	11.98-04.02	■
1.9 TDI (ATD)		Diesel	FWD	1896	74	101	09.00-05.05	■
1.9 TDI (ATD)		Diesel	FWD	1896	74	101	09.00-05.05	■
1.9 TDI (AXR)		Diesel	FWD	1896	74	101	09.00-05.05	■
1.9 TDI (AXR)		Diesel	FWD	1896	74	101	09.00-05.05	■
1.9 TDI (BEW)		Diesel	FWD	1896	74	101	09.00-05.05	■
1.9 TDI (BEW)		Diesel	FWD	1896	74	101	09.00-05.05	■
1.9 TDI 4motion (ATD)		Diesel	4WD	1896	74	101	09.00-05.05	■
1.9 TDI 4motion (ATD)		Diesel	4WD	1896	74	101	09.00-05.05	■
1.9 TDI (AHF)	01/99-	Diesel	FWD	1896	81	110	10.98-06.01	■
1.9 TDI (AHF)	01/99-	Diesel	FWD	1896	81	110	10.98-06.01	■
1.9 TDI (ASV)	01/99-	Diesel	FWD	1896	81	110	10.98-06.01	■
1.9 TDI (ASV)	01/99-	Diesel	FWD	1896	81	110	10.98-06.01	■
1.9 TDI (AJM)	01/99-	Diesel	FWD	1896	85	115	12.98-01.02	■
1.9 TDI (AJM)	01/99-	Diesel	FWD	1896	85	115	12.98-01.02	■
1.9 TDI (AUY)	01/99-	Diesel	FWD	1896	85	115	12.98-01.02	■
1.9 TDI (AUY)	01/99-	Diesel	FWD	1896	85	115	12.98-01.02	■
1.9 TDI 4motion (AJM)		Diesel	4WD	1896	85	115	02.99-06.01	■
1.9 TDI 4motion (AJM)		Diesel	4WD	1896	85	115	02.99-06.01	■
1.9 TDI 4motion (AUY)		Diesel	4WD	1896	85	115	02.99-06.01	■
1.9 TDI 4motion (AUY)		Diesel	4WD	1896	85	115	02.99-06.01	■
<b>BORA Variant / JETTA IV (1J6) 05.99-05.05</b>					<b>Estate (Compact car-C Segment)</b>			
1.4 16V (AHW)	-12/01	Gasolina	FWD	1390	55	75	09.01-05.05	■
1.4 16V (AHW)	-12/01	Gasolina	FWD	1390	55	75	09.01-05.05	■
1.4 16V (AXP)	-12/01	Gasolina	FWD	1390	55	75	09.01-05.05	■
1.4 16V (AXP)	-12/01	Gasolina	FWD	1390	55	75	09.01-05.05	■
1.4 16V (BCA)	-12/01	Gasolina	FWD	1390	55	75	09.01-05.05	■
1.4 16V (BCA)	-12/01	Gasolina	FWD	1390	55	75	09.01-05.05	■
1.6 (AEH)	01/00-	Gasolina	FWD	1595	74	100	05.99-05.05	■
1.6 (AEH)	01/00-	Gasolina	FWD	1595	74	100	05.99-05.05	■
1.6 (AKL)	01/00-	Gasolina	FWD	1595	74	100	05.99-05.05	■
1.6 (AKL)	01/00-	Gasolina	FWD	1595	74	100	05.99-05.05	■
1.6 (APF)	01/00-	Gasolina	FWD	1595	74	100	05.99-05.05	■
1.6 (APF)	01/00-	Gasolina	FWD	1595	74	100	05.99-05.05	■
1.6 (AVU)		Gasolina	FWD	1595	75	102	08.00-05.05	■
1.6 (AVU)		Gasolina	FWD	1595	75	102	08.00-05.05	■
1.6 (BFQ)		Gasolina	FWD	1595	75	102	08.00-05.05	■
1.6 (BFQ)		Gasolina	FWD	1595	75	102	08.00-05.05	■
1.6 16V (ATN)		Gasolina	FWD	1598	77	105	02.00-05.05	■
1.6 16V (ATN)		Gasolina	FWD	1598	77	105	02.00-05.05	■
1.6 16V (AUS)		Gasolina	FWD	1598	77	105	02.00-05.05	■
1.6 16V (AUS)		Gasolina	FWD	1598	77	105	02.00-05.05	■
1.6 16V (AZD)		Gasolina	FWD	1598	77	105	02.00-05.05	■
1.6 16V (AZD)		Gasolina	FWD	1598	77	105	02.00-05.05	■
1.6 16V (BCB)		Gasolina	FWD	1598	77	105	02.00-05.05	■
1.6 16V (BCB)		Gasolina	FWD	1598	77	105	02.00-05.05	■
1.6 FSI (BAD)		Gasolina	FWD	1598	81	110	01.02-05.05	■
1.6 FSI (BAD)		Gasolina	FWD	1598	81	110	01.02-05.05	■
1.8 4motion (AGN)	-12/00	Gasolina	4WD	1781	92	125	05.99-05.05	■
1.8 4motion (AGN)	-12/00	Gasolina	4WD	1781	92	125	05.99-05.05	■

# LISTA DE APLICACIONES - BUYERS GUIDE

2.0 (APK)		Gasolina	FWD	1984	85	115	05.99-05.05	■
2.0 (APK)		Gasolina	FWD	1984	85	115	05.99-05.05	■
2.0 (AQY)		Gasolina	FWD	1984	85	115	05.99-05.05	■
2.0 (AQY)		Gasolina	FWD	1984	85	115	05.99-05.05	■
2.0 (AVH)		Gasolina	FWD	1984	85	115	05.99-05.05	■
2.0 (AVH)		Gasolina	FWD	1984	85	115	05.99-05.05	■
2.0 (AZG)		Gasolina	FWD	1984	85	115	05.99-05.05	■
2.0 (AZG)		Gasolina	FWD	1984	85	115	05.99-05.05	■
2.0 (AZH)		Gasolina	FWD	1984	85	115	05.99-05.05	■
2.0 (AZH)		Gasolina	FWD	1984	85	115	05.99-05.05	■
2.0 (AZJ)		Gasolina	FWD	1984	85	115	05.99-05.05	■
2.0 (AZJ)		Gasolina	FWD	1984	85	115	05.99-05.05	■
2.0 (BEV)		Gasolina	FWD	1984	85	115	05.99-05.05	■
2.0 (BEV)		Gasolina	FWD	1984	85	115	05.99-05.05	■
2.0 4motion (AZH)		Gasolina	4WD	1984	85	115	04.00-05.05	■
2.0 4motion (AZH)		Gasolina	4WD	1984	85	115	04.00-05.05	■
2.0 4motion (AZJ)		Gasolina	4WD	1984	85	115	04.00-05.05	■
2.0 4motion (AZJ)		Gasolina	4WD	1984	85	115	04.00-05.05	■
2.0 4motion (ATF)		Gasolina	4WD	1984	88	120	12.99-05.03	■
2.0 4motion (ATF)		Gasolina	4WD	1984	88	120	12.99-05.03	■
1.9 TDI (AGR)		Diesel	FWD	1896	66	90	07.04-05.05	■
1.9 TDI (AGR)		Diesel	FWD	1896	66	90	07.04-05.05	■
1.9 TDI (ALH)		Diesel	FWD	1896	66	90	07.04-05.05	■
1.9 TDI (ALH)		Diesel	FWD	1896	66	90	07.04-05.05	■
1.9 TDI (ATD)		Diesel	FWD	1896	74	101	09.00-05.05	■
1.9 TDI (ATD)		Diesel	FWD	1896	74	101	09.00-05.05	■
1.9 TDI (AXR)		Diesel	FWD	1896	74	101	09.00-05.05	■
1.9 TDI (AXR)		Diesel	FWD	1896	74	101	09.00-05.05	■
1.9 TDI (BEW)		Diesel	FWD	1896	74	101	09.00-05.05	■
1.9 TDI (BEW)		Diesel	FWD	1896	74	101	09.00-05.05	■
1.9 TDI 4motion (ATD)		Diesel	4WD	1896	74	101	09.00-05.05	■
1.9 TDI 4motion (ATD)		Diesel	4WD	1896	74	101	09.00-05.05	■
1.9 TDI (AHF)		Diesel	FWD	1896	81	110	05.99-06.01	■
1.9 TDI (AHF)		Diesel	FWD	1896	81	110	05.99-06.01	■
1.9 TDI (ASV)		Diesel	FWD	1896	81	110	05.99-06.01	■
1.9 TDI (ASV)		Diesel	FWD	1896	81	110	05.99-06.01	■
1.9 TDI (AJM)		Diesel	FWD	1896	85	115	05.99-06.01	■
1.9 TDI (AJM)		Diesel	FWD	1896	85	115	05.99-06.01	■
1.9 TDI (AUY)		Diesel	FWD	1896	85	115	05.99-06.01	■
1.9 TDI (AUY)		Diesel	FWD	1896	85	115	05.99-06.01	■
1.9 TDI 4motion (AJM)		Diesel	4WD	1896	85	115	05.99-06.01	■
1.9 TDI 4motion (AJM)		Diesel	4WD	1896	85	115	05.99-06.01	■
1.9 TDI 4motion (AUY)		Diesel	4WD	1896	85	115	05.99-06.01	■
1.9 TDI 4motion (AUY)		Diesel	4WD	1896	85	115	05.99-06.01	■
<b>GOLF IV (1J1) 08.97-04.08</b>							<b>Hatchback (Compact car-C Segment)</b>	
1.4 16V (AHW)	01/99-	Gasolina	FWD	1390	55	75	10.97-05.04	■
1.4 16V (AHW)	01/99-	Gasolina	FWD	1390	55	75	10.97-05.04	■
1.4 16V (AKQ)	01/99-	Gasolina	FWD	1390	55	75	10.97-05.04	■
1.4 16V (AKQ)	01/99-	Gasolina	FWD	1390	55	75	10.97-05.04	■
1.4 16V (APE)	01/99-	Gasolina	FWD	1390	55	75	10.97-05.04	■
1.4 16V (APE)	01/99-	Gasolina	FWD	1390	55	75	10.97-05.04	■

# LISTA DE APLICACIONES - BUYERS GUIDE

1.4 16V (AXP)	01/99-	Gasolina	FWD	1390	55	75	10.97-05.04	■
1.4 16V (AXP)	01/99-	Gasolina	FWD	1390	55	75	10.97-05.04	■
1.4 16V (BCA)	01/99-	Gasolina	FWD	1390	55	75	10.97-05.04	■
1.4 16V (BCA)	01/99-	Gasolina	FWD	1390	55	75	10.97-05.04	■
1.6		Gasolina	FWD	1595	68	92	12.98-05.02	■
1.6		Gasolina	FWD	1595	68	92	12.98-05.02	■
1.6 (AEH)	01/03-	Gasolina	FWD	1595	74	100	08.97-05.04	■
1.6 (AEH)	01/03-	Gasolina	FWD	1595	74	100	08.97-05.04	■
1.6 (AKL)	01/03-	Gasolina	FWD	1595	74	100	08.97-05.04	■
1.6 (AKL)	01/03-	Gasolina	FWD	1595	74	100	08.97-05.04	■
1.6 (APF)	01/03-	Gasolina	FWD	1595	74	100	08.97-05.04	■
1.6 (APF)	01/03-	Gasolina	FWD	1595	74	100	08.97-05.04	■
1.6 (AVU)	-12/01	Gasolina	FWD	1595	75	102	08.00-06.05	■
1.6 (AVU)	-12/01	Gasolina	FWD	1595	75	102	08.00-06.05	■
1.6 (BFQ)	-12/01	Gasolina	FWD	1595	75	102	08.00-06.05	■
1.6 (BFQ)	-12/01	Gasolina	FWD	1595	75	102	08.00-06.05	■
1.6		Gasolina	FWD	1595	78	107	08.03-06.05	■
1.6		Gasolina	FWD	1595	78	107	08.03-06.05	■
1.6 (BAH)		Gasolina	FWD	1598	74	101	02.01-03.07	■
1.6 (BAH)		Gasolina	FWD	1598	74	101	02.01-03.07	■
1.6 16V (ATN)	01/03-	Gasolina	FWD	1598	77	105	02.00-06.05	■
1.6 16V (ATN)	01/03-	Gasolina	FWD	1598	77	105	02.00-06.05	■
1.6 16V (AUS)	01/03-	Gasolina	FWD	1598	77	105	02.00-06.05	■
1.6 16V (AUS)	01/03-	Gasolina	FWD	1598	77	105	02.00-06.05	■
1.6 16V (AZD)	01/03-	Gasolina	FWD	1598	77	105	02.00-06.05	■
1.6 16V (AZD)	01/03-	Gasolina	FWD	1598	77	105	02.00-06.05	■
1.6 16V (BCB)	01/03-	Gasolina	FWD	1598	77	105	02.00-06.05	■
1.6 16V (BCB)	01/03-	Gasolina	FWD	1598	77	105	02.00-06.05	■
1.8	01/99-	Gasolina	FWD	1781	77	105	04.98-05.02	■
1.8	01/99-	Gasolina	FWD	1781	77	105	04.98-05.02	■
1.8 4motion (AGN)	01/99-	Gasolina	4WD	1781	92	125	05.98-06.05	■
1.8 4motion (AGN)	01/99-	Gasolina	4WD	1781	92	125	05.98-06.05	■
2.0 (AEG)	01/03-	Gasolina	FWD	1984	85	115	07.98-05.04	■
2.0 (AEG)	01/03-	Gasolina	FWD	1984	85	115	07.98-05.04	■
2.0 (APK)	01/03-	Gasolina	FWD	1984	85	115	07.98-05.04	■
2.0 (APK)	01/03-	Gasolina	FWD	1984	85	115	07.98-05.04	■
2.0 (AQY)	01/03-	Gasolina	FWD	1984	85	115	07.98-05.04	■
2.0 (AQY)	01/03-	Gasolina	FWD	1984	85	115	07.98-05.04	■
2.0 (AVH)	01/03-	Gasolina	FWD	1984	85	115	07.98-05.04	■
2.0 (AVH)	01/03-	Gasolina	FWD	1984	85	115	07.98-05.04	■
2.0 (AZG)	01/03-	Gasolina	FWD	1984	85	115	07.98-05.04	■
2.0 (AZG)	01/03-	Gasolina	FWD	1984	85	115	07.98-05.04	■
2.0 (AZJ)	01/03-	Gasolina	FWD	1984	85	115	07.98-05.04	■
2.0 (AZJ)	01/03-	Gasolina	FWD	1984	85	115	07.98-05.04	■
2.0 (BER)	01/03-	Gasolina	FWD	1984	85	115	07.98-05.04	■
2.0 (BER)	01/03-	Gasolina	FWD	1984	85	115	07.98-05.04	■
2.0 (BEV)	01/03-	Gasolina	FWD	1984	85	115	07.98-05.04	■
2.0 (BEV)	01/03-	Gasolina	FWD	1984	85	115	07.98-05.04	■
2.0 4motion (AZH)	-12/03	Gasolina	4WD	1984	85	115	10.00-06.05	■
2.0 4motion (AZH)	-12/03	Gasolina	4WD	1984	85	115	10.00-06.05	■
2.0 4motion (AZJ)	-12/03	Gasolina	4WD	1984	85	115	10.00-06.05	■

# LISTA DE APLICACIONES - BUYERS GUIDE

2.0 4motion (AZJ)	-12/03	Gasolina	4WD	1984	85	115	10.00-06.05	■	
1.9 SDI (AGP)	01/99-	Diesel	FWD	1896	50	68	08.97-06.05	■	
1.9 SDI (AGP)	01/99-	Diesel	FWD	1896	50	68	08.97-06.05	■	
1.9 SDI (AQM)	01/99-	Diesel	FWD	1896	50	68	08.97-06.05	■	
1.9 SDI (AQM)	01/99-	Diesel	FWD	1896	50	68	08.97-06.05	■	
1.9 TDI (AGR)	01/99-	Diesel	FWD	1896	66	90	10.97-05.04	■	
1.9 TDI (AGR)	01/99-	Diesel	FWD	1896	66	90	10.97-05.04	■	
1.9 TDI (ALH)	01/99-	Diesel	FWD	1896	66	90	10.97-05.04	■	
1.9 TDI (ALH)	01/99-	Diesel	FWD	1896	66	90	10.97-05.04	■	
1.9 TDI 4motion (AGR)		Diesel	4WD	1896	66	90	07.98-04.02	■	
1.9 TDI 4motion (AGR)		Diesel	4WD	1896	66	90	07.98-04.02	■	
1.9 TDI (ATD)	01/03-	Diesel	FWD	1896	74	101	09.00-06.05	■	
1.9 TDI (ATD)	01/03-	Diesel	FWD	1896	74	101	09.00-06.05	■	
1.9 TDI (AXR)	01/03-	Diesel	FWD	1896	74	101	09.00-06.05	■	
1.9 TDI (AXR)	01/03-	Diesel	FWD	1896	74	101	09.00-06.05	■	
1.9 TDI (BEW)	01/03-	Diesel	FWD	1896	74	101	09.00-06.05	■	
1.9 TDI (BEW)	01/03-	Diesel	FWD	1896	74	101	09.00-06.05	■	
1.9 TDI 4motion (ATD)	01/01-	Diesel	4WD	1896	74	101	09.00-06.05	■	
1.9 TDI 4motion (ATD)	01/01-	Diesel	4WD	1896	74	101	09.00-06.05	■	
1.9 TDI (AHF)	01/99-	Diesel	FWD	1896	81	110	08.97-05.04	■	
1.9 TDI (AHF)	01/99-	Diesel	FWD	1896	81	110	08.97-05.04	■	
1.9 TDI (ASV)	01/99-	Diesel	FWD	1896	81	110	08.97-05.04	■	
1.9 TDI (ASV)	01/99-	Diesel	FWD	1896	81	110	08.97-05.04	■	
1.9 TDI (AJM)		Diesel	FWD	1896	85	115	12.98-06.01	■	
1.9 TDI (AJM)		Diesel	FWD	1896	85	115	12.98-06.01	■	
1.9 TDI (AUY)		Diesel	FWD	1896	85	115	12.98-06.01	■	
1.9 TDI (AUY)		Diesel	FWD	1896	85	115	12.98-06.01	■	
1.9 TDI 4motion (AJM)		Diesel	4WD	1896	85	115	09.99-06.01	■	
1.9 TDI 4motion (AJM)		Diesel	4WD	1896	85	115	09.99-06.01	■	
1.9 TDI 4motion (AUY)		Diesel	4WD	1896	85	115	09.99-06.01	■	
1.9 TDI 4motion (AUY)		Diesel	4WD	1896	85	115	09.99-06.01	■	
<b>GOLF IV VAN Variant / JETTA IV (1J5) 05.99-06.06</b>							<b>Estate Van (Compact car-C Segment)</b>		
1.4 (AXP)	-12/03	Gasolina	FWD	1390	55	75	05.00-06.06	■	
1.4 (AXP)	-12/03	Gasolina	FWD	1390	55	75	05.00-06.06	■	
1.4 (BCA)	-12/03	Gasolina	FWD	1390	55	75	05.00-06.06	■	
1.4 (BCA)	-12/03	Gasolina	FWD	1390	55	75	05.00-06.06	■	
1.6 (AUS)	-12/03	Gasolina	FWD	1598	77	105	05.00-06.06	■	
1.6 (AUS)	-12/03	Gasolina	FWD	1598	77	105	05.00-06.06	■	
1.6 (AZD)	-12/03	Gasolina	FWD	1598	77	105	05.00-06.06	■	
1.6 (AZD)	-12/03	Gasolina	FWD	1598	77	105	05.00-06.06	■	
1.6 (BCB)	-12/03	Gasolina	FWD	1598	77	105	05.00-06.06	■	
1.6 (BCB)	-12/03	Gasolina	FWD	1598	77	105	05.00-06.06	■	
1.9 SDI (AQM)	-12/03	Diesel	FWD	1896	50	68	05.99-05.06	■	
1.9 SDI (AQM)	-12/03	Diesel	FWD	1896	50	68	05.99-05.06	■	
1.9 TDI (AGR)	-12/03	Diesel	FWD	1896	66	90	05.99-05.06	■	
1.9 TDI (AGR)	-12/03	Diesel	FWD	1896	66	90	05.99-05.06	■	
1.9 TDI (ALH)	-12/03	Diesel	FWD	1896	66	90	05.99-05.06	■	
1.9 TDI (ALH)	-12/03	Diesel	FWD	1896	66	90	05.99-05.06	■	
1.9 TDI (ATD)	-12/03	Diesel	FWD	1896	74	101	02.00-06.06	■	
1.9 TDI (ATD)	-12/03	Diesel	FWD	1896	74	101	02.00-06.06	■	
1.9 TDI (AXR)	-12/03	Diesel	FWD	1896	74	101	02.00-06.06	■	

# LISTA DE APLICACIONES - BUYERS GUIDE

1.9 TDI (AXR)	-12/03	Diesel	FWD	1896	74	101	02.00-06.06	■	
1.9 TDI (AHF)	-12/03	Diesel	FWD	1896	81	110	05.99-05.06	■	
1.9 TDI (AHF)	-12/03	Diesel	FWD	1896	81	110	05.99-05.06	■	
1.9 TDI (ASV)	-12/03	Diesel	FWD	1896	81	110	05.99-05.06	■	
1.9 TDI (ASV)	-12/03	Diesel	FWD	1896	81	110	05.99-05.06	■	
1.9 TDI (AJM)		Diesel	FWD	1896	85	116	05.99-04.02	■	
1.9 TDI (AJM)		Diesel	FWD	1896	85	116	05.99-04.02	■	
<b>GOLF IV Variant / JETTA IV (1J5) 05.99-06.06</b>					<b>Estate (Compact car-C Segment)</b>				
1.4 16V (AHW)	-12/03	Gasolina	FWD	1390	55	75	05.99-06.06	■	
1.4 16V (AHW)	-12/03	Gasolina	FWD	1390	55	75	05.99-06.06	■	
1.4 16V (AKQ)	-12/03	Gasolina	FWD	1390	55	75	05.99-06.06	■	
1.4 16V (AKQ)	-12/03	Gasolina	FWD	1390	55	75	05.99-06.06	■	
1.4 16V (APE)	-12/03	Gasolina	FWD	1390	55	75	05.99-06.06	■	
1.4 16V (APE)	-12/03	Gasolina	FWD	1390	55	75	05.99-06.06	■	
1.4 16V (AXP)	-12/03	Gasolina	FWD	1390	55	75	05.99-06.06	■	
1.4 16V (AXP)	-12/03	Gasolina	FWD	1390	55	75	05.99-06.06	■	
1.4 16V (BCA)	-12/03	Gasolina	FWD	1390	55	75	05.99-06.06	■	
1.4 16V (BCA)	-12/03	Gasolina	FWD	1390	55	75	05.99-06.06	■	
1.6 (AEH)		Gasolina	FWD	1595	74	101	05.99-04.02	■	
1.6 (AEH)		Gasolina	FWD	1595	74	101	05.99-04.02	■	
1.6 (AKL)		Gasolina	FWD	1595	74	101	05.99-04.02	■	
1.6 (AKL)		Gasolina	FWD	1595	74	101	05.99-04.02	■	
1.6 (APF)		Gasolina	FWD	1595	74	101	05.99-04.02	■	
1.6 (APF)		Gasolina	FWD	1595	74	101	05.99-04.02	■	
1.6 (AVU)	-12/01	Gasolina	FWD	1595	75	102	08.00-06.06	■	
1.6 (AVU)	-12/01	Gasolina	FWD	1595	75	102	08.00-06.06	■	
1.6 (BFQ)	-12/01	Gasolina	FWD	1595	75	102	08.00-06.06	■	
1.6 (BFQ)	-12/01	Gasolina	FWD	1595	75	102	08.00-06.06	■	
1.6 16V (ATN)	-12/03	Gasolina	FWD	1598	77	105	02.00-06.06	■	
1.6 16V (ATN)	-12/03	Gasolina	FWD	1598	77	105	02.00-06.06	■	
1.6 16V (AUS)	-12/03	Gasolina	FWD	1598	77	105	02.00-06.06	■	
1.6 16V (AUS)	-12/03	Gasolina	FWD	1598	77	105	02.00-06.06	■	
1.6 16V (AZD)	-12/03	Gasolina	FWD	1598	77	105	02.00-06.06	■	
1.6 16V (AZD)	-12/03	Gasolina	FWD	1598	77	105	02.00-06.06	■	
1.6 16V (BCB)	-12/03	Gasolina	FWD	1598	77	105	02.00-06.06	■	
1.6 16V (BCB)	-12/03	Gasolina	FWD	1598	77	105	02.00-06.06	■	
1.6 FSI (BAD)	-12/03	Gasolina	FWD	1598	81	110	01.02-06.06	■	
1.6 FSI (BAD)	-12/03	Gasolina	FWD	1598	81	110	01.02-06.06	■	
1.8 4motion (AGN)	-12/01	Gasolina	4WD	1781	92	125	05.99-06.06	■	
1.8 4motion (AGN)	-12/01	Gasolina	4WD	1781	92	125	05.99-06.06	■	
2.0 (APK)	01/03-	Gasolina	FWD	1984	85	115	05.99-06.06	■	
2.0 (APK)	01/03-	Gasolina	FWD	1984	85	115	05.99-06.06	■	
2.0 (AQY)	01/03-	Gasolina	FWD	1984	85	115	05.99-06.06	■	
2.0 (AQY)	01/03-	Gasolina	FWD	1984	85	115	05.99-06.06	■	
2.0 (AZJ)	01/03-	Gasolina	FWD	1984	85	115	05.99-06.06	■	
2.0 (AZJ)	01/03-	Gasolina	FWD	1984	85	115	05.99-06.06	■	
2.0 4motion (AZH)	-12/03	Gasolina	4WD	1984	85	115	10.00-06.06	■	
2.0 4motion (AZH)	-12/03	Gasolina	4WD	1984	85	115	10.00-06.06	■	
2.0 4motion (AZJ)	-12/03	Gasolina	4WD	1984	85	115	10.00-06.06	■	
2.0 4motion (AZJ)	-12/03	Gasolina	4WD	1984	85	115	10.00-06.06	■	
2.0 4motion (ATF)		Gasolina	4WD	1984	88	120	12.99-06.06	■	

# LISTA DE APLICACIONES - BUYERS GUIDE

2.0 4motion (ATF)		Gasolina	4WD	1984	88	120	12.99-06.06	■	
2.0 Bi-Fuel (BEH)	-12/03	Gasol./Gas (CNG)	FWD	1984	85	116	02.02-06.06	■	
2.0 Bi-Fuel (BEH)	-12/03	Gasol./Gas (CNG)	FWD	1984	85	116	02.02-06.06	■	
1.9 SDI (AGP)	-12/03	Diesel	FWD	1896	50	68	05.99-06.06	■	
1.9 SDI (AGP)	-12/03	Diesel	FWD	1896	50	68	05.99-06.06	■	
1.9 SDI (AQM)	-12/03	Diesel	FWD	1896	50	68	05.99-06.06	■	
1.9 SDI (AQM)	-12/03	Diesel	FWD	1896	50	68	05.99-06.06	■	
1.9 TDI (AGR)	-12/03	Diesel	FWD	1896	66	90	05.99-05.06	■	
1.9 TDI (AGR)	-12/03	Diesel	FWD	1896	66	90	05.99-05.06	■	
1.9 TDI (ALH)	-12/03	Diesel	FWD	1896	66	90	05.99-05.06	■	
1.9 TDI (ALH)	-12/03	Diesel	FWD	1896	66	90	05.99-05.06	■	
1.9 TDI 4motion (AGR)		Diesel	4WD	1896	66	90	05.99-04.02	■	
1.9 TDI 4motion (AGR)		Diesel	4WD	1896	66	90	05.99-04.02	■	
1.9 TDI (ATD)	-12/03	Diesel	FWD	1896	74	101	09.00-06.06	■	
1.9 TDI (ATD)	-12/03	Diesel	FWD	1896	74	101	09.00-06.06	■	
1.9 TDI (AXR)	-12/03	Diesel	FWD	1896	74	101	09.00-06.06	■	
1.9 TDI (AXR)	-12/03	Diesel	FWD	1896	74	101	09.00-06.06	■	
1.9 TDI 4motion (ATD)	01/01-	Diesel	4WD	1896	74	101	09.00-06.06	■	
1.9 TDI 4motion (ATD)	01/01-	Diesel	4WD	1896	74	101	09.00-06.06	■	
1.9 TDI (AHF)		Diesel	FWD	1896	81	110	05.99-06.01	■	
1.9 TDI (AHF)		Diesel	FWD	1896	81	110	05.99-06.01	■	
1.9 TDI (ASV)		Diesel	FWD	1896	81	110	05.99-06.01	■	
1.9 TDI (ASV)		Diesel	FWD	1896	81	110	05.99-06.01	■	
1.9 TDI (AJM)		Diesel	FWD	1896	85	115	08.99-06.01	■	
1.9 TDI (AJM)		Diesel	FWD	1896	85	115	08.99-06.01	■	
1.9 TDI (AUY)		Diesel	FWD	1896	85	115	08.99-06.01	■	
1.9 TDI (AUY)		Diesel	FWD	1896	85	115	08.99-06.01	■	
1.9 TDI 4motion (AJM)		Diesel	4WD	1896	85	115	12.99-04.01	■	
1.9 TDI 4motion (AJM)		Diesel	4WD	1896	85	115	12.99-04.01	■	
<b>GOLF V Variant / BORA V / JETTA V / VENTO V (1K5) 01.07-07.09</b>					<b>Estate (Compact car-C Segment)</b>				
1.6 (BSE)		Gasolina	FWD	1595	75	102	06.07-07.09	■	
1.6 (BSE)		Gasolina	FWD	1595	75	102	06.07-07.09	■	
1.6 (BSF)		Gasolina	FWD	1595	75	102	06.07-07.09	■	
1.6 (BSF)		Gasolina	FWD	1595	75	102	06.07-07.09	■	
1.6 (CCSA)		Gasolina	FWD	1595	75	102	06.07-07.09	■	
1.6 (CCSA)		Gasolina	FWD	1595	75	102	06.07-07.09	■	
1.9 TDI (BLS)		Diesel	FWD	1896	77	105	06.07-07.09	■	
1.9 TDI (BLS)		Diesel	FWD	1896	77	105	06.07-07.09	■	
1.9 TDI (BXE)		Diesel	FWD	1896	77	105	06.07-07.09	■	
1.9 TDI (BXE)		Diesel	FWD	1896	77	105	06.07-07.09	■	
1.9 TDI 4motion (BLS)		Diesel	4WD	1896	77	105	01.08-07.09	■	
1.9 TDI 4motion (BLS)		Diesel	4WD	1896	77	105	01.08-07.09	■	
<b>JETTA V / BORA / VENTO (1K2) 09.04-12.13</b>					<b>Saloon (Compact car-C Segment)</b>				
1.6 (BGU)		Gasolina	FWD	1595	75	102	09.04-10.10	■	
1.6 (BGU)		Gasolina	FWD	1595	75	102	09.04-10.10	■	
1.6 (BSE)		Gasolina	FWD	1595	75	102	09.04-10.10	■	
1.6 (BSE)		Gasolina	FWD	1595	75	102	09.04-10.10	■	
1.6 (BSF)		Gasolina	FWD	1595	75	102	09.04-10.10	■	
1.6 (BSF)		Gasolina	FWD	1595	75	102	09.04-10.10	■	

# LISTA DE APLICACIONES - BUYERS GUIDE

1.6 (CCSA)		Gasolina	FWD	1595	75	102	09.04-10.10	■
1.6 (CCSA)		Gasolina	FWD	1595	75	102	09.04-10.10	■
1.6 FSI (BLF)		Gasolina	FWD	1598	85	115	09.05-10.10	■
1.6 FSI (BLF)		Gasolina	FWD	1598	85	115	09.05-10.10	■
1.9 TDI (BKC)		Diesel	FWD	1896	77	105	08.05-10.10	■
1.9 TDI (BKC)		Diesel	FWD	1896	77	105	08.05-10.10	■
1.9 TDI (BLS)		Diesel	FWD	1896	77	105	08.05-10.10	■
1.9 TDI (BLS)		Diesel	FWD	1896	77	105	08.05-10.10	■
1.9 TDI (BXE)		Diesel	FWD	1896	77	105	08.05-10.10	■
1.9 TDI (BXE)		Diesel	FWD	1896	77	105	08.05-10.10	■
							<b>Convertible (Compact car-C Segment)</b>	
<b>NEW BEETLE / BETTLE (1Y7) 09.02-07.12</b>								
1.4 (BCA)		Gasolina	FWD	1390	55	75	01.03-09.10	■
1.4 (BCA)		Gasolina	FWD	1390	55	75	01.03-09.10	■
1.6 (BFS)		Gasolina	FWD	1595	75	102	01.03-09.10	■
1.6 (BFS)		Gasolina	FWD	1595	75	102	01.03-09.10	■
1.8 T (AWU)		Gasolina	FWD	1781	110	150	01.03-09.10	■
1.8 T (AWU)		Gasolina	FWD	1781	110	150	01.03-09.10	■
1.8 T (AWV)		Gasolina	FWD	1781	110	150	01.03-09.10	■
1.8 T (AWV)		Gasolina	FWD	1781	110	150	01.03-09.10	■
1.8 T (BKF)		Gasolina	FWD	1781	110	150	01.03-09.10	■
1.8 T (BKF)		Gasolina	FWD	1781	110	150	01.03-09.10	■
2.0 (AZJ)		Gasolina	FWD	1984	85	115	09.02-10.10	■
2.0 (AZJ)		Gasolina	FWD	1984	85	115	09.02-10.10	■
2.0 (BDC)		Gasolina	FWD	1984	85	115	09.02-10.10	■
2.0 (BDC)		Gasolina	FWD	1984	85	115	09.02-10.10	■
2.0 (BEV)		Gasolina	FWD	1984	85	115	09.02-10.10	■
2.0 (BEV)		Gasolina	FWD	1984	85	115	09.02-10.10	■
2.0 (BGD)		Gasolina	FWD	1984	85	115	09.02-10.10	■
2.0 (BGD)		Gasolina	FWD	1984	85	115	09.02-10.10	■
1.9 TDI (BSW)		Diesel	FWD	1896	77	105	07.05-09.10	■
1.9 TDI (BSW)		Diesel	FWD	1896	77	105	07.05-09.10	■
							<b>Hatchback (Compact car-C Segment)</b>	
<b>NEW BEETLE / BETTLE / NOVO FUSCA (9C1, 1C1) 01.98-12.13</b>								
1.4 (BCA)		Gasolina	FWD	1390	55	75	11.01-09.10	■
1.4 (BCA)		Gasolina	FWD	1390	55	75	11.01-09.10	■
1.6 (AWH)		Gasolina	FWD	1595	74	100	10.99-09.00	■
1.6 (AWH)		Gasolina	FWD	1595	74	100	10.99-09.00	■
1.6 (AYD)		Gasolina	FWD	1595	75	102	06.00-09.10	■
1.6 (AYD)		Gasolina	FWD	1595	75	102	06.00-09.10	■
1.6 (BFS)		Gasolina	FWD	1595	75	102	06.00-09.10	■
1.6 (BFS)		Gasolina	FWD	1595	75	102	06.00-09.10	■
1.8 T (AGU)		Gasolina	FWD	1781	110	150	10.99-09.10	■
1.8 T (AGU)		Gasolina	FWD	1781	110	150	10.99-09.10	■
1.8 T (APH)		Gasolina	FWD	1781	110	150	10.99-09.10	■
1.8 T (APH)		Gasolina	FWD	1781	110	150	10.99-09.10	■
1.8 T (AVC)		Gasolina	FWD	1781	110	150	10.99-09.10	■
1.8 T (AVC)		Gasolina	FWD	1781	110	150	10.99-09.10	■
1.8 T (AWU)		Gasolina	FWD	1781	110	150	10.99-09.10	■
1.8 T (AWU)		Gasolina	FWD	1781	110	150	10.99-09.10	■
1.8 T (AWV)		Gasolina	FWD	1781	110	150	10.99-09.10	■
1.8 T (AWV)		Gasolina	FWD	1781	110	150	10.99-09.10	■

## LISTA DE APLICACIONES - BUYERS GUIDE

1.8 T (BKF)		Gasolina	FWD	1781	110	150	10.99-09.10	■
1.8 T (BKF)		Gasolina	FWD	1781	110	150	10.99-09.10	■
2.0 (AEG)	01/99-	Gasolina	FWD	1984	85	115	01.98-09.10	■
2.0 (AEG)	01/99-	Gasolina	FWD	1984	85	115	01.98-09.10	■
2.0 (APK)	01/99-	Gasolina	FWD	1984	85	115	01.98-09.10	■
2.0 (APK)	01/99-	Gasolina	FWD	1984	85	115	01.98-09.10	■
2.0 (AQY)	01/99-	Gasolina	FWD	1984	85	115	01.98-09.10	■
2.0 (AQY)	01/99-	Gasolina	FWD	1984	85	115	01.98-09.10	■
2.0 (AVH)	01/99-	Gasolina	FWD	1984	85	115	01.98-09.10	■
2.0 (AVH)	01/99-	Gasolina	FWD	1984	85	115	01.98-09.10	■
2.0 (AZG)	01/99-	Gasolina	FWD	1984	85	115	01.98-09.10	■
2.0 (AZG)	01/99-	Gasolina	FWD	1984	85	115	01.98-09.10	■
2.0 (AZJ)	01/99-	Gasolina	FWD	1984	85	115	01.98-09.10	■
2.0 (AZJ)	01/99-	Gasolina	FWD	1984	85	115	01.98-09.10	■
2.0 (BER)	01/99-	Gasolina	FWD	1984	85	115	01.98-09.10	■
2.0 (BER)	01/99-	Gasolina	FWD	1984	85	115	01.98-09.10	■
2.0 (BEV)	01/99-	Gasolina	FWD	1984	85	115	01.98-09.10	■
2.0 (BEV)	01/99-	Gasolina	FWD	1984	85	115	01.98-09.10	■
1.9 TDI (ALH)	01/99-	Diesel	FWD	1896	66	90	01.98-06.04	■
1.9 TDI (ALH)	01/99-	Diesel	FWD	1896	66	90	01.98-06.04	■
1.9 TDI (ATD)		Diesel	FWD	1896	74	101	02.01-09.10	■
1.9 TDI (ATD)		Diesel	FWD	1896	74	101	02.01-09.10	■
1.9 TDI (AXR)		Diesel	FWD	1896	74	101	02.01-09.10	■
1.9 TDI (AXR)		Diesel	FWD	1896	74	101	02.01-09.10	■
1.9 TDI (BEW)		Diesel	FWD	1896	74	101	02.01-09.10	■
1.9 TDI (BEW)		Diesel	FWD	1896	74	101	02.01-09.10	■
1.9 TDI (BSW)		Diesel	FWD	1896	77	105	07.05-09.10	■
1.9 TDI (BSW)		Diesel	FWD	1896	77	105	07.05-09.10	■