

1

LISTA DE APLICACIONES - BUYERS GUIDE

1.8 16V (BG0B, BG0M) (F4P 770)	Gasolina	FWD	1783	88	120	03.01-09.07
1.8 16V (BG0B, BG0M) (F4P 773)	Gasolina	FWD	1783	88	120	03.01-09.07
1.8 16V (BG0B, BG0M) (F4P 773)	Gasolina	FWD	1783	88	120	03.01-09.07
1.8 16V (BG0B, BG0C, BG0J, BG0M, BG0V) (F4P 770)	Gasolina	FWD	1783	89	121	03.01-05.05
1.8 16V (BG0B, BG0C, BG0J, BG0M, BG0V) (F4P 770)	Gasolina	FWD	1783	89	121	03.01-05.05
1.8 16V (BG0B, BG0C, BG0J, BG0M, BG0V) (F4P 772)	Gasolina	FWD	1783	89	121	03.01-05.05
1.8 16V (BG0B, BG0C, BG0J, BG0M, BG0V) (F4P 772)	Gasolina	FWD	1783	89	121	03.01-05.05
2.0 16V (BG00, BG0W, BG0K, BG0P) (F4R 712)	Gasolina	FWD	1998	98	133	08.02-12.06
2.0 16V (BG00, BG0W, BG0K, BG0P) (F4R 712)	Gasolina	FWD	1998	98	133	08.02-12.06
2.0 16V (BG00, BG0W, BG0K, BG0P) (F4R 713)	Gasolina	FWD	1998	98	133	08.02-12.06
2.0 16V (BG00, BG0W, BG0K, BG0P) (F4R 713)	Gasolina	FWD	1998	98	133	08.02-12.06
2.0 16V (BG00, BG0W, BG0K, BG0P) (F4R 714)	Gasolina	FWD	1998	98	133	08.02-12.06
2.0 16V (BG00, BG0W, BG0K, BG0P) (F4R 714)	Gasolina	FWD	1998	98	133	08.02-12.06
2.0 16V (BG00, BG0W, BG0K, BG0P) (F4R 715)	Gasolina	FWD	1998	98	133	08.02-12.06
2.0 16V (BG00, BG0W, BG0K, BG0P) (F4R 715)	Gasolina	FWD	1998	98	133	08.02-12.06
2.0 16V (BG00, BG0K, BG0P, BG0W) (F4R 712)	Gasolina	FWD	1998	99	135	08.02-12.07
2.0 16V (BG00, BG0K, BG0P, BG0W) (F4R 712)	Gasolina	FWD	1998	99	135	08.02-12.07
2.0 16V (BG00, BG0K, BG0P, BG0W) (F4R 713)	Gasolina	FWD	1998	99	135	08.02-12.07
2.0 16V (BG00, BG0K, BG0P, BG0W) (F4R 713)	Gasolina	FWD	1998	99	135	08.02-12.07
2.0 16V (BG00, BG0K, BG0P, BG0W) (F4R 714)	Gasolina	FWD	1998	99	135	08.02-12.07
2.0 16V (BG00, BG0K, BG0P, BG0W) (F4R 714)	Gasolina	FWD	1998	99	135	08.02-12.07
2.0 16V (BG00, BG0K, BG0P, BG0W) (F4R 715)	Gasolina	FWD	1998	99	135	08.02-12.07
2.0 16V (BG00, BG0K, BG0P, BG0W) (F4R 715)	Gasolina	FWD	1998	99	135	08.02-12.07
2.0 16V IDE (BG0N) (F5R 700)	Gasolina	FWD	1998	103	140	04.01-09.07
2.0 16V IDE (BG0N) (F5R 700)	Gasolina	FWD	1998	103	140	04.01-09.07
2.0 16V IDE (BG0N) (F5R 701)	Gasolina	FWD	1998	103	140	04.01-09.07
2.0 16V IDE (BG0N) (F5R 701)	Gasolina	FWD	1998	103	140	04.01-09.07
2.0 16V Turbo (BG0S, BG1L, BG1M) (F4R 764)	Gasolina	FWD	1998	120	163	01.03-03.05
2.0 16V Turbo (BG0S, BG1L, BG1M) (F4R 764)	Gasolina	FWD	1998	120	163	01.03-03.05
2.0 16V Turbo (BG0S, BG1L, BG1M) (F4R 765)	Gasolina	FWD	1998	120	163	01.03-03.05
2.0 16V Turbo (BG0S, BG1L, BG1M) (F4R 765)	Gasolina	FWD	1998	120	163	01.03-03.05
2.0 16V (BG03, BG0Z, BG0T, BG1Y) (F4R 784)	Gasolina	FWD	1998	125	170	01.05-09.07
2.0 16V (BG03, BG0Z, BG0T, BG1Y) (F4R 784)	Gasolina	FWD	1998	125	170	01.05-09.07
2.0 16V (BG03, BG0Z, BG0T, BG1Y) (F4R 786)	Gasolina	FWD	1998	125	170	01.05-09.07
2.0 16V (BG03, BG0Z, BG0T, BG1Y) (F4R 786)	Gasolina	FWD	1998	125	170	01.05-09.07
2.0 16V (BG03, BG0Z, BG0T, BG1Y) (F4R 787)	Gasolina	FWD	1998	125	170	01.05-09.07
2.0 16V (BG03, BG0Z, BG0T, BG1Y) (F4R 787)	Gasolina	FWD	1998	125	170	01.05-09.07
2.0 16V (BG1Y) (F4R 886)	Gasolina	FWD	1998	150	204	01.05-09.07
2.0 16V (BG1Y) (F4R 886)	Gasolina	FWD	1998	150	204	01.05-09.07
2.0 16V (BG1Y) (F4R 887)	Gasolina	FWD	1998	150	204	01.05-09.07

LISTA DE APLICACIONES - BUYERS GUIDE

2.0 16V (BG1Y) (F4R 887)	Gasolina	FWD	1998	150	204	01.05-09.07
3.0 V6 24V (BG01, BG02, BG0D, BG0Y) (L7X 731)	Gasolina	FWD	2946	152	207	03.01-08.07
3.0 V6 24V (BG01, BG02, BG0D, BG0Y) (L7X 731)	Gasolina	FWD	2946	152	207	03.01-08.07
2.9 V6 24V	Gasolina	FWD	2946	155	211	03.01-08.07
2.9 V6 24V	Gasolina	FWD	2946	155	211	03.01-08.07
2.9 V6 24V	Gasolina	FWD	2946	157	210	09.02-12.05
2.9 V6 24V	Gasolina	FWD	2946	157	210	09.02-12.05
1.9 dCi (BG05) (F9Q 664)	Diesel	FWD	1870	68	92	03.04-05.05
1.9 dCi (BG05) (F9Q 664)	Diesel	FWD	1870	68	92	03.04-05.05
1.9 dCi (BG0R, BG0E) (F9Q 754)	Diesel	FWD	1870	74	100	10.01-05.05
1.9 dCi (BG0R, BG0E) (F9Q 754)	Diesel	FWD	1870	74	100	10.01-05.05
1.9 dCi (BG0E) (F9Q 752)	Diesel	FWD	1870	77	105	06.01-05.05
1.9 dCi (BG0E) (F9Q 752)	Diesel	FWD	1870	77	105	06.01-05.05
1.9 dCi (F9Q 718)	Diesel	FWD	1870	79	107	03.01-09.07
1.9 dCi (F9Q 718)	Diesel	FWD	1870	79	107	03.01-09.07
1.9 dCi (F9Q 754)	Diesel	FWD	1870	79	107	03.01-09.07
1.9 dCi (F9Q 754)	Diesel	FWD	1870	79	107	03.01-09.07
1.9 dCi (BG1A, BG1W, BG0G) (F9Q 674)	Diesel	FWD	1870	81	110	01.05-08.07
1.9 dCi (BG1A, BG1W, BG0G) (F9Q 674)	Diesel	FWD	1870	81	110	01.05-08.07
1.9 dCi (BG1A, BG1W, BG0G) (F9Q 758)	Diesel	FWD	1870	81	110	01.05-08.07
1.9 dCi (BG1A, BG1W, BG0G) (F9Q 758)	Diesel	FWD	1870	81	110	01.05-08.07
1.9 dCi (BG08, BG0G) (F9Q 650)	Diesel	FWD	1870	88	120	03.01-09.07
1.9 dCi (BG08, BG0G) (F9Q 650)	Diesel	FWD	1870	88	120	03.01-09.07
1.9 dCi (BG08, BG0G) (F9Q 670)	Diesel	FWD	1870	88	120	03.01-09.07
1.9 dCi (BG08, BG0G) (F9Q 670)	Diesel	FWD	1870	88	120	03.01-09.07
1.9 dCi (BG08, BG0G) (F9Q 674)	Diesel	FWD	1870	88	120	03.01-09.07
1.9 dCi (BG08, BG0G) (F9Q 674)	Diesel	FWD	1870	88	120	03.01-09.07
1.9 dCi (BG08, BG0G) (F9Q 750)	Diesel	FWD	1870	88	120	03.01-09.07
1.9 dCi (BG08, BG0G) (F9Q 750)	Diesel	FWD	1870	88	120	03.01-09.07
1.9 dCi (BG1A, BG1V) (F9Q 758)	Diesel	FWD	1870	96	130	05.05-08.07
1.9 dCi (BG1A, BG1V) (F9Q 758)	Diesel	FWD	1870	96	130	05.05-08.07
1.9 dCi (BG1A, BG1V) (F9Q 759)	Diesel	FWD	1870	96	130	05.05-08.07
1.9 dCi (BG1A, BG1V) (F9Q 759)	Diesel	FWD	1870	96	130	05.05-08.07
2.0 dCi (BG1T) (M9R 740)	Diesel	FWD	1995	110	150	08.05-08.06
2.0 dCi (BG1T) (M9R 740)	Diesel	FWD	1995	110	150	08.05-08.06
2.0 dCi (BG14, BG1S) (M9R 760)	Diesel	FWD	1995	127	173	01.06-08.07
2.0 dCi (BG14, BG1S) (M9R 760)	Diesel	FWD	1995	127	173	01.06-08.07
2.2 dCi (G9T 600)	Diesel	FWD	2188	102	140	05.05-08.07
2.2 dCi (G9T 600)	Diesel	FWD	2188	102	140	05.05-08.07
2.2 dCi (G9T 605)	Diesel	FWD	2188	102	140	05.05-08.07
2.2 dCi (G9T 605)	Diesel	FWD	2188	102	140	05.05-08.07
2.2 dCi (G9T 706)	Diesel	FWD	2188	102	140	05.05-08.07
2.2 dCi (G9T 706)	Diesel	FWD	2188	102	140	05.05-08.07
2.2 dCi (G9T 707)	Diesel	FWD	2188	102	140	05.05-08.07
2.2 dCi (G9T 707)	Diesel	FWD	2188	102	140	05.05-08.07
2.2 dCi (BG0F) (G9T 700)	Diesel	FWD	2188	110	150	10.01-08.06
2.2 dCi (BG0F) (G9T 700)	Diesel	FWD	2188	110	150	10.01-08.06
2.2 dCi (BG0F) (G9T 702)	Diesel	FWD	2188	110	150	10.01-08.06
2.2 dCi (BG0F) (G9T 702)	Diesel	FWD	2188	110	150	10.01-08.06

LISTA DE APLICACIONES - BUYERS GUIDE

LAGUNA II Grandtour (KG0/1_) 03.01-					Estate (Large family car-D Segment)			
1.6 16V (KG0A, KG0L) (K4M 710)		Gasolina	FWD	1598	79	107	03.01-12.07	■
1.6 16V (KG0A, KG0L) (K4M 710)		Gasolina	FWD	1598	79	107	03.01-12.07	■
1.6 16V (KG0A, KG0L) (K4M 714)		Gasolina	FWD	1598	79	107	03.01-12.07	■
1.6 16V (KG0A, KG0L) (K4M 714)		Gasolina	FWD	1598	79	107	03.01-12.07	■
1.6 16V (K4M 716)		Gasolina	FWD	1598	82	112	02.05-08.07	■
1.6 16V (K4M 716)		Gasolina	FWD	1598	82	112	02.05-08.07	■
1.8 16V (KG0J) (F4P 770)		Gasolina	FWD	1783	85	116	03.01-05.05	■
1.8 16V (KG0J) (F4P 770)		Gasolina	FWD	1783	85	116	03.01-05.05	■
1.8 16V (KG0J) (F4P 771)		Gasolina	FWD	1783	85	116	03.01-05.05	■
1.8 16V (KG0J) (F4P 771)		Gasolina	FWD	1783	85	116	03.01-05.05	■
1.8 16V (KG0J) (F4P 774)		Gasolina	FWD	1783	85	116	03.01-05.05	■
1.8 16V (KG0J) (F4P 774)		Gasolina	FWD	1783	85	116	03.01-05.05	■
1.8 16V (KG0J) (F4P 775)		Gasolina	FWD	1783	85	116	03.01-05.05	■
1.8 16V (KG0J) (F4P 775)		Gasolina	FWD	1783	85	116	03.01-05.05	■
1.8 16V (F4P 770)		Gasolina	FWD	1783	86	117	03.01-05.05	■
1.8 16V (F4P 770)		Gasolina	FWD	1783	86	117	03.01-05.05	■
1.8 16V (F4P 770)		Gasolina	FWD	1783	89	121	03.01-05.05	■
1.8 16V (F4P 770)		Gasolina	FWD	1783	89	121	03.01-05.05	■
1.8 16V (F4P 774)		Gasolina	FWD	1783	89	121	03.01-05.05	■
1.8 16V (F4P 774)		Gasolina	FWD	1783	89	121	03.01-05.05	■
2.0 16V (KG00, KG0K, KG0W, KG0P) (F4R 712)		Gasolina	FWD	1998	99	135	08.02-12.07	■
2.0 16V (KG00, KG0K, KG0W, KG0P) (F4R 712)		Gasolina	FWD	1998	99	135	08.02-12.07	■
2.0 16V (KG00, KG0K, KG0W, KG0P) (F4R 713)		Gasolina	FWD	1998	99	135	08.02-12.07	■
2.0 16V (KG00, KG0K, KG0W, KG0P) (F4R 713)		Gasolina	FWD	1998	99	135	08.02-12.07	■
2.0 16V (KG00, KG0K, KG0W, KG0P) (F4R 714)		Gasolina	FWD	1998	99	135	08.02-12.07	■
2.0 16V (KG00, KG0K, KG0W, KG0P) (F4R 714)		Gasolina	FWD	1998	99	135	08.02-12.07	■
2.0 16V (KG00, KG0K, KG0W, KG0P) (F4R 715)		Gasolina	FWD	1998	99	135	08.02-12.07	■
2.0 16V (KG00, KG0K, KG0W, KG0P) (F4R 715)		Gasolina	FWD	1998	99	135	08.02-12.07	■
2.0 16V IDE (KG0N) (F5R 700)		Gasolina	FWD	1998	103	140	04.01-09.07	■
2.0 16V IDE (KG0N) (F5R 700)		Gasolina	FWD	1998	103	140	04.01-09.07	■
2.0 16V IDE (KG0N) (F5R 701)		Gasolina	FWD	1998	103	140	04.01-09.07	■
2.0 16V IDE (KG0N) (F5R 701)		Gasolina	FWD	1998	103	140	04.01-09.07	■
2.0 16V Turbo (KG0S, KG1L, KG03) (F4R 764)		Gasolina	FWD	1998	120	163	01.03-08.05	■
2.0 16V Turbo (KG0S, KG1L, KG03) (F4R 764)		Gasolina	FWD	1998	120	163	01.03-08.05	■
2.0 16V Turbo (KG0S, KG1L, KG03) (F4R 765)		Gasolina	FWD	1998	120	163	01.03-08.05	■
2.0 16V Turbo (KG0S, KG1L, KG03) (F4R 765)		Gasolina	FWD	1998	120	163	01.03-08.05	■
2.0 16V (KG03, KG0Z, KG0T, KG1Y) (F4R 784)		Gasolina	FWD	1998	125	170	01.05-09.07	■
2.0 16V (KG03, KG0Z, KG0T, KG1Y) (F4R 784)		Gasolina	FWD	1998	125	170	01.05-09.07	■
2.0 16V (KG03, KG0Z, KG0T, KG1Y) (F4R 786)		Gasolina	FWD	1998	125	170	01.05-09.07	■
2.0 16V (KG03, KG0Z, KG0T, KG1Y) (F4R 786)		Gasolina	FWD	1998	125	170	01.05-09.07	■
2.0 16V (KG03, KG0Z, KG0T, KG1Y) (F4R 787)		Gasolina	FWD	1998	125	170	01.05-09.07	■
2.0 16V (KG03, KG0Z, KG0T, KG1Y) (F4R 787)		Gasolina	FWD	1998	125	170	01.05-09.07	■
2.0 16V (KG1Y) (F4R 886)		Gasolina	FWD	1998	150	204	01.05-09.07	■
2.0 16V (KG1Y) (F4R 886)		Gasolina	FWD	1998	150	204	01.05-09.07	■

LISTA DE APLICACIONES - BUYERS GUIDE

2.0 16V (KG1Y) (F4R 887)	Gasolina	FWD	1998	150	204	01.05-09.07
2.0 16V (KG1Y) (F4R 887)	Gasolina	FWD	1998	150	204	01.05-09.07
2.9 V6 24V	Gasolina	FWD	2946	157	210	09.02-12.05
2.9 V6 24V	Gasolina	FWD	2946	157	210	09.02-12.05
1.9 dCi (KG05) (F9Q 664)	Diesel	FWD	1870	68	92	03.04-05.05
1.9 dCi (KG05) (F9Q 664)	Diesel	FWD	1870	68	92	03.04-05.05
1.9 dCi (KG0E, KG0R) (F9Q 752)	Diesel	FWD	1870	74	100	10.01-05.05
1.9 dCi (KG0E, KG0R) (F9Q 752)	Diesel	FWD	1870	74	100	10.01-05.05
1.9 dCi (KG0E) (F9Q 752)	Diesel	FWD	1870	77	105	06.01-05.05
1.9 dCi (KG0E) (F9Q 752)	Diesel	FWD	1870	77	105	06.01-05.05
1.9 dCi (F9Q 754)	Diesel	FWD	1870	79	107	03.01-12.07
1.9 dCi (F9Q 754)	Diesel	FWD	1870	79	107	03.01-12.07
1.9 dCi (KG1A, KG1W, KG0G) (F9Q 674)	Diesel	FWD	1870	81	110	01.05-12.07
1.9 dCi (KG1A, KG1W, KG0G) (F9Q 674)	Diesel	FWD	1870	81	110	01.05-12.07
1.9 dCi (KG1A, KG1W, KG0G) (F9Q 758)	Diesel	FWD	1870	81	110	01.05-12.07
1.9 dCi (KG1A, KG1W, KG0G) (F9Q 758)	Diesel	FWD	1870	81	110	01.05-12.07
1.9 dCi (KG0G) (F9Q 670)	Diesel	FWD	1870	88	120	03.01-09.07
1.9 dCi (KG0G) (F9Q 670)	Diesel	FWD	1870	88	120	03.01-09.07
1.9 dCi (KG0G) (F9Q 674)	Diesel	FWD	1870	88	120	03.01-09.07
1.9 dCi (KG0G) (F9Q 674)	Diesel	FWD	1870	88	120	03.01-09.07
1.9 dCi (KG0G) (F9Q 750)	Diesel	FWD	1870	88	120	03.01-09.07
1.9 dCi (KG0G) (F9Q 750)	Diesel	FWD	1870	88	120	03.01-09.07
1.9 dCi (KG1V) (F9Q 758)	Diesel	FWD	1870	96	130	05.05-12.07
1.9 dCi (KG1V) (F9Q 758)	Diesel	FWD	1870	96	130	05.05-12.07
1.9 dCi (KG1V) (F9Q 759)	Diesel	FWD	1870	96	130	05.05-12.07
1.9 dCi (KG1V) (F9Q 759)	Diesel	FWD	1870	96	130	05.05-12.07
2.0 dCi (KG1T) (M9R 740)	Diesel	FWD	1995	110	150	08.05-08.06
2.0 dCi (KG1T) (M9R 740)	Diesel	FWD	1995	110	150	08.05-08.06
2.0 dCi (KG1S) (M9R 760)	Diesel	FWD	1995	127	173	01.06-12.07
2.0 dCi (KG1S) (M9R 760)	Diesel	FWD	1995	127	173	01.06-12.07
2.2 dCi (KG09) (G9T 600)	Diesel	FWD	2188	85	116	04.04-10.05
2.2 dCi (KG09) (G9T 600)	Diesel	FWD	2188	85	116	04.04-10.05
2.2 dCi (KG0F, KG1N) (G9T 600)	Diesel	FWD	2188	102	140	05.05-12.07
2.2 dCi (KG0F, KG1N) (G9T 600)	Diesel	FWD	2188	102	140	05.05-12.07
2.2 dCi (KG0F, KG1N) (G9T 706)	Diesel	FWD	2188	102	140	05.05-12.07
2.2 dCi (KG0F, KG1N) (G9T 706)	Diesel	FWD	2188	102	140	05.05-12.07
2.2 dCi (KG0F, KG1N) (G9T 707)	Diesel	FWD	2188	102	140	05.05-12.07
2.2 dCi (KG0F, KG1N) (G9T 707)	Diesel	FWD	2188	102	140	05.05-12.07
2.2 dCi (KG0F) (G9T 702)	Diesel	FWD	2188	110	150	10.01-08.06
2.2 dCi (KG0F) (G9T 702)	Diesel	FWD	2188	110	150	10.01-08.06