


LISTA DE APLICACIONES - BUYERS GUIDE

31523-4681



8 424073 104359

Weight: 17.211



31523-4681



Brembo

140.6x65.9x19

Ø280x24x65.5

WVA

23917

MAKE

CITROËN

FIAT

PEUGEOT



Trac.

CC

Kw

CV



Front / Rear

CITROËN

JUMPER II / RELAY (244) 02.02-

Platform/Chassis (LCVs-N1 Segment)

2.2 HDi (4HY (DW12UTED))	Diesel	FWD	2179	74	101	02.02-06.06	■
2.2 HDi (4HY (DW12UTED))	Diesel	FWD	2179	74	101	02.02-06.06	■

FIAT

DUCATO II (244_) 12.01-

Bus (Minibus-M2-Segment)

2.0 (RFL)	Gasolina	FWD	1998	81	110	12.01-07.06	■
2.0 (RFL)	Gasolina	FWD	1998	81	110	12.01-07.06	■
2.0 4x4 (RFL)	Gasolina	4WD	1998	81	110	05.02-07.06	■
2.0 4x4 (RFL)	Gasolina	4WD	1998	81	110	05.02-07.06	■
2.0 JTD (RHV)	Diesel	FWD	1997	62	84	12.01-07.06	■
2.0 JTD (RHV)	Diesel	FWD	1997	62	84	12.01-07.06	■
2.3 JTD (F1AE0481C)	Diesel	FWD	2286	81	110	12.01-07.06	■
2.3 JTD (F1AE0481C)	Diesel	FWD	2286	81	110	12.01-07.06	■
2.8 JTD (8140.43S)	-12/07	Diesel	FWD	2798	94	12.01-	■
2.8 JTD (8140.43S)	-12/07	Diesel	FWD	2798	94	12.01-	■
2.8 JTD 4x4 (8140.43S)		Diesel	4WD	2798	94	12.01-07.06	■
2.8 JTD 4x4 (8140.43S)		Diesel	4WD	2798	94	12.01-07.06	■
2.8 TD (8140.43)		Diesel	FWD	2799	90	11.03-07.06	■
2.8 TD (8140.43)		Diesel	FWD	2799	90	11.03-07.06	■
2.8 TD 4x4 (8140.43)		Diesel	4WD	2799	90	11.03-07.06	■
2.8 TD 4x4 (8140.43)		Diesel	4WD	2799	90	11.03-07.06	■
2.8 JTD (8140.43N)		Diesel	FWD	2800	107	04.04-07.06	■
2.8 JTD (8140.43N)		Diesel	FWD	2800	107	04.04-07.06	■

LISTA DE APLICACIONES - BUYERS GUIDE

DUCATO II (244_) 12.01-					Platform/Chassis (LCVs-N1 Segment)			
2.0 JTD (RHV)		Diesel	FWD	1997	62	84	12.01-07.06	■
2.0 JTD (RHV)		Diesel	FWD	1997	62	84	12.01-07.06	■
2.3 JTD (F1AE0481C)		Diesel	FWD	2286	81	110	12.01-07.06	■
2.3 JTD (F1AE0481C)		Diesel	FWD	2286	81	110	12.01-07.06	■
2.8 JTD (8140.43S)		Diesel	FWD	2798	94	128	12.01-07.06	■
2.8 JTD (8140.43S)		Diesel	FWD	2798	94	128	12.01-07.06	■
2.8 JTD 4x4 (8140.43S)		Diesel	4WD	2798	94	128	12.01-07.06	■
2.8 JTD 4x4 (8140.43S)		Diesel	4WD	2798	94	128	12.01-07.06	■
2.8 JTD (8140.43)		Diesel	FWD	2799	90	122	11.03-07.06	■
2.8 JTD (8140.43)		Diesel	FWD	2799	90	122	11.03-07.06	■
2.8 JTD 4x4		Diesel	4WD	2799	90	122	11.03-07.06	■
2.8 JTD 4x4		Diesel	4WD	2799	90	122	11.03-07.06	■
2.8 JTD Power (8140.43N)		Diesel	FWD	2800	107	146	04.04-07.06	■
2.8 JTD Power (8140.43N)		Diesel	FWD	2800	107	146	04.04-07.06	■
DUCATO II (244_) 12.01-					Van (LCVs-N1 Segment)			
2.0 (RFL)		Gasolina	FWD	1998	81	110	12.01-07.06	■
2.0 (RFL)		Gasolina	FWD	1998	81	110	12.01-07.06	■
2.0 4x4 (RFL)		Gasolina	4WD	1998	81	110	05.02-07.06	■
2.0 4x4 (RFL)		Gasolina	4WD	1998	81	110	05.02-07.06	■
2.0 JTD (RHV)		Diesel	FWD	1997	62	84	12.01-07.06	■
2.0 JTD (RHV)		Diesel	FWD	1997	62	84	12.01-07.06	■
2.3 JTD (F1AE0481C)		Diesel	FWD	2286	81	110	12.01-07.06	■
2.3 JTD (F1AE0481C)		Diesel	FWD	2286	81	110	12.01-07.06	■
2.8 JTD (8140.43S)	-12/07	Diesel	FWD	2798	94	128	12.01-12.11	■
2.8 JTD (8140.43S)	-12/07	Diesel	FWD	2798	94	128	12.01-12.11	■
2.8 JTD 4x4 (8140.43S)		Diesel	4WD	2798	94	128	12.01-07.06	■
2.8 JTD 4x4 (8140.43S)		Diesel	4WD	2798	94	128	12.01-07.06	■
2.8 TD (8140.43)		Diesel	FWD	2799	90	122	12.01-07.06	■
2.8 TD (8140.43)		Diesel	FWD	2799	90	122	12.01-07.06	■
2.8 TD		Diesel	RWD	2799	90	122	11.03-07.06	■
2.8 TD		Diesel	RWD	2799	90	122	11.03-07.06	■
2.8 JTD Power (8140.43N)		Diesel	FWD	2800	107	146	04.04-07.06	■
2.8 JTD Power (8140.43N)		Diesel	FWD	2800	107	146	04.04-07.06	■
PEUGEOT								
BOXER II (244, Z_) 12.01-					Bus (Minibus-M2-Segment)			
2.0 HDi (RHV (DW10TD))	01/04-	Diesel	FWD	1997	62	84	12.01-06.06	■
2.0 HDi (RHV (DW10TD))	01/04-	Diesel	FWD	1997	62	84	12.01-06.06	■
2.0 HDi (RHV (DW10UTD))	01/04-	Diesel	FWD	1997	62	84	12.01-06.06	■
2.0 HDi (RHV (DW10UTD))	01/04-	Diesel	FWD	1997	62	84	12.01-06.06	■
2.2 HDi (4HY (DW12UTD))	01/04-	Diesel	FWD	2179	74	101	12.01-06.06	■
2.2 HDi (4HY (DW12UTD))	01/04-	Diesel	FWD	2179	74	101	12.01-06.06	■
2.8 HDi (8140.43S (F28DTCR))	01/04-	Diesel	FWD	2798	94	128	12.01-06.06	■
2.8 HDi (8140.43S (F28DTCR))	01/04-	Diesel	FWD	2798	94	128	12.01-06.06	■
2.8 HDi 4x4 (8140.43S (F28DTCR))	01/04-	Diesel	4WD	2798	94	128	12.01-06.06	■
2.8 HDi 4x4 (8140.43S (F28DTCR))	01/04-	Diesel	4WD	2798	94	128	12.01-06.06	■
2.8 HDi (8140.43N)		Diesel	FWD	2798	107	145	04.04-06.06	■
2.8 HDi (8140.43N)		Diesel	FWD	2798	107	145	04.04-06.06	■

LISTA DE APLICACIONES - BUYERS GUIDE

BOXER II (244) 12.01-					Platform/Chassis (LCVs-N1 Segment)			
2.0 HDi (RHV (DW10TD))		Diesel	FWD	1997	62	84	12.01-06.06	■
2.0 HDi (RHV (DW10TD))		Diesel	FWD	1997	62	84	12.01-06.06	■
2.0 HDi (RHV (DW10UTD))		Diesel	FWD	1997	62	84	12.01-06.06	■
2.0 HDi (RHV (DW10UTD))		Diesel	FWD	1997	62	84	12.01-06.06	■
2.2 HDi (4HY (DW12UTED))		Diesel	FWD	2179	74	101	12.01-06.06	■
2.2 HDi (4HY (DW12UTED))		Diesel	FWD	2179	74	101	12.01-06.06	■
2.8 HDi (8140.43S (F28DTCR))		Diesel	FWD	2798	94	128	12.01-06.06	■
2.8 HDi (8140.43S (F28DTCR))		Diesel	FWD	2798	94	128	12.01-06.06	■
2.8 HDi 4x4 (8140.43S (F28DTCR))		Diesel	4WD	2798	94	128	12.01-06.06	■
2.8 HDi 4x4 (8140.43S (F28DTCR))		Diesel	4WD	2798	94	128	12.01-06.06	■
BOXER II (244) 12.01-					Van (LCVs-N1 Segment)			
2.0 (RFL (XU10J2U))	01/04-	Gasolina	FWD	1998	81	110	12.01-06.06	■
2.0 (RFL (XU10J2U))	01/04-	Gasolina	FWD	1998	81	110	12.01-06.06	■
2.0 HDi (RHV (DW10TD))	01/04-	Diesel	FWD	1997	62	84	04.02-06.06	■
2.0 HDi (RHV (DW10TD))	01/04-	Diesel	FWD	1997	62	84	04.02-06.06	■
2.0 HDi (RHV (DW10UTD))	01/04-	Diesel	FWD	1997	62	84	04.02-06.06	■
2.0 HDi (RHV (DW10UTD))	01/04-	Diesel	FWD	1997	62	84	04.02-06.06	■
2.2 HDi (4HY (DW12UTED))	01/04-	Diesel	FWD	2179	74	101	12.01-06.06	■
2.2 HDi (4HY (DW12UTED))	01/04-	Diesel	FWD	2179	74	101	12.01-06.06	■
2.8 HDi (8140.43S (F28DTCR))	01/04-	Diesel	FWD	2798	94	128	12.01-06.06	■
2.8 HDi (8140.43S (F28DTCR))	01/04-	Diesel	FWD	2798	94	128	12.01-06.06	■
2.8 HDi 4x4 (8140.43S (F28DTCR))	01/04-	Diesel	4WD	2798	94	128	12.01-06.06	■
2.8 HDi 4x4 (8140.43S (F28DTCR))	01/04-	Diesel	4WD	2798	94	128	12.01-06.06	■