


LISTA DE APLICACIONES - BUYERS GUIDE

31663-3406



8 424073 202956

Weight: 14.300



31663-3406



Ate - Teves

122.9x43.49x17.3
Ø300x20x66

WVA

23926

23927

24226

MAKE

BMW

BMW (BRILLIANCE)



Trac.

CC

Kw

CV



Front / Rear

BMW

1 Serie (E88) 12.07-12.13

					Convertible (Compact car-C Segment)				
118 i (N43 B20 A)		Gasolina	RWD	1995	105	143	03.08-10.13		■
118 i (N43 B20 A)		Gasolina	RWD	1995	105	143	03.08-10.13		■
120 i (N43 B20 A)		Gasolina	RWD	1995	125	170	12.07-10.13		■
120 i (N43 B20 A)		Gasolina	RWD	1995	125	170	12.07-10.13		■
125 i (N52 B30 A)		Gasolina	RWD	2996	160	218	12.07-10.13		■
125 i (N52 B30 A)		Gasolina	RWD	2996	160	218	12.07-10.13		■
125 i (N52 B30 B)		Gasolina	RWD	2996	160	218	12.07-10.13		■
125 i (N52 B30 B)		Gasolina	RWD	2996	160	218	12.07-10.13		■
125 i (N52 B30 BF)		Gasolina	RWD	2996	160	218	12.07-10.13		■
125 i (N52 B30 BF)		Gasolina	RWD	2996	160	218	12.07-10.13		■
120 d (N47 D20 A)		Diesel	RWD	1995	130	177	03.08-12.13		■
120 d (N47 D20 A)		Diesel	RWD	1995	130	177	03.08-12.13		■
120 d (N47 D20 C)		Diesel	RWD	1995	130	177	03.08-12.13		■
120 d (N47 D20 C)		Diesel	RWD	1995	130	177	03.08-12.13		■
120 d (N47 D20 C)		Diesel	RWD	1995	145	197	03.08-12.13		■
120 d (N47 D20 C)		Diesel	RWD	1995	145	197	03.08-12.13		■

1 Serie (E82) 10.06-10.13

					Coupe (Compact car-C Segment)				
125 i (N52 B30 A)		Gasolina	RWD	2996	160	218	03.08-10.13		■
125 i (N52 B30 A)		Gasolina	RWD	2996	160	218	03.08-10.13		■
125 i (N52 B30 B)		Gasolina	RWD	2996	160	218	03.08-10.13		■
125 i (N52 B30 B)		Gasolina	RWD	2996	160	218	03.08-10.13		■
125 i (N52 B30 BF)		Gasolina	RWD	2996	160	218	03.08-10.13		■

LISTA DE APLICACIONES - BUYERS GUIDE

125 i (N52 B30 BF)		Gasolina	RWD	2996	160	218	03.08-10.13	■
120 d (N47 D20 A)		Diesel	RWD	1995	130	177	09.07-10.13	■
120 d (N47 D20 A)		Diesel	RWD	1995	130	177	09.07-10.13	■
120 d (N47 D20 C)		Diesel	RWD	1995	130	177	09.07-10.13	■
120 d (N47 D20 C)		Diesel	RWD	1995	130	177	09.07-10.13	■
120 d (N47 D20 A)		Diesel	RWD	1995	145	197	09.07-10.13	■
120 d (N47 D20 A)		Diesel	RWD	1995	145	197	09.07-10.13	■
120 d (N47 D20 C)		Diesel	RWD	1995	145	197	09.07-10.13	■
120 d (N47 D20 C)		Diesel	RWD	1995	145	197	09.07-10.13	■
123 d (N47 D20 B)		Diesel	RWD	1995	150	204	10.07-09.13	■
123 d (N47 D20 B)		Diesel	RWD	1995	150	204	10.07-09.13	■
123 d (N47 D20 D)		Diesel	RWD	1995	150	204	10.07-09.13	■
123 d (N47 D20 D)		Diesel	RWD	1995	150	204	10.07-09.13	■
1 Serie (E87) 02.03-01.13					Hatchback (Compact car-C Segment)			
116 i (N45 B16 A)		Gasolina	RWD	1596	85	115	06.04-06.11	■
116 i (N45 B16 A)		Gasolina	RWD	1596	85	115	06.04-06.11	■
116 i (N43 B16 AA)		Gasolina	RWD	1599	90	122	09.07-06.11	■
116 i (N43 B16 AA)		Gasolina	RWD	1599	90	122	09.07-06.11	■
116 i (N43 B20 A)		Gasolina	RWD	1995	90	122	01.09-06.11	■
116 i (N43 B20 A)		Gasolina	RWD	1995	90	122	01.09-06.11	■
120 i (N46 B20 B)		Gasolina	RWD	1995	110	150	06.04-02.07	■
120 i (N46 B20 B)		Gasolina	RWD	1995	110	150	06.04-02.07	■
120 i (N46 B20 BD)		Gasolina	RWD	1995	110	150	06.04-02.07	■
120 i (N46 B20 BD)		Gasolina	RWD	1995	110	150	06.04-02.07	■
120 i (N46 B20 C)		Gasolina	RWD	1995	110	150	06.04-02.07	■
120 i (N46 B20 C)		Gasolina	RWD	1995	110	150	06.04-02.07	■
120 i (N46 B20 CC)		Gasolina	RWD	1995	110	150	06.04-02.07	■
120 i (N46 B20 CC)		Gasolina	RWD	1995	110	150	06.04-02.07	■
120 i (N46 B20 A)		Gasolina	RWD	1995	115	156	03.07-06.11	■
120 i (N46 B20 A)		Gasolina	RWD	1995	115	156	03.07-06.11	■
120 i (N46 B20 B)		Gasolina	RWD	1995	115	156	03.07-06.11	■
120 i (N46 B20 B)		Gasolina	RWD	1995	115	156	03.07-06.11	■
120 i (N46 B20 BD)		Gasolina	RWD	1995	115	156	03.07-06.11	■
120 i (N46 B20 BD)		Gasolina	RWD	1995	115	156	03.07-06.11	■
120 i (N46 B20 C)		Gasolina	RWD	1995	115	156	03.07-06.11	■
120 i (N46 B20 C)		Gasolina	RWD	1995	115	156	03.07-06.11	■
120 i (N46 B20 CC)		Gasolina	RWD	1995	115	156	03.07-06.11	■
120 i (N46 B20 CC)		Gasolina	RWD	1995	115	156	03.07-06.11	■
120 i (N43 B20 A)		Gasolina	RWD	1995	120	163	03.07-06.11	■
120 i (N43 B20 A)		Gasolina	RWD	1995	120	163	03.07-06.11	■
118 i (N43 B20 A)		Gasolina	RWD	1995	125	170	03.07-12.07	■
118 i (N43 B20 A)		Gasolina	RWD	1995	125	170	03.07-12.07	■
120 i (N43 B20 A)		Gasolina	RWD	1995	125	170	03.07-06.11	■
120 i (N43 B20 A)		Gasolina	RWD	1995	125	170	03.07-06.11	■
130 i (N52 B30 A)		Gasolina	RWD	2996	195	265	09.06-12.11	■
130 i (N52 B30 A)		Gasolina	RWD	2996	195	265	09.06-12.11	■
130 i (N52 B30 B)		Gasolina	RWD	2996	195	265	09.06-12.11	■
130 i (N52 B30 B)		Gasolina	RWD	2996	195	265	09.06-12.11	■
130 i (N52 B30 BF)		Gasolina	RWD	2996	195	265	09.06-12.11	■
130 i (N52 B30 BF)		Gasolina	RWD	2996	195	265	09.06-12.11	■
116 d (N47 D20 C)		Diesel	RWD	1995	66	90	01.11-12.11	■

LISTA DE APLICACIONES - BUYERS GUIDE

116 d (N47 D20 C)	Diesel	RWD	1995	66	90	01.11-12.11	■
116 d (N47 D20 A)	Diesel	RWD	1995	85	116	03.09-06.11	■
116 d (N47 D20 A)	Diesel	RWD	1995	85	116	03.09-06.11	■
116 d (N47 D20 C)	Diesel	RWD	1995	85	116	03.09-06.11	■
116 d (N47 D20 C)	Diesel	RWD	1995	85	116	03.09-06.11	■
118 d (N47 D20 A)	Diesel	RWD	1995	100	136	03.07-06.11	■
118 d (N47 D20 A)	Diesel	RWD	1995	100	136	03.07-06.11	■
118 d (N47 D20 C)	Diesel	RWD	1995	100	136	03.07-06.11	■
118 d (N47 D20 C)	Diesel	RWD	1995	100	136	03.07-06.11	■
118 d (N47 D20 A)	Diesel	RWD	1995	100	136	09.06-12.11	■
118 d (N47 D20 A)	Diesel	RWD	1995	100	136	09.06-12.11	■
118 d (N47 D20 C)	Diesel	RWD	1995	100	136	09.06-12.11	■
118 d (N47 D20 C)	Diesel	RWD	1995	100	136	09.06-12.11	■
118 d (N47 D20 A)	Diesel	RWD	1995	105	143	03.07-06.11	■
118 d (N47 D20 A)	Diesel	RWD	1995	105	143	03.07-06.11	■
118 d (N47 D20 C)	Diesel	RWD	1995	105	143	03.07-06.11	■
118 d (N47 D20 C)	Diesel	RWD	1995	105	143	03.07-06.11	■
118 d (N47 D20 A)	Diesel	RWD	1995	105	143	09.06-12.11	■
118 d (N47 D20 A)	Diesel	RWD	1995	105	143	09.06-12.11	■
118 d (N47 D20 C)	Diesel	RWD	1995	105	143	09.06-12.11	■
118 d (N47 D20 C)	Diesel	RWD	1995	105	143	09.06-12.11	■
120 d (M47 D20 (204D4))	Diesel	RWD	1995	110	150	06.04-02.07	■
120 d (M47 D20 (204D4))	Diesel	RWD	1995	110	150	06.04-02.07	■
120 d (M47 D20 (204D4))	Diesel	RWD	1995	115	156	05.06-02.07	■
120 d (M47 D20 (204D4))	Diesel	RWD	1995	115	156	05.06-02.07	■
120 d (M47 D20 (204D4))	Diesel	RWD	1995	120	163	06.04-06.11	■
120 d (M47 D20 (204D4))	Diesel	RWD	1995	120	163	06.04-06.11	■
120 d (N47 D20 A)	Diesel	RWD	1995	120	163	06.04-06.11	■
120 d (N47 D20 A)	Diesel	RWD	1995	120	163	06.04-06.11	■
120 d (N47 D20 A)	Diesel	RWD	1995	120	163	03.07-12.11	■
120 d (N47 D20 A)	Diesel	RWD	1995	120	163	03.07-12.11	■
120 d (N47 D20 C)	Diesel	RWD	1995	120	163	03.07-12.11	■
120 d (N47 D20 C)	Diesel	RWD	1995	120	163	03.07-12.11	■
120 d (N47 D20 A)	Diesel	RWD	1995	125	170	03.07-10.10	■
120 d (N47 D20 A)	Diesel	RWD	1995	125	170	03.07-10.10	■
120 d (N47 D20 A)	Diesel	RWD	1995	130	177	03.07-06.11	■
120 d (N47 D20 A)	Diesel	RWD	1995	130	177	03.07-06.11	■
120 d (N47 D20 C)	Diesel	RWD	1995	130	177	03.07-06.11	■
120 d (N47 D20 C)	Diesel	RWD	1995	130	177	03.07-06.11	■
120 d (N47 D20 A)	Diesel	RWD	1995	130	177	03.07-12.11	■
120 d (N47 D20 A)	Diesel	RWD	1995	130	177	03.07-12.11	■
120 d (N47 D20 C)	Diesel	RWD	1995	130	177	03.07-12.11	■
120 d (N47 D20 C)	Diesel	RWD	1995	130	177	03.07-12.11	■
120 d (N47 D20 A)	Diesel	RWD	1995	145	197	03.07-12.11	■
120 d (N47 D20 A)	Diesel	RWD	1995	145	197	03.07-12.11	■
120 d (N47 D20 C)	Diesel	RWD	1995	145	197	03.07-12.11	■
120 d (N47 D20 C)	Diesel	RWD	1995	145	197	03.07-12.11	■
123 d (N47 D20 B)	Diesel	RWD	1995	150	204	03.07-12.11	■
123 d (N47 D20 B)	Diesel	RWD	1995	150	204	03.07-12.11	■
123 d (N47 D20 D)	Diesel	RWD	1995	150	204	03.07-12.11	■
123 d (N47 D20 D)	Diesel	RWD	1995	150	204	03.07-12.11	■

LISTA DE APLICACIONES - BUYERS GUIDE

3 Serie V (E93) 05.06-12.13					Convertible (Compact executive car-D Segment)			
318i (N43 B20 A)		Gasolina	RWD	1995	105	143	03.10-12.13	■
318i (N43 B20 A)		Gasolina	RWD	1995	105	143	03.10-12.13	■
320i (N46 B20 B)		Gasolina	RWD	1995	115	156	01.07-08.13	■
320i (N46 B20 B)		Gasolina	RWD	1995	115	156	01.07-08.13	■
320i (N43 B20 A)		Gasolina	RWD	1995	120	163	09.06-10.13	■
320i (N43 B20 A)		Gasolina	RWD	1995	120	163	09.06-10.13	■
320i (N43 B20 A)		Gasolina	RWD	1995	125	170	03.07-10.13	■
320i (N43 B20 A)		Gasolina	RWD	1995	125	170	03.07-10.13	■
320 d (N47 D20 A)		Diesel	RWD	1995	130	177	03.08-02.10	■
320 d (N47 D20 A)		Diesel	RWD	1995	130	177	03.08-02.10	■
320 d (N47 D20 C)		Diesel	RWD	1995	130	177	03.08-02.10	■
320 d (N47 D20 C)		Diesel	RWD	1995	130	177	03.08-02.10	■
3 Serie V (E92) 01.05-12.13					Coupe (Compact executive car-D Segment)			
320i		Gasolina	FWD	1955	112	152	01.10-	■
320i		Gasolina	FWD	1955	112	152	01.10-	■
318i (N43 B20 A)		Gasolina	RWD	1995	105	143	03.10-12.13	■
318i (N43 B20 A)		Gasolina	RWD	1995	105	143	03.10-12.13	■
320i		Gasolina	RWD	1995	110	150	11.06-06.07	■
320i		Gasolina	RWD	1995	110	150	11.06-06.07	■
320i (N46 B20 B)		Gasolina	RWD	1995	115	156	06.07-12.13	■
320i (N46 B20 B)		Gasolina	RWD	1995	115	156	06.07-12.13	■
320i (N43 B20 A)		Gasolina	RWD	1995	120	163	01.07-06.13	■
320i (N43 B20 A)		Gasolina	RWD	1995	120	163	01.07-06.13	■
320i (N43 B20 A)		Gasolina	RWD	1995	125	170	03.07-06.13	■
320i (N43 B20 A)		Gasolina	RWD	1995	125	170	03.07-06.13	■
323 i		Gasolina	FWD	2497	130	177	04.06-02.12	■
323 i		Gasolina	FWD	2497	130	177	04.06-02.12	■
323 i (N52 B25 AE)		Gasolina	RWD	2497	140	190	04.06-02.12	■
323 i (N52 B25 AE)		Gasolina	RWD	2497	140	190	04.06-02.12	■
323 i (N52 B25 BE)		Gasolina	RWD	2497	140	190	04.06-02.12	■
323 i (N52 B25 BE)		Gasolina	RWD	2497	140	190	04.06-02.12	■
325i (N52 B25 A)		Gasolina	RWD	2497	150	204	03.10-10.13	■
325i (N52 B25 A)		Gasolina	RWD	2497	150	204	03.10-10.13	■
325i (N52 B25 AF)		Gasolina	RWD	2497	150	204	03.10-10.13	■
325i (N52 B25 AF)		Gasolina	RWD	2497	150	204	03.10-10.13	■
325i (N52 B25 BF)		Gasolina	RWD	2497	150	204	03.10-10.13	■
325i (N52 B25 BF)		Gasolina	RWD	2497	150	204	03.10-10.13	■
325i (N52 B25 A)		Gasolina	RWD	2497	155	211	03.10-06.13	■
325i (N52 B25 A)		Gasolina	RWD	2497	155	211	03.10-06.13	■
325i (N52 B25 AF)		Gasolina	RWD	2497	155	211	03.10-06.13	■
325i (N52 B25 AF)		Gasolina	RWD	2497	155	211	03.10-06.13	■
325i (N52 B25 BF)		Gasolina	RWD	2497	155	211	03.10-06.13	■
325i (N52 B25 BF)		Gasolina	RWD	2497	155	211	03.10-06.13	■
325i (N52 B25 A)		Gasolina	RWD	2497	160	218	06.06-02.10	■
325i (N52 B25 A)		Gasolina	RWD	2497	160	218	06.06-02.10	■
325i (N52 B25 AF)		Gasolina	RWD	2497	160	218	06.06-02.10	■
325i (N52 B25 AF)		Gasolina	RWD	2497	160	218	06.06-02.10	■
325i (N52 B25 BF)		Gasolina	RWD	2497	160	218	06.06-02.10	■
325i (N52 B25 BF)		Gasolina	RWD	2497	160	218	06.06-02.10	■

LISTA DE APLICACIONES - BUYERS GUIDE

325i (N53 B30 A)		Gasolina	RWD	2996	155	211	03.10-06.13	■
325i (N53 B30 A)		Gasolina	RWD	2996	155	211	03.10-06.13	■
325i (N53 B30 A)		Gasolina	RWD	2996	160	218	09.07-06.13	■
325i (N53 B30 A)		Gasolina	RWD	2996	160	218	09.07-06.13	■
328i (N51 B30 A)		Gasolina	RWD	2996	171	233	09.06-12.10	■
328i (N51 B30 A)		Gasolina	RWD	2996	171	233	09.06-12.10	■
328i (N51 B30 A)		Gasolina	RWD	2996	172	234	06.06-06.13	■
328i (N51 B30 A)		Gasolina	RWD	2996	172	234	06.06-06.13	■
328i (N52 B30 A)		Gasolina	RWD	2996	172	234	06.06-06.13	■
328i (N52 B30 A)		Gasolina	RWD	2996	172	234	06.06-06.13	■
320 d (N47 D20 A)		Diesel	RWD	1995	120	163	03.07-06.13	■
320 d (N47 D20 A)		Diesel	RWD	1995	120	163	03.07-06.13	■
320 d (N47 D20 C)		Diesel	RWD	1995	120	163	03.07-06.13	■
320 d (N47 D20 C)		Diesel	RWD	1995	120	163	03.07-06.13	■
320 d (N47 D20 A)		Diesel	RWD	1995	130	177	09.06-02.10	■
320 d (N47 D20 A)		Diesel	RWD	1995	130	177	09.06-02.10	■
320 d (N47 D20 C)		Diesel	RWD	1995	130	177	09.06-02.10	■
320 d (N47 D20 C)		Diesel	RWD	1995	130	177	09.06-02.10	■
320 d (N47 D20 C)		Diesel	RWD	1995	130	177	09.06-02.10	■
320 d (N47 D20 C)		Diesel	RWD	1995	135	184	03.10-06.13	■
320 d (N47 D20 C)		Diesel	RWD	1995	135	184	03.10-06.13	■
320 d (N47 D20 A)		Diesel	RWD	1995	145	197	09.06-02.10	■
320 d (N47 D20 A)		Diesel	RWD	1995	145	197	09.06-02.10	■
320 d (N47 D20 C)		Diesel	RWD	1995	145	197	09.06-02.10	■
320 d (N47 D20 C)		Diesel	RWD	1995	145	197	09.06-02.10	■
320 d (N47 D20 C)		Diesel	RWD	1995	147	200	03.10-06.13	■
320 d (N47 D20 C)		Diesel	RWD	1995	147	200	03.10-06.13	■
3 Serie V (E90) 02.04-02.12					Saloon (Compact executive car-D Segment)			
318i (N46 B20 B)		Gasolina	RWD	1995	95	129	09.05-08.07	■
318i (N46 B20 B)		Gasolina	RWD	1995	95	129	09.05-08.07	■
318i (N46 B20 B)		Gasolina	RWD	1995	100	136	09.07-10.11	■
318i (N46 B20 B)		Gasolina	RWD	1995	100	136	09.07-10.11	■
318i (N46 B20 C)		Gasolina	RWD	1995	100	136	09.07-10.11	■
318i (N46 B20 C)		Gasolina	RWD	1995	100	136	09.07-10.11	■
318i (N46 B20 CC)		Gasolina	RWD	1995	100	136	09.07-10.11	■
318i (N46 B20 CC)		Gasolina	RWD	1995	100	136	09.07-10.11	■
318i (N46 B20 CD)		Gasolina	RWD	1995	100	136	09.07-10.11	■
318i (N46 B20 CD)		Gasolina	RWD	1995	100	136	09.07-10.11	■
318i (N46 B20 E)		Gasolina	RWD	1995	100	136	09.07-10.11	■
318i (N46 B20 E)		Gasolina	RWD	1995	100	136	09.07-10.11	■
318i (N43 B20 A)		Gasolina	RWD	1995	105	143	09.07-10.11	■
318i (N43 B20 A)		Gasolina	RWD	1995	105	143	09.07-10.11	■
320i (N46 B20 B)		Gasolina	RWD	1995	110	150	12.04-08.07	■
320i (N46 B20 B)		Gasolina	RWD	1995	110	150	12.04-08.07	■
320i (N46 B20 BD)		Gasolina	RWD	1995	110	150	12.04-08.07	■
320i (N46 B20 BD)		Gasolina	RWD	1995	110	150	12.04-08.07	■
320i (N46 B20 C)		Gasolina	RWD	1995	110	150	12.04-08.07	■
320i (N46 B20 C)		Gasolina	RWD	1995	110	150	12.04-08.07	■
320i (N46 B20 CB)		Gasolina	RWD	1995	110	150	12.04-08.07	■
320i (N46 B20 CB)		Gasolina	RWD	1995	110	150	12.04-08.07	■
320i (N46 B20 B)		Gasolina	RWD	1995	115	156	02.07-12.11	■
320i (N46 B20 B)		Gasolina	RWD	1995	115	156	02.07-12.11	■

LISTA DE APLICACIONES - BUYERS GUIDE

320i (N46 B20 C)	Gasolina	RWD	1995	115	156	02.07-12.11	■
320i (N46 B20 C)	Gasolina	RWD	1995	115	156	02.07-12.11	■
320i (N46 B20 CC)	Gasolina	RWD	1995	115	156	02.07-12.11	■
320i (N46 B20 CC)	Gasolina	RWD	1995	115	156	02.07-12.11	■
320i (N46 B20 CD)	Gasolina	RWD	1995	115	156	02.07-12.11	■
320i (N46 B20 CD)	Gasolina	RWD	1995	115	156	02.07-12.11	■
320i (N46 B20 E)	Gasolina	RWD	1995	115	156	02.07-12.11	■
320i (N46 B20 E)	Gasolina	RWD	1995	115	156	02.07-12.11	■
320i (N43 B20 A)	Gasolina	RWD	1995	120	163	03.07-12.11	■
320i (N43 B20 A)	Gasolina	RWD	1995	120	163	03.07-12.11	■
320i (N43 B20 A)	Gasolina	RWD	1995	125	170	09.07-10.11	■
320i (N43 B20 A)	Gasolina	RWD	1995	125	170	09.07-10.11	■
325i	Gasolina	FWD	2494	141	189	09.07-12.08	■
325i	Gasolina	FWD	2494	141	189	09.07-12.08	■
325i	Gasolina	FWD	2494	224	300	09.08-12.10	■
325i	Gasolina	FWD	2494	224	300	09.08-12.10	■
323 i (N52 B25 A)	Gasolina	RWD	2497	130	177	09.05-02.07	■
323 i (N52 B25 A)	Gasolina	RWD	2497	130	177	09.05-02.07	■
323 i (N52 B25 B)	Gasolina	RWD	2497	130	177	09.05-02.07	■
323 i (N52 B25 B)	Gasolina	RWD	2497	130	177	09.05-02.07	■
323 i (N52 B25 BE)	Gasolina	RWD	2497	130	177	09.05-02.07	■
323 i (N52 B25 BE)	Gasolina	RWD	2497	130	177	09.05-02.07	■
323 i (N52 B25 BF)	Gasolina	RWD	2497	130	177	09.05-02.07	■
323 i (N52 B25 BF)	Gasolina	RWD	2497	130	177	09.05-02.07	■
323 i (N52 B25 A)	Gasolina	RWD	2497	140	190	03.07-12.11	■
323 i (N52 B25 A)	Gasolina	RWD	2497	140	190	03.07-12.11	■
323 i (N52 B25 BF)	Gasolina	RWD	2497	140	190	03.07-12.11	■
323 i (N52 B25 BF)	Gasolina	RWD	2497	140	190	03.07-12.11	■
325i (N52 B25 A)	Gasolina	RWD	2497	155	211	01.06-12.11	■
325i (N52 B25 A)	Gasolina	RWD	2497	155	211	01.06-12.11	■
325i (N52 B25 A)	Gasolina	RWD	2497	160	218	12.04-12.11	■
325i (N52 B25 A)	Gasolina	RWD	2497	160	218	12.04-12.11	■
325i (N52 B25 B)	Gasolina	RWD	2497	160	218	12.04-12.11	■
325i (N52 B25 B)	Gasolina	RWD	2497	160	218	12.04-12.11	■
325i (N52 B25 BF)	Gasolina	RWD	2497	160	218	12.04-12.11	■
325i (N52 B25 BF)	Gasolina	RWD	2497	160	218	12.04-12.11	■
325 xi (N52 B25 A)	Gasolina	4WD	2497	160	218	09.05-08.08	■
325 xi (N52 B25 A)	Gasolina	4WD	2497	160	218	09.05-08.08	■
325i (N52 B25)	Gasolina	RWD	2497	163	222	09.08-12.09	■
325i (N52 B25)	Gasolina	RWD	2497	163	222	09.08-12.09	■
325i (N53 B30 A)	Gasolina	RWD	2996	155	211	03.07-12.11	■
325i (N53 B30 A)	Gasolina	RWD	2996	155	211	03.07-12.11	■
325i (N53 B30 A)	Gasolina	RWD	2996	160	218	03.07-12.11	■
325i (N53 B30 A)	Gasolina	RWD	2996	160	218	03.07-12.11	■
325 xi (N53 B30 A)	Gasolina	4WD	2996	160	218	09.07-08.08	■
325 xi (N53 B30 A)	Gasolina	4WD	2996	160	218	09.07-08.08	■
328i (N51 B30 A)	Gasolina	RWD	2996	172	234	09.06-12.11	■
328i (N51 B30 A)	Gasolina	RWD	2996	172	234	09.06-12.11	■
318 d (M47 D20 (204D4))	Diesel	RWD	1995	90	122	03.05-08.07	■
318 d (M47 D20 (204D4))	Diesel	RWD	1995	90	122	03.05-08.07	■
318 d (N47 D20 A)	Diesel	RWD	1995	100	136	09.07-10.11	■

LISTA DE APLICACIONES - BUYERS GUIDE

318 d (N47 D20 A)		Diesel	RWD	1995	100	136	09.07-10.11	■
318 d (N47 D20 C)		Diesel	RWD	1995	100	136	09.07-10.11	■
318 d (N47 D20 C)		Diesel	RWD	1995	100	136	09.07-10.11	■
318 d (N47 D20 A)		Diesel	RWD	1995	105	143	02.07-10.11	■
318 d (N47 D20 A)		Diesel	RWD	1995	105	143	02.07-10.11	■
318 d (N47 D20 C)		Diesel	RWD	1995	105	143	02.07-10.11	■
318 d (N47 D20 C)		Diesel	RWD	1995	105	143	02.07-10.11	■
320 d (M47 D20 (204D4))		Diesel	RWD	1995	110	150	12.04-09.07	■
320 d (M47 D20 (204D4))		Diesel	RWD	1995	110	150	12.04-09.07	■
320 d		Diesel	RWD	1995	115	156	12.04-09.07	■
320 d		Diesel	RWD	1995	115	156	12.04-09.07	■
320 d (M47 D20 (204D4))		Diesel	RWD	1995	120	163	12.04-10.11	■
320 d (M47 D20 (204D4))		Diesel	RWD	1995	120	163	12.04-10.11	■
320 d (N47 D20 A)		Diesel	RWD	1995	120	163	12.04-10.11	■
320 d (N47 D20 A)		Diesel	RWD	1995	120	163	12.04-10.11	■
320 d (N47 D20 C)		Diesel	RWD	1995	120	163	12.04-10.11	■
320 d (N47 D20 C)		Diesel	RWD	1995	120	163	12.04-10.11	■
320 d (N47 D20 C)		Diesel	RWD	1995	125	170	01.07-12.09	■
320 d (N47 D20 C)		Diesel	RWD	1995	125	170	01.07-12.09	■
320 d (N47 D20 A)		Diesel	RWD	1995	130	177	09.07-02.10	■
320 d (N47 D20 A)		Diesel	RWD	1995	130	177	09.07-02.10	■
320 d (N47 D20 C)		Diesel	RWD	1995	130	177	09.07-02.10	■
320 d (N47 D20 C)		Diesel	RWD	1995	130	177	09.07-02.10	■
320 d (N47 D20 C)		Diesel	RWD	1995	135	184	03.10-10.11	■
320 d (N47 D20 C)		Diesel	RWD	1995	135	184	03.10-10.11	■
3 Serie V Touring (E91) 12.04-12.12						Estate (Compact executive car-D Segment)		
316 i (N43 B16 AA)		Gasolina	RWD	1599	90	122	09.08-06.12	■
316 i (N43 B16 AA)		Gasolina	RWD	1599	90	122	09.08-06.12	■
318i (N46 B20 B)		Gasolina	RWD	1995	100	136	09.07-03.12	■
318i (N46 B20 B)		Gasolina	RWD	1995	100	136	09.07-03.12	■
318i (N43 B20 A)		Gasolina	RWD	1995	105	143	05.07-05.12	■
318i (N43 B20 A)		Gasolina	RWD	1995	105	143	05.07-05.12	■
320i (N46 B20 B)		Gasolina	RWD	1995	110	150	09.05-06.12	■
320i (N46 B20 B)		Gasolina	RWD	1995	110	150	09.05-06.12	■
320i (N46 B20 C)		Gasolina	RWD	1995	110	150	09.05-06.12	■
320i (N46 B20 C)		Gasolina	RWD	1995	110	150	09.05-06.12	■
320i (N43 B20 A)		Gasolina	RWD	1995	125	170	02.07-12.12	■
320i (N43 B20 A)		Gasolina	RWD	1995	125	170	02.07-12.12	■
325i (N52 B25 A)		Gasolina	RWD	2497	160	218	12.04-08.08	■
325i (N52 B25 A)		Gasolina	RWD	2497	160	218	12.04-08.08	■
325 xi (N52 B25 A)		Gasolina	4WD	2497	160	218	08.05-08.08	■
325 xi (N52 B25 A)		Gasolina	4WD	2497	160	218	08.05-08.08	■
325i (N53 B30 A)		Gasolina	RWD	2996	155	211	09.07-06.12	■
325i (N53 B30 A)		Gasolina	RWD	2996	155	211	09.07-06.12	■
325i (N53 B30 A)		Gasolina	RWD	2996	160	218	09.07-06.12	■
325i (N53 B30 A)		Gasolina	RWD	2996	160	218	09.07-06.12	■
325 xi (N53 B30 A)		Gasolina	4WD	2996	160	218	09.07-08.08	■
325 xi (N53 B30 A)		Gasolina	4WD	2996	160	218	09.07-08.08	■
316 d (N47 D20 C)		Diesel	RWD	1995	85	116	09.09-06.12	■
316 d (N47 D20 C)		Diesel	RWD	1995	85	116	09.09-06.12	■
318 d (N47 D20 A)		Diesel	RWD	1995	100	136	07.07-06.12	■

LISTA DE APLICACIONES - BUYERS GUIDE

318 d (N47 D20 A)		Diesel	RWD	1995	100	136	07.07-06.12	■
318 d (N47 D20 C)		Diesel	RWD	1995	100	136	07.07-06.12	■
318 d (N47 D20 C)		Diesel	RWD	1995	100	136	07.07-06.12	■
318 d (N47 D20 A)		Diesel	RWD	1995	105	143	09.07-06.12	■
318 d (N47 D20 A)		Diesel	RWD	1995	105	143	09.07-06.12	■
318 d (N47 D20 C)		Diesel	RWD	1995	105	143	09.07-06.12	■
318 d (N47 D20 C)		Diesel	RWD	1995	105	143	09.07-06.12	■
320 d (M47 D20 (204D4))		Diesel	RWD	1995	120	163	06.05-06.12	■
320 d (M47 D20 (204D4))		Diesel	RWD	1995	120	163	06.05-06.12	■
320 d (N47 D20 A)		Diesel	RWD	1995	120	163	06.05-06.12	■
320 d (N47 D20 A)		Diesel	RWD	1995	120	163	06.05-06.12	■
320 d (N47 D20 C)		Diesel	RWD	1995	120	163	06.05-06.12	■
320 d (N47 D20 C)		Diesel	RWD	1995	120	163	06.05-06.12	■
320 d (N47 D20 A)		Diesel	RWD	1995	130	177	02.07-12.10	■
320 d (N47 D20 A)		Diesel	RWD	1995	130	177	02.07-12.10	■
320 d (N47 D20 C)		Diesel	RWD	1995	130	177	02.07-12.10	■
320 d (N47 D20 C)		Diesel	RWD	1995	130	177	02.07-12.10	■
320 d (N47 D20 C)		Diesel	RWD	1995	135	184	03.10-05.12	■
320 d (N47 D20 C)		Diesel	RWD	1995	135	184	03.10-05.12	■
320 d (N47 D20 C)		Diesel	RWD	1995	147	200	03.10-05.12	■
320 d (N47 D20 C)		Diesel	RWD	1995	147	200	03.10-05.12	■
BMW (BRILLIANCE)								
3 SERIES V (E90) 10.04-09.12					Saloon (Compact executive car-D Segment)			
318i		Gasolina	FWD	1995	100	136	01.09-09.12	■
318i		Gasolina	FWD	1995	100	136	01.09-09.12	■
320i		Gasolina	FWD	1995	112	152	01.10-09.12	■
320i		Gasolina	FWD	1995	112	152	01.10-09.12	■
320i		Gasolina	FWD	1995	115	156	12.07-12.08	■
320i		Gasolina	FWD	1995	115	156	12.07-12.08	■
325i (N52 B25 BF)		Gasolina	RWD	2497	160	218	06.05-09.12	■
325i (N52 B25 BF)		Gasolina	RWD	2497	160	218	06.05-09.12	■