

# LISTA DE APLICACIONES - BUYERS GUIDE


## 610222 E C



8 424073 093752

Weight: 54

O.E.M.	MAKE
190 7942	IVECO
980 19079 42	IVECO



## 610222 E C



500 mm.

WVA
29030
29065
29067
MAKE
IVECO



Trac.	CC	Kw	CV
-------	----	----	----



Front / Rear

### IVECO

#### Dumper 01.91-

-	01/91-	Diesel					01.91-	■	■
---	--------	--------	--	--	--	--	--------	---	---

#### EuroCargo I-III 01.91-09.15

#### Dump Truck

65 E 12 K (8040.25X.4000)	-12/96	Diesel		3908	85	116	01.91-09.15	■	■
75 E 12 K (8040.25X.4000)		Diesel		3908	85	116	01.91-09.15	■	■
65 E 14 K (8040.45.4000)	-12/96	Diesel		3908	100	136	01.91-09.15	■	■
75 E 14 K (8040.45.4000)		Diesel		3908	100	136	01.91-09.15	■	■
75 E 14 K (8040.45.4180)		Diesel		3908	100	136	01.91-09.15	■	■
100 E 17 K tector, 100 E 17 DK tector (F4AE0481A)		Diesel		3922	125	170	09.00-09.15	■	■
80 E 17 K, 80 E 17 DK tector, 80 E 18 K tector (F4AE0481A)		Diesel		3922	125	170	09.00-09.15	■	■
80 E 17 K, 80 E 17 DK tector, 80 E 18 K tector (F4AE3481B)		Diesel		3922	125	170	09.00-09.15	■	■
90 E 17 K tector, 90 E 17 DK tector (F4AE0481A)		Diesel		3922	125	170	09.00-09.15	■	■
100 E 15 K (8060.25R.4200 LTC)		Diesel		5861	105	143	01.91-09.15	■	■
75 E 15 K (8060.25R.4200 LTC)	-12/96	Diesel		5861	105	143	01.91-09.15	■	■
80 E 15 K (8060.25R.4200 LTC)		Diesel		5861	105	143	01.91-09.15	■	■
80 E 15 K (8060.25R.4200 LTC)		Diesel		5861	105	143	01.91-09.15	■	■
100 E 18 K (8060.25V.4000)		Diesel		5861	130	177	01.91-09.15	■	■
80 E 18 K (8060.25V.4000)		Diesel		5861	130	177	01.91-09.15	■	■
80 E 18 K (8060.25V.4000)		Diesel		5861	130	177	01.91-09.15	■	■
100 E 18 K tector, 100 E 18 DK tector (F4AE0681E)		Diesel		5883	134	181	09.00-09.15	■	■
80 E 18 K tector, 80 E 18 DK tector (F4AE0681E)		Diesel		5883	134	181	09.00-09.15	■	■

# LISTA DE APLICACIONES - BUYERS GUIDE

90 E 18 K tector, 90 E 18 DK tector (F4AE0681E)		Diesel		5883	134	181	09.00-09.15	■	■
100 E 21 K tector, 100 E 21 DK tector (F4AE0681D)		Diesel		5883	154	209	09.00-09.15	■	■
180 E 21 K tector (F4AE0681D)		Diesel		5883	154	209	09.00-09.15	■	■
80 E 21 K, 80 E 21 DK tector, 80 E 22 K tector (F4AE0681D)		Diesel		5883	154	209	09.00-09.15	■	■
80 E 21 K, 80 E 21 DK tector, 80 E 22 K tector (F4AE3681B)		Diesel		5883	154	209	09.00-09.15	■	■
90 E 21 K tector, 90 E 21 DK tector (F4AE0681D)		Diesel		5883	154	209	09.00-09.15	■	■
<b>EuroCargo I-III 01.91-09.15</b>					<b>Platform/Chassis</b>				
65 E 12, 65 E 12 P (8040.25X.4000)	-12/96	Diesel		3908	85	116	01.91-09.15	■	■
75 E 12, 75 E 12 P (8040.25X.4000)	-12/96	Diesel		3908	85	116	01.91-09.15	■	■
65 E 14, 65 E 14 P (8040.45.4000)	-12/96	Diesel		3908	100	136	01.91-09.15	■	■
75 E 14, 75 E 14 P (8040.45.4000)	-12/96	Diesel		3908	100	136	01.91-09.15	■	■
75 E 14, 75 E 14 P (8040.45.4180)	-12/96	Diesel		3908	100	136	01.91-09.15	■	■
80 EL 15 tector (F4AE0481C)		Diesel		3922	110	149	09.00-09.15	■	■
100 E 17, 100 E 17 DP tector, 100 E 18 tector (F4AE0481A)		Diesel		3922	125	170	09.00-09.15	■	■
100 E 17, 100 E 17 DP tector, 100 E 18 tector (F4AE3481B)		Diesel		3922	125	170	09.00-09.15	■	■
80 E 17, 80 E 17 D tector, 80 E 17 DP tector, 80 E 18 tector (F4AE0481A)		Diesel		3922	125	170	09.00-09.15	■	■
80 E 17, 80 E 17 D tector, 80 E 17 DP tector, 80 E 18 tector (F4AE3481B)		Diesel		3922	125	170	09.00-09.15	■	■
90 E 17, 90 E 17D tector, 90 E 17 DP tector, 90 E 18 tector (F4AE0481A)		Diesel		3922	125	170	09.00-09.15	■	■
90 E 17, 90 E 17D tector, 90 E 17 DP tector, 90 E 18 tector (F4AE3481B)		Diesel		3922	125	170	09.00-09.15	■	■
80 E 18 tector, 80 E 18 P tector, 80 E 18 FP tector (F4AE3481B)		Diesel		3922	130	177	09.06-09.15	■	■
80 EL 18 tector, 80 EL 18 P tector (F4AE3481B)		Diesel		3922	130	177	09.06-09.15	■	■
100 E 15, 100 E 15 P (8060.25R.4200 LTC)		Diesel		5861	105	143	01.91-09.15	■	■
100 E 15, 100 E 15 P (8060.45R.5000)		Diesel		5861	105	143	01.91-09.15	■	■
100 E 15, 100 E 15 P (8060.45R.5001)		Diesel		5861	105	143	01.91-09.15	■	■
100 E 15, 100 E 15 P (8060.45R.5003)		Diesel		5861	105	143	01.91-09.15	■	■
100 E 15, 100 E 15 P (8060.45R.5005)		Diesel		5861	105	143	01.91-09.15	■	■
75 E 15, 75 E 15 P, 80 E 15 (8060.25R.4200 LTC)	-12/96	Diesel		5861	105	143	01.91-09.15	■	■
80 E 15, 80 E 15 P (8060.25R.4200 LTC)		Diesel		5861	105	143	01.91-09.15	■	■
95 E 15 W (8060.25R.4750)	-12/96	Diesel		5861	105	143	01.91-09.15	■	■
95 E 15 W (8060.25R.4755)	-12/96	Diesel		5861	105	143	01.91-09.15	■	■
95 E 15 W (8060.25R.4760)	-12/96	Diesel		5861	105	143	01.91-09.15	■	■
95 E 15 W (8060.25R.4764)	-12/96	Diesel		5861	105	143	01.91-09.15	■	■
95 E 15 W (8060.45R.5050)	-12/96	Diesel		5861	105	143	01.91-09.15	■	■
95 E 15 W (8060.45R.5051)	-12/96	Diesel		5861	105	143	01.91-09.15	■	■
100 E 18, 100 E 18 P (8060.25V.4000)		Diesel		5861	130	177	01.91-09.15	■	■
80 E 18, 80 E 18 P, 18 E 80 FP (8060.25V.4000)		Diesel		5861	130	177	01.91-09.15	■	■
80 E 18, 80 E 18 P, 18 E 80 FP (8060.25V.4000)		Diesel		5861	130	177	01.91-09.15	■	■
100 E 21, 100 E 21 P (8060.45.4100 TCA)		Diesel		5861	152	207	01.91-09.15	■	■
100 E 21, 100 E 21 P (8060.45.4180)		Diesel		5861	152	207	01.91-09.15	■	■
80 E 21, 80 E 21 P, 21 E 80 FP (8060.45.4100 TCA)		Diesel		5861	152	207	01.91-09.15	■	■
80 E 21, 80 E 21 P, 21 E 80 FP (8060.45.4180)		Diesel		5861	152	207	01.91-09.15	■	■
80E21, 80E21P, 80E21FP, 80EL21, 80EL21P (8060.45.4100 TCA)		Diesel		5861	152	207	01.91-09.15	■	■

# LISTA DE APLICACIONES - BUYERS GUIDE

80E21, 80E21P, 80E21FP, 80EL21, 80EL21P (8060.45.4180)		Diesel		5861	152	207	01.91-09.15	■	■
95 E 21 W (8060.45.4700)	-12/96	Diesel		5861	152	207	01.91-09.15	■	■
95 E 21 W (8060.45.4702)	-12/96	Diesel		5861	152	207	01.91-09.15	■	■
95 E 21 W (8060.45.4704)	-12/96	Diesel		5861	152	207	01.91-09.15	■	■
95 E 21 W (8060.45.4706)	-12/96	Diesel		5861	152	207	01.91-09.15	■	■
95 E 21 W (8060.45.4708)	-12/96	Diesel		5861	152	207	01.91-09.15	■	■
95 E 21 W (8060.45.5250)	-12/96	Diesel		5861	152	207	01.91-09.15	■	■
95 E 21 W (8060.45.5251)	-12/96	Diesel		5861	152	207	01.91-09.15	■	■
95 E 21 W (8060.45.5255)	-12/96	Diesel		5861	152	207	01.91-09.15	■	■
90 E 18 tector, 90 E 18 D tector, 90 E 18 DP tector (F4AE0681E)		Diesel		5883	130	177	09.00-09.15	■	■
100 E 18 tector, 100 E 18 P tector, 100 E 18 FP tector (F4AE0681D)		Diesel		5883	134	181	09.00-09.15	■	■
100 E 18 tector, 100 E 18 P tector, 100 E 18 FP tector (F4AE0681E)		Diesel		5883	134	181	09.00-09.15	■	■
100 E 18 W tector, 100 E 18 WS tector (F4AE0681E)		Diesel		5883	134	181	09.00-09.15	■	■
100 E 18 W tector, 100 E 18 WS tector (F4AE3681C)		Diesel		5883	134	181	09.00-09.15	■	■
80 E 18 tector, 80 E 18 D tector, 80 E 18 DP tector (F4AE0681D)		Diesel		5883	134	181	09.00-09.15	■	■
80 E 18 tector, 80 E 18 D tector, 80 E 18 DP tector (F4AE0681E)		Diesel		5883	134	181	09.00-09.15	■	■
100 E 21, 100 E 21 DP tector, 100 E 22 tector (F4AE0681D)		Diesel		5883	154	209	09.00-09.15	■	■
100 E 21, 100 E 21 DP tector, 100 E 22 tector (F4AE3681B)		Diesel		5883	154	209	09.00-09.15	■	■
100 E 21 W tector, 100 E 21 WS tector (F4AE0681D)		Diesel		5883	154	209	09.00-09.15	■	■
80 E 21, 80 E 21 D tector, 80 E 21 DP tector, 80 E 22 tector (F4AE0681D)		Diesel		5883	154	209	09.00-09.15	■	■
80 E 21, 80 E 21 D tector, 80 E 21 DP tector, 80 E 22 tector (F4AE3681B)		Diesel		5883	154	209	09.00-09.15	■	■
90 E 21, 90 E 21 D tector, 90 E 21 DP tector, 90 E 22 tector (F4AE0681D)		Diesel		5883	154	209	09.00-09.15	■	■
90 E 21, 90 E 21 D tector, 90 E 21 DP tector, 90 E 22 tector (F4AE3681B)		Diesel		5883	154	209	09.00-09.15	■	■
<b>EuroCargo I-III 01.91-09.15</b>					<b>Truck Tractor</b>				
180 E 21 T (8060.45.4100 TCA)		Diesel		5861	152	207	01.91-09.15	■	■
<b>Zeta 01.79-12.92</b>					<b>Dump Truck</b>				
65-12 H (8040.25.200)		Diesel		3908	85	116	01.87-03.91	■	
79-12 H (8040.25.200)		Diesel		3908	85	116	01.87-03.91	■	
79-12 H (8040.25.220)		Diesel		3908	85	116	01.87-03.91	■	
109-14 H (8060.05.289)		Diesel		5861	101	137	11.85-03.91	■	
79-14 H (8060.05.280)	01/87-	Diesel		5861	101	137	12.85-03.91	■	
79-14 H (8060.05.280)	01/87-	Diesel		5861	101	137	12.85-03.91	■	
95-14 H (8060.04.669)		Diesel		5861	101	137	11.85-03.91	■	
<b>Zeta 01.79-12.92</b>					<b>Estate Van</b>				
60-11 V (8040.25.230 R)		Diesel		3908	74	101	01.87-03.91	■	
65-12 V (8040.25.200)		Diesel		3908	85	116	01.87-03.91	■	
79-12 V (8040.25.200)		Diesel		3908	85	116	01.87-03.91	■	
79-12 V (8040.25.220)		Diesel		3908	85	116	01.87-03.91	■	
79-12 V (8040.25.200)		Diesel		3908	85	116	01.87-03.91	■	
79-12 V (8040.25.220)		Diesel		3908	85	116	01.87-03.91	■	
79-14 V (8060.05.280)	01/87-	Diesel		5861	101	137	12.85-03.91	■	
79-14 V (8060.05.280)	01/87-	Diesel		5861	101	137	12.85-03.91	■	

# LISTA DE APLICACIONES - BUYERS GUIDE

Zeta 01.79-12.92					Platform/Chassis			
65-9 (8040.05.230)		Diesel		3908	65	88	01.87-03.91	■
60-11 (8040.25.230 R)		Diesel		3908	74	101	01.87-03.91	■
65-12 (8040.25.200)		Diesel		3908	85	116	01.87-03.91	■
79-12 (8040.25.200)		Diesel		3908	85	116	01.87-03.91	■
79-12 (8040.25.220)		Diesel		3908	85	116	01.87-03.91	■
79-12 (8040.25.200)		Diesel		3908	85	116	01.87-03.91	■
79-12 (8040.25.220)		Diesel		3908	85	116	01.87-03.91	■
109-14 (8060.05.289)		Diesel		5861	101	137	11.85-03.91	■
79-14 (8060.05.280)	01/87-	Diesel		5861	101	137	12.85-03.91	■
79-14 (8060.05.280)	01/87-	Diesel		5861	101	137	12.85-03.91	■
95-14 (8060.04.669)		Diesel		5861	101	137	11.85-03.91	■