

# LISTA DE APLICACIONES - BUYERS GUIDE


## 610256 E C



8 424073 088468

Weight: 56

O.E.M.	MAKE
190 8407	IVECO
500054528	-



## 610256 E C



295 mm.

WVA
29030
29067
29121
29122
MAKE
IVECO



Trac.	CC	Kw	CV		
					Front / Rear

### IVECO

#### DAILY II 01.89-05.99

					Bus (Minibus-M2-Segment)				
A 40-10 (95719111, 95719131, 95719311, 95719315,... (8140.23)	Diesel	RWD	2798	76	103	09.96-05.99	■	■	

#### DAILY II 01.89-05.99

					Dump Truck (Volquete-N2 Segment)				
35-8 K (14930304, 14931104, 14931111, 14931115, 14931204,... (8140.63)	-12/98	Diesel	RWD	2798	62	84	09.98-05.99	■	■
35-10 K (15030111, 15030211, 15030311, 15031111,... (8140.23)		Diesel	RWD	2798	76	103	01.97-05.99	■	■

#### DAILY II 01.89-05.99

					Platform/Chassis (LCVs-N1 Segment)				
30-8 (12910211, 12911111, 12911112, 12911117, 12911131,... (8140.07)	01/96-	Diesel	RWD	2499	55	75	01.92-08.98	■	■
30-8 (12910211, 12911111, 12911112, 12911117, 12911131,...	01/96-	Diesel	RWD	2499	55	75	01.92-08.98	■	■
30-8 (10011131, 10011132, 10011231, 10011232, 10011237,... (8140.67F.)	01/96-	Diesel	RWD	2499	60	82	01.92-08.98	■	■
30-8 (12910211, 12911111, 12911112, 12911117, 12911131,... (8140.67F.)	01/96-	Diesel	RWD	2499	60	82	01.92-08.98	■	■
30-8 (12910211, 12911111, 12911112, 12911117, 12911131,...	01/96-	Diesel	RWD	2499	60	82	01.92-08.98	■	■
35-8 (14930304, 14931104, 14931111, 14931115, 14931204,... (8140.63)	-12/98	Diesel	RWD	2798	62	84	09.98-05.99	■	■
49-10 (15050304, 15050404, 15050411, 15051204, 15051211,... (8140.23)		Diesel	RWD	2798	76	103	05.96-05.99	■	■
35-12 K (15130311, 15130411, 15131111, 15131204,... (8140.43.)		Diesel	RWD	2798	90	122	09.96-08.98	■	■
49-12 (15150211, 15150311, 15150404, 15150411, 15151204,... (8140.43.)		Diesel	RWD	2798	90	122	05.96-05.99	■	■
59-12 (15170211, 15170304, 15170311, 15170504, 15170511,... (8140.43.)		Diesel	RWD	2798	90	122	05.96-05.99	■	■

# LISTA DE APLICACIONES - BUYERS GUIDE

DAILY II 01.89-08.09					Van (LCVs-N1 Segment)				
30-8 (12914111, 12914112, 12914117, 12914131, 12914137,... (8140.07)	01/96-	Diesel	RWD	2499	55	75	01.89-08.98	■	■
30-8 (12914111, 12914112, 12914117, 12914131, 12914137,... (8140.07)	01/96-	Diesel	RWD	2499	55	75	01.89-08.98	■	■
30-8	01/96-	Diesel	RWD	2499	60	82	01.89-08.98	■	■
30-8 (12914111, 12914112, 12914117, 12914131, 12914137,... (8140.67F.)	01/96-	Diesel	RWD	2499	60	82	01.89-08.98	■	■
30-8 (14914111, 14914117, 14914211, 14914217, 14915111,... (8140.67F.)	01/95-	Diesel	RWD	2499	60	82	01.89-08.98	■	■
35-8 (14934104, 14934111, 14934204, 14934205, 14934211,... (8140.63)	-12/98	Diesel	RWD	2798	62	84	09.98-05.99	■	■
2.8 D		Diesel	RWD	2798	76	103	06.00-05.07	■	■
40-10 4x4 (15214104, 15214111, 15214117, 15215111) (8140.23)		Diesel	4WD	2798	76	103	01.97-05.99	■	■
2.8 D HM 4180		Diesel	RWD	2798	90	122	06.00-07.07	■	■
49-12 V (15154204, 15154211, 15154215, 15154217,... (8140.43.)		Diesel	RWD	2798	90	122	05.96-05.99	■	■
59-12 V (15174404, 15174411, 15174415, 15174417) (8140.43.)		Diesel	RWD	2798	90	122	05.96-05.99	■	■
DAILY III 03.98-10.09					Platform/Chassis (LCVs-N1 Segment)				
29 L 10 (ALJAV1A1, ALJA41AA, ALJA41A1, AHJA64A1,... (F1AE0481A)		Diesel	RWD	2287	70	95	09.02-04.06	■	■
35 C 10 V , 35 S 10 V (AMJA14A1, AMJA64A1, AMJA65A1,... (F1AE0481A)		Diesel	RWD	2287	70	95	09.02-04.06	■	■
40 C 10 (AEJB14A1) (F1AE0481A)		Diesel	RWD	2287	70	95	09.02-04.06	■	■
29 L 12 (ALKA41A1, AHKA64A1, ALLA51A1) (F1AE0481B)		Diesel	RWD	2287	85	116	09.02-04.06	■	■
35 C 12 , 35 S 12 (AEKA14A1, AEKA14AA, AEKA64A1,... (F1AE0481B)		Diesel	RWD	2287	85	116	09.02-04.06	■	■
29 L 14 (AHRA11C1B1, AHRA14C1B1, AHRA64C1B1) (F1AE0481M)		Diesel	RWD	2287	100	136	11.05-04.06	■	
35 C 14, 35 S 14 (F1AE0481M)		Diesel	RWD	2287	100	136	01.05-04.06	■	■
29 L 9 (8140.63)		Diesel	RWD	2798	62	84	05.99-04.06	■	■
35 S 9,35 C 9 (8140.63)		Diesel	RWD	2798	62	84	05.99-04.06	■	■
29 L 9 (8140.43R)		Diesel	RWD	2798	66	90	11.01-04.06	■	
29 L 11 (8140.43B)		Diesel	RWD	2798	78	105	05.99-04.06	■	■
29 L 11 (8140.43C)		Diesel	RWD	2798	78	105	05.99-04.06	■	■
35 S 11,35 C 11 (A2FC13AA, A6FBU4AB, A2NB14A1, A2ND13A1,... (8140.43B)		Diesel	RWD	2798	78	106	05.99-04.06	■	■
35 S 11,35 C 11 (A2FC13AA, A6FBU4AB, A2NB14A1, A2ND13A1,... (8140.43C)		Diesel	RWD	2798	78	106	05.99-04.06	■	■
50 C 11 (8140.43B)		Diesel	RWD	2798	78	106	05.99-04.06	■	■
50 C 11 (8140.43C)		Diesel	RWD	2798	78	106	05.99-04.06	■	■
29 L 13 (8140.43S)		Diesel	RWD	2798	92	125	11.01-04.06	■	■
35 S 13,35 C 13 (8140.43S)		Diesel	RWD	2798	92	125	05.99-04.06	■	■
40 C 13 (8140.43S)		Diesel	RWD	2798	92	125	05.99-04.06	■	■
50 C 13 (8140.43S)		Diesel	RWD	2798	92	125	05.99-04.06	■	■
65 C 13 (8140.43.K)		Diesel	RWD	2798	103	140	07.99-04.06	■	■
35C15 (8140.43N)		Diesel	RWD	2798	107	146	11.01-04.06	■	■
40C15 (8140.43N)		Diesel	RWD	2798	107	146	11.01-04.06	■	■
50C15 (8140.43N)		Diesel	RWD	2798	107	146	01.01-04.06	■	■
65C15 (8140.43N)		Diesel	RWD	2798	107	146	11.01-04.06		■
35 C 14 (F1CE0481A)		Diesel	RWD	2998	100	136	09.04-04.06	■	■
35 C 14 (F1CE0481E)		Diesel	RWD	2998	100	136	09.04-04.06	■	■
40 C 14 (F1CE0481A)		Diesel	RWD	2998	100	136	09.04-04.06	■	■
50 C 14 (F1CE0481A)		Diesel	RWD	2998	100	136	09.04-04.06	■	■
50 C 14 (F1CE0481E)		Diesel	RWD	2998	100	136	09.04-04.06	■	■
65 C 14 (F1CE0481A)		Diesel	RWD	2998	100	136	09.04-04.06	■	■

# LISTA DE APLICACIONES - BUYERS GUIDE

65 C 14 (F1CE0481E)		Diesel	RWD	2998	100	136	09.04-04.06	■	■
35 C 17, 35 S 17 (F1CE0481B)		Diesel	RWD	2998	122	166	01.05-04.06	■	■
40 C 17, 40 S 17 (F1CE0481B)		Diesel	RWD	2998	122	166	01.05-04.06	■	■
50 C 17 (F1CE0481B)		Diesel	RWD	2998	122	166	09.04-04.06	■	■
65 C 17 (F1CE0481B)		Diesel	RWD	2998	122	166	09.04-04.06	■	■
50 C 11 Natural Power (CNG) (8149.03)		CNG	RWD	2798	78	106	05.99-04.06	■	■
<b>DAILY III 05.99-10.09</b>					<b>Van (LCVs-N1 Segment)</b>				
29 L 10 V (ALJA43A2, ALJA42A2, ALJA41A2) (F1AE0481A)	-12/06	Diesel	RWD	2287	70	95	09.02-07.07	■	■
35 S 10 (ANJA41A1, ANJA42A2, ANJA42AB, ANJA43A, ANJAV1A,... (F1AE0481A)	-12/06	Diesel	RWD	2287	70	95	09.02-07.07	■	■
29 L 12 V (ALKA41A2, ALLA52A2, ALKA42A2) (F1AE0481B)	-12/06	Diesel	RWD	2287	85	116	09.02-07.07	■	■
35 C 12 V, 35 S 12 V (AGKA43A2, AGKB43A2, AGKB46A2,... (F1AE0481B)	-12/06	Diesel	RWD	2287	85	116	09.02-07.07	■	■
29L14 (F1AE0481M)		Diesel	RWD	2287	100	136	01.05-04.06	■	
35 C 14, 35 S 14 (F1AE0481M)		Diesel	RWD	2287	100	136	01.05-04.06	■	■
29 L 9 V (8140.63)	-12/06	Diesel	RWD	2798	62	84	05.99-07.07	■	■
35 S 9 V, 35 C 9 V (8140.63)	-12/06	Diesel	RWD	2798	62	84	05.99-07.07	■	■
29 L 9 V (8140.43R)		Diesel	RWD	2798	66	90	11.01-04.06	■	
35 S 9 V (8140.43R)		Diesel	RWD	2798	66	90	11.01-04.06	■	
29 L 11 V (8140.43B)		Diesel	RWD	2798	78	106	05.99-07.07	■	
29 L 11 V (8140.43C)		Diesel	RWD	2798	78	106	05.99-07.07	■	
35 S 11 V, 35 C 11 V (8140.43B)	-12/06	Diesel	RWD	2798	78	106	05.99-07.07	■	■
35 S 11 V, 35 C 11 V (8140.43C)	-12/06	Diesel	RWD	2798	78	106	05.99-07.07	■	■
50 C 11 (8140.43B)	-12/06	Diesel	RWD	2798	78	106	05.99-07.07	■	■
50 C 11 (8140.43C)	-12/06	Diesel	RWD	2798	78	106	05.99-07.07	■	■
29 L 13 (8140.43S)	-12/06	Diesel	RWD	2798	92	125	05.01-07.07	■	■
35 S 13 V, 35 C 13 V (8140.43S)	-12/06	Diesel	RWD	2798	92	125	05.99-07.07	■	■
40 C 13 (8140.43S)		Diesel	RWD	2798	92	125	05.99-04.06	■	■
50 C 13 (8140.43S)	-12/06	Diesel	RWD	2798	92	125	05.99-07.07	■	■
35 S 15 V, 35 C 15 V (A6HCV3B2, A6HBV4B2, A6HC41B2,... (8140.43N)	-12/06	Diesel	RWD	2798	107	146	11.02-07.07	■	■
40C15 (8140.43N)		Diesel	RWD	2798	107	146	11.01-04.06	■	■
50C15 (8140.43N)		Diesel	RWD	2798	107	146	01.01-04.06	■	■
65C15 (8140.43N)		Diesel	RWD	2798	107	146	11.01-04.06	■	■
35 C 14 (F1CE0481A)		Diesel	RWD	2998	100	136	09.04-04.06	■	■
35 C 14 (F1CE0481E)		Diesel	RWD	2998	100	136	09.04-04.06	■	■
40 C 14 (F1CE0481A)		Diesel	RWD	2998	100	136	09.04-04.06	■	■
45 C 14 (F1CE0481A)		Diesel	RWD	2998	100	136	07.99-04.06	■	■
50 C 14 (F1CE0481A)		Diesel	RWD	2998	100	136	09.04-04.06	■	■
50 C 14 (F1CE0481E)		Diesel	RWD	2998	100	136	09.04-04.06	■	■
65 C 14 (F1CE0481A)		Diesel	RWD	2998	100	136	09.04-04.06	■	■
65 C 14 (F1CE0481E)		Diesel	RWD	2998	100	136	09.04-04.06	■	■
35 C 17, 35 S 17 (F1CE0481B)		Diesel	RWD	2998	122	166	01.05-04.06	■	■
40 C 17, 40 S 17 (F1CE0481B)		Diesel	RWD	2998	122	166	07.99-12.06	■	■
50 C 17 (F1CE0481B)		Diesel	RWD	2998	122	166	09.04-04.06	■	■
65 C 17 (F1CE0481B)		Diesel	RWD	2998	122	166	09.04-04.06	■	■
<b>Dumper 01.91-</b>									
-	01/99-	Diesel					01.91-	■	■
<b>EuroCargo I-III 01.91-09.15</b>					<b>Dump Truck</b>				
65 E 12 K (8040.25X.4000)	01/97-	Diesel		3908	85	116	01.91-09.15	■	■
75 E 12 K (8040.25X.4000)		Diesel		3908	85	116	01.91-09.15	■	■

# LISTA DE APLICACIONES - BUYERS GUIDE

65 E 14 K (8040.45.4000)	01/97-	Diesel		3908	100	136	01.91-09.15	■	■
75 E 14 K (8040.45.4000)	-12/07	Diesel		3908	100	136	01.91-09.15	■	■
75 E 14 K (8040.45.4180)	-12/07	Diesel		3908	100	136	01.91-09.15	■	■
75 E 14 K tector (F4AE3481C)	-12/08	Diesel		3922	103	140	09.06-09.15	■	■
65 E 15 K tector (F4AE0481C)		Diesel		3922	110	149	09.00-09.15	■	■
75 E 15 K tector (F4AE0481C)		Diesel		3922	110	149	09.00-09.15	■	■
75 E 16 K tector (F4AE3481D)	-12/08	Diesel		3922	118	160	09.06-09.15	■	■
100 E 17 K tector, 100 E 17 DK tector (F4AE0481A)		Diesel		3922	125	170	09.00-09.15	■	■
75 E 17 K, 75 E 18 K tector (F4AE0481A)		Diesel		3922	125	170	09.00-09.15	■	■
75 E 17 K, 75 E 18 K tector (F4AE3481B)		Diesel		3922	125	170	09.00-09.15	■	■
80 E 17 K, 80 E 17 DK tector, 80 E 18 K tector (F4AE0481A)		Diesel		3922	125	170	09.00-09.15	■	■
80 E 17 K, 80 E 17 DK tector, 80 E 18 K tector (F4AE3481B)		Diesel		3922	125	170	09.00-09.15	■	■
90 E 17 K tector, 90 E 17 DK tector (F4AE0481A)		Diesel		3922	125	170	09.00-09.15	■	■
80 E 18 K tector (F4AE3481B)		Diesel		3922	130	177	09.06-09.15	■	■
100 E 15 K (8060.25R.4200 LTC)		Diesel		5861	105	143	01.91-09.15	■	■
75 E 15 K (8060.25R.4200 LTC)	01/97-	Diesel		5861	105	143	01.91-09.15	■	■
80 E 15 K (8060.25R.4200 LTC)		Diesel		5861	105	143	01.91-09.15	■	■
80 E 15 K (8060.25R.4200 LTC)		Diesel		5861	105	143	01.91-09.15	■	■
100 E 18 K (8060.25V.4000)		Diesel		5861	130	177	01.91-09.15	■	■
80 E 18 K (8060.25V.4000)		Diesel		5861	130	177	01.91-09.15	■	■
80 E 18 K (8060.25V.4000)		Diesel		5861	130	177	01.91-09.15	■	■
100 E 18 K tector, 100 E 18 DK tector (F4AE0681E)		Diesel		5883	134	181	09.00-09.15	■	■
120 E 18 K tector, 120 E 18 DK tector (F4AE0681E)		Diesel		5883	134	181	09.00-09.15	■	■
75 E 18 K tector (F4AE0681E)	-12/08	Diesel		5883	134	181	09.00-09.15	■	■
80 E 18 K tector, 80 E 18 DK tector (F4AE0681E)		Diesel		5883	134	181	09.00-09.15	■	■
90 E 18 K tector, 90 E 18 DK tector (F4AE0681E)		Diesel		5883	134	181	09.00-09.15	■	■
100 E 21 K tector, 100 E 21 DK tector (F4AE0681D)		Diesel		5883	154	209	09.00-09.15	■	■
180 E 21 K tector (F4AE0681D)		Diesel		5883	154	209	09.00-09.15	■	■
80 E 21 K, 80 E 21 DK tector, 80 E 22 K tector (F4AE0681D)		Diesel		5883	154	209	09.00-09.15	■	■
80 E 21 K, 80 E 21 DK tector, 80 E 22 K tector (F4AE3681B)		Diesel		5883	154	209	09.00-09.15	■	■
90 E 21 K tector, 90 E 21 DK tector (F4AE0681D)		Diesel		5883	154	209	09.00-09.15	■	■
120 E 24 K tector, 120 E 24 DK tector (F4AE0681B)		Diesel		5883	176	240	09.00-09.15	■	■
120 E 28 K tector (F4AE0681A)		Diesel		5883	202	275	09.00-09.15	■	■
120 E 28 K tector (F4AE3681E)		Diesel		5883	202	275	09.00-09.15	■	■
<b>EuroCargo I-III 01.91-09.15</b>					<b>Platform/Chassis</b>				
65 E 12, 65 E 12 P (8040.25X.4000)	01/97-	Diesel		3908	85	116	01.91-09.15	■	■
75 E 12, 75 E 12 P (8040.25X.4000)	01/97-	Diesel		3908	85	116	01.91-09.15	■	■
65 E 14, 65 E 14 P (8040.45.4000)	01/97-	Diesel		3908	100	136	01.91-09.15	■	■
75 E 14, 75 E 14 P (8040.45.4000)	01/97-	Diesel		3908	100	136	01.91-09.15	■	■
75 E 14, 75 E 14 P (8040.45.4180)	01/97-	Diesel		3908	100	136	01.91-09.15	■	■
65 E 13 tector (F4AE0481D)		Diesel		3922	95	130	09.00-09.15	■	■
75 E 13 tector, 75 E 13 P tector (F4AE0481D)		Diesel		3922	95	130	09.00-09.15	■	■
75 E 14 tector, 75 E 14 P tector (F4AE3481C)	-12/08	Diesel		3922	103	140	09.06-09.15	■	■
65 E 15 tector, 65 E 15 P tector (F4AE0481C)		Diesel		3922	110	149	09.00-09.15	■	■
75 E 15 tector, 75 E 15 P tector (F4AE0481C)		Diesel		3922	110	149	09.00-09.15	■	■

# LISTA DE APLICACIONES - BUYERS GUIDE

80 EL 15 tector (F4AE0481C)		Diesel		3922	110	149	09.00-09.15	■	■
75 E 16 tector, 75 E 16 P tector (F4AE3481D)	-12/08	Diesel		3922	118	160	09.06-09.15	■	■
100 E 17, 100 E 17 DP tector, 100 E 18 tector (F4AE0481A)		Diesel		3922	125	170	09.00-09.15	■	■
100 E 17, 100 E 17 DP tector, 100 E 18 tector (F4AE3481B)		Diesel		3922	125	170	09.00-09.15	■	■
75 E 17, 75 E 17 P, 75 E 18 tector (F4AE0481A)		Diesel		3922	125	170	09.00-09.15	■	■
75 E 17, 75 E 17 P, 75 E 18 tector (F4AE3481B)		Diesel		3922	125	170	09.00-09.15	■	■
80 E 17, 80 E 17 D tector, 80 E 17 DP tector, 80 E 18 tector (F4AE0481A)		Diesel		3922	125	170	09.00-09.15	■	■
80 E 17, 80 E 17 D tector, 80 E 17 DP tector, 80 E 18 tector (F4AE3481B)		Diesel		3922	125	170	09.00-09.15	■	■
90 E 17, 90 E 17D tector, 90 E 17 DP tector, 90 E 18 tector (F4AE0481A)		Diesel		3922	125	170	09.00-09.15	■	■
90 E 17, 90 E 17D tector, 90 E 17 DP tector, 90 E 18 tector (F4AE3481B)		Diesel		3922	125	170	09.00-09.15	■	■
80 E 18 tector, 80 E 18 P tector, 80 E 18 FP tector (F4AE3481B)		Diesel		3922	130	177	09.06-09.15	■	■
80 E 18 tector, 80 E 18 P tector, 80 E 18 FP tector (F4AE3481B)		Diesel		3922	130	177	09.06-09.15	■	■
80 EL 18 tector, 80 EL 18 P tector (F4AE3481B)		Diesel		3922	130	177	09.06-09.15	■	■
100 E 15, 100 E 15 P (8060.25R.4200 LTC)		Diesel		5861	105	143	01.91-09.15	■	■
100 E 15, 100 E 15 P (8060.45R.5000)		Diesel		5861	105	143	01.91-09.15	■	■
100 E 15, 100 E 15 P (8060.45R.5001)		Diesel		5861	105	143	01.91-09.15	■	■
100 E 15, 100 E 15 P (8060.45R.5003)		Diesel		5861	105	143	01.91-09.15	■	■
100 E 15, 100 E 15 P (8060.45R.5005)		Diesel		5861	105	143	01.91-09.15	■	■
75 E 15, 75 E 15 P, 80 E 15 (8060.25R.4200 LTC)	01/97-	Diesel		5861	105	143	01.91-09.15	■	■
80 E 15, 80 E 15 P (8060.25R.4200 LTC)		Diesel		5861	105	143	01.91-09.15	■	■
95 E 15 W (8060.25R.4750)	01/97-	Diesel		5861	105	143	01.91-09.15	■	■
95 E 15 W (8060.25R.4755)	01/97-	Diesel		5861	105	143	01.91-09.15	■	■
95 E 15 W (8060.25R.4760)	01/97-	Diesel		5861	105	143	01.91-09.15	■	■
95 E 15 W (8060.25R.4764)	01/97-	Diesel		5861	105	143	01.91-09.15	■	■
95 E 15 W (8060.45R.5050)	01/97-	Diesel		5861	105	143	01.91-09.15	■	■
95 E 15 W (8060.45R.5051)	01/97-	Diesel		5861	105	143	01.91-09.15	■	■
100 E 18, 100 E 18 P (8060.25V.4000)		Diesel		5861	130	177	01.91-09.15	■	■
80 E 18, 80 E 18 P, 18 E 80 FP (8060.25V.4000)		Diesel		5861	130	177	01.91-09.15	■	■
80 E 18, 80 E 18 P, 18 E 80 FP (8060.25V.4000)		Diesel		5861	130	177	01.91-09.15	■	■
100 E 21, 100 E 21 P (8060.45.4100 TCA)		Diesel		5861	152	207	01.91-09.15	■	■
100 E 21, 100 E 21 P (8060.45.4180)		Diesel		5861	152	207	01.91-09.15	■	■
80 E 21, 80 E 21 P, 21 E 80 FP (8060.45.4100 TCA)		Diesel		5861	152	207	01.91-09.15	■	■
80 E 21, 80 E 21 P, 21 E 80 FP (8060.45.4180)		Diesel		5861	152	207	01.91-09.15	■	■
80E21, 80E21P, 80E21FP, 80EL21, 80EL21P (8060.45.4100 TCA)		Diesel		5861	152	207	01.91-09.15	■	■
80E21, 80E21P, 80E21FP, 80EL21, 80EL21P (8060.45.4180)		Diesel		5861	152	207	01.91-09.15	■	■
95 E 21 W (8060.45.4700)	01/97-	Diesel		5861	152	207	01.91-09.15	■	■
95 E 21 W (8060.45.4702)	01/97-	Diesel		5861	152	207	01.91-09.15	■	■
95 E 21 W (8060.45.4704)	01/97-	Diesel		5861	152	207	01.91-09.15	■	■
95 E 21 W (8060.45.4706)	01/97-	Diesel		5861	152	207	01.91-09.15	■	■
95 E 21 W (8060.45.4708)	01/97-	Diesel		5861	152	207	01.91-09.15	■	■
95 E 21 W (8060.45.5250)	01/97-	Diesel		5861	152	207	01.91-09.15	■	■
95 E 21 W (8060.45.5251)	01/97-	Diesel		5861	152	207	01.91-09.15	■	■
95 E 21 W (8060.45.5255)	01/97-	Diesel		5861	152	207	01.91-09.15	■	■

# LISTA DE APLICACIONES - BUYERS GUIDE

90 E 18 tector, 90 E 18 D tector, 90 E 18 DP tector (F4AE0681E)		Diesel		5883	130	177	09.00-09.15	■	■
100 E 18 tector, 100 E 18 P tector, 100 E 18 FP tector (F4AE0681D)		Diesel		5883	134	181	09.00-09.15	■	■
100 E 18 tector, 100 E 18 P tector, 100 E 18 FP tector (F4AE0681E)		Diesel		5883	134	181	09.00-09.15	■	■
100 E 18 W tector, 100 E 18 WS tector (F4AE0681E)		Diesel		5883	134	181	09.00-09.15	■	■
100 E 18 W tector, 100 E 18 WS tector (F4AE3681C)		Diesel		5883	134	181	09.00-09.15	■	■
120 E 18 tector, 120 E 18 D tector, 120 E 18 DP tector (F4AE0681D)		Diesel		5883	134	181	09.00-09.15	■	■
120 E 18 tector, 120 E 18 D tector, 120 E 18 DP tector (F4AE0681E)		Diesel		5883	134	181	09.00-09.15	■	■
75 E 18 tector, 75 E 18 P tector (F4AE0681D)	-12/08	Diesel		5883	134	181	09.00-09.15	■	■
75 E 18 tector, 75 E 18 P tector (F4AE0681E)	-12/08	Diesel		5883	134	181	09.00-09.15	■	■
80 E 18 tector, 80 E 18 D tector, 80 E 18 DP tector (F4AE0681D)		Diesel		5883	134	181	09.00-09.15	■	■
80 E 18 tector, 80 E 18 D tector, 80 E 18 DP tector (F4AE0681E)		Diesel		5883	134	181	09.00-09.15	■	■
100 E 21, 100 E 21 DP tector, 100 E 22 tector (F4AE0681D)		Diesel		5883	154	209	09.00-09.15	■	■
100 E 21, 100 E 21 DP tector, 100 E 22 tector (F4AE3681B)		Diesel		5883	154	209	09.00-09.15	■	■
100 E 21 W tector, 100 E 21 WS tector (F4AE0681D)		Diesel		5883	154	209	09.00-09.15	■	■
80 E 21, 80 E 21 D tector, 80 E 21 DP tector, 80 E 22 tector (F4AE0681D)		Diesel		5883	154	209	09.00-09.15	■	■
80 E 21, 80 E 21 D tector, 80 E 21 DP tector, 80 E 22 tector (F4AE3681B)		Diesel		5883	154	209	09.00-09.15	■	■
90 E 21, 90 E 21 D tector, 90 E 21 DP tector, 90 E 22 tector (F4AE0681D)		Diesel		5883	154	209	09.00-09.15	■	■
90 E 21, 90 E 21 D tector, 90 E 21 DP tector, 90 E 22 tector (F4AE3681B)		Diesel		5883	154	209	09.00-09.15	■	■
120 E 24, 120 E 24 DP tector, 120 E 25 FP tector (F4AE0681B)		Diesel		5883	176	240	09.00-09.15	■	■
120 E 24, 120 E 24 DP tector, 120 E 25 FP tector (F4AE3681D)		Diesel		5883	176	240	09.00-09.15	■	■
120 E 28 tector, 120 E 28 P tector, 120 E 28 FP tector (F4AE0681A)		Diesel		5883	202	275	09.00-09.15	■	■
120 E 28 tector, 120 E 28 P tector, 120 E 28 FP tector (F4AE3681E)		Diesel		5883	202	275	09.00-09.15	■	■
<b>EuroCargo I-III 01.91-09.15</b>					<b>Truck Tractor</b>				
180 E 21 T (8060.45.4100 TCA)		Diesel		5861	152	207	01.91-09.15	■	■
<b>Zeta 01.79-12.92</b>					<b>Dump Truck</b>				
65-12 H (8040.25.200)		Diesel		3908	85	116	01.87-03.91	■	
79-12 H (8040.25.200)		Diesel		3908	85	116	01.87-03.91	■	
79-12 H (8040.25.220)		Diesel		3908	85	116	01.87-03.91	■	
109-14 H (8060.05.289)		Diesel		5861	101	137	11.85-03.91	■	
79-14 H (8060.05.280)	01/87-	Diesel		5861	101	137	12.85-03.91	■	
79-14 H (8060.05.280)	01/87-	Diesel		5861	101	137	12.85-03.91	■	
95-14 H (8060.04.669)		Diesel		5861	101	137	11.85-03.91	■	
<b>Zeta 01.79-12.92</b>					<b>Estate Van</b>				
60-11 V (8040.25.230 R)		Diesel		3908	74	101	01.87-03.91	■	
65-12 V (8040.25.200)		Diesel		3908	85	116	01.87-03.91	■	
79-12 V (8040.25.200)		Diesel		3908	85	116	01.87-03.91	■	
79-12 V (8040.25.220)		Diesel		3908	85	116	01.87-03.91	■	
79-12 V (8040.25.200)		Diesel		3908	85	116	01.87-03.91	■	
79-12 V (8040.25.220)		Diesel		3908	85	116	01.87-03.91	■	
79-14 V (8060.05.280)	01/87-	Diesel		5861	101	137	12.85-03.91	■	
79-14 V (8060.05.280)	01/87-	Diesel		5861	101	137	12.85-03.91	■	

# LISTA DE APLICACIONES - BUYERS GUIDE

Zeta 01.79-12.92					Platform/Chassis			
65-9 (8040.05.230)		Diesel		3908	65	88	01.87-03.91	■
60-11 (8040.25.230 R)		Diesel		3908	74	101	01.87-03.91	■
65-12 (8040.25.200)		Diesel		3908	85	116	01.87-03.91	■
79-12 (8040.25.200)		Diesel		3908	85	116	01.87-03.91	■
79-12 (8040.25.220)		Diesel		3908	85	116	01.87-03.91	■
79-12 (8040.25.200)		Diesel		3908	85	116	01.87-03.91	■
79-12 (8040.25.220)		Diesel		3908	85	116	01.87-03.91	■
109-14 (8060.05.289)		Diesel		5861	101	137	11.85-03.91	■
79-14 (8060.05.280)	01/87-	Diesel		5861	101	137	12.85-03.91	■
79-14 (8060.05.280)	01/87-	Diesel		5861	101	137	12.85-03.91	■
95-14 (8060.04.669)		Diesel		5861	101	137	11.85-03.91	■