

# LISTA DE APLICACIONES - BUYERS GUIDE


## 610428 E C



8 424073 096524

Weight: 120

O.E.M.	MAKE
3348 0087	MAN
81 50822 6014	MAN



## 610428 E C



295 mm.

**WVA**

29088

**MAKE**

MAN



Trac.	CC	Kw	CV
-------	----	----	----



Front / Rear

### MAN

#### L2000 06.93-

									<b>Bus</b>
10.150 FOC (D 0824 LFO)		Diesel		4580	114	155	02.95-01.96	■	■
8.150 FOC, 8.150 FOCL (D 0824 LFO)	01/96-	Diesel		4580	114	155	02.95-	■	■
10.220 FOC, 10.220 FOCL (D 0826 LFL03)	01/96-	Diesel		6871	162	220	02.95-	■	■
8.220 FOC, 8.220 FOCL (D 0826 LFL03)	01/96-	Diesel		6871	162	220	04.95-	■	■

#### L2000 06.93-

									<b>Dump Truck</b>
8.103 LK (D 0824 FL 01)	01/95-	Diesel		4580	75	102	10.93-06.96	■	
8.113 LK, L-KI, LRK, LR-KI, LRK-L, LK-L (D 0824 LFL 04)	01/96-	Diesel		4580	81	110	08.95-	■	
10.145 LK, L-KI, LRK, LR-KI, LRK-L, LK-L (LE140C) (D 0834 LFL 02)		Diesel		4580	103	140	09.00-	■	
8.145 LK, LRK, L-KI, LRK-L, LK-L, LR-KILK (LE140C) (D 0834 LFL 02)		Diesel		4580	103	140	09.00-	■	
9.145 LK, L-KI, LRK, LR-KI, LRK-L, LK-L (LE140C) (D 0834 LFL 02)		Diesel		4580	103	140	09.00-	■	
9.163 LK (D 0824 LFL 07)	01/96-	Diesel		4580	104	141	08.95-03.97	■	
10.153 LK (D 0824 LFL 01)	01/96-	Diesel		4580	114	155	10.93-06.96	■	
10.153 LK (D 0824 LFL 05)	01/96-	Diesel		4580	114	155	10.93-06.96	■	
10.163 LAEK, LAEK-L, LAERK, LAERK-L, LAK, LAK-L, LARK (D 0824 LFL 02)	01/96-	Diesel		4580	114	155	01.95-	■	
10.163 LAEK, LAEK-L, LAERK, LAERK-L, LAK, LAK-L, LARK (D 0824 LFL 06)	01/96-	Diesel		4580	114	155	01.95-	■	
10.163 LAEK, LAEK-L, LAERK, LAERK-L, LAK, LAK-L, LARK (D 0824 LFL 09)	01/96-	Diesel		4580	114	155	01.95-	■	
10.163 LK, L-KI, LRK, LR-KI, LRK-L, LK-L (D 0824 LFL 02)	01/96-	Diesel		4580	114	155	05.94-	■	
10.163 LK, L-KI, LRK, LR-KI, LRK-L, LK-L (D 0824 LFL 06)	01/96-	Diesel		4580	114	155	05.94-	■	

# LISTA DE APLICACIONES - BUYERS GUIDE

10.163 LK, L-KI, LRK, LR-KI, LRK-L, LK-L (D 0824 LFL 09)	01/96-	Diesel		4580	114	155	05.94-	■	
8.153 LAEK (D 0824 LFL 01)		Diesel		4580	114	155	01.95-09.96	■	
8.153 LAEK (D 0824 LFL 05)		Diesel		4580	114	155	01.95-09.96	■	
8.153 LK (D 0824 LFL 01)	01/95-	Diesel		4580	114	155	10.93-07.97	■	
8.153 LK (D 0824 LFL 05)	01/95-	Diesel		4580	114	155	10.93-07.97	■	
8.163 LK, L-KI, LRK, LR-KI, LRK-L, LK-L (D 0824 LFL 02)	01/96-	Diesel		4580	114	155	05.94-	■	
8.163 LK, L-KI, LRK, LR-KI, LRK-L, LK-L (D 0824 LFL 06)	01/96-	Diesel		4580	114	155	05.94-	■	
8.163 LK, L-KI, LRK, LR-KI, LRK-L, LK-L (D 0824 LFL 09)	01/96-	Diesel		4580	114	155	05.94-	■	
9.153 LK (D 0824 LFL 01)	01/96-	Diesel		4580	114	155	10.93-06.96	■	
9.153 LK (D 0824 LFL 05)	01/96-	Diesel		4580	114	155	10.93-06.96	■	
9.163 LK, L-KI, LRK, LR-KI, LRK-L, LK-L (D 0824 LFL 02)	01/96-	Diesel		4580	114	155	05.94-	■	
9.163 LK, L-KI, LRK, LR-KI, LRK-L, LK-L (D 0824 LFL 06)	01/96-	Diesel		4580	114	155	05.94-	■	
9.163 LK, L-KI, LRK, LR-KI, LRK-L, LK-L (D 0824 LFL 09)	01/96-	Diesel		4580	114	155	05.94-	■	
10.185 LAEK, LAEK-L, LAERK, LAERK-L, LAK, LAK-L, LARK (D 0834 LFL 03)		Diesel		4580	132	180	09.00-	■	
10.185 LK, L-KI, LRK, LR-KI, LRK-L, LK-L (LE180C) (D 0834 LFL 03)		Diesel		4580	132	180	09.00-	■	
8.185 LAEK, LAEK-L, LAERK, LAERK-L, LAK, LAK-L, LARK, LARK-L (D 0834 LFL 03)		Diesel		4580	132	180	09.00-	■	
8.185 LK, L-KI, LRK, LR-KI LRK-L, LK-L (LE180C) (D 0834 LFL 03)		Diesel		4580	132	180	09.00-	■	
9.185 LK, L-KI, LRK, LR-KI, LRK-L, LK-L (LE180C) (D 0834 LFL 03)		Diesel		4580	132	180	09.00-	■	
10.223 LK (D 0826 LFL02)	01/96-	Diesel		6871	162	220	10.93-06.96	■	
10.223 LK (D 0826 LFL06)	01/96-	Diesel		6871	162	220	10.93-06.96	■	
10.224 LAEK, LAEK-L, LAERK, LAERK-L, LAK, LAK-L, LARK (D 0826 LFL03)	01/96-	Diesel		6871	162	220	01.95-	■	
10.224 LK, L-KI, LRK, LR-KI, LRK-L, LK-L (D 0826 LFL03)	01/96-	Diesel		6871	162	220	05.94-	■	
10.225 LAEK, LAEK-L, LAERK, LAERK-L, LAK, LAK-L, LARK (D 0836 LFL 02)		Diesel		6871	162	220	09.00-	■	
10.225 LK, L-KI, LRK, LR-KI, LRK-L, LK-L (LE220C) (D 0836 LFL 02)		Diesel		6871	162	220	09.00-	■	
8.223 LK (D 0826 LFL02)	01/96-	Diesel		6871	162	220	10.93-06.96	■	
8.223 LK (D 0826 LFL06)	01/96-	Diesel		6871	162	220	10.93-06.96	■	
8.224 LAK, LAEK, LARK, LAERK (D 0826 LFL03)	01/96-	Diesel		6871	162	220	01.95-	■	
8.224 LK, LRK, L-KI, LR-KI (D 0826 LFL03)	01/96-	Diesel		6871	162	220	05.94-	■	
8.225 LAEK, LAEK-L, LAERK, LAERK-L, LAK, LAK-L, LARK, LARK-L (D 0836 LFL 02)		Diesel		6871	162	220	09.00-	■	
8.225 LK, L-KI, LRK, LR-KI, LRK-L, LK-L (LE220C) (D 0836 LFL 02)		Diesel		6871	162	220	09.00-	■	
9.223 LK (D 0826 LFL02)	01/96-	Diesel		6871	162	220	10.93-06.96	■	
9.223 LK (D 0826 LFL06)	01/96-	Diesel		6871	162	220	10.93-06.96	■	
9.224 LK, L-KI, LRK, LR-KI, LRK-L, LK-L (D 0826 LFL03)	01/96-	Diesel		6871	162	220	05.94-	■	
9.225 LK, L-KI, LRK, LR-KI, LRK-L, LK-L (LE220C) (D 0836 LFL 02)		Diesel		6871	162	220	09.00-	■	
<b>L2000 06.93-</b>					<b>Platform/Chassis</b>				
8.103 LC, 8.103 LLC (D 0824 FL 01)	01/96-	Diesel		4580	75	102	10.93-06.96	■	■
8.113 LC, 8.113 LLC (D 0824 LFL 04)	01/96-	Diesel		4580	81	110	08.95-	■	■
8.113 LC,8.113 LLC, LRC, LLRC(LE110C) (D 0824 LFL 08)		Diesel		4580	83	113	09.00-	■	■
10.145 LC,10.145 LLC, LRC, LLRC (LE140C) (D 0834 LFL 02)		Diesel		4580	103	140	09.00-	■	■
8.145 LC, LLC, LLRC, LRC (LE140C) (D 0834 LFL 02)		Diesel		4580	103	140	09.00-	■	■

# LISTA DE APLICACIONES - BUYERS GUIDE

9.145 LC,9.145 LLC, LRC, LLRC (LE140C) (D 0834 LFL 02)		Diesel		4580	103	140	09.00-	■	■
8.163 LAEC (D 0824 LFL 07)		Diesel		4580	104	141	08.95-03.97	■	
8.163 LC,8.163 LLC, LRC, LLRC, L-LF (D 0824 LFL 07)	01/96-	Diesel		4580	104	141	08.95-	■	■
9.163 LC (D 0824 LFL 07)	01/96-	Diesel		4580	104	141	08.95-03.97	■	■
10.153 LAEK (D 0824 LFL 01)	01/96-	Diesel		4580	114	155	10.93-06.96	■	
10.153 LAEK (D 0824 LFL 05)	01/96-	Diesel		4580	114	155	10.93-06.96	■	
10.153 LC,10.153 LLC (D 0824 LFL 01)	01/96-	Diesel		4580	114	155	10.93-06.96	■	■
10.153 LC,10.153 LLC (D 0824 LFL 05)	01/96-	Diesel		4580	114	155	10.93-06.96	■	■
10.163 LAC, LAEC, LARC, LAERC (D 0824 LFL 02)	01/96-	Diesel		4580	114	155	05.94-	■	
10.163 LAC, LAEC, LARC, LAERC (D 0824 LFL 06)	01/96-	Diesel		4580	114	155	05.94-	■	
10.163 LAC, LAEC, LARC, LAERC (D 0824 LFL 09)	01/96-	Diesel		4580	114	155	05.94-	■	
10.163 LC,10.163 LLC (D 0824 LFL 02)	01/96-	Diesel		4580	114	155	05.94-	■	■
10.163 LC,10.163 LLC (D 0824 LFL 06)	01/96-	Diesel		4580	114	155	05.94-	■	■
10.163 LC,10.163 LLC (D 0824 LFL 09)	01/96-	Diesel		4580	114	155	05.94-	■	■
10.163 LC,10.163 LLC, LRC, LLRC (LE160C) (D 0824 LFL 09)		Diesel		4580	114	155	09.00-	■	■
8.153 LAEC (D 0824 LFL 01)		Diesel		4580	114	155	01.95-06.96	■	
8.153 LAEC (D 0824 LFL 05)		Diesel		4580	114	155	01.95-06.96	■	
8.153 LC,8.153 LLC (D 0824 LFL 01)	01/96-	Diesel		4580	114	155	10.93-07.97	■	■
8.153 LC,8.153 LLC (D 0824 LFL 05)	01/96-	Diesel		4580	114	155	10.93-07.97	■	■
8.163 LAC, LAEC, LARC, LAERC, LA-LF, LAE-LF (D 0824 LFL 02)	-12/96	Diesel		4580	114	155	01.95-	■	
8.163 LAC, LAEC, LARC, LAERC, LA-LF, LAE-LF (D 0824 LFL 06)	-12/96	Diesel		4580	114	155	01.95-	■	
8.163 LAC, LAEC, LARC, LAERC, LA-LF, LAE-LF (D 0824 LFL 09)	-12/96	Diesel		4580	114	155	01.95-	■	
8.163 LC,8.163 LLC (D 0824 LFL 02)	01/96-	Diesel		4580	114	155	05.94-	■	■
8.163 LC,8.163 LLC (D 0824 LFL 06)	01/96-	Diesel		4580	114	155	05.94-	■	■
8.163 LC,8.163 LLC (D 0824 LFL 09)	01/96-	Diesel		4580	114	155	05.94-	■	■
8.163 LC, LLC, LLRC, LRC (LE160C) (D 0824 LFL 09)		Diesel		4580	114	155	09.00-	■	■
9.153 LC,9.153 LLC (D 0824 LFL 01)	-12/95	Diesel		4580	114	155	10.93-06.96	■	■
9.153 LC,9.153 LLC (D 0824 LFL 05)	-12/95	Diesel		4580	114	155	10.93-06.96	■	■
9.163 LC,9.163 LLC, LRC, LLRC (D 0824 LFL 02)	01/96-	Diesel		4580	114	155	05.94-	■	■
9.163 LC,9.163 LLC, LRC, LLRC (D 0824 LFL 06)	01/96-	Diesel		4580	114	155	05.94-	■	■
9.163 LC,9.163 LLC, LRC, LLRC (D 0824 LFL 09)	01/96-	Diesel		4580	114	155	05.94-	■	■
10.185 LAC, LAEC, LARC, LAERC, LA-LA (LE180C) (D 0834 LFL 03)		Diesel		4580	132	180	09.00-	■	
10.185 LC,10.185 LLC, LRC, LLRC (LE180C) (D 0834 LFL 03)		Diesel		4580	132	180	09.00-	■	■
12.185 LC, LLC (LE180C) (D 0834 LFL 03)	01/00-	Diesel		4580	132	180	09.99-	■	■
8.185 LAC, LAEC, LARC, LAERC, LA-LF, LAE-LF (LE180C) (D 0834 LFL 03)		Diesel		4580	132	180	09.00-	■	
8.185 LC, LLC, LRC, LLRC (LE180C) (D 0834 LFL 03)		Diesel		4580	132	180	09.00-	■	■
9.185 LC,9.185 LLC, LRC, LLRC (LE180C) (D 0834 LFL 03)		Diesel		4580	132	180	09.00-	■	■
10.223 LAEC (D 0826 LFL06)	01/96-	Diesel		6871	162	220	01.95-06.96	■	
10.223 LC,10.223 LLC (D 0826 LFL02)	01/96-	Diesel		6871	162	220	10.93-06.96	■	■
10.223 LC,10.223 LLC (D 0826 LFL06)	01/96-	Diesel		6871	162	220	10.93-06.96	■	■
10.224 LAC, LAEC, LARC, LAERC (D 0826 LFL03)	01/96-	Diesel		6871	162	220	01.95-	■	
10.224 LAC, LAEC, LARC, LAERC (D 0826 LFL10)	01/96-	Diesel		6871	162	220	01.95-	■	

# LISTA DE APLICACIONES - BUYERS GUIDE

10.224 LC,10.224 LLC, LRC, LLRC (D 0826 LFL03)	01/96-	Diesel		6871	162	220	05.94-	■	■
10.224 LC,10.224 LLC, LRC, LLRC (D 0826 LFL10)	01/96-	Diesel		6871	162	220	05.94-	■	■
10.225 LAC, LAEC, LARC, LAERC (LE220C) (D 0836 LFL 02)		Diesel		6871	162	220	09.00-	■	
10.225 LC, 10.225 LLC, LRC, LLRC (LE220C) (D 0836 LFL 02)		Diesel		6871	162	220	09.00-	■	■
12.225 LC, LLC (LE220C) (D 0836 LFL 02)	01/00-	Diesel		6871	162	220	09.99-	■	■
8.223 LAEC (D 0826 LFL06)		Diesel		6871	162	220	01.95-06.96	■	
8.223 LC,8.223 LLC (D 0826 LFL02)	01/96-	Diesel		6871	162	220	10.93-06.96	■	■
8.223 LC,8.223 LLC (D 0826 LFL06)	01/96-	Diesel		6871	162	220	10.93-06.96	■	■
8.224 LAC, LAEC, LARC, LAERC (D 0826 LFL03)		Diesel		6871	162	220	01.95-	■	
8.224 LC,8.224 LLC, LRC, LLRC (D 0826 LFL03)	01/96-	Diesel		6871	162	220	05.94-	■	■
8.225 LAC, LAEC, LARC, LAERC (LE220C) (D 0836 LFL 02)		Diesel		6871	162	220	09.00-	■	
8.225 LC,8.225 LLC, LRC, LLRC (LE220C) (D 0826 LFL10)		Diesel		6871	162	220	09.00-	■	■
8.225 LC,8.225 LLC, LRC, LLRC (LE220C) (D 0836 LFL 02)		Diesel		6871	162	220	09.00-	■	■
9.223 LC,9.223 LLC (D 0826 LFL02)	01/96-	Diesel		6871	162	220	10.93-06.96	■	■
9.223 LC,9.223 LLC (D 0826 LFL06)	01/96-	Diesel		6871	162	220	10.93-06.96	■	■
9.224 LC,9.224 LLC, LRC, LLRC (D 0826 LFL03)	01/96-	Diesel		6871	162	220	05.94-	■	■
9.225 LC,9.225 LLC, LRC, LLRC (LE220C) (D 0836 LFL 02)		Diesel		6871	162	220	09.00-	■	■
<b>L2000 06.93-</b>					<b>Truck Tractor</b>				
10.145 LLS, LLRS (LE140C) (D 0834 LFL 02)		Diesel		4580	103	140	09.00-	■	■
8.145 LLS, LLRS (LE140C) (D 0834 LFL 02)		Diesel		4580	103	140	09.00-	■	■
9.145 LLS, LLRS (LE140C) (D 0834 LFL 02)		Diesel		4580	103	140	09.00-	■	■
10.153 LLS (D 0824 LFL 01)	01/96-	Diesel		4580	114	155	10.93-06.96	■	■
10.153 LLS (D 0824 LFL 05)	01/96-	Diesel		4580	114	155	10.93-06.96	■	■
10.163 LLS, LLRS (D 0824 LFL 02)	01/96-	Diesel		4580	114	155	05.94-	■	■
10.163 LLS, LLRS (D 0824 LFL 06)	01/96-	Diesel		4580	114	155	05.94-	■	■
10.163 LLS, LLRS (D 0824 LFL 09)	01/96-	Diesel		4580	114	155	05.94-	■	■
8.153 LLS (D 0824 LFL 01)	01/95-	Diesel		4580	114	155	10.93-06.96	■	■
8.153 LLS (D 0824 LFL 05)	01/95-	Diesel		4580	114	155	10.93-06.96	■	■
8.163 LLS, LLRS (D 0824 LFL 02)	01/96-	Diesel		4580	114	155	05.94-	■	■
8.163 LLS, LLRS (D 0824 LFL 06)	01/96-	Diesel		4580	114	155	05.94-	■	■
8.163 LLS, LLRS (D 0824 LFL 09)	01/96-	Diesel		4580	114	155	05.94-	■	■
9.163 LLS, LLRS (D 0824 LFL 02)	01/96-	Diesel		4580	114	155	05.94-	■	■
9.163 LLS, LLRS (D 0824 LFL 06)	01/96-	Diesel		4580	114	155	05.94-	■	■
9.163 LLS, LLRS (D 0824 LFL 09)	01/96-	Diesel		4580	114	155	05.94-	■	■
10.185 LLS, LLRS (LE180C) (D 0834 LFL 03)		Diesel		4580	132	180	09.00-	■	■
8.185 LLS, LLRS (LE180C) (D 0834 LFL 03)		Diesel		4580	132	180	09.00-	■	■
9.185 LLS, LLRS (LE 180C) (D 0834 LFL 03)		Diesel		4580	132	180	09.00-	■	■
10.223 LLS (D 0826 LFL02)	01/95-	Diesel		6871	162	220	10.93-06.96	■	■
10.223 LLS (D 0826 LFL06)	01/95-	Diesel		6871	162	220	10.93-06.96	■	■
10.224 LLS, LLRS (D 0826 LFL03)	01/96-	Diesel		6871	162	220	05.94-	■	■
10.225 LLS, LLRS (LE220C) (D 0836 LFL 02)		Diesel		6871	162	220	09.00-	■	■
8.223 LLS (D 0826 LFL02)	-12/95	Diesel		6871	162	220	10.93-06.96	■	■
8.223 LLS (D 0826 LFL06)	-12/95	Diesel		6871	162	220	10.93-06.96	■	■
8.224 LLS, LLRS (D 0826 LFL03)	-12/95	Diesel		6871	162	220	05.94-	■	■
8.225 LLS, LLRS (LE220C) (D 0836 LFL 02)		Diesel		6871	162	220	09.00-	■	■
9.223 LLS (D 0826 LFL02)	01/96-	Diesel		6871	162	220	10.93-06.96	■	■

# LISTA DE APLICACIONES - BUYERS GUIDE

9.223 LLS (D 0826 LFL06)	01/96-	Diesel		6871	162	220	10.93-06.96	■	■
9.224 LLS, LLRS (D 0826 LFL03)	01/96-	Diesel		6871	162	220	05.94-	■	■
9.225 LLS, LLRS (LE220C) (D 0836 LFL 02)		Diesel		6871	162	220	09.00-	■	■
<b>M 2000 L 04.95-</b>					<b>Dump Truck</b>				
12.163 LK, LRK (D 0824 LFL 06)		Diesel		4580	114	155	08.95-	■	■
12.163 LK, LRK (D 0824 LFL 09)		Diesel		4580	114	155	08.95-	■	■
12.224, 12.225, LK, LRK (D 0826 LFL03)		Diesel		6871	162	220	08.95-	■	■
12.224, 12.225, LK, LRK (D 0826 LFL10)		Diesel		6871	162	220	08.95-	■	■
<b>M 2000 L 04.95-</b>					<b>Platform/Chassis</b>				
12.163 LC, LLC, LRC, LLRC (D 0824 LFL 06)		Diesel		4580	114	155	08.95-	■	■
12.163 LC, LLC, LRC, LLRC (D 0824 LFL 09)		Diesel		4580	114	155	08.95-	■	■
12.224 LC, LLC, LRC, LLRC (D 0826 LFL03)		Diesel		6871	162	220	08.95-	■	■
12.224 LC, LLC, LRC, LLRC (D 0826 LFL10)		Diesel		6871	162	220	08.95-	■	■
<b>SG 09.72-</b>					<b>Bus</b>				
SG 192	01/96-	Diesel					09.72-	■	■
<b>SL III 01.96-</b>									
SL 160		Diesel					01.96-	■	■
SL 750		Diesel					01.96-	■	■
<b>SÜ 10.75-</b>					<b>Bus</b>				
SÜ 210	01/96-	Diesel					10.75-	■	■
SÜ 230	01/96-	Diesel					10.75-	■	■