


LISTA DE APLICACIONES - BUYERS GUIDE

610474 E C



Weight: 76



610474 E C



635 mm.

O.E.M.	MAKE
34 35 6 762 252	BMW
34 35 6 789 439	BMW

WVA
23793
23916
23935
23968
24096
MAKE
BMW
BMW (BRILLIANCE)



	Trac.	CC	Kw	CV			Front / Rear
--	-------	----	----	----	--	--	--------------

BMW

1 Serie (E88) 12.07-12.13	Convertible (Compact car-C Segment)							
118 i (N46 B20 B)		Gasolina	RWD	1995	100	136	09.08-12.13	■
118 i (N43 B20 A)	-12/10	Gasolina	RWD	1995	105	143	03.08-10.13	■
120 i (N46 B20 B)		Gasolina	RWD	1995	115	156	03.08-12.13	■
120 i (N46 B20 C)		Gasolina	RWD	1995	115	156	03.08-12.13	■
120 i (N46 B20 E)		Gasolina	RWD	1995	115	156	03.08-12.13	■
120 i (N43 B20 A)	-12/10	Gasolina	RWD	1995	120	163	03.08-12.13	■
120 i (N43 B20 A)	-12/10	Gasolina	RWD	1995	125	170	12.07-10.13	■
125 i (N52 B30 A)	-12/10	Gasolina	RWD	2996	160	218	12.07-10.13	■
125 i (N52 B30 B)	-12/10	Gasolina	RWD	2996	160	218	12.07-10.13	■
125 i (N52 B30 BF)	-12/10	Gasolina	RWD	2996	160	218	12.07-10.13	■
128 i (N51 B30 A)		Gasolina	RWD	2996	172	234	12.07-10.13	■
128 i (N52 B30 A)		Gasolina	RWD	2996	172	234	12.07-10.13	■
118 d (N47 D20 A)	-12/10	Diesel	RWD	1995	100	136	09.08-12.13	■
118 d (N47 D20 C)	-12/10	Diesel	RWD	1995	100	136	09.08-12.13	■
118 d (N47 D20 A)	-12/10	Diesel	RWD	1995	105	143	09.08-12.13	■
118 d (N47 D20 C)	-12/10	Diesel	RWD	1995	105	143	09.08-12.13	■
120 d (N47 D20 A)	-12/10	Diesel	RWD	1995	120	163	03.08-12.13	■
120 d (N47 D20 C)	-12/10	Diesel	RWD	1995	120	163	03.08-12.13	■
120 d (N47 D20 A)	-12/10	Diesel	RWD	1995	130	177	03.08-12.13	■
120 d (N47 D20 C)	-12/10	Diesel	RWD	1995	130	177	03.08-12.13	■
120 d (N47 D20 C)	-12/10	Diesel	RWD	1995	145	197	03.08-12.13	■
123 d (N47 D20 B)	-12/10	Diesel	RWD	1995	150	204	09.08-12.13	■
123 d (N47 D20 D)	-12/10	Diesel	RWD	1995	150	204	09.08-12.13	■

LISTA DE APLICACIONES - BUYERS GUIDE

1 Serie (E82) 10.06-10.13					Coupe (Compact car-C Segment)			
120 i (N46 B20 B)		Gasolina	RWD	1995	115	156	09.09-10.13	■
120 i (N46 B20 BD)		Gasolina	RWD	1995	115	156	09.09-10.13	■
120 i (N46 B20 C)		Gasolina	RWD	1995	115	156	09.09-10.13	■
120 i (N46 B20 E)		Gasolina	RWD	1995	115	156	09.09-10.13	■
120 i (N43 B20 A)	-12/10	Gasolina	RWD	1995	125	170	10.07-10.13	■
3.0 128 i	01/07-	Gasolina	FWD	2995	169	230	10.06-	■
125 i (N52 B30 A)	-12/10	Gasolina	RWD	2996	160	218	03.08-10.13	■
125 i (N52 B30 B)	-12/10	Gasolina	RWD	2996	160	218	03.08-10.13	■
125 i (N52 B30 BF)	-12/10	Gasolina	RWD	2996	160	218	03.08-10.13	■
128 i (N51 B30 A,N52 B30 A)		Gasolina	RWD	2996	172	234	10.07-10.13	■
118 d (N47 D20 C)		Diesel	RWD	1995	100	136	09.09-10.13	■
118 d (N47 D20 C)	-12/10	Diesel	RWD	1995	105	143	09.09-10.13	■
120 d (N47 D20 A)	-12/10	Diesel	RWD	1995	120	163	09.07-10.13	■
120 d (N47 D20 C)	-12/10	Diesel	RWD	1995	120	163	09.07-10.13	■
120 d (N47 D20 A)	-12/10	Diesel	RWD	1995	130	177	09.07-10.13	■
120 d (N47 D20 C)	-12/10	Diesel	RWD	1995	130	177	09.07-10.13	■
120 d (N47 D20 A)	-12/10	Diesel	RWD	1995	145	197	09.07-10.13	■
120 d (N47 D20 C)	-12/10	Diesel	RWD	1995	145	197	09.07-10.13	■
123 d (N47 D20 B)	-12/10	Diesel	RWD	1995	150	204	10.07-09.13	■
123 d (N47 D20 D)	-12/10	Diesel	RWD	1995	150	204	10.07-09.13	■
1 Serie (E87) 02.03-12.13					Hatchback (Compact car-C Segment)			
116 i (N45 B16 A)		Gasolina	RWD	1596	85	115	06.04-06.11	■
116 i (N45 B16 A)	-12/10	Gasolina	RWD	1596	85	115	09.07-12.11	■
116 i		Gasolina	RWD	1599	89	121	03.07-06.11	■
116 i (N43 B16 AA)		Gasolina	RWD	1599	90	122	09.07-06.11	■
116 i (N43 B16 AA)	-12/10	Gasolina	RWD	1599	90	122	03.07-12.11	■
116 i (N43 B20 A)		Gasolina	RWD	1995	90	122	01.09-06.11	■
116 i (N43 B20 A)	01/09-	Gasolina	RWD	1995	90	122	11.08-12.11	■
118 i (N46 B20 B)		Gasolina	RWD	1995	95	129	07.04-02.07	■
118 i	-12/10	Gasolina	FWD	1995	95	129	09.06-09.12	■
118 i (N46 B20 B)		Gasolina	RWD	1995	95	129	09.06-02.08	■
118 i (N46 B20 B)		Gasolina	RWD	1995	100	136	10.06-06.11	■
118 i (N46 B20 B)	01/07-	Gasolina	RWD	1995	100	136	09.06-12.11	■
118 i (N43 B20 A)		Gasolina	RWD	1995	105	143	09.06-06.11	■
118 i (N43 B20 A)	01/07-	Gasolina	RWD	1995	105	143	09.06-12.11	■
120 i (N46 B20 B)		Gasolina	RWD	1995	110	150	06.04-02.07	■
120 i (N46 B20 BD)		Gasolina	RWD	1995	110	150	06.04-02.07	■
120 i (N46 B20 C)		Gasolina	RWD	1995	110	150	06.04-02.07	■
120 i (N46 B20 CC)		Gasolina	RWD	1995	110	150	06.04-02.07	■
120 i	-12/10	Gasolina	FWD	1995	110	150	09.06-09.12	■
120 i (N46 B20 A)		Gasolina	RWD	1995	115	156	03.07-06.11	■
120 i (N46 B20 B)		Gasolina	RWD	1995	115	156	03.07-06.11	■
120 i (N46 B20 BD)		Gasolina	RWD	1995	115	156	03.07-06.11	■
120 i (N46 B20 C)		Gasolina	RWD	1995	115	156	03.07-06.11	■
120 i (N46 B20 CC)		Gasolina	RWD	1995	115	156	03.07-06.11	■
120 i (N46 B20 B)		Gasolina	RWD	1995	115	156	03.07-12.11	■
120 i (N46 B20 C)		Gasolina	RWD	1995	115	156	03.07-12.11	■
120 i (N43 B20 A)		Gasolina	RWD	1995	120	163	03.07-06.11	■
120 i (N43 B20 A)		Gasolina	RWD	1995	120	163	03.07-12.11	■

LISTA DE APLICACIONES - BUYERS GUIDE

118 i (N43 B20 A)		Gasolina	RWD	1995	125	170	03.07-12.07	■
120 i (N43 B20 A)		Gasolina	RWD	1995	125	170	03.07-06.11	■
120 i (N43 B20 A)		Gasolina	RWD	1995	125	170	03.07-09.12	■
130 i (N52 B30 A)		Gasolina	RWD	2996	190	258	03.07-06.11	■
130 i (N52 B30 AF)		Gasolina	RWD	2996	190	258	03.07-06.11	■
130 i (N52 B30 B)		Gasolina	RWD	2996	190	258	03.07-06.11	■
130 i (N52 B30 BF)		Gasolina	RWD	2996	190	258	03.07-06.11	■
130 i (N52 B30 A)	-12/10	Gasolina	RWD	2996	190	258	09.06-12.11	■
130 i (N52 B30 B)	-12/10	Gasolina	RWD	2996	190	258	09.06-12.11	■
130 i (N52 B30 BF)	-12/10	Gasolina	RWD	2996	190	258	09.06-12.11	■
130 i (N52 B30 A)		Gasolina	RWD	2996	195	265	09.05-02.07	■
130 i (N52 B30 AF)		Gasolina	RWD	2996	195	265	09.05-02.07	■
130 i (N52 B30 BF)		Gasolina	RWD	2996	195	265	09.05-02.07	■
130 i (N52 B30 A)	-12/10	Gasolina	RWD	2996	195	265	09.06-12.11	■
130 i (N52 B30 B)	-12/10	Gasolina	RWD	2996	195	265	09.06-12.11	■
130 i (N52 B30 BF)	-12/10	Gasolina	RWD	2996	195	265	09.06-12.11	■
116 d (N47 D20 C)		Diesel	RWD	1995	66	90	01.11-12.11	■
116 d (N47 D20 A)		Diesel	RWD	1995	66	90	01.11-12.11	■
116 d (N47 D20 C)		Diesel	RWD	1995	66	90	01.11-12.11	■
116 d (N47 D20 A)		Diesel	RWD	1995	85	116	03.09-06.11	■
116 d (N47 D20 C)		Diesel	RWD	1995	85	116	03.09-06.11	■
116 d (N47 D20 A)	01/09-	Diesel	RWD	1995	85	116	11.08-12.11	■
116 d (N47 D20 C)	01/09-	Diesel	RWD	1995	85	116	11.08-12.11	■
118 d (M47 D20 (204D4))		Diesel	RWD	1995	90	122	06.04-02.07	■
118 d	-12/10	Diesel	RWD	1995	90	122	09.06-09.12	■
118 d (N47 D20 A)		Diesel	RWD	1995	100	136	03.07-06.11	■
118 d (N47 D20 C)		Diesel	RWD	1995	100	136	03.07-06.11	■
118 d (N47 D20 A)	01/07-	Diesel	RWD	1995	100	136	09.06-12.11	■
118 d (N47 D20 C)	01/07-	Diesel	RWD	1995	100	136	09.06-12.11	■
118 d (N47 D20 A)		Diesel	RWD	1995	105	143	03.07-06.11	■
118 d (N47 D20 C)		Diesel	RWD	1995	105	143	03.07-06.11	■
118 d (N47 D20 A)	01/07-	Diesel	RWD	1995	105	143	09.06-12.11	■
118 d (N47 D20 C)	01/07-	Diesel	RWD	1995	105	143	09.06-12.11	■
120 d (M47 D20 (204D4))		Diesel	RWD	1995	110	150	06.04-02.07	■
120 d (M47 D20 (204D4))		Diesel	RWD	1995	120	163	06.04-06.11	■
120 d (N47 D20 A)		Diesel	RWD	1995	120	163	06.04-06.11	■
120 d (N47 D20 A)	-12/10	Diesel	RWD	1995	120	163	03.07-12.11	■
120 d (N47 D20 C)	-12/10	Diesel	RWD	1995	120	163	03.07-12.11	■
120 d (N47 D20 A)		Diesel	RWD	1995	130	177	03.07-06.11	■
120 d (N47 D20 C)		Diesel	RWD	1995	130	177	03.07-06.11	■
120 d (N47 D20 A)		Diesel	RWD	1995	130	177	03.07-12.11	■
120 d (N47 D20 C)		Diesel	RWD	1995	130	177	03.07-12.11	■
120 d (N47 D20 A)		Diesel	RWD	1995	145	197	03.07-12.11	■
120 d (N47 D20 C)		Diesel	RWD	1995	145	197	03.07-12.11	■
123 d (N47 D20 B)		Diesel	RWD	1995	150	204	03.07-06.11	■
123 d (N47 D20 D)		Diesel	RWD	1995	150	204	03.07-06.11	■
123 d (N47 D20 B)	-12/10	Diesel	RWD	1995	150	204	03.07-12.11	■
123 d (N47 D20 D)	-12/10	Diesel	RWD	1995	150	204	03.07-12.11	■
3 Serie V (E93) 05.06-12.13					Convertible (Compact executive car-D Segment)			
320i (N46 B20 B)		Gasolina	RWD	1995	115	156	01.07-08.13	■
320i (N43 B20 A)		Gasolina	RWD	1995	120	163	09.06-10.13	■

LISTA DE APLICACIONES - BUYERS GUIDE

320i (N43 B20 A)	-12/12	Gasolina	RWD	1995	125	170	03.07-10.13	■	
325i (N52 B25 A)		Gasolina	RWD	2497	160	218	12.06-02.10	■	
335 i (N54 B30 A)	-12/12	Gasolina	RWD	2979	225	306	12.06-10.13	■	
335 i (N55 B30 A)	-12/12	Gasolina	RWD	2979	225	306	12.06-10.13	■	
325i (N53 B30 A)		Gasolina	RWD	2996	155	211	10.06-12.13	■	
325i (N53 B30 A)	-12/12	Gasolina	RWD	2996	160	218	03.07-12.13	■	
330i (N53 B30 A)	-12/12	Gasolina	RWD	2996	200	272	03.07-10.13	■	
330i (N52 B30 A)		Gasolina	RWD	2996	200	272	03.07-02.10	■	
325 d (M57 D30 (306D3))		Diesel	RWD	2993	145	197	03.07-12.10	■	
325 d (N57 D30 A)		Diesel	RWD	2993	150	204	09.09-09.13	■	
325 d (M57 D30 (306D3))		Diesel	RWD	2993	155	211	03.07-12.10	■	
3 Serie V (E92) 01.05-12.13							Coupe (Compact executive car-D Segment)		
316 i (N43 B16 AA)		Gasolina	RWD	1599	90	122	09.07-06.13	■	
320i		Gasolina	RWD	1995	110	150	11.06-06.07	■	
320i (N46 B20 B)		Gasolina	RWD	1995	115	156	06.07-12.13	■	
320i (N43 B20 A)		Gasolina	RWD	1995	120	163	01.07-06.13	■	
320i (N43 B20 A)	-12/12	Gasolina	RWD	1995	125	170	03.07-06.13	■	
323 i (N52 B25 AE)		Gasolina	RWD	2497	140	190	04.06-02.12	■	
323 i (N52 B25 BE)		Gasolina	RWD	2497	140	190	04.06-02.12	■	
325i (N52 B25 A)		Gasolina	RWD	2497	160	218	06.06-02.10	■	
325i (N52 B25 AF)		Gasolina	RWD	2497	160	218	06.06-02.10	■	
325i (N52 B25 BF)		Gasolina	RWD	2497	160	218	06.06-02.10	■	
325 xi (N52 B25 A)		Gasolina	4WD	2497	160	218	09.06-02.10	■	
325i (N53 B30 A)	-12/12	Gasolina	RWD	2996	160	218	09.07-06.13	■	
328i (N51 B30 A)		Gasolina	RWD	2996	172	234	06.06-06.13	■	
328i (N52 B30 A)		Gasolina	RWD	2996	172	234	06.06-06.13	■	
330i (N52 B30 A)		Gasolina	RWD	2996	200	272	09.06-02.10	■	
330i (N52 B30 AF)		Gasolina	RWD	2996	200	272	09.06-02.10	■	
330i (N52 B30 BF)		Gasolina	RWD	2996	200	272	09.06-02.10	■	
320 d (N47 D20 A)		Diesel	RWD	1995	130	177	09.06-02.10	■	
320 d (N47 D20 C)		Diesel	RWD	1995	130	177	09.06-02.10	■	
325 d (N57 D30 A)	-12/12	Diesel	RWD	2993	150	204	09.09-06.13	■	
325 d (M57 D30 (306D3))		Diesel	RWD	2993	155	211	02.07-02.10	■	
3 Serie V (E90) 02.04-12.13							Saloon (Compact executive car-D Segment)		
316 i (N45 B16 A)		Gasolina	RWD	1596	85	115	09.05-10.11	■	
316 i (N45 B16 AC)		Gasolina	RWD	1596	85	115	09.05-10.11	■	
316 i (N43 B16 A)		Gasolina	RWD	1599	90	122	09.07-10.11	■	
316 i (N43 B16 AA)		Gasolina	RWD	1599	90	122	09.07-10.11	■	
1.8 316 i 15"	01/05-	Gasolina	FWD	1795			02.04-	■	
1.8 316 i 15"	01/05-	Gasolina	FWD	1795			02.04-	■	
1.8 316 i 15"	01/05-	Gasolina	FWD	1795			02.04-	■	
1.8 316 i 15"	01/05-	Gasolina	FWD	1795			02.04-	■	
318i (N46 B20 B)		Gasolina	RWD	1995	95	129	09.05-08.07	■	
318i (N46 B20 B)		Gasolina	RWD	1995	100	136	09.07-10.11	■	
318i (N46 B20 C)		Gasolina	RWD	1995	100	136	09.07-10.11	■	
318i (N46 B20 CC)		Gasolina	RWD	1995	100	136	09.07-10.11	■	
318i (N46 B20 CD)		Gasolina	RWD	1995	100	136	09.07-10.11	■	
318i (N46 B20 E)		Gasolina	RWD	1995	100	136	09.07-10.11	■	
318i (N43 B20 A)		Gasolina	RWD	1995	105	143	09.07-10.11	■	
320i (N46 B20 B)		Gasolina	RWD	1995	110	150	12.04-08.07	■	

LISTA DE APLICACIONES - BUYERS GUIDE

320i (N46 B20 BD)		Gasolina	RWD	1995	110	150	12.04-08.07	■
320i (N46 B20 C)		Gasolina	RWD	1995	110	150	12.04-08.07	■
320i (N46 B20 CB)		Gasolina	RWD	1995	110	150	12.04-08.07	■
320i (N46 B20 B)		Gasolina	RWD	1995	115	156	02.07-12.11	■
320i (N46 B20 C)		Gasolina	RWD	1995	115	156	02.07-12.11	■
320i (N46 B20 CC)		Gasolina	RWD	1995	115	156	02.07-12.11	■
320i (N46 B20 CD)		Gasolina	RWD	1995	115	156	02.07-12.11	■
320i (N46 B20 E)		Gasolina	RWD	1995	115	156	02.07-12.11	■
320i (N43 B20 A)		Gasolina	RWD	1995	120	163	03.07-12.11	■
320i (N43 B20 A)		Gasolina	RWD	1995	125	170	09.07-10.11	■
320 si (N45 B20 A)		Gasolina	RWD	1997	127	173	09.05-08.06	■
325i		Gasolina	FWD	2494	224	300	09.08-12.10	■
323 i (N52 B25 A)		Gasolina	RWD	2497	140	190	03.07-12.11	■
323 i (N52 B25 BF)		Gasolina	RWD	2497	140	190	03.07-12.11	■
325i (N52 B25 A)		Gasolina	RWD	2497	155	211	01.06-12.11	■
325i (N52 B25 A)		Gasolina	RWD	2497	160	218	12.04-12.11	■
325i (N52 B25 B)		Gasolina	RWD	2497	160	218	12.04-12.11	■
325i (N52 B25 BF)		Gasolina	RWD	2497	160	218	12.04-12.11	■
330i		Gasolina	FWD	2979	175	235	09.06-12.07	■
325i (N53 B30 A)		Gasolina	RWD	2996	155	211	03.07-12.11	■
328i (N51 B30 A)		Gasolina	RWD	2996	172	234	09.06-12.11	■
330i (N52 B30 A)		Gasolina	RWD	2996	190	258	12.04-10.11	■
330i (N52 B30 BF)		Gasolina	RWD	2996	190	258	12.04-10.11	■
330 xi (N52 B30 A)		Gasolina	4WD	2996	190	258	09.05-08.07	■
330i (N52 B30 A)		Gasolina	RWD	2996	200	272	03.07-12.11	■
330i (N52 B30 BF)		Gasolina	RWD	2996	200	272	03.07-12.11	■
316 d (N47 D20 C)		Diesel	RWD	1995	85	116	07.09-12.11	■
318 d (M47 D20 (204D4))		Diesel	RWD	1995	90	122	03.05-08.07	■
318 d (N47 D20 A)		Diesel	RWD	1995	100	136	09.07-10.11	■
318 d (N47 D20 C)		Diesel	RWD	1995	100	136	09.07-10.11	■
318 d (N47 D20 A)		Diesel	RWD	1995	105	143	02.07-10.11	■
318 d (N47 D20 C)		Diesel	RWD	1995	105	143	02.07-10.11	■
320 d		Diesel	RWD	1995	115	156	12.04-09.07	■
320 d (M47 D20 (204D4))		Diesel	RWD	1995	120	163	12.04-10.11	■
320 d (N47 D20 A)		Diesel	RWD	1995	120	163	12.04-10.11	■
320 d (N47 D20 C)		Diesel	RWD	1995	120	163	12.04-10.11	■
320 d xDrive (N47 D20 C)	-12/10	Diesel	4WD	1995	120	163	09.08-10.11	■
325 d (M57 D30 (306D3))		Diesel	RWD	2993	145	197	09.06-02.10	■
325 d (N57 D30 A)		Diesel	RWD	2993	150	204	03.10-10.11	■
3 Serie V Touring (E91) 12.04-12.12						Estate (Compact executive car-D Segment)		
316 i (N43 B16 AA)		Gasolina	RWD	1599	90	122	09.08-06.12	■
318i (N46 B20 B)		Gasolina	RWD	1995	95	129	01.06-08.07	■
318i (N46 B20 B)		Gasolina	RWD	1995	100	136	09.07-03.12	■
318i (N43 B20 A)		Gasolina	RWD	1995	105	143	05.07-05.12	■
320i (N46 B20 B)		Gasolina	RWD	1995	110	150	09.05-06.12	■
320i (N46 B20 C)		Gasolina	RWD	1995	110	150	09.05-06.12	■
320i (N46 B20 B)		Gasolina	RWD	1995	115	156	09.05-06.12	■
320i (N46 B20 BD)		Gasolina	RWD	1995	115	156	09.05-06.12	■
320i (N46 B20 C)		Gasolina	RWD	1995	115	156	09.05-06.12	■
323 i (N52 B25 A)		Gasolina	RWD	2497	130	177	04.06-06.07	■
323 i (N52 B25 A)		Gasolina	RWD	2497	140	190	09.06-07.08	■

LISTA DE APLICACIONES - BUYERS GUIDE

325i (N52 B25 A)		Gasolina	RWD	2497	155	211	12.04-12.10	■
325i (N52 B25 AF)		Gasolina	RWD	2497	155	211	12.04-12.10	■
325i (N52 B25 B)		Gasolina	RWD	2497	155	211	12.04-12.10	■
325i (N52 B25 BF)		Gasolina	RWD	2497	155	211	12.04-12.10	■
325i (N52 B25 A)		Gasolina	RWD	2497	160	218	12.04-08.08	■
330i (N52 B30 A)		Gasolina	RWD	2996	190	258	08.05-08.07	■
330i (N53 B30 A)		Gasolina	RWD	2996	200	272	09.07-06.12	■
330i		Gasolina	RWD	2996	200	272	03.07-06.12	■
320 d (M47 D20 (204D4))		Diesel	RWD	1995	110	150	12.04-08.07	■
320 d (M47 D20 (204D4))		Diesel	RWD	1995	120	163	06.05-06.12	■
320 d (N47 D20 A)		Diesel	RWD	1995	120	163	06.05-06.12	■
320 d (N47 D20 C)		Diesel	RWD	1995	120	163	06.05-06.12	■
320 d xDrive (N47 D20 C)		Diesel	4WD	1995	120	163	07.09-06.12	■
320 d (N47 D20 A)		Diesel	RWD	1995	145	197	02.07-02.10	■
320 d (N47 D20 C)		Diesel	RWD	1995	145	197	02.07-02.10	■
320 d (N47 D20 C)		Diesel	RWD	1995	147	200	03.10-05.12	■
320 d xDrive (N47 D20 C)		Diesel	4WD	1995	147	200	03.10-05.12	■
325 d (M57 D30 (306D3))		Diesel	RWD	2993	145	197	09.06-06.12	■
325 d (N57 D30 A)		Diesel	RWD	2993	150	204	02.10-06.12	■
330 d (M57 D30 (306D3))		Diesel	RWD	2993	170	231	12.04-08.08	■
330 d (N57 D30 A)		Diesel	RWD	2993	180	245	02.08-05.12	■

BMW (BRILLIANCE)

3 SERIES V (E90) 10.04-09.12					Saloon (Compact executive car-D Segment)			
325i (N52 B25 BF)		Gasolina	RWD	2497	160	218	06.05-09.12	■