


# LISTA DE APLICACIONES - BUYERS GUIDE

## 78BD4623-2



Weight: 11.920

O.E.M.	MAKE
1611841080	PEUGEOT
1618864380	CITROËN
424922	PEUGEOT
424923	PEUGEOT
424991	PEUGEOT
9404249918	FIAT
940429918	FIAT
9467548487	FIAT
SU001A1062	TOYOTA



## 78BD4623-2

**E1 90R-02C0415/0014**



Ø290x14x49

MAKE
CITROËN
FIAT
PEUGEOT
TOYOTA



	Trac.	CC	Kw	CV			Front / Rear
--	-------	----	----	----	--	--	--------------

### CITROËN

<b>JUMPY II / DISPATCH (VF7) 01.07-</b>							<b>Bus (Minibus-M2-Segment)</b>			
2.0 i (RFH (EW10A))	Gasolina	FWD	1997	103	140	01.07-03.16			■	
2.0 i (RFJ (EW10A))	Gasolina	FWD	1997	103	140	01.07-03.16			■	
1.6 HDi 90 16V (9HU (DV6UTED4))	Diesel	FWD	1560	66	90	01.07-03.16			■	
1.6 HDi 90 8V (9HH (DV6DUM))	Diesel	FWD	1560	66	90	01.07-03.16			■	
1.6 HDi 90 8V (9HM (DV6UC))	Diesel	FWD	1560	66	90	01.07-03.16			■	
2.0 HDi 95 (AHY (DW10CE))	Diesel	FWD	1997	72	98	07.11-03.16			■	
2.0 HDi 120 (RHK (DW10UTED4))	Diesel	FWD	1997	88	120	01.07-03.16			■	
2.0 HDi 125 (AHZ (DW10CD))	Diesel	FWD	1997	94	128	07.11-03.16			■	
2.0 HDi 140 (RHR (DW10BTED4))	Diesel	FWD	1997	100	136	01.07-03.16			■	
2.0 HDi 165 (RHH (DW10CTED4))	Diesel	FWD	1997	120	163	07.10-03.16			■	
<b>JUMPY II / DISPATCH 11.06-</b>							<b>Platform/Chassis (LCVs-N1 Segment)</b>			
2.0 I (X_RFH)	Gasolina	FWD	1997	103	140	11.06-03.16			■	
1.6 HDi 90 16V (9HU (DV6UTED4))	Diesel	FWD	1560	66	90	06.07-03.16			■	
1.6 HDi 90 8V (9HH (DV6DUM))	Diesel	FWD	1560	66	90	06.07-03.16			■	
2.0 HDi 100 (X_AHY)	Diesel	FWD	1997	72	98	07.11-03.16			■	
2.0 HDi (X_RHG)	Diesel	FWD	1997	88	120	01.09-03.16			■	
2.0 HDi 125 (AHZ (DW10CD))	Diesel	FWD	1997	94	128	07.11-			■	
2.0 HDi (X_RHH)	Diesel	FWD	1997	120	163	07.10-03.16			■	
<b>JUMPY II / DISPATCH 01.07-</b>							<b>Van (LCVs-N1 Segment)</b>			
2.0 i (RFH (EW10A))	Gasolina	FWD	1997	103	140	01.07-03.16			■	
1.6 HDi 90 16V (9HU (DV6UTED4))	Diesel	FWD	1560	66	90	01.07-03.16			■	
1.6 HDi 90 8V (9HH (DV6DUM))	Diesel	FWD	1560	66	90	01.07-03.16			■	

# LISTA DE APLICACIONES - BUYERS GUIDE

1.6 HDi 90 8V (9HM (DV6UC))		Diesel	FWD	1560	66	90	01.07-03.16	■
2.0 HDi 95 (AHY (DW10CE))		Diesel	FWD	1997	72	98	07.11-03.16	■
2.0 HDi 120 (RHK (DW10UTED4))		Diesel	FWD	1997	88	120	01.07-03.16	■
2.0 HDi 120 4x4 (RHK (DW10UTED4))		Diesel	4WD	1997	88	120	01.10-03.16	■
2.0 HDi 125 (AHZ (DW10CD))		Diesel	FWD	1997	94	128	07.11-03.16	■
2.0 HDi 125 4x4 (AHZ (DW10CD))		Diesel	4WD	1997	94	128	07.11-03.16	■
2.0 HDi 140 (RHR (DW10BTED4))		Diesel	FWD	1997	100	136	01.07-03.16	■
2.0 HDi 165 (RHH (DW10CTED4))		Diesel	FWD	1997	120	163	07.10-03.16	■
<b>FIAT</b>								
<b>SCUDO II (270_, 272_) 01.07-</b>						<b>Bus (Minibus-M2-Segment)</b>		
1.6 D Multijet (9HU)		Diesel	FWD	1560	66	90	01.07-03.16	■
1.6 D Multijet (9H07 (DV6UC))		Diesel	FWD	1560	66	90	02.11-03.16	■
1.6 D Multijet (9HM (DV6UC))		Diesel	FWD	1560	66	90	02.11-03.16	■
2.0 D Multijet (RHK)		Diesel	FWD	1997	88	120	01.07-03.16	■
2.0 D Multijet 4x4 (RHK)		Diesel	4WD	1997	88	120	01.07-03.16	■
2.0 D Multijet (RH02)		Diesel	FWD	1997	94	128	04.11-03.16	■
2.0 D Multijet 4x4 (RH02)		Diesel	4WD	1997	94	128	04.11-03.16	■
2.0 D Multijet (RHR)		Diesel	FWD	1997	100	136	01.07-03.16	■
2.0 D Multijet 4x4 (RHR)		Diesel	4WD	1997	100	136	01.07-03.16	■
2.0 D Multijet (RH02)		Diesel	FWD	1997	120	163	07.10-03.16	■
2.0 D Multijet (RHH)		Diesel	FWD	1997	120	163	07.10-03.16	■
<b>SCUDO II (270_, 272_) 01.07-</b>						<b>Platform/Chassis (LCVs-N1 Segment)</b>		
1.6 D Multijet (9HU)		Diesel	FWD	1560	66	90	01.07-03.16	■
2.0 D Multijet (RHK)		Diesel	FWD	1997	88	120	01.07-03.16	■
2.0 D Multijet (RH02)		Diesel	FWD	1997	94	128	05.11-03.16	■
2.0 D Multijet (DW10BTED4)		Diesel	FWD	1997	100	136	01.07-03.16	■
2.0 D Multijet (RHR)		Diesel	FWD	1997	100	136	01.07-03.16	■
2.0 D Multijet (RH02)		Diesel	FWD	1997	120	163	07.10-03.16	■
2.0 D Multijet (RHH)		Diesel	FWD	1997	120	163	07.10-03.16	■
<b>SCUDO II (270_, 272_) 01.07-</b>						<b>Van (LCVs-N1 Segment)</b>		
1.6 D Multijet (9HU)		Diesel	FWD	1560	66	90	01.07-03.16	■
1.6 D Multijet (9H07 (DV6UC))		Diesel	FWD	1560	66	90	02.11-03.16	■
1.6 D Multijet (9HM (DV6UC))		Diesel	FWD	1560	66	90	02.11-03.16	■
2.0 D Multijet (RHK)		Diesel	FWD	1997	88	120	01.07-03.16	■
2.0 D Multijet 4x4 (RHK)		Diesel	4WD	1997	88	120	01.07-03.16	■
2.0 D Multijet (RH02)		Diesel	FWD	1997	94	128	05.11-03.16	■
2.0 D Multijet 4x4 (RH02)		Diesel	4WD	1997	94	128	05.11-03.16	■
2.0 D Multijet (RHR)		Diesel	FWD	1997	100	136	01.07-03.16	■
2.0 D Multijet 4x4 (RHR)		Diesel	4WD	1997	100	136	01.07-03.16	■
2.0 D Multijet (RH02)		Diesel	FWD	1997	120	163	07.10-03.16	■
2.0 D Multijet (RHH)		Diesel	FWD	1997	120	163	07.10-03.16	■
<b>PEUGEOT</b>								
<b>EXPERT II 01.07-</b>						<b>Platform/Chassis (LCVs-N1 Segment)</b>		
2.0 16V (X_RFH)		Gasolina	FWD	1997	103	140	01.07-03.16	■
1.6 HDi 90 16V (9HU (DV6UTED4))		Diesel	FWD	1560	66	90	01.07-	■
1.6 HDi 90 8V (9HH (DV6DUM))		Diesel	FWD	1560	66	90	01.07-	■
1.6 HDi 90 8V (9HM (DV6UC))		Diesel	FWD	1560	66	90	01.07-	■
2.0 HDi 120 (RHK (DW10UTED4))		Diesel	FWD	1997	88	120	01.07-	■
2.0 HDi 130 (AHZ (DW10CD))		Diesel	FWD	1997	94	128	03.11-	■

# LISTA DE APLICACIONES - BUYERS GUIDE

2.0 HDi 140 (RHR (DW10BTED4))	Diesel	FWD	1997	100	136	01.07-	■
2.0 HDi 165 (RHH (DW10CTED4))	Diesel	FWD	1997	120	163	09.09-	■
<b>EXPERT II (VF3A_, VF3U_, VF3X_) 01.07-</b>				<b>Van (LCVs-N1 Segment)</b>			
2.0 16V (RFH (EW10A))	Gasolina	FWD	1997	103	140	01.07-	■
2.0 16V (RFJ (EW10A))	Gasolina	FWD	1997	103	140	01.07-	■
1.6 HDi 90 16V (9HU (DV6UTED4))	Diesel	FWD	1560	66	90	01.07-	■
1.6 HDi 90 8V (9HH (DV6DUM))	Diesel	FWD	1560	66	90	01.07-	■
1.6 HDi 90 8V (9HM (DV6UC))	Diesel	FWD	1560	66	90	01.07-	■
2.0 HDi 100	Diesel	FWD	1997	72	98	03.11-	■
2.0 HDi 120 (RHK (DW10UTED4))	Diesel	FWD	1997	88	120	01.07-	■
2.0 HDi 120 4x4 (RHK (DW10UTED4))	Diesel	4WD	1997	88	120	01.10-	■
2.0 HDi 130 (AHZ (DW10CD))	Diesel	FWD	1997	94	128	03.11-	■
2.0 HDi 130 4x4 (AHZ (DW10CD))	Diesel	4WD	1997	94	128	01.12-03.16	■
2.0 HDi 140 (RHR (DW10BTED4))	Diesel	FWD	1997	100	136	01.07-	■
2.0 HDi 165 (RHH (DW10CTED4))	Diesel	FWD	1997	120	163	09.09-	■
<b>EXPERT II Tepee (VF3X_) 01.07-</b>				<b>Bus (Minibus-M2-Segment)</b>			
2.0 16V (RFH (EW10A))	Gasolina	FWD	1997	103	140	01.07-03.16	■
2.0 16V (RFJ (EW10A))	Gasolina	FWD	1997	103	140	01.07-03.16	■
1.6 HDi 90 16V (9HU (DV6UTED4))	Diesel	FWD	1560	66	90	01.07-03.16	■
1.6 HDi 90 8V (9HH (DV6DUM))	Diesel	FWD	1560	66	90	01.07-03.16	■
1.6 HDi 90 8V (9HM (DV6UC))	Diesel	FWD	1560	66	90	01.07-03.16	■
2.0 HDi 100 (AHY (DW10CE))	Diesel	FWD	1997	72	98	03.11-03.16	■
2.0 HDi 120 (RHK (DW10UTED4))	Diesel	FWD	1997	88	120	01.07-03.16	■
2.0 HDi 120 4x4 (RHK (DW10UTED4))	Diesel	4WD	1997	88	120	01.07-03.16	■
2.0 HDi 130 (AHZ (DW10CD))	Diesel	FWD	1997	94	128	03.11-	■
2.0 HDi 130 4x4 (AHZ (DW10CD))	Diesel	4WD	1997	94	128	03.11-03.16	■
2.0 HDi 140 (RHR (DW10BTED4))	Diesel	FWD	1997	100	136	01.07-	■
2.0 HDi 165 (RHH (DW10CTED4))	Diesel	FWD	1997	120	163	09.09-	■
<b>PARTNER (5_, G_) 03.97-07.08</b>				<b>Platform/Chassis (LCVs-N1 Segment)</b>			
1.6 HDi 75	Diesel	FWD	1560	55	75	02.06-07.08	■
<b>TOYOTA</b>							
<b>PROACE (MDX_) 06.13-03.16</b>				<b>Van (LCVs-N1 Segment)</b>			
1.6 D (MDX9) (3WZ-TV)	Diesel	FWD	1560	66	90	06.13-03.16	■
2.0 D (MDX3) (4WZ-FTW)	Diesel	FWD	1997	94	128	06.13-03.16	■
2.0 D 4x4 (MDX4) (4WZ-FTW)	Diesel	4WD	1997	94	128	06.13-03.16	■
2.0 D (MDX6) (4WZ-FHV)	Diesel	FWD	1997	120	163	06.13-03.16	■