

LISTA DE APLICACIONES - BUYERS GUIDE

COMBO Mk II (C) (F25) 09.01-02.12					Box Body/MPV (LCVs-N1 Segment)			
1.4 16V (Z 14 XE)		Gasolina	FWD	1389	66	90	10.01-05.07	■
1.6 (Z 16 SE)		Gasolina	FWD	1598	62	84	09.01-10.04	■
1.6 CNG 16V (Y 16 YNG)		Gasol./Gas (CNG)	FWD	1598	69	94	06.06-02.12	■
1.6 CNG 16V (Z 16 YNG)		Gasol./Gas (CNG)	FWD	1598	69	94	06.06-02.12	■
1.6 CNG 16V (Z 16 YNG)		Gasol./Gas (CNG)	FWD	1598	71	97	04.05-02.12	■
1.3 CDTI 16V (Y 13 DT)		Diesel	FWD	1248	51	69	09.04-02.12	■
1.3 CDTI 16V (Z 13 DT)		Diesel	FWD	1248	51	69	09.04-02.12	■
1.3 CDTI 16V (Z 13 DTJ)		Diesel	FWD	1248	55	75	10.05-11.11	■
COMBO TOUR Mk II (C) (F25) 09.01-02.12					MPV (Large MPV-M1 Segment)			
1.6 (Z 16 SE)		Gasolina	FWD	1598	64	87	10.01-06.04	■
1.6 CNG (Z 16 YNG)		Gasol./Gas (CNG)	FWD	1598	69	94	06.06-09.10	■
1.6 CNG (Z 16 YNG)		Gasol./Gas (CNG)	FWD	1598	71	97	04.05-02.12	■
1.3 CDTI 16V (Z 13 DTJ)		Diesel	FWD	1248	55	75	07.06-02.12	■
1.7 DI 16V (Y 17 DTL)		Diesel	FWD	1686	48	65	09.01-06.04	■
1.7 DTI 16V (Y 17 DT)		Diesel	FWD	1686	55	75	10.01-02.12	■
MERIVA Mk I (A) (X03) 01.03-06.10					MPV (Mini MPV-M1 Segment)			
1.6 i 16V (Z 16 XE)		Gasolina	FWD	1598	74	100	01.03-09.05	■
1.6 i 16V Twinport (Z 16 XEP)		Gasolina	FWD	1598	77	105	05.03-06.10	■
1.6 Turbo (Z 16 LET)		Gasolina	FWD	1598	132	180	05.06-06.10	■
1.8 i 16V (Z 18 XE)		Gasolina	FWD	1796	92	125	05.03-06.10	■
1.3 CDTi (Y 13 DT)		Diesel	FWD	1248	51	69	04.05-06.10	■
1.3 CDTi (Z 13 DT)		Diesel	FWD	1248	51	69	04.05-06.10	■
1.3 CDTi (Z 13 DTJ)		Diesel	FWD	1248	55	75	01.03-10.09	■
1.7 DTI (Y 17 DT)		Diesel	FWD	1686	55	75	06.03-06.10	■