

LISTA DE APLICACIONES - BUYERS GUIDE

78CV0047-1



Qty: 998 Weight: 36.000

O.E.M.	MAKE
1962301	DAF
508030009	VAN HOOL
81 50803 0015	MAN
81501100009	MAN
81501100010	MAN
81508020010	MAN
81508030001	MAN
81508030010	MAN
81508030014	MAN
MBR5010	MERITOR
MBR5011	MERITOR

78CV0047-1



Ø438x45x135

MAKE
MAN



Trac.	CC	Kw	CV
-------	----	----	----



Front / Rear

MAN

							Platform/Chassis				
<b>E2000 08.97-</b>											
26.310 FAVLC (D 2866 LF23)		Diesel		11967	228	310	05.00-	■			
26.360 FAVLC (D 2866 LF24)		Diesel		11967	265	360	05.00-	■			
26.410 DFARC (D 2866 LF25)		Diesel		11967	301	410	05.00-	■			
26.410 DFRC (D 2866 LF25)		Diesel		11967	301	410	05.00-	■			
26.410 FAVLC		Diesel		11967	301	410	05.00-	■			
26.460 DFARC (D 2876 LF 03)		Diesel		12816	338	460	05.00-	■			
26.460 FAVLC (D 2876 LF 03)		Diesel		12816	338	460	05.00-	■			
26.464		Diesel		12816	338	460	01.97-03.04	■			
<b>E2000 08.97-</b>							Truck Tractor				
26.414		Diesel		11967	301	409	01.97-03.04	■			
26.414		Diesel		11967	301	409	01.97-03.04	■			
26.460 DFLS, DFLRS (D 2876 LF 03)		Diesel		12816	338	460	05.00-	■			
26.464		Diesel		12816	338	460	01.97-03.04	■			
<b>F2000 01.94-</b>							Concrete Mixer				
27.414		Diesel		12816	301	409	08.94-02.05	■			
<b>F2000 01.94-</b>							Dump Truck				
18.273		Diesel		9973	198	269	06.94-01.00	■			
18.293		Diesel		9973	213	290	06.94-01.00	■			
18.323		Diesel		9973	235	320	06.94-01.00	■			
33.323 DFK (D 2865 LF23)		Diesel		9973	235	320	01.94-12.95	■			
18.343		Diesel		9973	250	340	06.94-01.00	■			
19.344		Diesel		9973	250	340	06.94-01.00	■			

## LISTA DE APLICACIONES - BUYERS GUIDE

33.343 DFK (D 2865 LF21)	-12/96	Diesel		9973	250	340	01.94-	■
38.364		Diesel		11967	265	360	08.94-02.05	■
33.373 DFK, DF-KI (D 2866 LF21)		Diesel		11967	272	370	01.94-	■
33.403 DFK, DF-KI (D 2866 LF20)	-12/96	Diesel		11967	294	400	01.94-	■
38.414		Diesel		11967	301	409	08.94-02.05	■
33.423 DFK, DF-KI (D 2866 LF22)		Diesel		11967	309	420	01.94-	■
38.423		Diesel		11967	309	420	08.94-02.05	■
27.414		Diesel		12816	301	409	08.94-02.05	■
33.414		Diesel		12816	301	409	08.94-02.05	■
38.414		Diesel		12816	301	409	08.94-02.05	■
33.463 DFK, DF-KI (D 2876 LF 02)	-12/96	Diesel		12816	338	460	01.94-	■
38.463		Diesel		12816	338	460	08.94-02.05	■
38.464		Diesel		12816	338	460	08.94-02.05	■
<b>F2000 01.94-</b>				<b>Platform/Chassis</b>				
18.273 F, FL, FLL (D 2865 LF22)	-12/96	Diesel		9973	198	269	06.94-	■
19.273 F, FL, FLL (D 2865 LF22)		Diesel		9973	198	269	01.94-	■
22.273	-12/96	Diesel		9973	198	269	07.94-01.00	■
23.273	-12/96	Diesel		9973	198	269	06.94-01.00	■
26.273 DFC,26.273 DFCL (D 2865 LF22)		Diesel		9973	198	269	01.94-12.95	■
26.273 FNLC,26.273 FNLLC,26.273 FVLC (D 2865 LF22)		Diesel		9973	198	269	01.94-12.95	■
26.273 FNLC,26.273 FNLLC,26.273 FVLC		Diesel		9973	198	269	01.94-12.95	■
27.273	-12/96	Diesel		9973	198	269	06.94-01.00	■
27.273	-12/96	Diesel		9973	198	269	07.94-01.00	■
27.273 DFC (D 2865 LF22)		Diesel		9973	198	269	01.94-12.95	■
28.273	-12/96	Diesel		9973	198	269	07.94-01.00	■
18.293		Diesel		9973	213	290	06.94-01.00	■
19.293 FC,19.293 FLC,19.293 FLLC (D 2865 LF20)	-12/96	Diesel		9973	213	290	01.94-	■
19.293 FC,19.293 FLC,19.293 FLLC (D 2865 LF24)	-12/96	Diesel		9973	213	290	01.94-	■
22.293	-12/96	Diesel		9973	213	290	07.94-01.00	■
23.293 FNLLC (D 2865 LF20)	-12/96	Diesel		9973	213	290	01.94-	■
23.293 FNLLC (D 2865 LF24)	-12/96	Diesel		9973	213	290	01.94-	■
26.293 DFC,26.293 DFCL (D 2865 LF20)	-12/96	Diesel		9973	213	290	01.94-	■
26.293 DFC,26.293 DFCL (D 2865 LF24)	-12/96	Diesel		9973	213	290	01.94-	■
26.293 FNLC,26.293 FNLLC,26.293 FVLC (D 2865 LF20)	-12/96	Diesel		9973	213	290	01.94-	■
26.293 FNLC,26.293 FNLLC,26.293 FVLC (D 2865 LF24)	-12/96	Diesel		9973	213	290	01.94-	■
27.293	-12/96	Diesel		9973	213	290	06.94-01.00	■
27.293	-12/96	Diesel		9973	213	290	07.94-01.00	■
27.293 DFC (D 2865 LF20)	-12/96	Diesel		9973	213	290	01.94-	■
27.293 DFC (D 2865 LF24)	-12/96	Diesel		9973	213	290	01.94-	■
28.293	-12/96	Diesel		9973	213	290	07.94-01.00	■
18.323		Diesel		9973	235	320	06.94-01.00	■
19.323 FC,19.323 FLC,19.323 FLLC (D 2865 LF23)		Diesel		9973	235	320	01.94-12.95	■
22.323	-12/96	Diesel		9973	235	320	07.94-01.00	■
23.323	-12/96	Diesel		9973	235	320	06.94-01.00	■
26.323 DFC,26.323 DFCL (D 2865 LF23)		Diesel		9973	235	320	01.94-12.95	■
26.323 FNLC,26.323 FNLLC,26.323 FVLC (D 2865 LF23)		Diesel		9973	235	320	01.94-12.95	■
26.323 FNLC,26.323 FNLLC,26.323 FVLC		Diesel		9973	235	320	01.94-12.95	■
27.323	-12/96	Diesel		9973	235	320	06.94-01.00	■

## LISTA DE APLICACIONES - BUYERS GUIDE

27.323	-12/96	Diesel		9973	235	320	07.94-01.00	■
27.323 DFC (D 2865 LF23)		Diesel		9973	235	320	01.94-12.95	■
28.323	-12/96	Diesel		9973	235	320	07.94-01.00	■
33.323 DFC (D 2865 LF23)		Diesel		9973	235	320	01.94-12.95	■
18.343		Diesel		9973	250	340	06.94-01.00	■
19.343 FC,19.343 FLC,19.343 FLLC (D 2865 LF21)	-12/96	Diesel		9973	250	340	01.94-	■
19.344		Diesel		9973	250	340	06.94-01.00	■
22.343	-12/96	Diesel		9973	250	340	07.94-01.00	■
23.343 FNLLC (D 2865 LF21)	-12/96	Diesel		9973	250	340	01.94-	■
23.344	-12/96	Diesel		9973	250	340	06.94-01.00	■
26.343 DFC,26.343 DFLLC (D 2865 LF21)	-12/96	Diesel		9973	250	340	01.94-	■
26.343 FNLC,26.343 FNLLC,26.343 FVLC (D 2865 LF21)	-12/96	Diesel		9973	250	340	01.94-	■
27.343	-12/96	Diesel		9973	250	340	06.94-01.00	■
27.343	-12/96	Diesel		9973	250	340	07.94-01.00	■
27.343 DFC (D 2865 LF21)	-12/96	Diesel		9973	250	340	01.94-	■
28.343	-12/96	Diesel		9973	250	340	07.94-01.00	■
33.343 DFC (D 2865 LF21)	-12/96	Diesel		9973	250	340	01.94-	■
18.314	-12/96	Diesel		11967	228	310	06.94-05.02	■
18.364	-12/96	Diesel		11967	265	360	06.94-05.02	■
38.364		Diesel		11967	265	360	08.94-02.05	■
19.373 FC, FLC, FLLC, FRC, FLRC, F-NL (D 2866 LF21)		Diesel		11967	272	370	01.94-	■
24.373		Diesel		11967	272	370	06.94-02.05	■
26.373 DFC,26.373 DFLLC (D 2866 LF21)		Diesel		11967	272	370	01.94-12.95	■
26.373 FNLC,26.373 FNLLC,26.373 FVLC (D 2866 LF21)		Diesel		11967	272	370	01.94-12.95	■
26.373 FNLC,26.373 FNLLC,26.373 FVLC		Diesel		11967	272	370	01.94-12.95	■
27.373 DFC (D 2866 LF21)		Diesel		11967	272	370	01.94-	■
33.373 DFC (D 2866 LF21)		Diesel		11967	272	370	01.94-	■
19.403 FC, FLC, FLLC, FRC, FLRC, F-NL (D 2866 LF20)	-12/96	Diesel		11967	294	400	01.94-	■
23.403 FNLLC (D 2866 LF20)	-12/96	Diesel		11967	294	400	01.94-	■
26.403 DFC,26.403 DFLLC (D 2866 LF20)	-12/96	Diesel		11967	294	400	01.94-	■
26.403 FNLC,26.403 FNLLC,26.403 FVLC (D 2866 LF20)	-12/96	Diesel		11967	294	400	01.94-	■
27.403 DFC (D 2866 LF20)	-12/96	Diesel		11967	294	400	01.94-	■
33.403 DFC (D 2866 LF20)	-12/96	Diesel		11967	294	400	01.94-	■
18.414	-12/96	Diesel		11967	301	409	06.94-05.02	■
38.414		Diesel		11967	301	409	08.94-02.05	■
19.423 FC, FLC, FLLC, F-NL (D 2866 LF22)		Diesel		11967	309	420	01.94-	■
24.423		Diesel		11967	309	420	06.94-02.05	■
24.423		Diesel		11967	309	420	06.94-02.05	■
26.423 DFC,26.423 DFLLC (D 2866 LF22)		Diesel		11967	309	420	01.94-12.95	■
26.423 FNLC,26.423 FNLLC,26.423 FVLC (D 2866 LF22)		Diesel		11967	309	420	01.94-12.95	■
26.423 FNLC,26.423 FNLLC,26.423 FVLC		Diesel		11967	309	420	01.94-12.95	■
27.423 DFC (D 2866 LF22)		Diesel		11967	309	420	01.94-	■
33.423 DFC (D 2866 LF22)		Diesel		11967	309	420	01.94-	■
38.423		Diesel		11967	309	420	08.94-02.05	■
18.414	-12/96	Diesel		12816	301	409	06.94-05.02	■
19.414	-12/96	Diesel		12816	301	409	06.94-01.03	■
27.414		Diesel		12816	301	409	08.94-02.05	■
33.414		Diesel		12816	301	409	08.94-02.05	■

# LISTA DE APLICACIONES - BUYERS GUIDE

38.414		Diesel		12816	301	409	08.94-02.05	■
18.464	-12/96	Diesel		12816	338	460	06.94-05.02	■
19.463 FC, FLC, FLLC, FRC, FLRC, F-NL (D 2876 LF 02)	-12/96	Diesel		12816	338	460	01.94-	■
23.463 FNLLC (D 2876 LF 02)	-12/96	Diesel		12816	338	460	01.94-	■
26.463 DFC, DFCL (D 2876 LF 02)	-12/96	Diesel		12816	338	460	01.94-	■
26.463 FNLC, FNLLC, FNLLRC, FNLLW, FNLR, FNLLRC, FVLC (D 2876 LF 02)	-12/96	Diesel		12816	338	460	01.94-	■
27.463 DFC (D 2876 LF 02)	-12/96	Diesel		12816	338	460	01.94-	■
27.464 DFC (D 2876 LF 06)	-12/96	Diesel		12816	338	460	01.94-	■
33.463 DFC (D 2876 LF 02)	-12/96	Diesel		12816	338	460	01.94-	■
38.463		Diesel		12816	338	460	08.94-02.05	■
38.464		Diesel		12816	338	460	08.94-02.05	■
<b>F2000 01.94-</b>								<b>Platform/Chassis</b>
26.233 FVLC CNG (E 2866 DF 01)	-12/96	Gasolina		11967	170	231	09.96-	■
<b>F2000 01.94-</b>								<b>Truck Tractor</b>
18.273		Diesel		9973	198	269	06.94-01.00	■
19.273 FS,19.273 FLS (D 2865 LF22)		Diesel		9973	198	269	01.94-12.95	■
22.273	-12/96	Diesel		9973	198	269	07.94-01.00	■
26.273 DFS,26.273 DFSL (D 2865 LF22)		Diesel		9973	198	269	01.94-12.95	■
26.273 FNLS,26.273 FVLS		Diesel		9973	198	269	01.94-12.95	■
27.273	-12/96	Diesel		9973	198	269	07.94-01.00	■
27.273 DFS (D 2865 LF22)		Diesel		9973	198	269	01.94-12.95	■
28.273	-12/96	Diesel		9973	198	269	07.94-01.00	■
18.293		Diesel		9973	213	290	06.94-01.00	■
19.293 FS,19.293 FLS,19.293 FLLS (D 2865 LF20)	-12/96	Diesel		9973	213	290	01.94-	■
19.293 FS,19.293 FLS,19.293 FLLS (D 2865 LF24)	-12/96	Diesel		9973	213	290	01.94-	■
22.293	-12/96	Diesel		9973	213	290	07.94-01.00	■
26.293 DFS,26.293 DFSL (D 2865 LF20)	-12/96	Diesel		9973	213	290	01.94-	■
26.293 DFS,26.293 DFSL (D 2865 LF24)	-12/96	Diesel		9973	213	290	01.94-	■
27.293	-12/96	Diesel		9973	213	290	07.94-01.00	■
27.293 DFS (D 2865 LF20)	-12/96	Diesel		9973	213	290	01.94-	■
27.293 DFS (D 2865 LF24)	-12/96	Diesel		9973	213	290	01.94-	■
28.293	-12/96	Diesel		9973	213	290	07.94-01.00	■
18.323		Diesel		9973	235	320	06.94-01.00	■
19.323 FS,19.323 FLS,19.323 FLLS (D 2865 LF23)		Diesel		9973	235	320	01.94-12.95	■
22.323	-12/96	Diesel		9973	235	320	07.94-01.00	■
26.323 DFS,26.323 DFSL (D 2865 LF23)		Diesel		9973	235	320	01.94-12.95	■
26.323 FNLS,26.323 FVLS		Diesel		9973	235	320	01.94-12.95	■
27.323	-12/96	Diesel		9973	235	320	07.94-01.00	■
27.323 DFS (D 2865 LF23)		Diesel		9973	235	320	01.94-12.95	■
28.323	-12/96	Diesel		9973	235	320	07.94-01.00	■
33.323 DFS (D 2865 LF23)		Diesel		9973	235	320	01.94-12.95	■
18.343		Diesel		9973	250	340	06.94-01.00	■
19.343 FS,19.343 FLS,19.343 FLLS (D 2865 LF21)	-12/96	Diesel		9973	250	340	01.94-	■
19.344		Diesel		9973	250	340	06.94-01.00	■
22.343	-12/96	Diesel		9973	250	340	07.94-01.00	■
26.343 DFS,26.343 DFSL (D 2865 LF21)	-12/96	Diesel		9973	250	340	01.94-	■
27.343	-12/96	Diesel		9973	250	340	07.94-01.00	■
27.343 DFS (D 2865 LF21)	-12/96	Diesel		9973	250	340	01.94-	■

## LISTA DE APLICACIONES - BUYERS GUIDE

28.343		-12/96	Diesel		9973	250	340	07.94-01.00	■
33.343 DFS (D 2865 LF21)		-12/96	Diesel		9973	250	340	01.94-	■
18.314		-12/96	Diesel		11967	228	310	06.94-05.02	■
18.364		-12/96	Diesel		11967	265	360	06.94-05.02	■
38.364			Diesel		11967	265	360	08.94-02.05	■
19.373 FS, FLS, FLLS, FRS, FLRS, FLLRS (D 2866 LF21)			Diesel		11967	272	370	01.94-	■
24.373			Diesel		11967	272	370	06.94-02.05	■
24.373			Diesel		11967	272	370	06.94-02.05	■
26.373 DFS,26.373 DFLS (D 2866 LF21)			Diesel		11967	272	370	01.94-12.95	■
26.373 FNLS,26.373 FVLS (D 2866 LF21)			Diesel		11967	272	370	01.94-12.95	■
26.373 FNLS,26.373 FVLS			Diesel		11967	272	370	01.94-12.95	■
27.373 DFS (D 2866 LF21)			Diesel		11967	272	370	01.94-	■
33.373 DFS, DFRS (D 2866 LF21)			Diesel		11967	272	370	01.94-	■
19.403 FS, FLS, FLLS, FRS, FLRS, FLLRS (D 2866 LF20)		-12/96	Diesel		11967	294	400	01.94-	■
26.403 DFS,26.403 DFLS (D 2866 LF20)		-12/96	Diesel		11967	294	400	01.94-	■
26.403 FNLS,26.403 FVLS (D 2866 LF20)		-12/96	Diesel		11967	294	400	01.94-	■
27.403 DFS (D 2866 LF20)		-12/96	Diesel		11967	294	400	01.94-	■
33.403 DFS, DFRS (D 2866 LF20)		-12/96	Diesel		11967	294	400	01.94-	■
40.403 DFAS (D 2866 LF20)		-12/96	Diesel		11967	294	400	01.94-	■
18.414		-12/96	Diesel		11967	301	409	06.94-05.02	■
38.414			Diesel		11967	301	409	08.94-02.05	■
19.423 FS, FLS, FLLS (D 2866 LF22)			Diesel		11967	309	420	01.94-	■
24.423			Diesel		11967	309	420	06.94-02.05	■
24.423			Diesel		11967	309	420	06.94-02.05	■
26.423 DFS,26.423 DFLS (D 2866 LF22)			Diesel		11967	309	420	01.94-12.95	■
26.423 FNLS,26.423 FVLS (D 2866 LF22)			Diesel		11967	309	420	01.94-12.95	■
26.423 FNLS,26.423 FVLS			Diesel		11967	309	420	01.94-12.95	■
27.423 DFS (D 2866 LF22)			Diesel		11967	309	420	01.94-	■
33.423 DFS, DFRS (D 2866 LF22)			Diesel		11967	309	420	01.94-	■
38.423			Diesel		11967	309	420	08.94-02.05	■
18.414		-12/96	Diesel		12816	301	409	06.94-05.02	■
19.414		-12/96	Diesel		12816	301	409	06.94-08.05	■
27.414			Diesel		12816	301	409	08.94-02.05	■
33.414			Diesel		12816	301	409	08.94-02.05	■
38.414			Diesel		12816	301	409	08.94-02.05	■
18.464		-12/96	Diesel		12816	338	460	06.94-05.02	■
19.463 FS, FLS, FLLS, FRS, FLRS, FLLRS (D 2876 LF 02)		-12/96	Diesel		12816	338	460	01.94-	■
26.463 DFS, DFLS (D 2876 LF 02)		-12/96	Diesel		12816	338	460	01.94-	■
26.463 FNLS, FVLS, FVLR (D 2876 LF 02)		-12/96	Diesel		12816	338	460	01.94-	■
27.463 DFS (D 2876 LF 02)		-12/96	Diesel		12816	338	460	01.94-	■
27.464 DFS (D 2876 LF 06)		-12/96	Diesel		12816	338	460	01.94-	■
33.463 DFS, DFRS (D 2876 LF 02)		-12/96	Diesel		12816	338	460	01.94-	■
38.463			Diesel		12816	338	460	08.94-02.05	■
38.464			Diesel		12816	338	460	08.94-02.05	■
40.463 DFS (D 2876 LF 02)		-12/96	Diesel		12816	338	460	01.94-	■
19.603 FLS, 19604 FLS (D 2840 LF20)		-12/96	Diesel		18273	441	600	04.96-	■
26.603 DFS, DFLS (D 2840 LF20)		-12/96	Diesel		18273	441	600	06.96-	■
27.603 DFS (D 2840 LF20)		-12/96	Diesel		18273	441	600	01.96-	■
33.603 DFS, DFRS (D 2840 LF20)		-12/96	Diesel		18273	441	600	06.96-	■

# LISTA DE APLICACIONES - BUYERS GUIDE

<b>F90 06.86-12.97</b>					<b>Dump Truck</b>			
24.502 DFK (D 2840 LF01)	Diesel		18273	368	500	02.90-12.90	■	
<b>F90 06.86-12.97</b>					<b>Platform/Chassis</b>			
22.462	Diesel		18273	338	460	01.89-06.92	■	
25.462	Diesel		18273	338	460	01.91-06.92	■	
19.502 F,19.502 FL,19.502 FLL (D 2840 LF01)	Diesel		18273	368	500	02.90-06.96	■	
19.502 F,19.502 FL,19.502 FLL (D 2840 LF04)	Diesel		18273	368	500	02.90-06.96	■	
19.502 F,19.502 FL,19.502 FLL (D 2840 LF06)	Diesel		18273	368	500	02.90-06.96	■	
22.502	Diesel		18273	368	500	04.90-03.97	■	
24.502 DF (D 2840 LF01)	Diesel		18273	368	500	02.90-12.90	■	
24.502 FNL (D 2840 LF01)	Diesel		18273	368	500	02.90-12.90	■	
25.502 DF (D 2840 LF01)	Diesel		18273	368	500	09.90-12.92	■	
25.502 DF (D 2840 LF04)	Diesel		18273	368	500	09.90-12.92	■	
26.502 DF (D 2840 LF01)	Diesel		18273	368	500	02.90-06.96	■	
26.502 DF (D 2840 LF04)	Diesel		18273	368	500	02.90-06.96	■	
26.502 DF (D 2840 LF06)	Diesel		18273	368	500	02.90-06.96	■	
26.502 FNL,26.502 FNLL (D 2840 LF01)	Diesel		18273	368	500	09.91-06.96	■	
26.502 FNL,26.502 FNLL (D 2840 LF04)	Diesel		18273	368	500	09.91-06.96	■	
26.502 FNL,26.502 FNLL (D 2840 LF06)	Diesel		18273	368	500	09.91-06.96	■	
33.502 DF (D 2840 LF01)	Diesel		18273	368	500	09.91-06.96	■	
33.502 DF (D 2840 LF04)	Diesel		18273	368	500	09.91-06.96	■	
33.502 DF (D 2840 LF06)	Diesel		18273	368	500	09.91-06.96	■	
<b>F90 06.86-12.97</b>					<b>Truck Tractor</b>			
22.462	Diesel		18273	338	460	01.89-06.92	■	
25.462	Diesel		18273	338	460	01.91-06.92	■	
19.502 FS,19.502 FLS,19.502 FLLS (D 2840 LF01)	Diesel		18273	368	500	02.90-06.96	■	
19.502 FS,19.502 FLS,19.502 FLLS (D 2840 LF04)	Diesel		18273	368	500	02.90-06.96	■	
19.502 FS,19.502 FLS,19.502 FLLS (D 2840 LF06)	Diesel		18273	368	500	02.90-06.96	■	
22.502	Diesel		18273	368	500	04.90-01.97	■	
24.502 DFS (D 2840 LF01)	Diesel		18273	368	500	02.90-12.90	■	
25.502 DFS (D 2840 LF01)	Diesel		18273	368	500	09.90-12.92	■	
25.502 DFS (D 2840 LF04)	Diesel		18273	368	500	09.90-12.92	■	
26.502 DFS,26.502 DFSL (D 2840 LF04)	Diesel		18273	368	500	02.90-06.96	■	
26.502 DFS,26.502 DFSL (D 2840 LF06)	Diesel		18273	368	500	02.90-06.96	■	
<b>HOCL</b>					<b>Bus</b>			
18.310 HOCL/R (D 2866 LOH 25)	Diesel		11967	228	310	01.92-	■	■
18.310 HOCL/R (D 2866 LOH 27)	Diesel		11967	228	310	01.92-	■	■
<b>LION'S COACH 09.95-</b>					<b>Bus</b>			
FRH 352,RH 353 (D 2866 LOH 26)	Diesel		11967	257	350	06.96-10.01	■	■
FRH 402,RH 403 (D 2866 LOH 23)	Diesel		11967	294	400	09.95-	■	■
<b>LION'S COMFORT 09.96-</b>					<b>Bus</b>			
RN 313 (D 2866 LUH 20)	Diesel		11967	228	310	09.96-	■	■
RN 313 (D 2866 LUH26)	Diesel		11967	228	310	09.96-	■	■
<b>LION'S STAR 03.91-</b>					<b>Bus</b>			
FRH 352,RH 353 (D 2866 LOH 26)	Diesel		11967	257	350	09.95-02.02	■	■
FRH 402,RH 403 (D 2866 LOH 23)	Diesel		11967	294	400	09.95-10.01	■	■
FRH 422 (D 2866 LOH 20)	Diesel		11967	309	420	01.93-09.96	■	■

# LISTA DE APLICACIONES - BUYERS GUIDE

<b>M 2000 L 04.95-</b>					<b>Concrete Mixer</b>			
26.284 DL-TM, DLR-TM	Diesel		6871	206	280	05.01-	■	
26.285 DL-TM, DLR-TM	Diesel		6871	206	280	05.01-	■	
<b>M 2000 L 04.95-</b>					<b>Dump Truck</b>			
14.163	Diesel		4580	118	160	04.95-03.05	■	
15.163	Diesel		4580	118	160	07.95-04.02	■	
18.223	Diesel		6871	162	220	03.97-08.06	■	
19.224	Diesel		6871	162	220	04.95-08.06	■	
19.225	Diesel		6871	162	220	04.95-08.06	■	
19.255	Diesel		6871	180	245	04.95-08.06	■	
18.255	Diesel		6871	188	256	03.95-02.07	■	
19.255	Diesel		6871	188	256	04.95-08.06	■	
19.264	Diesel		6871	191	260	04.95-08.06	■	
18.263	Diesel		6871	196	266	03.95-04.02	■	
18.264	Diesel		6871	196	266	03.95-02.07	■	
19.264	Diesel		6871	196	266	04.95-08.06	■	
18.283	Diesel		6871	206	280	04.98-08.06	■	
19.284	Diesel		6871	206	280	04.95-08.06	■	
19.285	Diesel		6871	206	280	04.95-08.06	■	
<b>M 2000 L 04.95-</b>					<b>Municipal Vehicle</b>			
18.224, 18.225, L-KO, LR-KO	Diesel		6871	162	220	05.01-	■	
18.255	Diesel		6871	188	256	03.95-02.07	■	
18.263	Diesel		6871	191	260	03.95-04.02	■	
18.263	Diesel		6871	196	266	03.95-04.02	■	
18.264	Diesel		6871	196	266	03.95-02.07	■	
18.285	Diesel		6871	206	280	03.95-02.07	■	
<b>M 2000 L 04.95-</b>					<b>Platform/Chassis</b>			
15.163 LC, LLC, LLLC, LLLRC, LLRC, LRC (D 0824 LFL 06)	Diesel		4580	114	155	08.95-	■	
15.163 LC, LLC, LLLC, LLLRC, LLRC, LRC (D 0824 LFL 09)	Diesel		4580	114	155	08.95-	■	
14.163	Diesel		4580	118	160	04.95-03.05	■	
14.163	Diesel		4580	118	160	02.97-04.01	■	
15.163	Diesel		4580	118	160	07.95-04.02	■	
15.185 LC, LLC, LLLC, LLLRC, LLRC, LRC	Diesel		4580	132	180	05.01-	■	
15.223	Diesel		6871	162	220	03.97-02.07	■	
15.224 LC, LLC, LLLC, LRC, LLRC, LLLRC (D 0826 LFL03)	Diesel		6871	162	220	08.95-	■	
15.224 LC, LLC, LLLC, LRC, LLRC, LLLRC (D 0826 LFL10)	Diesel		6871	162	220	08.95-	■	
15.225 LC, LLC, LLLC, LRC, LLRC, LLLRC, (LE220B) (D 0836 LFL 02)	Diesel		6871	162	220	09.99-	■	
18.223	Diesel		6871	162	220	03.97-08.06	■	
18.224, 18.225, LC, LLC, LLLC, LRC, LLRC, LLLRC (D 0826 LFL03)	Diesel		6871	162	220	08.95-	■	
18.224, 18.225, LC, LLC, LLLC, LRC, LLRC, LLLRC (D 0826 LFL10)	Diesel		6871	162	220	08.95-	■	
18.224, 18.225, LC, LLC, LLLC, LRC, LLRC, LLLRC (D 0836 LFL 02)	Diesel		6871	162	220	08.95-	■	
19.224, 19.225, LC, LLC, LLLC, LLLRC, LLRC, LRC	Diesel		6871	162	224	05.01-	■	
20.224, 20225 LNLC, LNLLC	Diesel		6871	162	224	05.01-	■	
20.224 LNLC, LNLLC	Diesel		6871	162	224	05.01-	■	
15.255 LC, LLC, LLLC, LRC, LLRC, LLLRC, (LE250B) (D 0836 LFL 05)	Diesel		6871	180	245	09.99-	■	

# LISTA DE APLICACIONES - BUYERS GUIDE

18.255 LAC, LARC (D 0836 LFL 05)	Diesel	6871	180	245	05.01-	■
18.255 LC, LLC, LLLC, LRC, LLRC, LLLRC, (LE250B) (D 0836 LFL 05)	Diesel	6871	180	245	09.99-	■
19.255 LC, LLC, LLLC, LLLRC, LLRC, LRC	Diesel	6871	180	245	05.01-	■
20.255 LNLC, LNLLC	Diesel	6871	180	245	05.01-	■
15.255	Diesel	6871	188	256	04.95-08.06	■
18.255	Diesel	6871	188	256	03.95-02.07	■
18.263	Diesel	6871	188	256	03.99-02.07	■
19.255	Diesel	6871	188	256	04.95-08.06	■
20.255	Diesel	6871	188	256	07.95-08.06	■
15.263, 15.264 LC, LLC, LLLC, LRC, LLRC, LLLRC (D 0826 LFL09)	Diesel	6871	191	260	08.95-	■
18.263, 18.264, LC, LLC, LLLC, LRC, LLRC, LLLRC (D 0826 LFL09)	Diesel	6871	191	260	08.95-	■
19.264 LC, LLC, LLLC, LLLRC, LLRC, LRC	Diesel	6871	191	260	05.01-	■
20.264 LNLC, LNLLC	Diesel	6871	191	260	05.01-	■
15.263	Diesel	6871	196	266	04.95-08.06	■
15.264	Diesel	6871	196	266	04.95-08.06	■
18.263	Diesel	6871	196	266	03.95-04.02	■
18.264	Diesel	6871	196	266	03.95-02.07	■
18.275	Diesel	6871	196	266	05.05-02.07	■
19.264	Diesel	6871	196	266	04.95-08.06	■
20.264	Diesel	6871	196	266	07.95-08.06	■
15.284 LC, LLC, LLLC, LRC, LLRC, LLLRC (D 0836 LF 01)	Diesel	6871	206	280	06.98-	■
15.285 LC, LLC, LLLC, LRC, LLRC, LLLRC, (LE280B) (D 0836 LFL 03)	Diesel	6871	206	280	09.99-	■
18.283	Diesel	6871	206	280	04.98-02.07	■
18.284 LC, LLC, LLLC, LRC, LLRC, LLLRC (D 0836 LF 01)	Diesel	6871	206	280	06.98-	■
18.285 LC, LLC, LLLC, LRC, LLRC, LLLRC, (LE280B) (D 0836 LFL 03)	Diesel	6871	206	280	09.99-	■
19.284, 19.285, LC, LLC, LLLC, LLLRC, LLRC, LRC (D 0836 LFL 03)	Diesel	6871	206	280	05.01-	■
20.284, 20.285, LNLC, LNLLC	Diesel	6871	206	280	05.01-	■
<b>M 2000 M 08.95-12.05</b>						<b>Platform/Chassis</b>
18.224 MC, MLC, MLLC, MRC, MLRC, MLLRC (D 0826 LF15)	Diesel	6871	162	220	08.95-12.05	■
18.224 MC, MLC, MLLC, MRC, MLRC, MLLRC (D 0826 LF18)	Diesel	6871	162	220	08.95-12.05	■
23.224	Diesel	6871	162	220	05.95-07.05	■
23.225	Diesel	6871	162	220	05.95-07.05	■
25.224 MNLC, MNLLC, MNLRC, MNLLRC, MVLC (D 0826 LF15)	Diesel	6871	162	220	08.95-12.05	■
25.224 MNLC, MNLLC, MNLRC, MNLLRC, MVLC (D 0826 LF18)	Diesel	6871	162	220	08.95-12.05	■
25.224 MNLC, MNLLC, MNLRC, MNLLRC, MVLC (D 0826 LFL10)	Diesel	6871	162	220	08.95-12.05	■
18.255 MAC, MARC (D 0836 LF 05)	Diesel	6871	180	245	10.00-12.05	■
18.255 MC, MLC, MLLC, MLRC, MRC, MLLRC (D 0836 LF 05)	Diesel	6871	180	245	10.00-12.05	■
23.255	Diesel	6871	180	245	05.95-07.05	■
25.255 MNLC, MNLLC, MNLRC, MNLLRC, MVLC (D 0836 LF 05)	Diesel	6871	180	245	10.00-12.05	■
25.255 MNLC, MNLLC, MNLRC, MNLLRC, MVLC (D 0836 LFL 05)	Diesel	6871	180	245	10.00-12.05	■
18.264 MC, MLC, MLLC, MRC, MLRC, MLLRC (D 0826 LF17)	Diesel	6871	191	260	08.95-12.05	■
23.264	Diesel	6871	191	260	05.95-07.05	■
25.264 MNLC, MNLLC, MNLRC, MNLLRC, MVLC (D 0826 LF17)	Diesel	6871	191	260	08.95-12.05	■

# LISTA DE APLICACIONES - BUYERS GUIDE

23.264		Diesel		6871	196	266	05.95-07.05	■		
25.264		Diesel		6871	196	266	05.95-07.05	■		
18.284 MC, MLC, MLLC, MLRC, MRC, MLLRC (D 0836 LF 01)		Diesel		6871	206	280	06.98-12.05	■		
23.284		Diesel		6871	206	280	05.95-07.05	■		
23.285		Diesel		6871	206	280	05.95-07.05	■		
25.284 MNLC, MNLLC, MNLRC, MNLLRC, MVLC (D 0836 LF 01)		Diesel		6871	206	280	02.00-12.05	■		
<b>M 2000 M 08.95-12.05</b>							<b>Truck Tractor</b>			
18.224 MLS, MLRS (D 0826 LF15)		Diesel		6871	162	220	08.95-12.05	■		
18.224 MLS, MLRS (D 0826 LF18)		Diesel		6871	162	220	08.95-12.05	■		
18.225 MLS, MLRS		Diesel		6871	162	220	02.03-12.05	■		
18.255 MLS, MLRS (D 0836 LF 05)		Diesel		6871	180	245	10.00-12.05	■		
18.264 MLS, MLRS (D 0826 LF17)		Diesel		6871	191	260	08.95-12.05	■		
18.264		Diesel		6871	196	266	04.95-07.05	■		
18.284 MLS, MLRS (D 0836 LF 01)		Diesel		6871	206	280	06.98-12.05	■		
<b>NL 09.88-</b>										
313		Diesel		11967	230	313	01.95-10.97	■	■	
350		Diesel		11967	257	349	01.95-10.01	■	■	
370		Diesel		11967	272	370	01.92-10.97	■	■	
400		Diesel		11967	294	400	01.95-03.08	■	■	
420		Diesel		11967	309	420	01.92-10.97	■	■	