

LISTA DE APLICACIONES - BUYERS GUIDE

79PB4001 C



8 424073 205971

Weight: 900

O.E.M.	MAKE
1163244	BMW
1163255	BMW
1165968	BMW
2213310	BMW
34212213310	BMW
34411163244	BMW
34411163255	BMW
34411165968	BMW
34416755273	BMW
34416761290	BMW
34416761291	BMW
6755273	BMW
6761290	BMW
6761291	BMW



79PB4001 C

(E) 90R-01489/082



MAKE
ALPINA
BMW
BMW (BRILLIANCE)



Trac.	CC	Kw	CV
-------	----	----	----



Front / Rear

ALPINA

ROADSTER S (E85) 07.03-12.05

Convertible (Sports car-S Segment)

3.3 (E 5/2)	Gasolina	RWD	3346	221	300	07.03-12.05	■
-------------	----------	-----	------	-----	-----	-------------	---

BMW

1 Serie (E88) 12.07-12.13

Convertible (Compact car-C Segment)

118 i (N46 B20 B)	Gasolina	RWD	1995	100	136	09.08-12.13	■
118 i (N43 B20 A)	Gasolina	RWD	1995	105	143	03.08-10.13	■
120 i (N46 B20 B)	Gasolina	RWD	1995	115	156	03.08-12.13	■
120 i (N46 B20 C)	Gasolina	RWD	1995	115	156	03.08-12.13	■
120 i (N46 B20 E)	Gasolina	RWD	1995	115	156	03.08-12.13	■
120 i (N43 B20 A)	Gasolina	RWD	1995	120	163	03.08-12.13	■
120 i (N43 B20 A)	Gasolina	RWD	1995	125	170	12.07-10.13	■
125 i (N52 B30 A)	Gasolina	RWD	2996	160	218	12.07-10.13	■
125 i (N52 B30 B)	Gasolina	RWD	2996	160	218	12.07-10.13	■
125 i (N52 B30 BF)	Gasolina	RWD	2996	160	218	12.07-10.13	■
128 i (N51 B30 A)	Gasolina	RWD	2996	172	234	12.07-10.13	■
128 i (N52 B30 A)	Gasolina	RWD	2996	172	234	12.07-10.13	■
118 d (N47 D20 A)	Diesel	RWD	1995	100	136	09.08-12.13	■
118 d (N47 D20 C)	Diesel	RWD	1995	100	136	09.08-12.13	■
118 d (N47 D20 A)	Diesel	RWD	1995	105	143	09.08-12.13	■
118 d (N47 D20 C)	Diesel	RWD	1995	105	143	09.08-12.13	■
120 d (N47 D20 A)	Diesel	RWD	1995	120	163	03.08-12.13	■
120 d (N47 D20 C)	Diesel	RWD	1995	120	163	03.08-12.13	■
120 d (N47 D20 A)	Diesel	RWD	1995	130	177	03.08-12.13	■

LISTA DE APLICACIONES - BUYERS GUIDE

120 d (N47 D20 C)		Diesel	RWD	1995	130	177	03.08-12.13	■
120 d (N47 D20 C)		Diesel	RWD	1995	145	197	03.08-12.13	■
1 Serie (E82) 10.06-10.13					Coupe (Compact car-C Segment)			
120 i (N46 B20 B)		Gasolina	RWD	1995	115	156	09.09-10.13	■
120 i (N46 B20 BD)		Gasolina	RWD	1995	115	156	09.09-10.13	■
120 i (N46 B20 C)		Gasolina	RWD	1995	115	156	09.09-10.13	■
120 i (N46 B20 E)		Gasolina	RWD	1995	115	156	09.09-10.13	■
120 i (N43 B20 A)		Gasolina	RWD	1995	125	170	10.07-10.13	■
125 i (N52 B30 A)		Gasolina	RWD	2996	160	218	03.08-10.13	■
125 i (N52 B30 B)		Gasolina	RWD	2996	160	218	03.08-10.13	■
125 i (N52 B30 BF)		Gasolina	RWD	2996	160	218	03.08-10.13	■
128 i (N51 B30 A,N52 B30 A)		Gasolina	RWD	2996	172	234	10.07-10.13	■
118 d (N47 D20 C)		Diesel	RWD	1995	100	136	09.09-10.13	■
118 d (N47 D20 C)		Diesel	RWD	1995	105	143	09.09-10.13	■
120 d (N47 D20 A)		Diesel	RWD	1995	120	163	09.07-10.13	■
120 d (N47 D20 C)		Diesel	RWD	1995	120	163	09.07-10.13	■
120 d (N47 D20 A)		Diesel	RWD	1995	130	177	09.07-10.13	■
120 d (N47 D20 C)		Diesel	RWD	1995	130	177	09.07-10.13	■
120 d (N47 D20 A)		Diesel	RWD	1995	145	197	09.07-10.13	■
120 d (N47 D20 C)		Diesel	RWD	1995	145	197	09.07-10.13	■
1 Serie (E87) 02.03-01.13					Hatchback (Compact car-C Segment)			
116 i (N45 B16 A)		Gasolina	RWD	1596	85	115	06.04-06.11	■
116 i (N45 B16 A)		Gasolina	RWD	1596	85	115	09.07-12.11	■
116 i (N43 B16 AA)		Gasolina	RWD	1599	90	122	09.07-06.11	■
116 i (N43 B16 AA)		Gasolina	RWD	1599	90	122	03.07-12.11	■
116 i (N43 B20 A)		Gasolina	RWD	1995	90	122	01.09-06.11	■
116 i (N43 B20 A)		Gasolina	RWD	1995	90	122	11.08-12.11	■
118 i (N46 B20 B)		Gasolina	RWD	1995	95	129	07.04-02.07	■
118 i (N46 B20 B)		Gasolina	RWD	1995	95	129	09.06-02.08	■
118 i (N46 B20 B)		Gasolina	RWD	1995	100	136	10.06-06.11	■
118 i (N46 B20 B)		Gasolina	RWD	1995	100	136	09.06-12.11	■
118 i (N43 B20 A)		Gasolina	RWD	1995	105	143	09.06-06.11	■
118 i (N43 B20 A)		Gasolina	RWD	1995	105	143	09.06-12.11	■
120 i (N46 B20 B)		Gasolina	RWD	1995	110	150	06.04-02.07	■
120 i (N46 B20 BD)		Gasolina	RWD	1995	110	150	06.04-02.07	■
120 i (N46 B20 C)		Gasolina	RWD	1995	110	150	06.04-02.07	■
120 i (N46 B20 CC)		Gasolina	RWD	1995	110	150	06.04-02.07	■
120 i (N46 B20 A)		Gasolina	RWD	1995	115	156	03.07-06.11	■
120 i (N46 B20 B)		Gasolina	RWD	1995	115	156	03.07-06.11	■
120 i (N46 B20 BD)		Gasolina	RWD	1995	115	156	03.07-06.11	■
120 i (N46 B20 C)		Gasolina	RWD	1995	115	156	03.07-06.11	■
120 i (N46 B20 CC)		Gasolina	RWD	1995	115	156	03.07-06.11	■
120 i (N46 B20 B)		Gasolina	RWD	1995	115	156	03.07-12.11	■
120 i (N46 B20 C)		Gasolina	RWD	1995	115	156	03.07-12.11	■
120 i (N43 B20 A)		Gasolina	RWD	1995	120	163	03.07-06.11	■
120 i (N43 B20 A)		Gasolina	RWD	1995	120	163	03.07-12.11	■
118 i (N43 B20 A)		Gasolina	RWD	1995	125	170	03.07-12.07	■
120 i (N43 B20 A)		Gasolina	RWD	1995	125	170	03.07-06.11	■
120 i (N43 B20 A)		Gasolina	RWD	1995	125	170	03.07-09.12	■
116 d (N47 D20 C)		Diesel	RWD	1995	66	90	01.11-12.11	■

LISTA DE APLICACIONES - BUYERS GUIDE

116 d (N47 D20 A)		Diesel	RWD	1995	66	90	01.11-12.11	■
116 d (N47 D20 C)		Diesel	RWD	1995	66	90	01.11-12.11	■
116 d (N47 D20 A)		Diesel	RWD	1995	85	116	03.09-06.11	■
116 d (N47 D20 C)		Diesel	RWD	1995	85	116	03.09-06.11	■
116 d (N47 D20 A)		Diesel	RWD	1995	85	116	11.08-12.11	■
116 d (N47 D20 C)		Diesel	RWD	1995	85	116	11.08-12.11	■
118 d (M47 D20 (204D4))		Diesel	RWD	1995	90	122	06.04-02.07	■
118 d (N47 D20 A)		Diesel	RWD	1995	100	136	03.07-06.11	■
118 d (N47 D20 C)		Diesel	RWD	1995	100	136	03.07-06.11	■
118 d (N47 D20 A)		Diesel	RWD	1995	100	136	09.06-12.11	■
118 d (N47 D20 C)		Diesel	RWD	1995	100	136	09.06-12.11	■
118 d (N47 D20 A)		Diesel	RWD	1995	105	143	03.07-06.11	■
118 d (N47 D20 C)		Diesel	RWD	1995	105	143	03.07-06.11	■
118 d (N47 D20 A)		Diesel	RWD	1995	105	143	09.06-12.11	■
118 d (N47 D20 C)		Diesel	RWD	1995	105	143	09.06-12.11	■
120 d (M47 D20 (204D4))		Diesel	RWD	1995	110	150	06.04-02.07	■
120 d (M47 D20 (204D4))		Diesel	RWD	1995	115	156	05.06-02.07	■
120 d (M47 D20 (204D4))		Diesel	RWD	1995	120	163	06.04-06.11	■
120 d (N47 D20 A)		Diesel	RWD	1995	120	163	06.04-06.11	■
120 d (N47 D20 A)		Diesel	RWD	1995	120	163	03.07-12.11	■
120 d (N47 D20 C)		Diesel	RWD	1995	120	163	03.07-12.11	■
120 d (N47 D20 A)		Diesel	RWD	1995	125	170	03.07-10.10	■
120 d (N47 D20 A)		Diesel	RWD	1995	130	177	03.07-06.11	■
120 d (N47 D20 C)		Diesel	RWD	1995	130	177	03.07-06.11	■
120 d (N47 D20 A)		Diesel	RWD	1995	130	177	03.07-12.11	■
120 d (N47 D20 C)		Diesel	RWD	1995	130	177	03.07-12.11	■
120 d (N47 D20 A)		Diesel	RWD	1995	145	197	03.07-12.11	■
120 d (N47 D20 C)		Diesel	RWD	1995	145	197	03.07-12.11	■
1 Serie II (F20) 07.11-06.19					Hatchback (Compact car-C Segment)			
116 i (B38 B15 A)		Gasolina	RWD	1499	80	109	03.15-06.19	■
116 i (B38 B15 A)		Gasolina	RWD	1499	80	109	03.15-06.19	■
118 i (B38 B15 A)		Gasolina	RWD	1499	100	136	07.15-06.19	■
118 i (B38 B15 A)		Gasolina	RWD	1499	100	136	03.15-06.19	■
114 i (N13 B16 A)		Gasolina	RWD	1598	75	102	07.12-02.15	■
114 i (N13 B16 A)		Gasolina	RWD	1598	75	102	07.12-01.15	■
116 i (N13 B16 A)		Gasolina	RWD	1598	100	136	07.11-02.15	■
116 i (N13 B16 A)		Gasolina	RWD	1598	100	136	12.11-02.15	■
118 i (N13 B16 A)		Gasolina	RWD	1598	100	136	03.15-06.15	■
118 i (N13 B16 A)		Gasolina	RWD	1598	100	136	03.15-06.19	■
118 i (N13 B16 A)		Gasolina	RWD	1598	125	170	07.11-02.15	■
118 i (N13 B16 A)		Gasolina	RWD	1598	125	170	07.12-06.19	■
120 i (N13 B16 A)		Gasolina	RWD	1598	130	177	03.15-06.16	■
120 i (N13 B16 A)		Gasolina	RWD	1598	130	177	03.15-06.19	■
120 i Active Flex		Gasolina	FWD	1997	135	184	03.15-	■
125 i (N20 B20 A)		Gasolina	RWD	1997	160	218	03.12-11.17	■
125 i (N20 B20 A)		Gasolina	RWD	1997	160	218	12.11-12.19	■
125 i (N20 B20 A)		Gasolina	RWD	1997	175	238	03.12-11.17	■
125 i (N20 B20 A)		Gasolina	RWD	1997	175	238	03.13-06.19	■
120 i (B48 B20 A)		Gasolina	RWD	1998	135	184	07.16-06.19	■
120 i (B48 B20 A)		Gasolina	RWD	1998	135	184	07.16-06.19	■
125 i (B48 B20 B)		Gasolina	RWD	1998	165	224	07.16-06.19	■

LISTA DE APLICACIONES - BUYERS GUIDE

125 i (B48 B20 B)	Gasolina	RWD	1998	165	224	10.15-06.19
M 135 i (N55 B30 A)	Gasolina	RWD	2979	235	320	07.12-02.15
M 135 i (N55 B30 A)	Gasolina	RWD	2979	235	320	12.11-06.16
M 135 i xDrive (N55 B30 A)	Gasolina	4WD	2979	235	320	11.12-02.15
M 135 i xDrive (N55 B30 A)	Gasolina	4WD	2979	235	320	02.12-06.16
M 135 i (N55 B30 A)	Gasolina	RWD	2979	240	326	03.15-06.16
M 135 i (N55 B30 A)	Gasolina	RWD	2979	240	326	03.15-06.16
M 135 i xDrive (N55 B30 A)	Gasolina	4WD	2979	240	326	03.15-06.16
M 135 i xDrive (N55 B30 A)	Gasolina	4WD	2979	240	326	03.15-06.16
M 140 i (B58 B30 A)	Gasolina	RWD	2998	250	340	07.16-06.19
M 140 i (B58 B30 A)	Gasolina	RWD	2998	250	340	10.15-06.19
M 140 i xDrive (B58 B30 A)	Gasolina	4WD	2998	250	340	07.16-06.19
M 140 i xDrive (B58 B30 A)	Gasolina	4WD	2998	250	340	09.15-06.19
125 i Active Flex (N20 B20 A)	Gasol./Etanol	RWD	1997	160	218	11.14-11.17
125 i Active Flex	Gasol./Etanol	RWD	1997	160	218	08.14-
114 D (B37 D15 A)	Diesel	RWD	1496	70	95	07.15-06.19
114 D (B37 D15 A)	Diesel	RWD	1496	70	95	06.15-05.19
116 d (B37 D15 A)	Diesel	RWD	1496	85	116	03.15-06.19
116 d (B37 D15 A)	Diesel	RWD	1496	85	116	03.15-05.19
114 D (N47 D16 A)	Diesel	RWD	1598	70	95	11.12-06.15
114 D (N47 D16 A)	Diesel	RWD	1598	70	95	07.12-05.19
116 d (N47 D16 A)	Diesel	RWD	1598	85	116	03.12-02.15
116 d (N47 D16 A)	Diesel	RWD	1598	85	116	12.11-02.15
116 d (N47 D20 C)	Diesel	RWD	1995	85	116	07.11-02.15
116 d (N47 D20 C)	Diesel	RWD	1995	85	116	07.12-02.15
118 d (B47 D20 A)	Diesel	RWD	1995	100	136	07.11-06.19
118 d (N47 D20 C)	Diesel	RWD	1995	100	136	07.11-06.19
118 d (N47 D20 C)	Diesel	RWD	1995	100	136	12.11-06.19
118 d (N47 D20 C)	Diesel	RWD	1995	105	143	07.11-02.15
118 d (N47 D20 C)	Diesel	RWD	1995	105	143	12.11-02.15
118 d xDrive (N47 D20 C)	Diesel	4WD	1995	105	143	07.13-02.15
118 d xDrive (N47 D20 C)	Diesel	4WD	1995	105	143	05.13-02.15
118 d (B47 D20 A)	Diesel	RWD	1995	110	150	03.15-06.19
118 d (B47 D20 A)	Diesel	RWD	1995	110	150	03.15-06.19
118 d xDrive (B47 D20 A)	Diesel	4WD	1995	110	150	03.15-06.19
118 d xDrive (B47 D20 A)	Diesel	4WD	1995	110	150	03.15-05.19
120 d (B47 D20 A)	Diesel	RWD	1995	120	163	07.11-06.19
120 d (N47 D20 C)	Diesel	RWD	1995	120	163	07.11-06.19
120 d (N47 D20 C)	Diesel	RWD	1995	120	163	07.12-06.19
120 d (N47 D20 C)	Diesel	RWD	1995	135	184	07.11-02.15
120 d (N47 D20 C)	Diesel	RWD	1995	135	184	07.12-02.15
120 d xDrive (N47 D20 C)	Diesel	4WD	1995	135	184	11.12-02.15
120 d xDrive (N47 D20 C)	Diesel	4WD	1995	135	184	02.12-02.15
120 d (B47 D20 A)	Diesel	RWD	1995	140	190	03.15-06.19
120 d (B47 D20 A)	Diesel	RWD	1995	140	190	03.15-06.19
120 d xDrive (B47 D20 A)	Diesel	4WD	1995	140	190	03.15-06.19
120 d xDrive (B47 D20 A)	Diesel	4WD	1995	140	190	03.15-06.19
120 d (N47 D20 C)	Diesel	RWD	1995	147	200	07.11-02.15
120 d (N47 D20 C)	Diesel	RWD	1995	147	200	01.12-02.15
120 d xDrive (N47 D20 C)	Diesel	4WD	1995	147	200	11.12-02.15
120 d xDrive (N47 D20 C)	Diesel	4WD	1995	147	200	01.12-02.15

LISTA DE APLICACIONES - BUYERS GUIDE

120 d		Diesel	RWD	1995	151	205	03.15-06.19	■
120 d		Diesel	RWD	1995	151	205	03.15-06.19	■
120 d xDrive		Diesel	4WD	1995	151	205	03.15-06.19	■
120 d xDrive		Diesel	4WD	1995	151	205	03.15-06.19	■
125 d (B47 D20 B)		Diesel	RWD	1995	155	211	03.12-06.19	■
125 d (N47 D20 D)		Diesel	RWD	1995	155	211	03.12-06.19	■
125 d (N47 D20 D)		Diesel	RWD	1995	155	211	12.11-05.19	■
125 d (N47 D20 D)		Diesel	RWD	1995	160	218	03.12-02.15	■
125 d (N47 D20 D)		Diesel	RWD	1995	160	218	12.11-02.15	■
125 d (B47 D20 B)		Diesel	RWD	1995	165	224	03.15-06.19	■
125 d (B47 D20 B)		Diesel	RWD	1995	165	224	03.15-05.19	■
1 Serie II Van (F20) 03.15-06.19					Hatchback Van (Compact car-C Segment)			
118 i (B38 B15 A)		Gasolina	RWD	1499	100	136	07.15-06.19	■
120 i (B48 B20 A)		Gasolina	RWD	1998	135	184	07.16-06.19	■
M 140 i (B58 B30 A)		Gasolina	RWD	2998	250	340	07.16-06.19	■
118 d (B47 D20 A)		Diesel	RWD	1995	110	150	03.15-06.19	■
120 d (B47 D20 A)		Diesel	RWD	1995	140	190	03.15-06.19	■
2 Serie (F23) 03.14-					Convertible (Compact car-C Segment)			
218i (B38 B15 A)		Gasolina	RWD	1499	100	136	03.15-06.21	■
220 i (B38 B15 A)		Gasolina	RWD	1499	100	136	10.17-	■
220 i (N20 B20 A)		Gasolina	RWD	1997	135	184	04.14-06.21	■
220 i (N20 B20 B)		Gasolina	RWD	1997	135	184	04.14-06.21	■
228 i (N20 B20 A)		Gasolina	RWD	1997	180	245	11.14-06.16	■
228 i		Gasolina	FWD	1997	180	245	09.15-	■
218i		Gasolina	RWD	1998	100	136	11.20-06.21	■
220 i (B48 B20 A)		Gasolina	RWD	1998	135	184	09.15-06.21	■
225 i (B48 B20 A)		Gasolina	RWD	1998	135	184	10.17-06.21	■
230 i (B46 B20 B)		Gasolina	RWD	1998	185	252	07.16-06.21	■
230 i (B48 B20 B)		Gasolina	RWD	1998	185	252	07.16-06.21	■
230 i		Gasolina	FWD	1998	185	252	09.16-	■
M 235 i (N55 B30 A)		Gasolina	RWD	2979	240	326	11.14-06.16	■
M 235 i xDrive (N55 B30 A)		Gasolina	4WD	2979	240	326	07.15-06.16	■
M240 i (B58 B30 A)		Gasolina	RWD	2998	250	340	09.15-06.21	■
M240 i xDrive (B58 B30 A)		Gasolina	4WD	2998	250	340	09.15-06.21	■
218d (B47 D20 A)		Diesel	RWD	1995	100	136	07.15-09.20	■
218d (B47 D20 A)		Diesel	RWD	1995	110	150	07.15-09.20	■
220 D (B47 D20 A)		Diesel	RWD	1995	120	163	03.14-09.20	■
220 D (B47 D20 A)		Diesel	RWD	1995	140	190	03.14-09.20	■
220 D		Diesel	RWD	1995	151	205	03.14-09.20	■
225 d (B47 D20 B)		Diesel	RWD	1995	165	224	07.15-05.19	■
2 Serie (F22, F87) 10.12-					Coupe (Compact car-C Segment)			
218i (B38 B15 A)		Gasolina	RWD	1499	100	136	03.15-06.21	■
220 i (B38 B15 A)		Gasolina	RWD	1499	100	136	10.17-	■
220 i (N20 B20 A)		Gasolina	RWD	1997	135	184	10.13-06.21	■
220 i (N20 B20 B)		Gasolina	RWD	1997	135	184	10.13-06.21	■
228 i (N20 B20 A)		Gasolina	RWD	1997	179	243	01.14-	■
228 i (N20 B20 A)		Gasolina	RWD	1997	180	245	07.14-06.16	■
228 i (N26 B20 A)		Gasolina	RWD	1997	180	245	07.14-06.16	■
228 i xDrive (N70 B20 A,N26 B20 A)		Gasolina	4WD	1997	180	245	01.14-	■
220 i (B48 B20 A)		Gasolina	RWD	1998	135	184	09.15-06.21	■

LISTA DE APLICACIONES - BUYERS GUIDE

225 i		Gasolina	RWD	1998	135	184	10.17-06.21	■
230 i (B46 B20 B)		Gasolina	RWD	1998	185	252	07.16-06.21	■
230 i (B48 B20 B)		Gasolina	RWD	1998	185	252	07.16-06.21	■
230 i		Gasolina	FWD	1998	185	252	09.16-	■
M 235 i		Gasolina	FWD	2979	235	320	03.14-	■
M 235 i (N55 B30 A)		Gasolina	RWD	2979	240	326	10.13-06.16	■
M 235 i xDrive (N55 B30 A)		Gasolina	4WD	2979	240	326	07.14-06.16	■
M240 i (B58 B30 A)		Gasolina	RWD	2998	250	340	09.15-06.21	■
M240 i xDrive (B58 B30 A)		Gasolina	4WD	2998	250	340	09.15-06.21	■
218d (B47 D20 A)		Diesel	RWD	1995	100	136	03.14-09.20	■
218d (N47 D20 C)		Diesel	RWD	1995	100	136	03.14-09.20	■
218d (N47 D20 C)		Diesel	RWD	1995	105	143	03.14-06.15	■
218d (B47 D20 A)		Diesel	RWD	1995	110	150	07.15-09.20	■
220 D (B47 D20 A)		Diesel	RWD	1995	120	163	11.14-09.20	■
220 D (N47 D20 C)		Diesel	RWD	1995	120	163	11.14-09.20	■
220 d xDrive (B47 D20 A)		Diesel	4WD	1995	120	163	03.15-09.20	■
220 D (N47 D20 C)		Diesel	RWD	1995	135	184	10.13-06.17	■
220 D (B47 D20 A)		Diesel	RWD	1995	140	190	03.14-09.20	■
220 d xDrive (B47 D20 A)		Diesel	4WD	1995	140	190	06.14-09.20	■
220 D (N47 D20 C)		Diesel	RWD	1995	147	200	10.12-11.14	■
220 D		Diesel	RWD	1995	151	205	03.14-09.20	■
220 d xDrive		Diesel	4WD	1995	151	205	06.14-09.20	■
225 d (N47 D20 D)		Diesel	RWD	1995	160	218	01.14-06.17	■
225 d (B47 D20 B)		Diesel	RWD	1995	165	224	07.15-05.19	■
3 Serie IV (E46) 04.00-12.07					Convertible (Compact executive car-D Segment)			
318 Ci (N42 B20 A)		Gasolina	RWD	1995	100	136	12.00-08.06	■
318 Ci (N46 B20 A)		Gasolina	RWD	1995	100	136	12.00-08.06	■
318 Ci (N42 B20 A)		Gasolina	RWD	1995	105	143	09.01-12.07	■
318 Ci (N46 B20 A)		Gasolina	RWD	1995	105	143	09.01-12.07	■
318 Ci (N46 B20 A)		Gasolina	RWD	1995	110	150	03.04-08.06	■
318 Ci (N46 B20 C)		Gasolina	RWD	1995	110	150	03.04-08.06	■
320 Ci (M54 B22 (226S1))		Gasolina	RWD	2171	120	163	01.06-12.07	■
320 Ci (M54 B22 (226S1))		Gasolina	RWD	2171	125	170	09.00-12.07	■
323 Ci (M52 B25 (256S4))		Gasolina	RWD	2494	120	163	04.00-09.00	■
323 Ci (M52 B25 (256S4))		Gasolina	RWD	2494	125	170	04.00-09.00	■
325 Ci (M54 B25 (256S5))		Gasolina	RWD	2494	141	192	09.00-08.06	■
320 Cd (M47 D20 (204D4))		Diesel	RWD	1995	110	150	02.05-12.07	■
3 Serie IV (E46) 12.98-07.06					Coupe (Compact executive car-D Segment)			
316 Ci (M43 B16 (164E3))		Gasolina	RWD	1596	77	105	04.00-07.06	■
316 Ci (N45 B16 A)		Gasolina	RWD	1596	85	115	06.02-07.06	■
318 Ci (M43 B19 (194E1))		Gasolina	RWD	1895	85	116	12.99-08.01	■
318 Ci (M43 B19 (194E1))		Gasolina	RWD	1895	87	118	12.99-08.01	■
320 Ci (M52 B20 (206S4))		Gasolina	RWD	1990	110	150	02.99-08.01	■
318 Ci (N42 B20 A)		Gasolina	RWD	1995	100	136	12.00-05.06	■
318 Ci (N46 B20 A)		Gasolina	RWD	1995	100	136	12.00-05.06	■
318 Ci (N42 B20 A)		Gasolina	RWD	1995	105	143	09.01-02.04	■
318 Ci (N46 B20 A)		Gasolina	RWD	1995	110	150	03.04-05.06	■
318 Ci (N46 B20 C)		Gasolina	RWD	1995	110	150	03.04-05.06	■
320 Ci (M54 B22 (226S1))		Gasolina	RWD	2171	120	163	01.00-05.06	■
320 Ci (M54 B22 (226S1))		Gasolina	RWD	2171	125	170	01.00-05.06	■

LISTA DE APLICACIONES - BUYERS GUIDE

323 Ci (M52 B25 (256S4))		Gasolina	RWD	2494	120	163	04.99-09.00	■
323 Ci (M52 B25 (256S4))		Gasolina	RWD	2494	125	170	04.99-09.00	■
323 i (M52 B25 (256S4))		Gasolina	RWD	2494	127	173	04.99-12.00	■
325i (M53 B25 (256S6))		Gasolina	RWD	2494	132	179	09.02-05.06	■
325 Ci (M54 B25 (256S5))		Gasolina	RWD	2494	137	186	09.00-07.06	■
325 Ci (M54 B25 (256S5))		Gasolina	RWD	2494	141	192	09.00-05.06	■
328 Ci (M52 B28 (286S2))		Gasolina	RWD	2793	142	193	12.98-05.00	■
320 Cd (M47 D20 (204D4))		Diesel	RWD	1995	110	150	11.03-07.06	■
3 Serie IV (E46) 12.97-05.05					Saloon (Compact executive car-D Segment)			
316 i (M43 B16 (164E3))		Gasolina	RWD	1596	77	105	04.00-02.05	■
316 i (N40 B16 A)		Gasolina	RWD	1596	85	115	06.02-02.05	■
316 i (N45 B16 A)		Gasolina	RWD	1596	85	115	06.02-02.05	■
316 i (N42 B18 A)		Gasolina	RWD	1796	85	115	02.02-02.05	■
316 i (N46 B18 A)		Gasolina	RWD	1796	85	115	02.02-02.05	■
316 i (M43 B19 (194E1))		Gasolina	RWD	1895	77	105	12.98-02.02	■
318i (M43 B19 (194E1))		Gasolina	RWD	1895	87	118	12.97-09.01	■
320i (M52 B20 (206S4))		Gasolina	RWD	1990	110	150	03.98-09.00	■
318i (N42 B20 A)		Gasolina	RWD	1995	100	136	09.01-02.05	■
318i (N42 B20 A)		Gasolina	RWD	1995	105	143	09.01-02.05	■
318i (N46 B20 A)		Gasolina	RWD	1995	105	143	09.01-02.05	■
318i (N46 B20 C)		Gasolina	RWD	1995	105	143	09.01-02.05	■
320i (M54 B22 (226S1))		Gasolina	RWD	2171	120	163	09.00-02.05	■
320i (M54 B22 (226S1))		Gasolina	RWD	2171	125	170	09.00-02.05	■
323 i (M52 B25 (256S4))		Gasolina	RWD	2494	120	163	03.98-09.00	■
323 i (M52 B25 (256S4))		Gasolina	RWD	2494	125	170	03.98-09.00	■
325i (M56 B25 (256S6))		Gasolina	RWD	2494	132	179	09.02-01.05	■
325i		Gasolina	RWD	2494	137	186	09.00-04.05	■
325i (M54 B25 (256S5))		Gasolina	RWD	2494	141	192	09.00-02.05	■
328i (M52 B28 (286S2))		Gasolina	RWD	2793	142	193	02.98-06.00	■
328i (M52 B28 (286S2))		Gasolina	RWD	2793	144	196	09.98-12.00	■
318 d (M47 D20 (204D1))		Diesel	RWD	1951	85	116	09.01-03.03	■
320 d (M47 D20 (204D1))		Diesel	RWD	1951	95	129	02.98-08.01	■
320 d (M47 D20 (204D1))		Diesel	RWD	1951	100	136	04.98-09.01	■
318 d (M47 D20 (204D4))		Diesel	RWD	1995	85	116	03.03-02.05	■
320 d (M47 D20 (204D4))		Diesel	RWD	1995	110	150	09.01-05.05	■
3 Serie IV Touring (E46) 06.99-07.05					Estate (Compact executive car-D Segment)			
316 i (N42 B18 A)		Gasolina	RWD	1796	85	115	03.02-02.05	■
316 i (N46 B18 A)		Gasolina	RWD	1796	85	115	03.02-02.05	■
318i (M43 B19 (194E1))		Gasolina	RWD	1895	85	116	10.99-09.01	■
318i (M43 B19 (194E1))		Gasolina	RWD	1895	87	118	10.99-09.01	■
320i (M52 B20 (206S4))		Gasolina	RWD	1990	110	150	10.99-09.00	■
318i (N42 B20 A)		Gasolina	RWD	1995	105	143	09.01-07.05	■
318i (N46 B20 A)		Gasolina	RWD	1995	105	143	09.01-07.05	■
318i (N46 B20 C)		Gasolina	RWD	1995	105	143	09.01-07.05	■
320i (M54 B22 (226S1))		Gasolina	RWD	2171	120	163	09.00-02.05	■
320i (M54 B22 (226S1))		Gasolina	RWD	2171	125	170	09.00-02.05	■
323 i (M52 B25 (256S3))		Gasolina	RWD	2494	125	170	10.99-12.00	■
325i (M56 B25 (256S6))		Gasolina	RWD	2494	132	179	09.02-07.05	■
325i (M54 B25 (256S5))		Gasolina	RWD	2494	137	186	09.00-02.05	■
325i (M54 B25 (256S5))		Gasolina	RWD	2494	141	192	09.00-02.05	■

LISTA DE APLICACIONES - BUYERS GUIDE

328i (M52 B28 (286S2))		Gasolina	RWD	2793	142	193	06.99-05.00	■
318 d (M47 D20 (204D1))		Diesel	RWD	1951	85	115	10.02-03.03	■
320 d (M47 D20 (204D1))		Diesel	RWD	1951	100	136	03.00-09.01	■
318 d (M47 D20 (204D4))		Diesel	RWD	1995	85	116	03.03-02.05	■
320 d (M47 D20 (204D4))		Diesel	RWD	1995	110	150	09.01-02.05	■
3 Serie IV Compact (E46) 03.01-02.05					Hatchback (Compact executive car-D Segment)			
316 ti (N40 B16 A)		Gasolina	RWD	1596	77	105	06.02-02.05	■
316 ti (N40 B16 A)		Gasolina	RWD	1596	85	115	06.02-02.05	■
316 ti (N45 B16 A)		Gasolina	RWD	1596	85	115	06.02-02.05	■
316 ti (N42 B18 A)		Gasolina	RWD	1796	85	115	06.01-02.05	■
316 ti (N46 B18 A)		Gasolina	RWD	1796	85	115	06.01-02.05	■
318 ti (N42 B20 A)		Gasolina	RWD	1995	100	136	03.01-12.04	■
318 ti (N46 B20 A)		Gasolina	RWD	1995	100	136	03.01-12.04	■
318 ti (N42 B20 A)		Gasolina	RWD	1995	105	143	03.01-12.04	■
318 ti (N46 B20 A)		Gasolina	RWD	1995	105	143	03.01-12.04	■
325 ti (M54 B25 (256S5))		Gasolina	RWD	2494	141	192	04.01-12.04	■
318 td (M47 D20 (204D4))		Diesel	RWD	1995	85	115	03.03-02.05	■
320 td (M47 D20 (204D4))		Diesel	RWD	1995	100	136	10.01-12.02	■
320 td (M47 D20 (204D4))		Diesel	RWD	1995	110	150	09.01-02.05	■
3 Serie V (E93) 05.06-12.13					Convertible (Compact executive car-D Segment)			
318i (N43 B20 A)		Gasolina	RWD	1995	105	143	03.10-12.13	■
320i (N46 B20 B)		Gasolina	RWD	1995	115	156	01.07-08.13	■
320i (N43 B20 A)		Gasolina	RWD	1995	120	163	09.06-10.13	■
320i (N43 B20 A)		Gasolina	RWD	1995	125	170	03.07-10.13	■
3 Serie V (E92) 01.05-12.13					Coupe (Compact executive car-D Segment)			
316 i (N43 B16 AA)		Gasolina	RWD	1599	90	122	09.07-06.13	■
320i		Gasolina	FWD	1955	112	152	01.10-	■
318i (N43 B20 A)		Gasolina	RWD	1995	105	143	03.10-12.13	■
320i (N46 B20 B)		Gasolina	RWD	1995	115	156	06.07-12.13	■
320i (N43 B20 A)		Gasolina	RWD	1995	120	163	01.07-06.13	■
320i (N43 B20 A)		Gasolina	RWD	1995	125	170	03.07-06.13	■
323 i		Gasolina	FWD	2497	130	177	04.06-02.12	■
323 i (N52 B25 AE)		Gasolina	RWD	2497	140	190	04.06-02.12	■
323 i (N52 B25 BE)		Gasolina	RWD	2497	140	190	04.06-02.12	■
325i (N52 B25 A)		Gasolina	RWD	2497	150	204	03.10-10.13	■
325i (N52 B25 AF)		Gasolina	RWD	2497	150	204	03.10-10.13	■
325i (N52 B25 BF)		Gasolina	RWD	2497	150	204	03.10-10.13	■
325i (N52 B25 A)		Gasolina	RWD	2497	155	211	03.10-06.13	■
325i (N52 B25 AF)		Gasolina	RWD	2497	155	211	03.10-06.13	■
325i (N52 B25 BF)		Gasolina	RWD	2497	155	211	03.10-06.13	■
325i (N52 B25 A)		Gasolina	RWD	2497	160	218	06.06-02.10	■
325i (N52 B25 AF)		Gasolina	RWD	2497	160	218	06.06-02.10	■
325i (N52 B25 BF)		Gasolina	RWD	2497	160	218	06.06-02.10	■
325i (N53 B30 A)		Gasolina	RWD	2996	155	211	03.10-06.13	■
325i (N53 B30 A)		Gasolina	RWD	2996	160	218	09.07-06.13	■
328i (N51 B30 A)		Gasolina	RWD	2996	172	234	06.06-06.13	■
328i (N52 B30 A)		Gasolina	RWD	2996	172	234	06.06-06.13	■
328 xi (N51 B30, N52 B30 A)		Gasolina	4WD	2996	172	234	09.06-08.08	■
320 d (N47 D20 A)		Diesel	RWD	1995	120	163	03.07-06.13	■
320 d (N47 D20 C)		Diesel	RWD	1995	120	163	03.07-06.13	■

LISTA DE APLICACIONES - BUYERS GUIDE

320 d (N47 D20 A)		Diesel	RWD	1995	130	177	09.06-02.10	■
320 d (N47 D20 C)		Diesel	RWD	1995	130	177	09.06-02.10	■
320 d (N47 D20 C)		Diesel	RWD	1995	135	184	03.10-06.13	■
320 d (N47 D20 A)		Diesel	RWD	1995	145	197	09.06-02.10	■
320 d (N47 D20 C)		Diesel	RWD	1995	145	197	09.06-02.10	■
320 d (N47 D20 C)		Diesel	RWD	1995	147	200	03.10-06.13	■
3 Serie V (E90) 02.04-02.12					Saloon (Compact executive car-D Segment)			
316 i (N45 B16 A)		Gasolina	RWD	1596	85	115	09.05-10.11	■
316 i (N45 B16 AC)		Gasolina	RWD	1596	85	115	09.05-10.11	■
316 i (N43 B16 A)		Gasolina	RWD	1599	90	122	09.07-10.11	■
316 i (N43 B16 AA)		Gasolina	RWD	1599	90	122	09.07-10.11	■
318i (N46 B20 B)		Gasolina	RWD	1995	95	129	09.05-08.07	■
318i (N46 B20 B)		Gasolina	RWD	1995	100	136	09.07-10.11	■
318i (N46 B20 C)		Gasolina	RWD	1995	100	136	09.07-10.11	■
318i (N46 B20 CC)		Gasolina	RWD	1995	100	136	09.07-10.11	■
318i (N46 B20 CD)		Gasolina	RWD	1995	100	136	09.07-10.11	■
318i (N46 B20 E)		Gasolina	RWD	1995	100	136	09.07-10.11	■
318i (N43 B20 A)		Gasolina	RWD	1995	105	143	09.07-10.11	■
320i (N46 B20 B)		Gasolina	RWD	1995	110	150	12.04-08.07	■
320i (N46 B20 BD)		Gasolina	RWD	1995	110	150	12.04-08.07	■
320i (N46 B20 C)		Gasolina	RWD	1995	110	150	12.04-08.07	■
320i (N46 B20 CB)		Gasolina	RWD	1995	110	150	12.04-08.07	■
320i (N46 B20 B)		Gasolina	RWD	1995	115	156	02.07-12.11	■
320i (N46 B20 C)		Gasolina	RWD	1995	115	156	02.07-12.11	■
320i (N46 B20 CC)		Gasolina	RWD	1995	115	156	02.07-12.11	■
320i (N46 B20 CD)		Gasolina	RWD	1995	115	156	02.07-12.11	■
320i (N46 B20 E)		Gasolina	RWD	1995	115	156	02.07-12.11	■
320i (N43 B20 A)		Gasolina	RWD	1995	120	163	03.07-12.11	■
320i (N43 B20 A)		Gasolina	RWD	1995	125	170	09.07-10.11	■
323 i (N52 B25 A)		Gasolina	RWD	2497	130	177	09.05-02.07	■
323 i (N52 B25 B)		Gasolina	RWD	2497	130	177	09.05-02.07	■
323 i (N52 B25 BE)		Gasolina	RWD	2497	130	177	09.05-02.07	■
323 i (N52 B25 BF)		Gasolina	RWD	2497	130	177	09.05-02.07	■
323 i (N52 B25 A)		Gasolina	RWD	2497	140	190	03.07-12.11	■
323 i (N52 B25 BF)		Gasolina	RWD	2497	140	190	03.07-12.11	■
325i (N52 B25 A)	discØ 300, increased payload, not increas.payload	Gasolina	RWD	2497	155	211	01.06-12.11	■
325i (N52 B25 A)	discØ 300, increased payload, not increas.payload	Gasolina	RWD	2497	160	218	12.04-12.11	■
325i (N52 B25 B)	discØ 300, increased payload, not increas.payload	Gasolina	RWD	2497	160	218	12.04-12.11	■
325i (N52 B25 BF)	discØ 300, increased payload, not increas.payload	Gasolina	RWD	2497	160	218	12.04-12.11	■
325i (N52 B25)		Gasolina	RWD	2497	163	222	09.08-12.09	■
325i (N53 B30 A)	discØ 300, not increas.payload	Gasolina	RWD	2996	155	211	03.07-12.11	■
325i (N53 B30 A)	discØ 300, not increas.payload	Gasolina	RWD	2996	160	218	03.07-12.11	■
325 i xDrive (N53 B30 A)	not increas.payload	Gasolina	4WD	2996	160	218	09.08-10.11	■
325 xi (N53 B30 A)	not increas.payload	Gasolina	4WD	2996	160	218	09.07-08.08	■
328i (N51 B30 A)		Gasolina	RWD	2996	172	234	09.06-12.11	■
316 d (N47 D20 C)		Diesel	RWD	1995	85	116	07.09-12.11	■
318 d (M47 D20 (204D4))		Diesel	RWD	1995	90	122	03.05-08.07	■
318 d (N47 D20 A)		Diesel	RWD	1995	100	136	09.07-10.11	■
318 d (N47 D20 C)		Diesel	RWD	1995	100	136	09.07-10.11	■

LISTA DE APLICACIONES - BUYERS GUIDE

318 d (N47 D20 A)		Diesel	RWD	1995	105	143	02.07-10.11	■
318 d (N47 D20 C)		Diesel	RWD	1995	105	143	02.07-10.11	■
320 d (M47 D20 (204D4))	discØ 300, not increas.payload	Diesel	RWD	1995	110	150	12.04-09.07	■
320 d	discØ 300, not increas.payload	Diesel	RWD	1995	115	156	12.04-09.07	■
320 d (M47 D20 (204D4))	discØ 300, not increas.payload	Diesel	RWD	1995	120	163	12.04-10.11	■
320 d (N47 D20 A)	discØ 300, not increas.payload	Diesel	RWD	1995	120	163	12.04-10.11	■
320 d (N47 D20 C)	discØ 300, not increas.payload	Diesel	RWD	1995	120	163	12.04-10.11	■
320 d (N47 D20 C)	discØ 300, not increas.payload	Diesel	RWD	1995	125	170	01.07-12.09	■
320 d (N47 D20 A)	discØ 300, not increas.payload	Diesel	RWD	1995	130	177	09.07-02.10	■
320 d (N47 D20 C)	discØ 300, not increas.payload	Diesel	RWD	1995	130	177	09.07-02.10	■
320 d (N47 D20 C)	discØ 300, not increas.payload	Diesel	RWD	1995	135	184	03.10-10.11	■
3 Serie V Touring (E91) 12.04-12.12					Estate (Compact executive car-D Segment)			
316 i (N43 B16 AA)		Gasolina	RWD	1599	90	122	09.08-06.12	■
318i (N46 B20 B)	increased payload, not increas.payload	Gasolina	RWD	1995	100	136	09.07-03.12	■
318i (N43 B20 A)	increased payload, not increas.payload	Gasolina	RWD	1995	105	143	05.07-05.12	■
320i (N46 B20 B)		Gasolina	RWD	1995	110	150	09.05-06.12	■
320i (N46 B20 C)		Gasolina	RWD	1995	110	150	09.05-06.12	■
320i (N46 B20 B)		Gasolina	RWD	1995	115	156	09.05-06.12	■
320i (N46 B20 BD)		Gasolina	RWD	1995	115	156	09.05-06.12	■
320i (N46 B20 C)		Gasolina	RWD	1995	115	156	09.05-06.12	■
320i (N43 B20 A)		Gasolina	RWD	1995	120	163	02.07-05.12	■
320i (N43 B20 A)		Gasolina	RWD	1995	125	170	02.07-12.12	■
316 d (N47 D20 C)	increased payload, not increas.payload	Diesel	RWD	1995	85	116	09.09-06.12	■
318 d (N47 D20 A)	not increas.payload	Diesel	RWD	1995	100	136	07.07-06.12	■
318 d (N47 D20 C)	not increas.payload	Diesel	RWD	1995	100	136	07.07-06.12	■
318 d (N47 D20 A)	not increas.payload	Diesel	RWD	1995	105	143	09.07-06.12	■
318 d (N47 D20 C)	not increas.payload	Diesel	RWD	1995	105	143	09.07-06.12	■
320 d (M47 D20 (204D4))	increased payload	Diesel	RWD	1995	120	163	06.05-06.12	■
320 d (N47 D20 A)	increased payload	Diesel	RWD	1995	120	163	06.05-06.12	■
320 d (N47 D20 C)	increased payload	Diesel	RWD	1995	120	163	06.05-06.12	■
320 d (N47 D20 A)	not increas.payload	Diesel	RWD	1995	130	177	02.07-12.10	■
320 d (N47 D20 C)	not increas.payload	Diesel	RWD	1995	130	177	02.07-12.10	■
320 d (N47 D20 C)	discØ 300, not increas.payload	Diesel	RWD	1995	135	184	03.10-05.12	■
320 d (N47 D20 A)		Diesel	RWD	1995	145	197	02.07-02.10	■
320 d (N47 D20 C)		Diesel	RWD	1995	145	197	02.07-02.10	■
320 d (N47 D20 C)	discØ 300, not increas.payload	Diesel	RWD	1995	147	200	03.10-05.12	■
3 Serie VI (F30, F80) 11.11-10.18					Saloon (Compact executive car-D Segment)			
318i (B38 B15 A)		Gasolina	RWD	1499	100	136	07.15-10.18	■
316 i (N13 B16 A)		Gasolina	RWD	1598	100	136	07.12-08.16	■
320i (N13 B16 A)		Gasolina	RWD	1598	125	170	11.12-06.16	■
320i		Gasolina	RWD	1997	134	182	03.12-10.18	■
320i (N20 B20 A)		Gasolina	RWD	1997	135	184	03.12-10.18	■
320i (N20 B20 B)		Gasolina	RWD	1997	135	184	03.12-10.18	■
320i (N20 B20 D)		Gasolina	RWD	1997	135	184	03.12-10.18	■
320 i Active Flex		Gasolina	FWD	1997	135	184	02.12-	■
328i (N20 B20 A)		Gasolina	RWD	1997	160	218	11.11-06.15	■
328i (N20 B20 A)		Gasolina	RWD	1997	180	245	11.11-10.18	■
328i (N20 B20 C)		Gasolina	RWD	1997	180	245	11.11-10.18	■
328i (N26 B20 A)		Gasolina	RWD	1997	180	245	11.11-10.18	■

LISTA DE APLICACIONES - BUYERS GUIDE

320i (B48 B20 A)		Gasolina	RWD	1998	135	184	07.15-10.18	■
316 d (B47 D20 A)	noSA S1DEA	Diesel	RWD	1995	85	116	03.12-10.18	■
316 d (N47 D20 C)	noSA S1DEA	Diesel	RWD	1995	85	116	03.12-10.18	■
318 d (B47 D20 A)		Diesel	RWD	1995	100	136	03.12-10.18	■
318 d (N47 D20 C)		Diesel	RWD	1995	100	136	03.12-10.18	■
318 d (N47 D20 C)		Diesel	RWD	1995	105	143	03.12-06.15	■
318 d (B47 D20 A)	noSA S1DEA	Diesel	RWD	1995	110	150	07.15-10.18	■
320 d (B47 D20 A)	noSA S1DEA	Diesel	RWD	1995	120	163	11.11-10.18	■
320 d (N47 D20 C)	noSA S1DEA	Diesel	RWD	1995	120	163	11.11-10.18	■
320 d (N47 D20 C)		Diesel	RWD	1995	135	184	11.11-03.16	■
320 d (B47 D20 A)	noSA S1DEA	Diesel	RWD	1995	140	190	07.15-10.18	■
320 d (N47 D20 C)		Diesel	RWD	1995	147	200	11.11-03.16	■
325 d (N47 D20 D)		Diesel	RWD	1995	155	211	03.13-02.16	■
325 d (N47 D20 D)		Diesel	RWD	1995	160	218	03.13-02.16	■
325 d (B47 D20 B)		Diesel	RWD	1995	165	224	03.16-02.18	■
3 Serie VI Touring (F31) 07.12-06.19					Estate (Compact executive car-D Segment)			
316 i (N13 B16 A)		Gasolina	RWD	1598	100	136	03.13-06.15	■
320i (N20 B20 B)		Gasolina	RWD	1997	120	163	11.12-06.15	■
320i (N20 B20 B)		Gasolina	RWD	1997	135	184	11.12-06.15	■
320i (B48 B20 A)		Gasolina	RWD	1998	135	184	07.15-06.19	■
320 i xDrive (B48 B20 A)		Gasolina	4WD	1998	135	184	07.15-06.19	■
316 d (B47 D20 A)		Diesel	RWD	1995	85	116	11.12-06.19	■
316 d (N47 D20 C)		Diesel	RWD	1995	85	116	11.12-06.19	■
318 d (B47 D20 A)		Diesel	RWD	1995	100	136	11.12-06.19	■
318 d (N47 D20 C)		Diesel	RWD	1995	100	136	11.12-06.19	■
318 d (N47 D20 C)		Diesel	RWD	1995	105	143	11.12-06.15	■
320 d (B47 D20 A)		Diesel	RWD	1995	120	163	07.12-06.19	■
320 d (N47 D20 C)		Diesel	RWD	1995	120	163	07.12-06.19	■
4 Serie (F33, F83) 10.13-					Convertible (Compact executive car-D Segment)			
420 D (B47 D20 A)		Diesel	RWD	1995	120	163	11.13-07.20	■
420 D (N47 D20 C)		Diesel	RWD	1995	120	163	11.13-07.20	■
420 D (N47 D20 C)		Diesel	RWD	1995	135	184	10.13-06.15	■
420 D (N47 D20 C)		Diesel	RWD	1995	147	200	10.13-06.15	■
4 Serie (F32, F82) 07.13-					Coupe (Compact executive car-D Segment)			
420 i (N20 B20 A)		Gasolina	RWD	1997	120	163	11.13-02.17	■
420 i (N20 B20 B)		Gasolina	RWD	1997	120	163	11.13-02.17	■
420 i xDrive (N20 B20 A)		Gasolina	4WD	1997	120	163	11.13-02.16	■
420 i xDrive (N20 B20 B)		Gasolina	4WD	1997	120	163	11.13-02.16	■
420 i (N20 B20 A)		Gasolina	RWD	1997	135	184	11.13-02.17	■
420 i (N20 B20 B)		Gasolina	RWD	1997	135	184	11.13-02.17	■
420 i xDrive (N20 B20 A)		Gasolina	4WD	1997	135	184	11.13-02.16	■
420 i xDrive (N20 B20 B)		Gasolina	4WD	1997	135	184	11.13-02.16	■
418 D (B47 D20 A)		Diesel	RWD	1995	100	136	03.14-12.20	■
418 D (N47 D20 C)		Diesel	RWD	1995	100	136	03.14-12.20	■
418 D (N47 D20 C)		Diesel	RWD	1995	105	143	03.14-06.15	■
420 D (B47 D20 A)		Diesel	RWD	1995	120	163	07.13-06.20	■
420 D (N47 D20 C)		Diesel	RWD	1995	120	163	07.13-06.20	■
420 D (B47 D20 A)		Diesel	RWD	1995	120	163	03.14-12.20	■
420 D (N47 D20 C)		Diesel	RWD	1995	120	163	03.14-12.20	■
420 D (N47 D20 C)		Diesel	RWD	1995	135	184	07.13-02.15	■

LISTA DE APLICACIONES - BUYERS GUIDE

420 D (N47 D20 C)		Diesel	RWD	1995	135	184	03.14-02.15	■
420 D (B47 D20 A)		Diesel	RWD	1995	140	190	03.15-06.20	■
420 D (N47 D20 C)		Diesel	RWD	1995	147	200	07.13-03.15	■
420 D (N47 D20 C)		Diesel	RWD	1995	147	200	03.14-02.15	■
425 d (N47 D20 D)		Diesel	RWD	1995	155	211	03.14-02.16	■
425 d (N47 D20 D)		Diesel	RWD	1995	160	218	03.14-02.16	■
X1 (E84) 03.09-06.15					SUV (Compact SUV-J Segment)			
sDrive 20 d (N47 D20 C)		Diesel	RWD	1995	135	184	07.12-06.15	■
Z4 (E85) 09.02-12.09					Convertible (Sports car-S Segment)			
2.0 i (N46 B20 B)		Gasolina	RWD	1995	110	150	03.05-02.09	■
2.2 i (M54 B22 (226S1))		Gasolina	RWD	2171	125	170	10.03-10.05	■
2.5 i (M54 B25 (256S5))		Gasolina	RWD	2494	141	192	12.02-12.05	■
2.5 i (N52 B25 A)		Gasolina	RWD	2497	130	177	09.05-02.09	■
2.5 si (N52 B25 A)		Gasolina	RWD	2497	155	211	09.05-02.09	■
2.5 si (N52 B25 AF)		Gasolina	RWD	2497	155	211	09.05-02.09	■
2.5 si (N52 B25 A)		Gasolina	RWD	2497	160	218	01.06-08.08	■
3.0 i (M54 B30 (306S3))		Gasolina	RWD	2979	170	231	12.02-12.05	■
3.0 Si		Gasolina	RWD	2996	160	218	09.05-12.08	■
3.0 Si		Gasolina	RWD	2996	190	258	01.06-08.08	■
3.0 Si (N52 B30 A)		Gasolina	RWD	2996	195	265	01.06-08.08	■
3.0 Si (N52 B30 BF)		Gasolina	RWD	2996	195	265	01.06-08.08	■
Z4 (E86) 03.06-01.09					Coupe (Sports car-S Segment)			
2.5 i (M54 B25 (256S5))		Gasolina	RWD	2494	141	192	11.06-04.08	■
3.0 Si		Gasolina	RWD	2996	160	218	03.06-01.09	■
3.0 Si		Gasolina	RWD	2996	190	258	03.06-08.08	■
3.0 Si (N52 B30 A)		Gasolina	RWD	2996	195	265	04.06-08.08	■
BMW (BRILLIANCE)								
3 SERIES IV (E46) 07.03-06.05					Saloon (Compact executive car-D Segment)			
318i		Gasolina	RWD	1995	105	143	06.04-06.05	■
325i		Gasolina	RWD	2494	141	192	07.03-06.05	■